

6620, Sidehill 6620 7720 and 8820 Combines



JOHN DEERE

TECHNICAL MANUAL 6620, Sidehill 6620 7720 and 8820 Combines

TM1202 (01JAN88) English

John Deere Harvester Works
TM1202 (01JAN88)

LITHO IN U.S.A.
ENGLISH



6620, SIDEHILL 6620, 7720 AND 8820 COMBINES

TECHNICAL MANUAL

TM-1202 (Jan-88)

CONTENTS

SECTION 10 - GENERAL

- Group 00 - General Specifications
- Group 05 - Diagnosing and Testing Procedures
- Group 10 - Tune-Up and Adjustment

SECTION 20 - ENGINE REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Cylinder Head, Valves and Camshaft
- Group 10 - Block, Liners, Pistons, and Rods
- Group 15 - Crankshaft and Main Bearings
- Group 20 - Lubrication System
- Group 25 - Cooling System

SECTION 30 - FUEL AND AIR REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Air Intake System
- Group 10 - Diesel Fuel System
- Group 15 - Control Linkage

SECTION 40 - ELECTRICAL REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Harness Replacement
- Group 10 - Charging Circuit Repair
- Group 15 - Starting Circuit Repair
- Group 20 - Lights, Instruments, and Accessories

SECTION 50 - POWER TRAIN REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Clutch
- Group 10 - Transmission
- Group 15 - Differential
- Group 20 - Final Drive
- Group 25 - Sundstrand Hydrostatic Drive
- Group 26 - Eaton Hydrostatic Drive
- Group 30 - 4-Wheel Drive (Planetary Gearing)
- Group 31 - 4-Wheel Drive (Cam Lobe)
- Group 35 - Posi-Torq Ground Drive
- Group 40 - Tires and Wheels

SECTION 60 - STEERING/BRAKES REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Power Steering
- Group 10 - Brakes

SECTION 70 - HYDRAULIC REPAIR

- Group 00 - Specifications
- Group 05 - Reservoir
- Group 10 - Hydraulic Pump
- Group 15 - Hydraulic Valves
- Group 20 - Hydraulic Cylinders
- Group 25 - Hydraulic Motors
- Group 30 - Accumulator

SECTION 80 - SEPARATOR SHELL REPAIR

- Group 00 - Specifications
- Group 05 - Rear Hood
- Group 10 - Cylinder Rear Cover
- Group 15 - Separator Uprights

SECTION 90 - OPERATOR STATION REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Air Conditioning System
- Group 10 - Air Intake (Pressurizer) System
- Group 15 - Heating System
- Group 20 - Personal Posture Seat
- Group 25 - Miscellaneous Components

SECTION 100 - HEADER REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - 200 and 900 Series Cutting Platforms
- Group 10 - 40 Series Corn Heads
- Group 15 - 50, 50A Series Row-Crop Heads

SECTION 110 - FEEDER HOUSE REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Feeder Conveyor Chain
- Group 10 - Feeder Conveyor Drum
- Group 15 - Feeder House Drives and Reverser Gear Case
- Group 20 - Feeder House Drives (SideHill 6620 Combines) (-610300)
- Group 25 - Feeder House Paddles, Stripper and Front Closure Sheets (SideHill 6620 Combines [-403300])
- Group 30 - Feeder Conveyor Chain, Upper Shaft, Paddle and Shaft, Conveyor Drum and Front Closure Sheets (SideHill 6620 Combines [403301-])

SECTION 120 - SEPARATOR REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Cylinder, Concave, and Beater
- Group 10 - POSI-TORQ™ Cylinder Drive
- Group 12 - Dual-Range Cylinder Drive
- Group 15 - Straw Walkers and Crankshafts
- Group 20 - Straw Chopper and Straw Spreader
- Group 25 - Shoe Augers, Fan, and Shoe Frame
- Group 30 - Tailings Elevator and Augers
- Group 35 - Lower Auger, Clean Grain Elevator, and Grain Tank Loading Auger

SECTION 130 - GRAIN TANK UNLOADING SYSTEM

- Group 00 - Specifications
- Group 05 - Grain Tank Cross Augers
- Group 10 - Vertical Auger and Bevel Gears
- Group 15 - Horizontal Auger and Gearcase

CONTENTS

SECTION 140 - MAJOR DRIVES REPAIR

- Group 00 - Specifications
- Group 05 - Engine Powershaft
- Group 10 - Primary Countershaft
- Group 15 - Secondary Countershaft

SECTION 150 - SIDEHILL LEVELING SYSTEM REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Electrical Components
- Group 10 - Hydraulic Components

SECTION 160 - AUTOMATIC HEADER HEIGHT CONTROL REPAIR

- Group 00 - Specifications and Special Tools
- Group 05 - Repair of Components

SECTION 220 - ENGINE OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - System Operation
- Group 10 - System Tests and Diagnosis

SECTION 230 - FUEL/AIR OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - Air Intake System
- Group 10 - Diesel Fuel System
- Group 15 - Control Linkage

SECTION 240 - ELECTRICAL OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - General Information and Diagnosis
- Group 06 - Electrical System Diagnosis
- Group 10 - Charging Circuit
- Group 15 - Starting Circuit
- Group 20 - Lights, Instruments and Accessory Circuits

SECTION 250 - POWER TRAIN OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - Clutch Diagnosis
- Group 10 - Transmission Diagnosis
- Group 15 - Final Drive Diagnosis
- Group 20 - Hydrostatic Drive Tests and Diagnosis
- Group 25 - 4-Wheel Drive Diagnosis (Planetary Gearing)
- Group 26 - 4-Wheel Drive (Cam Lobe)
- Group 30 - Posi-Torq Ground Drive Diagnosis

SECTION 260 - STEERING/BRAKES OPERATION AND TESTS

- Group 05 - Power Steering
- Group 10 - Brakes

SECTION 270 - HYDRAULIC OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 01 - Hydraulic System Operation
- Group 05 - Hydraulic System Tests
- Group 10 - Reservoir
- Group 15 - Hydraulic Pumps
- Group 20 - Hydraulic Valves
- Group 25 - Hydraulic Cylinders
- Group 30 - Hydraulic Motors
- Group 35 - Accumulator

SECTION 290 - OPERATOR STATION OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - Air Conditioning System
- Group 10 - Heating System

SECTION 350 - SIDEHILL LEVELING SYSTEM OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - General Information, Diagnosis, and Tests
- Group 10 - Electrical System
- Group 15 - Hydraulic System

SECTION 360 - AUTOMATIC HEADER HEIGHT CONTROL OPERATION AND TESTS

- Group 00 - Specifications and Special Tools
- Group 05 - General Information, Diagnosis, and Tests
- Group 10 - Mechanical System
- Group 15 - Electrical System
- Group 20 - Hydraulic System
- Group 25 - General Information, Diagnosis, and Tests - DIAL-A-MATIC™
- Group 30 - Mechanical System - DIAL-A-MATIC
- Group 35 - Electrical System - DIAL-A-MATIC
- Group 40 - Hydraulic System - DIAL-A-MATIC

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

The specifications given in this technical manual are intended for service only. They do not include normal factory manufacturing tolerances.

Copyright© 1988 Deere & Company
Moline, Illinois All rights reserved.

Previous Editions

Copyright© 1987, 1986, 1985, 1984, 1983, 1982, 1981, 1980,
1979, and 1978 Deere & Company

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

TECHNICAL MANUAL TABS

INTRODUCTION

To fully utilize this technical manual, you must understand how it is organized.

Only two tab colors are used—green and yellow. Each color represents a different type of information.

Spend a minute reading this now and save many minutes of searching later.

GREEN TAB SECTIONS

The green tab sections are repair sections that tell how to repair the components of the various systems.

Repair of a component includes:

- Removal from machine (when necessary)
- Disassembly
- Inspection
- Replacement of parts
- Assembly
- Adjustment
- Installation on machine (when necessary)

The numbers used for the repair (green tab) sections are part of an overall service publication numbering system. The numbers identify the same sections in the parts catalog, flat rate manual, service information bulletins, and service training courses.




YELLOW TAB SECTIONS

Each yellow tab section contains information on:

- System Operation
- System Tests

System operation explains how the system and its components work.

System tests tell how to test the system and diagnose the problem.



TAB POSITIONS

Each green tab and its corresponding yellow tab have the same tab position. This is to help you quickly locate the related information.



COLOR	POSITION	SEC. NO.	DESCRIPTION
Green	2nd	20	Engine Repair
Yellow	2nd	220	Engine Operation and Tests

HOW TO USE


Use the following three-step procedure to locate the desired information.

1. Determine the type of information you need. Is it repair, operation, or tests?
2. Go to the appropriate section tab:
Green for Repair
Yellow for Operation or Tests

3. Use the table of contents on the first page of the section to locate the information.



X8788 TYPE OF INFORMATION?



TECHNICAL MANUAL TABS

INTRODUCTION

To fully utilize this technical manual, you must understand how it is organized.

Only two tab colors are used—green and yellow. Each color represents a different type of information.

Spend a minute reading this now and save many minutes of searching later.

GREEN TAB SECTIONS

The green tab sections are repair sections that tell how to repair the components of the various systems.

Repair of a component includes:

- Removal from machine (when necessary)
- Disassembly
- Inspection
- Replacement of parts
- Assembly
- Adjustment
- Installation on machine (when necessary)

The numbers used for the repair (green tab) sections are part of an overall service publication numbering system. The numbers identify the same sections in the parts catalog, flat rate manual, service information bulletins, and service training courses.




YELLOW TAB SECTIONS

Each yellow tab section contains information on:

- System Operation
- System Tests

System operation explains how the system and its components work.

System tests tell how to test the system and diagnose the problem.



TAB POSITIONS

Each green tab and its corresponding yellow tab have the same tab position. This is to help you quickly locate the related information.

COLOR	POSITION	SEC. NO.	DESCRIPTION
Green	2nd	20	Engine Repair
Yellow	2nd	220	Engine Operation and Tests

HOW TO USE



Use the following three-step procedure to locate the desired information.

1. Determine the type of information you need. Is it repair, operation, or tests?
2. Go to the appropriate section tab:

Green for Repair


Yellow for Operation or Tests

3. Use the table of contents on the first page of the section to locate the information.



X8788

TYPE OF INFORMATION?



Section 10 GENERAL

CONTENTS OF THIS SECTION

	Page
GROUP 00 - GENERAL SPECIFICATIONS	
Serial Numbers	00-1
Specifications	00-2
Ground Speeds	00-4
Dimensions	00-10
GROUP 05 - DIAGNOSING AND TESTING PROCEDURES	05-1
GROUP 10 - TUNE-UP AND ADJUSTMENT	
General Information	10-1
Preliminary Engine Testing	10-1
Engine Tune-Up	10-1
Adjustments	10-3
Torque Chart	10-3
Care and Maintenance of Belts and Chains ..	10-4

Group 00 GENERAL SPECIFICATIONS

SERIAL NUMBERS

Serial Number Unit	Location	Serial Number Unit	Location
Separator... (-1982) Rear left hand upright (1983-) Near right hand side of tool box		Cutting Platform and Pickup Platform	Left-hand side of main frame
Engine	Front side of engine block on water jacket directly above starter	Corn Head	Lower right-hand side on bulk-head frame
Sundstrand Hydrostatic Unit ...	Under pump section	Row-Crop Head	Left-hand side end sheet of main frame
Eaton Hydrostatic Unit	Side of motor section		
Cam Lobe 4-Wheel Drive Motor	Top of motor		
Planetary 4-Wheel Drive Motor	None		

GROUND SPEED IN MPH (km/h) 6620 COMBINE (Posi-Torq Drive) 10 TO 82 AND 11 TO 90 RATIO FINAL DRIVES

Tire		Ply	1st Gear	2nd Gear	3rd Gear	4th Gear	Reverse Gear
Size	Type						
23.1-26	Cleat	8, 10	.7 to 1.7 (1.1 to 2.7)	1.6 to 3.9 (2.6 to 6.3)	2.9 to 7.2 (4.7 to 11.6)	6.6 to 16.5 (10.6 to 26.6)	1.3 to 3.2 (2.1 to 5.2)
23.1-26	Low Profile	8	.7 to 1.7 (1.1 to 2.7)	1.5 to 3.8 (2.4 to 6.1)	2.8 to 6.9 (4.5 to 11.1)	6.4 to 16.0 (10.3 to 25.7)	1.2 to 3.1 (2.1 to 5.0)
23.1-26	Cane & Rice	8, 10	.7 to 1.8 (1.1 to 2.9)	1.7 to 4.2 (2.7 to 6.8)	3.0 to 7.6 (4.8 to 12.2)	7.0 to 17.4 (11.3 to 28.0)	1.4 to 3.4 (2.3 to 5.5)
28.1-26	Cleat	10	.7 to 1.8 (1.1 to 2.9)	1.6 to 4.0 (2.6 to 6.4)	2.9 to 7.3 (4.8 to 11.8)	6.7 to 16.9 (10.8 to 27.2)	1.3 to 3.3 (2.1 to 5.3)
28.1-26	Cane & Rice	10	.7 to 1.8 (1.1 to 2.9)	1.7 to 4.2 (2.7 to 6.8)	3.0 to 7.6 (4.8 to 12.2)	7.0 to 17.4 (11.3 to 28.0)	1.4 to 3.4 (2.3 to 5.5)

10 TO 95 AND 11 TO 104 RATIO FINAL DRIVES

Tire or Tracks		Ply	1st Gear	2nd Gear	3rd Gear	4th Gear	Reverse Gear
Size	Type						
24.5-32	Cleat	10	.7 to 1.7 (1.1 to 2.7)	1.6 to 3.9 (2.4 to 6.3)	2.8 to 7.1 (4.5 to 11.4)	6.5 to 16.3 (10.5 to 26.2)	1.2 to 3.2 (2.1 to 5.2)
24.5-32	Cane & Rice	10	.7 to 1.7 (1.1 to 2.7)	1.6 to 4.0 (2.6 to 6.4)	2.9 to 7.3 (4.7 to 11.8)	6.7 to 16.8 (10.8 to 26.2)	1.3 to 3.3 (2.1 to 5.3)
Tracks			.3 to .8 (.5 to 1.3)	.7 to 1.8 (1.1 to 2.9)	1.3 to 3.3 (2.1 to 5.3)	3.0 to 7.6 (4.8 to 12.2)	.6 to 1.5 (1.0 to 2.4)

GROUND SPEED IN MPH (km/h) 6620 COMBINE (Hydrostatic Drive) 10 TO 82 AND 11 TO 90 RATIO FINAL DRIVES

Tire			1st Gear	2nd Gear	3rd Gear	4th Gear
Size	Type	Ply				
23.1-26	R1 Cleat	8, 10	0 to 1.7 (0 to 2.7)	0 to 3.8 (0 to 6.2)	0 to 6.9 (0 to 11.3)	0 to 16.0 (0 to 26.2)
23.1-26	R3 Low Profile	8	0 to 1.6 (0 to 2.6)	0 to 3.7 (0 to 6.0)	0 to 6.7 (0 to 10.9)	0 to 15.4 (0 to 25.1)
23.1-26	R2 Cane & Rice	8, 10	0 to 1.7 (0 to 2.8)	0 to 4.0 (0 to 6.6)	0 to 7.3 (0 to 11.9)	0 to 16.8 (0 to 28.0)
28.1-26	R1 Cleat	10	0 to 1.7 (0 to 2.8)	0 to 3.9 (0 to 6.3)	0 to 7.1 (0 to 11.6)	0 to 16.3 (0 to 26.7)
28.1-26	R2 Cane & Rice	10	0 to 1.7 (0 to 2.8)	0 to 4.0 (0 to 6.6)	0 to 7.3 (0 to 11.9)	0 to 16.8 (0 to 27.4)

10 TO 95 AND 11 TO 104 RATIO FINAL DRIVES

Tire or Tracks			1st Gear	2nd Gear	3rd Gear	4th Gear
Size	Type	Ply				
24.5-32	R1 Cleat	10	0 to 1.7 (0 to 2.7)	0 to 3.9 (0 to 6.3)	0 to 7.1 (0 to 11.4)	0 to 16.3 (0 to 26.2)
24.5-32	R2 Cane & Rice	10	0 to 1.7 (0 to 2.7)	0 to 4.0 (0 to 6.4)	0 to 7.3 (0 to 11.8)	0 to 16.8 (0 to 27.0)
Tracks			0 to .8 (0 to 1.3)	0 to 1.8 (0 to 2.9)	0 to 3.3 (0 to 5.3)	0 to 7.6 (0 to 12.2)

GROUND SPEED CONTROL RANGE IN MPH (km/h) SIDEHILL 6620 COMBINE

Tire			1st Gear	2nd Gear	3rd Gear	4th Gear
Size	Type	Ply Rating				
23.1-26	R1 Cleat	10	0 to 1.7 (0 to 2.7)	0 to 4.0 (0 to 6.4)	0 to 7.3 (0 to 11.8)	0 to 16.7 (0 to 26.9)
23.1-26	R2 Cane & Rice	10	0 to 1.8 (0 to 2.9)	0 to 4.2 (0 to 6.8)	0 to 7.6 (0 to 12.2)	0 to 17.6 (0 to 28.3)

GROUND SPEED CONTROL RANGE IN MPH (km/h) WITH 4-WHEEL DRIVE ENGAGED

SIDEHILL 6620, 6620 AND 7720 COMBINES

(HYDROSTATIC DRIVE)

Tire or Tracks Size	Type	Ply	1st Gear	2nd Gear	3rd Gear	4th Gear
23.1-26	R1 Cleat	8	0 to 1.5 (0 to 2.4)	0 to 3.1 (0 to 5.0)	0 to 4.8 (0 to 7.7)	0 to 7.9 (0 to 12.7)
23.1-26	R2 Cane & Rice	10	0 to 1.6 (0 to 2.6)	0 to 3.2 (0 to 5.1)	0 to 5.1 (0 to 8.2)	0 to 8.3 (0 to 13.4)
24.5-32	R1 Cleat	10	0 to 1.5 (0 to 2.4)	0 to 3.1 (0 to 5.0)	0 to 4.9 (0 to 7.9)	0 to 8.1 (0 to 13.0)
24.5-32	R2 Cane & Rice	10	0 to 1.5 (0 to 2.4)	0 to 3.2 (0 to 5.1)	0 to 5.0 (0 to 8.0)	0 to 8.4 (0 to 13.5)
28.1-26	R1 Cleat	10,12	0 to 1.5 (0 to 2.4)	0 to 3.2 (0 to 5.1)	0 to 5.0 (0 to 8.0)	0 to 8.3 (0 to 13.4)
28.1-26	R2 Cane & Rice	10,12	0 to 1.6 (0 to 2.6)	0 to 3.2 (0 to 5.1)	0 to 5.1 (0 to 8.2)	0 to 8.5 (0 to 13.6)
30.5-32	R1 Cleat	10	0 to 1.5 (0 to 2.4)	0 to 3.1 (0 to 5.0)	0 to 5.0 (0 to 8.0)	0 to 8.4 (0 to 13.5)
30.5-32	R2 Cane and Rice	10	0 to 1.5 (0 to 2.4)	0 to 3.2 (0 to 5.1)	0 to 5.0 (0 to 8.0)	0 to 8.4 (0 to 13.5)
Tracks			0 to .7 (0 to 1.1)	0 to 1.5 (0 to 2.4)	0 to 2.5 (0 to 4.0)	0 to 4.4 (0 to 7.1)

GROUND SPEED IN MPH (km/h) 7720 COMBINE (Posi-Torq Drive) 10 TO 82 AND 11 TO 90 RATIO FINAL DRIVES

Tire							
Size	Type	Ply	1st Gear	2nd Gear	3rd Gear	4th Gear	Reverse Gear
23.1-26	Cleat	10	.7 to 1.7 (1.1 to 2.7)	1.6 to 3.9 (2.6 to 6.2)	2.9 to 7.2 (4.7 to 11.7)	6.6 to 16.5 (10.7 to 26.7)	1.3 to 3.2 (2.1 to 5.2)
23.1-26	Low Profile	8	.7 to 1.7 (1.1 to 2.7)	1.5 to 3.8 (2.4 to 6.1)	2.8 to 6.9 (4.5 to 11.1)	6.4 to 16.0 (10.3 to 25.7)	1.2 to 3.1 (2.0 to 5.0)
23.1-26	Cane & Rice	10	.7 to 1.8 (1.1 to 2.9)	1.7 to 4.2 (2.7 to 6.8)	3.0 to 7.6 (4.9 to 12.2)	7.0 to 17.4 (11.3 to 28.1)	1.4 to 3.4 (2.3 to 5.5)
28.1-26	Cleat	12	.7 to 1.8 (1.1 to 2.9)	1.6 to 4.0 (2.6 to 6.4)	2.9 to 7.3 (4.7 to 11.8)	6.7 to 16.9 (10.8 to 27.2)	1.3 to 3.3 (2.1 to 5.3)
28.1-26	Cane & Rice	12	.7 to 1.8 (1.1 to 2.9)	1.7 to 4.2 (2.7 to 6.8)	3.0 to 7.6 (4.8 to 12.2)	7.0 to 17.4 (11.3 to 28.0)	1.4 to 3.4 (2.3 to 5.5)

10 TO 95 AND 11 TO 104 RATIO FINAL DRIVES

Tire or Tracks							
Size	Type	Ply	1st Gear	2nd Gear	3rd Gear	4th Gear	Reverse Gear
24.5-32	Cleat	10	.7 to 1.7 (1.1 to 2.7)	1.6 to 3.9 (2.6 to 6.3)	2.8 to 7.1 (4.5 to 11.4)	6.5 to 16.3 (10.5 to 26.2)	1.3 to 3.2 (2.1 to 5.2)
24.5-32	Cane & Rice	10	.7 to 1.7 (1.1 to 2.7)	1.6 to 4.0 (2.6 to 6.4)	2.9 to 7.3 (4.7 to 11.8)	6.7 to 16.8 (10.8 to 27.0)	1.3 to 3.3 (2.1 to 5.3)
30.5-32	Cleat	10	.7 to 1.7 (1.1 to 2.7)	1.6 to 3.9 (2.6 to 6.3)	2.9 to 7.2 (4.7 to 11.6)	6.6 to 16.4 (10.6 to 26.4)	1.3 to 3.2 (2.1 to 5.2)
30.5-32	Cane & Rice	10	.7 to 1.8 (1.1 to 2.9)	1.6 to 4.1 (2.6 to 6.7)	3.0 to 7.4 (4.9 to 11.9)	6.8 to 17.1 (11.0 to 27.8)	1.3 to 3.3 (1.8 to 5.3)
Tracks			.3 to .8 (.5 to 1.3)	.7 to 1.8 (1.1 to 2.9)	1.3 to 3.3 (2.1 to 5.3)	3.0 to 7.6 (4.8 to 12.2)	.6 to 1.5 (1.0 to 2.4)

GROUND SPEED IN MPH (km/h) 7720 COMBINE (Hydrostatic Drive) 10 TO 82 AND 11 TO 90 RATIO FINAL DRIVES

Tire			1st Gear	2nd Gear	3rd Gear	4th Gear
Size	Type	Ply				
23.1-26	R1 Cleat	10	0 to 1.7 (0 to 2.7)	0 to 3.8 (0 to 6.2)	0 to 6.9 (0 to 11.4)	0 to 16.0 (0 to 26.2)
23.1-26	R3 Low Profile	8	0 to 1.6 (0 to 2.6)	0 to 3.7 (0 to 6.0)	0 to 6.7 (0 to 10.9)	0 to 15.4 (0 to 25.1)
23.1-26	R2 Cane & Rice	10	0 to 1.7 (0 to 2.8)	0 to 4.0 (0 to 6.6)	0 to 7.3 (0 to 11.9)	0 to 16.8 (0 to 28.0)
28.1-26	R1 Cleat	12	0 to 1.7 (0 to 2.8)	0 to 3.9 (0 to 6.3)	0 to 7.1 (0 to 11.6)	0 to 16.3 (0 to 26.7)
28.1-26	R2 Cane & Rice	12	0 to 1.7 (0 to 2.8)	0 to 4.0 (0 to 6.6)	0 to 7.3 (0 to 11.9)	0 to 16.8 (0 to 27.4)

10 TO 95 AND 11 TO 104 RATIO FINAL DRIVES

Tire			1st Gear	2nd Gear	3rd Gear	4th Gear
Size	Type	Ply				
24.5-32	R1 Cleat	10	0 to 1.6 (0 to 2.6)	0 to 3.8 (0 to 6.2)	0 to 6.8 (0 to 11.1)	0 to 15.7 (0 to 25.6)
24.5-32	R2 Cane & Rice	10	0 to 1.7 (0 to 2.7)	0 to 3.9 (0 to 6.3)	0 to 7.1 (0 to 11.8)	0 to 16.2 (0 to 27.0)
30.5-32	R1 Cleat	10	0 to 1.7 (0 to 2.7)	0 to 3.8 (0 to 6.3)	0 to 6.9 (0 to 11.6)	0 to 15.9 (0 to 26.4)
30.5-32	R2 Cane & Rice	10	0 to 1.7 (0 to 2.7)	0 to 3.9 (0 to 6.3)	0 to 7.2 (0 to 11.6)	0 to 16.5 (0 to 26.5)
Tracks			0 to .8 (0 to 1.3)	0 to 1.7 (0 to 2.8)	0 to 3.2 (0 to 5.2)	0 to 7.3 (0 to 11.8)


GROUND SPEED CONTROL RANGE IN MPH (km/h) 7720 RICE AND 8820 COMBINES

	Tire Size and Type	Ply	1st Gear	2nd Gear	3rd Gear	4th Gear
24.5-32	R1 Cleat	10	0 to 1.6 (0 to 2.6)	0 to 3.6 (0 to 5.8)	0 to 6.5 (0 to 10.5)	0 to 15.0 (0 to 24.1)
24.5-32	R2 Cane and Rice	10	0 to 1.6 (0 to 2.6)	0 to 3.7 (0 to 6.0)	0 to 6.7 (0 to 10.8)	0 to 15.4 (0 to 24.8)
24.5-32	R3 Low Profile	10	0 to 1.5 (0 to 2.4)	0 to 3.4 (0 to 5.5)	0 to 6.3 (0 to 10.1)	0 to 14.4 (0 to 23.2)
18.4-38 Duals and 30.5-32	R1 Cleat	8, 10	0 to 1.6 (0 to 2.0)	0 to 3.6 (0 to 5.8)	0 to 6.5 (0 to 10.5)	0 to 15.1 (0 to 24.3)
18.4-38 Duals and 30.5-32	R2 Cane and Rice	8, 10	0 to 1.6 (0 to 2.6)	0 to 3.7 (0 to 6.0)	0 to 6.8 (0 to 10.9)	0 to 15.6 (0 to 25.1)
30.5-32	R3 Low Profile	10	0 to 1.5 (0 to 2.4)	0 to 3.4 (0 to 5.5)	0 to 6.3 (0 to 10.1)	0 to 14.4 (0 to 23.2)
73x44.00-32	R1.5 High Flotation	12	0 to 1.6 (0 to 2.6)	0 to 3.7 (0 to 6.0)	0 to 6.8 (0 to 10.9)	0 to 15.5 (0 to 25.0)
Tracks			0 to 1.1 (0 to 1.8)	0 to 2.4 (0 to 3.9)	0 to 4.4 (0 to 7.1)	0 to 10.1 (0 to 16.3)

GROUND SPEED CONTROL RANGE IN MPH (km/h) WITH 4-WHEEL DRIVE ENGAGED 7720 RICE AND 8820 COMBINES

	Tire Size and Type	Ply	1st Gear	2nd Gear	3rd Gear	4th Gear
24.5-32	R1 Cleat	10	0 to 1.4 (0 to 2.3)	0 to 2.9 (0 to 4.7)	0 to 4.6 (0 to 7.4)	0 to 7.8 (0 to 12.6)
24.5-32	R2 Cane and Rice	10	0 to 1.5 (0 to 2.4)	0 to 3.0 (0 to 4.8)	0 to 4.8 (0 to 7.7)	0 to 7.9 (0 to 12.7)
18.4-38 Duals and 30.5-32	R1 Cleat	8, 10	0 to 1.4 (0 to 2.3)	0 to 2.9 (0 to 4.7)	0 to 4.7 (0 to 7.6)	0 to 7.9 (0 to 12.7)
18.4-38 Duals and 30.5-32	R2 Cane and Rice	8, 10	0 to 1.5 (0 to 2.4)	0 to 3.0 (0 to 4.8)	0 to 4.8 (0 to 7.7)	0 to 8.0 (0 to 12.9)
73x44.00-32	R1.1 High Flotation	12	0 to 1.5 (0 to 2.4)	0 to 3.0 (0 to 4.8)	0 to 4.7 (0 to 7.6)	0 to 7.7 (0 to 12.4)
Tracks			0 to 1.0 (0 to 1.6)	0 to 2.0 (0 to 3.2)	0 to 3.2 (0 to 5.1)	0 to 5.5 (0 to 8.9)

DIMENSIONS



Dimensions are with combine equipped with standard equipment tires and radio antenna clipped to roof.

	6620	SideHill 6620	7720	8820
Standard Equipment Tires	23.1-26-in. Cleat (R-1)	23.1-26-in. Cleat (R-1)	24.5-32-in. Cleat (R-1)	30.5-32-in. Cleat (R-1)
A. Height (Grain Tank Flip-Up In Up Position)	13 ft. (3.96 m)	13 ft. 3 in. (4.04 m)	13 ft. 4 in. (3.96 m)	13 ft. 4 in. (4.06 m)
B. Height (Grain Tank Flip-Up In Down Position And Exhaust Pipe At Highest Point)	12 ft. 8 in. (3.86 m)	12 ft. 11 in. (3.94 m)	13 ft. (3.86 m)	13 ft. (3.96 m)
C. Width	12 ft. 4 in. (3.76 m)	13 ft. (3.96 m)	13 ft. 3 in. (4.04 m)	14 ft. 5 in. (4.39 m)
D. Wheel Tread - For tread widths refer to wheel spacers page in the operator's manual.				
E. Unloading Auger Discharge Height	12 ft. 2 in. (3.71 m)	12 ft. 5 in. (3.78 m)	12 ft. 2 in. (3.71 m)	12 ft. 6 in. (3.81 m)
F. Unloading Auger Clearance Height	11 ft. 8 in. (3.56 m)	11 ft. 11 in. (3.63 m)	11 ft. 8 in. (3.56 m)	12 ft. (3.66 m)
G. Unloading Auger Reach*	5 ft. 7 in. (1.70 m)	5 ft. 7 in. (1.70 m)	4 ft. 1 in. (1.24 m)	4 ft. 6 in. (1.37 m)
Header Size Used	20 ft. (6.1 m)	20 ft. (6.1 m)	24 ft. (7.32 m)	24 ft. (7.32 m)
H. Wheelbase (All but heavy-duty)	12 ft. 1 in. (3.68 m)	12 ft. 10 in. (3.91 m)	12 ft. 1 in. (3.68 m)	N/A
Heavy-Duty Rear Axle	12 ft. 8 in. (3.86 m)	12 ft. 8 in. (3.86 m)	12 ft. 8 in. (3.86 m)	12 ft. 8 in. (3.86 m)
**Turning Radius	N/A	N/A	20 ft. 8 in. (6.33 m)	26 ft. 4 in. (8.03 m)
***Clearance Radius	N/A	N/A	28 ft. 9 in. (8.89 m)	30 ft. (9.14 m)

*Add 3-ft. (0.9 m) for extra long unloading auger.

**Measured to center of outer wheel track.

***Measured to extreme scribed circle (end of unloading auger in transport position).

DIMENSIONS

	6620	SideHill 6620	7720	8820
I. Length*				
With Auger In The Rear Position:				
Separator Only	26 ft. 1 in. (7.95 m)	26 ft. 1 in. (7.95 m)	26 ft. 1 in. (7.95 m)	26 ft. 1 in. (7.95 m)
Separator With Corn Head	34 ft. 3 in. (10.44 m)	34 ft. 3 in. (10.44 m)	34 ft. 3 in. (10.44 m)	34 ft. 3 in. (10.44 m)
Separator With Row-Crop Head	35 ft. 8 in. (10.87 m)	35 ft. 8 in. (10.87 m)	35 ft. 8 in. (10.87 m)	35 ft. 8 in. (10.87 m)
Separator With Flexible Platform	36 ft. 4 in. (11.07 m)	36 ft. 4 in. (11.07 m)	36 ft. 4 in. (11.07 m)	36 ft. 4 in. (11.07 m)
Separator With Rigid Platform	33 ft. 8 in. (10.26 m)	33 ft. 8 in. (10.26 m)	33 ft. 8 in. (10.26 m)	33 ft. 8 in. (10.26 m)
Separator With Pickup Platform (pickup in)	33 ft. (10.06 m)	33 ft. (10.06 m)	33 ft. (10.06 m)	33 ft. (10.06 m)
J. Length**				
With Auger In The Out Position:				
Separator Only	22 ft. 9 in. (6.93 m)	22 ft. 9 in. (6.93 m)	22 ft. 9 in. (6.93 m)	22 ft. 9 in. (6.93 m)
Separator With Corn Head	30 ft. 11 in. (9.42 m)	30 ft. 11 in. (9.42 m)	30 ft. 11 in. (9.42 m)	30 ft. 11 in. (9.42 m)
Separator With-Row Crop Head	32 ft. 4 in. (9.86 m)	32 ft. 4 in. (9.86 m)	32 ft. 4 in. (9.86 m)	32 ft. 4 in. (9.86 m)
Separator With Flexible Platform	33 ft. (10.06 m)	33 ft. (10.06 m)	33 ft. (10.06 m)	33 ft. (10.06 m)
Separator With Rigid Platform	30 ft. 4 in. (9.25 m)	30 ft. 4 in. (9.25 m)	30 ft. 4 in. (9.25 m)	30 ft. 4 in. (9.25 m)
Separator With Pickup Platform (pickup in)	29 ft. 8 in. (9.04 m)	29 ft. 8 in. (9.04 m)	29 ft. 8 in. (9.04 m)	29 ft. 8 in. (9.04 m)
K. Ground Clearance	1 ft. 9 in. (.53 m)	2 ft. (.61 m)	1 ft. 9 in. (.53 m)	2 ft. 1 in. (.64 m)

*Add 14-in. (356 mm) for long-length feeder house.

**Add 12-in. (304 mm) for a straw chopper; and 2 ft. 11 in. (889 mm) for a straw spreader.

Group 05**DIAGNOSING AND TESTING PROCEDURES**

To prevent unnecessary loss of time and money, use the following seven steps for a quick and accurate method of locating troubles:

1. Know The Unit

In other words, "Do your Homework". Study the Operator's Manual and this manual to know how the individual components work and what their function is in the overall system.

Keep up with the latest service information. Read and then file in a handy place. Record the Service Information Bulletin numbers on the pages provided in the front of this manual. Information received today may have the cause and remedy of a problem being encountered.

2. Consult The Operator

Ask the operator how the combine was performing when it started to fail. Find out what was unusual about it.

Also find out if any "do-it-yourself" service was performed. (You may find the trouble somewhere else, but you should know if any corrective measures have already been taken.)

Ask how the combine is used and how often it is serviced. Many problems are caused by poor maintenance or abuse.

3. Operate The Combine

If the combine is operable, operate it yourself. Don't rely completely on the operator's story - check it yourself.

Are gauges reading normal? If not, maybe the component being monitored is not functioning correctly or the gauge is faulty.

How's the performance? Is the action perhaps too fast or too slow, erratic, or none at all?

Do the controls feel solid or "spongy"? Do they seem to be "sticking"?

Do you smell or see any signs of smoke?

Do you hear any unusual sounds? Where?

4. Inspect The Combine

Get off the combine and make a visual check. Use your eyes, ears, and nose to spot any signs of trouble.

Look closely at the components. Inspect for cracked welds, loose hardware, damaged linkages, worn or broken lines, etc.

During the inspection, make notes of all the trouble signs.

5. List The Possible Causes

With the information obtained during steps 1 through 4, make a list of the possible causes.

What were the signs you found while inspecting the combine? What is the most likely cause?

6. Reach Some Conclusions

Look over the list of possible causes and decide which are most likely and which are easiest to verify.

Review the "Diagnosing Malfunctions" section as a helpful guide.

Reach your decision on the probable causes and plan to check them first.

7. Test Your Conclusions

Before repairing components in the system, test your conclusions to see which are correct.

Some of the possible causes may be verified without further testing. Check these possibilities first.

Test will narrow the remaining list of possible causes and soon the actual cause(s) of trouble will be pinpointed.

With the cause(s) accurately located, it is now a simple matter to remove and repair the component(s) at fault.



Suggest:

If the above button click is invalid.

**Please download this document
first, and then click the above link
to download the complete manual.**

Thank you so much for reading

Group 10

TUNE-UP AND ADJUSTMENT

GENERAL INFORMATION

Before tuning up a combine engine, determine whether a tune-up will restore operating efficiency. When there is doubt, the following preliminary tests will help determine if the engine can be tuned up. If the

condition is satisfactory, proceed with the tune-up. Choose from the following procedures only those necessary to restore the combine.

PRELIMINARY ENGINE TESTING

Compression Test (minimum readings at 200-250 rpm cranking speed)

Engine	Compression Pressure
6466DH-01	26-28 Kg/cm ² (26-27 bar) (370-400 psi)
6466TH-01, TH-05	23-25 Kg/cm ² (23-26 bar) (330-370 psi)
ENGINE (-252662)	
6466TH-01, TH-05	27-32 Kg/cm ² (27-31 bar) (390-450 psi)
ENGINE (252663-)	
6466AH-01, AH-02	23-25 Kg/cm ² (23-26 bar) (330-370 psi)
ENGINE (-227649)	
6466AH-01, AH-02, AH-03	25-30 Kg/cm ² (25-29 bar) (355-415 psi)
ENGINE (227650-)	

It is very important that all cylinder pressures be approximately alike. There should be less than 25 psi (1.72 bar) (1.75 kg/cm²) difference between cylinder pressures.

ENGINE TUNE-UP

Air Intake System

Check system for leaks

Exhaust System

Check system for leaks. Check for restricted muffler or exhaust pipe

Crankcase Vent

Check for restrictions

Cooling System

Clean rotary screen, radiator core, hydrostatic oil cooler core, and air conditioning condenser
Clean and flush system and check thermostats
Check radiator cap
Inspect all hoses

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>