

**580N  
580SN WT  
580SN  
590SN  
Tier 4B (final)**

**Tractor Loader Backhoe**

*580N PIN NHC740665 and above; 580SN WT PIN NHC745126 and above;  
580SN PIN NHC743044 and above; 590SN PIN NHC746245 and above*

**SERVICE MANUAL**

**Part number 48194558**

1<sup>st</sup> edition English

October 2017

**CASE**  
CONSTRUCTION



## **SERVICE MANUAL**

**580N Four-Wheel Drive (4WD) Tier 4B (final) [NHC740665 - ], 580N Two-Wheel Drive (2WD) Tier 4B (final) [NHC740665 - ], 580SN Four-Wheel Drive (4WD) Tier 4B (final) [NHC743044 - ], 580SN Two-Wheel Drive (2WD) Tier 4B (final) [NHC743044 - ], 580SN WT Four-Wheel Drive (4WD) Tier 4B (final), Wide Track [NHC745126 - ], 590SN Four-Wheel Drive (4WD) Tier 4B (final) [NHC746245 - ], 590SN Two-Wheel Drive (2WD) Tier 4B (final) [NHC746245 - ]**

## Link Product / Engine

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
580N Two-Wheel Drive (2WD) Tier 4B (final) [NHC740665 - ]	North America	F5BFL413A*B007
580N Four-Wheel Drive (4WD) Tier 4B (final) [NHC740665 - ]	North America	F5BFL413A*B007
580SN Two-Wheel Drive (2WD) Tier 4B (final) [NHC743044 - ]	North America	F5BFL413A*B007
580SN Four-Wheel Drive (4WD) Tier 4B (final) [NHC743044 - ]	North America	F5BFL413A*B007
580SN WT Four-Wheel Drive (4WD) Tier 4B (final), Wide Track [NHC745126 - ]	North America	F5BFL413A*B007
590SN Two-Wheel Drive (2WD) Tier 4B (final) [NHC746245 - ]	North America	F5BFL413A*B007
590SN Four-Wheel Drive (4WD) Tier 4B (final) [NHC746245 - ]	North America	F5BFL413A*B007

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

# Contents

---

## INTRODUCTION

<b>Engine</b> .....	<b>10</b>
[10.001] Engine and crankcase .....	10.1
[10.103] Crankshaft and flywheel.....	10.2
[10.206] Fuel filters .....	10.3
[10.216] Fuel tanks .....	10.4
[10.218] Fuel injection system.....	10.5
[10.304] Engine lubrication system.....	10.6
[10.400] Engine cooling system .....	10.7
[10.414] Fan and drive .....	10.8
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.9
<b>Transmission</b> .....	<b>21</b>
[21.112] Power shuttle transmission.....	21.1
[21.113] Powershift transmission .....	21.2
[21.134] Power shuttle transmission external controls .....	21.3
[21.135] Powershift transmission external controls.....	21.4
[21.154] Power shuttle transmission internal components .....	21.5
[21.155] Powershift transmission internal components.....	21.6
<b>Front axle system</b> .....	<b>25</b>
[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.108] Final drive hub, steering knuckles, and shafts .....	25.3
[25.400] Non-powered front axle .....	25.4
<b>Rear axle system</b> .....	<b>27</b>
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential .....	27.2

[27.120] Planetary and final drives .....	27.3
<b>Brakes and controls .....</b>	<b>33</b>
[33.110] Parking brake or parking lock .....	33.1
[33.202] Hydraulic service brakes .....	33.2
<b>Hydraulic systems.....</b>	<b>35</b>
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.104] Fixed displacement pump .....	35.3
[35.106] Variable displacement pump .....	35.4
[35.204] Remote control valves .....	35.5
[35.300] Reservoir, cooler, and filters.....	35.6
[35.350] Safety and main relief valves .....	35.7
[35.357] Pilot system .....	35.8
[35.359] Main control valve .....	35.9
[35.525] Auxiliary hydraulic valves and lines .....	35.10
[35.701] Front loader arm hydraulic system .....	35.11
[35.703] Stabilizer hydraulic system .....	35.12
[35.723] Front loader bucket hydraulic system .....	35.13
[35.726] Excavator and backhoe hydraulic controls.....	35.14
[35.736] Boom hydraulic system .....	35.15
[35.737] Dipper hydraulic system.....	35.16
[35.738] Excavator and backhoe bucket hydraulic system.....	35.17
[35.739] Swing arm hydraulic system .....	35.18
[35.740] Telescopic arm hydraulic system.....	35.19
<b>Frames and ballasting .....</b>	<b>39</b>
[39.100] Frame .....	39.1
[39.129] Stabilizers .....	39.2
<b>Steering.....</b>	<b>41</b>

[41.101] Steering control .....	41.1
[41.200] Hydraulic control components.....	41.2
[41.216] Cylinders .....	41.3
<b>Wheels .....</b>	<b>44</b>
[44.511] Front wheels.....	44.1
[44.520] Rear wheels .....	44.2
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.200] Air conditioning.....	50.2
<b>Electrical systems .....</b>	<b>55</b>
[55.024] Transmission control system .....	55.1
[55.100] Harnesses and connectors.....	55.2
[55.201] Engine starting system .....	55.3
[55.301] Alternator.....	55.4
[55.302] Battery.....	55.5
[55.404] External lighting .....	55.6
[55.408] Warning indicators, alarms, and instruments .....	55.7
[55.510] Cab or platform harnesses and connectors.....	55.8
[55.640] Electronic modules .....	55.9
[55.988] Selective Catalytic Reduction (SCR) electrical system .....	55.10
[55.991] Telematics .....	55.11
[55.DTC] FAULT CODES.....	55.12
<b>Front loader and bucket.....</b>	<b>82</b>
[82.100] Arm.....	82.1
[82.300] Bucket.....	82.2
<b>Booms, dippers, and buckets .....</b>	<b>84</b>
[84.100] Bucket.....	84.1
[84.114] Boom pivoting support .....	84.2

[84.910] Boom .....	84.3
[84.912] Dipper arm .....	84.4
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.100] Engine hood and panels .....	90.1
[90.114] Operator protections .....	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.150] Cab.....	90.4
[90.151] Cab interior.....	90.5
[90.154] Cab doors and hatches .....	90.6
[90.156] Cab windshield and windows .....	90.7



## **INTRODUCTION**

---

## **Foreword - Important notice regarding equipment servicing**

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CASE CONSTRUCTION Sales and Service Networks.

## Safety rules


### Personal safety





This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

**FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.**

### Machine safety

**NOTICE:** Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

### Information

**NOTE:** Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

## **Safety rules - Personal safety**

Unless otherwise instructed, always perform these steps before you service the machine:

1. Park the machine on a flat, level surface.
2. Place the backhoe in the transport position with the swing lock pin installed for transport.
3. Place the loader bucket on the ground, with the bottom of the loader bucket parallel to the surface.
4. Place the direction control lever and the transmission in neutral.
5. If you need to open the hood to perform service, raise the loader arms and install the support strut.
6. Shut down the engine.
7. Place a 'Do Not Operate' tag on the key switch so that it is visible to other workers or remove the key.

---

## Safety rules - Ductile iron

**⚠ DANGER**

**Altering cast ductile iron can cause it to weaken or break.**

**Before you weld, cut, or drill holes on any part of this machine, make sure that the part is not cast ductile iron.**

**Failure to comply will result in death or serious injury.**

D0148A

Altering cast ductile iron can cause it to weaken or break. Unauthorized modifications to cast ductile iron parts can cause death or serious injury. Do not weld, cut, drill, repair, or attach items to cast ductile iron parts on this machine.

Before you weld, cut, or drill holes on any part of this machine, make sure the part is not cast ductile iron. See your dealer if you do not know if a part is cast ductile iron.

The following items are examples of cast ductile iron parts. There may also be other parts made of cast ductile iron that are not on the list below.

- two-wheel drive steering link
- dump links
- front axle
- stabilizers
- extend-a-hoe
- swing tower
- bucket linkage
- Air-Conditioning (A/C) compressor mounting bracket

Do not make any unauthorized modifications. Consult an authorized dealer before making any changes, additions, or modifications to this machine.

---

## Safety rules - Ecology and the environment

Soil, air, and water quality is important for all industries and life in general. When legislation does not yet rule the treatment of some of the substances that advanced technology requires, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

Familiarize yourself with the relative legislation applicable to your country, and make sure that you understand this legislation. Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, anti-freeze, cleaning agents, etc., with regard to the effect of these substances on man and nature and how to safely store, use, and dispose of these substances.

### Helpful hints

- Avoid the use of cans or other inappropriate pressurized fuel delivery systems to fill tanks. Such delivery systems may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of these products contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when you drain fluids such as used engine coolant mixtures, engine oil, hydraulic fluid, brake fluid, etc. Do not mix drained brake fluids or fuels with lubricants. Store all drained fluids safely until you can dispose of the fluids in a proper way that complies with all local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- The air-conditioning system contains gases that should not be released into the atmosphere. Consult an air-conditioning specialist or use a special extractor to recharge the system properly.
- Repair any leaks or defects in the engine cooling system or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding. Penetrating weld splatter may burn a hole or weaken hoses, allowing the loss of oils, coolant, etc.

### Battery recycling

Batteries and electric accumulators contain several substances that can have a harmful effect on the environment if the batteries are not properly recycled after use. Improper disposal of batteries can contaminate the soil, groundwater, and waterways. CASE CONSTRUCTION strongly recommends that you return all used batteries to a CASE CONSTRUCTION dealer, who will dispose of the used batteries or recycle the used batteries properly. In some countries, this is a legal requirement.



### Mandatory battery recycling

**NOTE:** The following requirements are mandatory in Brazil.

Batteries are made of lead plates and a sulfuric acid solution. Because batteries contain heavy metals such as lead, CONAMA Resolution 401/2008 requires you to return all used batteries to the battery dealer when you replace any batteries. Do not dispose of batteries in your household garbage.

Points of sale are obliged to:

- Accept the return of your used batteries
- Store the returned batteries in a suitable location
- Send the returned batteries to the battery manufacturer for recycling



## **SERVICE MANUAL**

### **Engine**

**580N Four-Wheel Drive (4WD) Tier 4B (final) [NHC740665 - ], 580N Two-Wheel Drive (2WD) Tier 4B (final) [NHC740665 - ], 580SN Four-Wheel Drive (4WD) Tier 4B (final) [NHC743044 - ], 580SN Two-Wheel Drive (2WD) Tier 4B (final) [NHC743044 - ], 580SN WT Four-Wheel Drive (4WD) Tier 4B (final), Wide Track [NHC745126 - ], 590SN Four-Wheel Drive (4WD) Tier 4B (final) [NHC746245 - ], 590SN Two-Wheel Drive (2WD) Tier 4B (final) [NHC746245 - ]**

## Engine - Remove

### **⚠ DANGER**

#### **Crushing hazard!**

If you service the machine with the loader lift arms raised, always use the support strut. Remove the retaining pin and place the support strut onto the cylinder rod. Install the retaining pin into the support strut. Lower the lift arms onto the support strut.

Failure to comply will result in death or serious injury.

D0084A

### **⚠ WARNING**

#### **Heavy objects!**

Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders.

Failure to comply could result in death or serious injury.

W0398A

**NOTICE:** Avoid contamination always clean all surrounding areas before disconnecting components. Always cap or plug all tubes, hoses, and component openings after disconnecting or removal.

**NOTICE:** Attach identification labels to all connectors, tubes, and hoses to help with the installation procedure.

#### **Prior operation:**

Disconnect the batteries. See **Battery - Disconnect (55.302)**.

#### **Prior operation:**

Drain the hydraulic tank. See **Oil reservoir - Drain fluid (35.300)**.

#### **Prior operation:**

Drain the transmission fluid. For Powershuttle transmissions see **Power shuttle transmission - Drain fluid (21.112)**. For Powershift transmissions see **Powershift transmission - Drain fluid (21.113)**.

#### **Prior operation:**

Remove the engine hood. See **Hood - Remove (90.105)**.


#### **Prior operation:**

Drain the cooling system. See **Radiator - Drain fluid (10.400)**.

#### **Prior operation:**


If applicable, discharge the Air-Conditioning (A/C) system. See **Air conditioning - Charging (50.200)**. Do not follow the charge system procedure.

1. Remove the bolts **(3)** that secure the air cleaner **(2)** to the fixed hood **(1)**.




RAIL16TLB1122BA 1

2. Attach a suitable lifting device to the fixed hood (1).
3. Remove the bolts (2) and lift the fixed hood off of the machine.




RAIL14TLB1156AA 2

4. Remove the bolts (1) from the front bumper (2).
5. Remove the front grille (3)




RAIL14UTL0048BA 3

6. Remove the air intake tube support bracket bolts (1) and bracket (2).




RAPH11TLB0030BA 4

7. Support the cooling package housing wrapper (1).




RAPH11TLB0038BA 5

8. Remove the cooling package housing wrapper bolts (1), (2).




RAPH11TLB0029BA 6

9. Carefully lift and remove the cooling package housing wrapper.




RAPH11TLB0038BA 7

10. Loosen the hose clamp **(3)** on the air cleaner outlet hose and disconnect the hose.
11. Loosen the hose clamp **(2)** on the Closed Crankcase Ventilation (CCV) hose and disconnect hose.
12. Remove all tie wraps **(1)** that secure the CCV hose position.




RAIL16TLB1123BA 8

13. Loosen and remove the exhaust tube clamp **(1)**.
14. Loosen the hose clamp on the air intake hose **(2)** and disconnect the hose.




RAIL14TLB1151AA 9

15. Disconnect the air restriction sensor **(1)** wiring.



RAIL14TLB1152AA 10


16. Disconnect the temperature sensor **(1)** connector.



RAIL14TLB1153AA 11


17. Remove the air cleaner assembly from the machine.

18. Loosen the clamps **(2)** from the Charge-Air-Cooler (CAC) tubes **(1)**, **(3)** and disconnect tubes.




RAIL16TLB1126BA 12

19. Disconnect the A/C condenser inlet line **(1)**.  
20. Disconnect the inlet fuel cooler line **(2)**.  
21. Disconnect the outlet fuel cooler line **(3)**.  
22. Disconnect the A/C condenser outlet line **(4)**.




RAPH11TLB0037BA 13

23. Remove the horn bracket nut **(1)**. Place the horn and horn bracket away from the cooling package.




RAPH11TLB0035BA 14

24. Loosen and remove the receiver/dryer hold-down clamps **(1)**. Place the receiver/dryer away from the cooling package.




RAPH11TLB0036BA 15

25. Label and disconnect the hydraulic oil hoses **(1)** leading to the hydraulic oil cooler.




RAPH11TLB0034BA 16

26. Disconnect the lower radiator hose **(1)** from the radiator.
27. Label and disconnect the transmission oil cooler hoses **(2)** leading to the transmission oil cooler.




RAPH11TLB0033BA 17

28. Disconnect the upper radiator hose (1) from the radiator.



RAIL16TLB1128BA 18

29. Disconnect the A/C high pressure line (1).  
 30. Disconnect the A/C low pressure line (5).  
 31. Locate and disconnect the A/C compressor electrical connection (4).  
 32. Disconnect the engine electrical connectors (2) and (3).




RAIL16TLB1127BA 19

33. Use a suitable lifting device and support the cooling package.


**NOTICE:** You may choose to remove the fan but it is not necessary as long as you are careful; move slowly and control the movement of the cooling package outward away from the fan.

34. Remove the hood strut post (2) and retainer (1).  
 35. Slowly remove the cooling package outward away from the fan.



RAPH11TLB0028BA 20


36. Disconnect fuel lines (1) and (2).



RAIL17TLB0350BA 21


37. Disconnect the water sensor electrical connector.

**NOTE:** Water sensor is located at the bottom of the primary fuel filter.




RAIL17TLB0350BA 22

38. Disconnect the glow plug control unit electrical connector (1).




RAPH11TLB0021BA 23

39. If applicable, disconnect the heater return hose (1).




RAPH11TLB0039BA 24

40. If applicable, disconnect the heater supply hose (1).




RAIL16TLB1131BA 25

41. Label and disconnect the alternator electrical connector (2) and the alternator battery wire (1).




RAIL16TLB1130BA 26

42. If equipped, remove the battery disconnect switch bracket from the frame and set aside.




RAIL14TLB0403AA 27

43. Remove the nut (3), disconnect the wire harness (4) and positive battery cable (2) from the terminal on the starter (1).




RAIL14TLB0403AA 28

44. Disconnect the ground strap.




RAIL14FRK0129BA 29


45. On the left-hand side of the engine remove both caps to access the flex plate bolts.



46. Insert the engine turning tool **380003372** into the lower opening **(2)** and rotate the flywheel until the flex plate bolt is visible in the top opening **(1)**.




RAPH12FRK0979BA 31




RAIL14FRK0139BA 32

47. Remove all the bolts that fasten the flywheel to the flex plate.



RAIL14FRK0140BA 33


48. Attach suitable lifting equipment to the three engine lifting eyelets. One in the front and two on the upper back of the engine.
49. Use the lifting device to support the weight of the engine.



RAIL16TLB1129BA 34

50. Remove the engine mounts (1).

**NOTE:** Lower radiator hose removed for picture clarity.



RAPH11TLB0019BA 35



**Suggest:**

**If the above button click is invalid.**

**Please download this document**


**first, and then click the above link**

**to download the complete manual.**

**Thank you so much for reading**

51. Remove the bell housing bolts (1).

**NOTE:** For powershift machines take note of the p-clamp location that secures the transmission dipstick tube on the left-hand side of the machine.



RAPH11TLB0020BA 36

52. Make sure that all the harness connectors and hoses have been disconnected and are clear of the engine. Slowly raise the engine from the frame and remove the engine from the machine.

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**