

1150D/1155D CRAWLERS TABLE OF CONTENTS

SERIES/SECTION	SECTION NO.	FORM NO.
1 GENERAL		
Safety Rules, Service Manual Introduction, and Torque Specifications	1001	8-41280
Maintenance and Lubrication	1002	8-41280
General Engine Specifications	1010	8-25220
Detailed Engine Specifications	1320	8-20040
2 ENGINE		
Engine Stall Tests, Engine Removal and Installation, Engine Accessories (Radiator, Air Cleaner, Mufflers, Ether Injection System, Turbocharger)	2000	8-41280
Engine Tune-Up	2002	9-76379
Cylinder Head, Valve Train, and Camshaft	2015	8-22560
Cylinder Block, Sleeves, Pistons, and Rods	2025	9-76176
Crankshaft, Main Bearings, Flywheel, and Oil Seals	2035	9-76187
Lubrication System	2046	8-22780
Cooling System	2055	9-76337
Engine Troubleshooting	2201	8-20110
Reconditioning the Engine Block	2290	8-21170
Turbocharger Failure Analysis	2565	9-78235
3 FUEL SYSTEM		
Fuel Tank, Fuel Lines, and Engine Controls	3001	8-41280
Fuel System and Filters	3010	9-75297
Robert Bosch Fuel Injection Pump	3012	9-74937
17 mm Fuel Injectors	3213	8-20240
4 ELECTRICAL		
Electrical System Specifications and Troubleshooting	4002	8-41280
Wiring Diagrams	4003	8-41280
Gauges	4004	8-41280
Batteries	4005	8-41280
Starter and Starter Solenoid	4006	8-41280
Alternator	4007	8-41280
5 TRACK AND SUSPENSION		
Case Lubricated Track	5504	8-42190
Track, Track Frame, and Suspension	5506	8-41280
Idler, Track Adjuster, and Recoil Housing	5508	8-41280
Sprockets	5509	8-41280
Carrier Rollers	5510	8-41280
Track Rollers	5511	8-41280

6 POWER TRAIN

Transmission Maintenance and Troubleshooting	6002	8-41280
Transmission Diagrams and Operation	6003	8-41280
Charging Pump	6005	9-67861
Transmission Control Valve	6007	8-41280
Torque Converter	6010	8-41280
Transmission	6016	8-41280
Final Drives	6017	8-41280
Transmission Controls	6018	8-41280
Drive Shaft	6021	8-41280

7 BRAKES

Brakes	7001	8-41280
--------------	------	---------

8 HYDRAULICS

Hydraulic System Specifications, Diagrams, Maintenance Troubleshooting, and Pressure Checks	8002	8-41280
Cleaning the Hydraulic System	8003	8-41280
Pump	8005	8-41280
Equipment Control Valve	8007	8-41280
Selector Valve	8021	8-41280
Cylinders	8090	8-41280

9 MOUNTED EQUIPMENT

Air Conditioning Troubleshooting	9002	8-41280
Air Conditioning System	9003	8-41280
Loader	9010	8-41280
Dozer Blade	9020	8-41280
Ripper	9031	8-41280
Cab and Canopy	9061	8-41280
Operators Seats and Seat Belts	9064	8-41280
Decals, Painting, and Noise Control	9201	8-41280
Winch	9300	8-41280

1001

SAFETY RULES SERVICE MANUAL INTRODUCTION AND TORQUE SPECIFICATIONS

TABLE OF CONTENTS

Safety Rules	1001-2	Illustrations and Photos	1001-4
Service Manual Introduction	1001-4	Clear and Simple English	1001-4
Right, Left, Front, and Rear	1001-4	Special Tools	1001-4
Text	1001-4	Product Identification Number (PIN) and Serial Numbers	1001-5
Table of Contents	1001-4	Torque Specifications	1001-6
Page Numbers	1001-4		

Written In *Clear
And
Simple
English*

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.


<https://www.ebooklibonline.com>

SERVICE MANUAL INTRODUCTION

This service manual has been prepared with the latest service information available. Troubleshooting, removal, disassembly, inspection and installation procedures, and complete specifications and tightening references can be found in most sections. Some sections have drawings but no written procedure because the job is so easily done. This service manual is one of the most important tools available to the service technician.

Right, Left, Front, and Rear

The terms right-hand and left-hand and front and rear as used in this manual indicate the right and left sides, and front and rear of the machine as seen from the operator's seat for correct operation of the machine or attachment.



Text

If the service manual is for more than one machine or different models of components (planetary axles, gear boxes, control valves, etc.) the procedures have the steps necessary to service each model.

Table of Contents

A Table of Contents is in the front of this manual. The Table of Contents shows the main divisions and the sections that are in each division. The individual sections, where necessary, have a Table of Contents on the cover or second page of that section.

Page Numbers

All page numbers are made of two numbers separated by a dash, such as 4002-9. The number before the dash is the section number. The number following the dash is the page number in that section. Page numbers will be found at the upper right or left of each page.

Illustrations and Photos

Illustrations are put as near as possible to the text and are to be used as part of the text. Photos normally are put below the step to which they apply.

Clear and Simple English

This manual is written in C.A.S.E. (Clear and Simple English). C.A.S.E. is easier to read and understand than "regular" English because C.A.S.E. uses a small number of common words and has special rules for writing.

All sections written in C.A.S.E. are indicated by the symbol below.

Written In *Clear
And
Simple
English*

Special Tools

Special tools are needed to remove and install, disassemble and assemble, check, and adjust some component parts of this machine. Some special tools can be easily made locally and the necessary information to make the tool is in this service manual. Other special tools are more difficult to make locally and are available from Service Tools in the U.S. and from Jobborn Manufacturing in Canada. Use these tools according to the instructions in this service manual for your personal safety and to do the job correctly.


Order special tools from either of the following companies:

Service Tools
P.O. Box 314
Owatonna, Minnesota 55060

Jobborn Manufacturing Co.
97 Frid Street
Hamilton, Ontario L8P 4M3
Canada

PRODUCT IDENTIFICATION NUMBER (PIN) AND SERIAL NUMBERS

NOTE: A serial number plate is also on some components such as the starter, alternator, pump, etc.



TORQUE SPECIFICATIONS - U.S. HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers, dry, or when lubricated with engine oil. Not applicable if special graphites, moly-disulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs			
  			
Size	Pound-Feet	Newton metres	Kilogram metres
1/4 in 6.4 mm	9-11	12-15	1.2-1.5
5/16 in 7.9 mm	17-21	23-28	2.4-2.9
3/8 in 9.5 mm	35-42	48-57	4.8-5.8
7/16 in 11.1 mm	54-64	73-87	7.5-8.8
1/2 in 12.7 mm	80-96	109-130	11.1-13.3
9/16 in 14.3 mm	110-132	149-179	15.2-18.2
5/8 in 15.9 mm	150-180	203-244	20.8-24.9
3/4 in 19.0 mm	270-324	366-439	37.3-44.8
7/8 in 22.2 mm	400-480	542-651	55.3-66.4
1.0 in 25.4 mm	580-696	787-944	80.2-96.2
1-1/8 in 28.6 mm	800-880	1085-1193	111-122
1-1/4 in 31.8 mm	1120-1240	1519-1681	155-171
1-3/8 in 34.9 mm	1460-1680	1980-2278	202-232
1-1/2 in 38.1 mm	1940-2200	2631-2983	268-304

Grade 8 Bolts, Nuts, and Studs			
  			
Size	Pound-Feet	Newton metres	Kilogram metres
1/4 in 6.4 mm	12-15	16-20	1.7-2.1
5/16 in 7.9 mm	24-29	33-39	3.3-4.0
3/8 in 9.5 mm	45-54	61-73	6.2-7.5
7/16 in 11.1 mm	70-84	95-114	9.7-11.6
1/2 in 12.7 mm	110-132	149-179	15.2-18.2
9/16 in 14.3 mm	160-192	217-260	22.1-26.5
5/8 in 15.9 mm	220-264	298-358	30.4-36.5
3/4 in 19.0 mm	380-456	515-618	52.5-63.0
7/8 in 22.2 mm	600-720	814-976	83.0-99.5
1.0 in 25.4 mm	900-1080	1220-1465	124-149
1-1/8 in 28.6 mm	1280-1440	1736-1953	177-199
1-1/4 in 31.8 mm	1820-2000	2468-2712	252-277
1-3/8 in 34.9 mm	2380-2720	3227-3688	329-376
1-1/2 in 38.1 mm	3160-3560	4285-4827	437-492

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
37 Degree Flare Fittings				
1/4 in 6.4 mm	7/16-20	6-12	8-16	0.8-1.7
5/16 in 7.9 mm	1/2-20	8-16	11-21	1.1-2.2
3/8 in 9.5 mm	9/16-18	10-25	14-33	1.4-3.5
1/2 in 12.7 mm	3/4-16	15-42	20-56	2.1-5.8
5/8 in 15.9 mm	7/8-14	25-58	34-78	3.5-8.0
3/4 in 19.0 mm	1-1/16-12	40-80	54-108	5.5-11.1
7/8 in 22.2 mm	1-3/16-12	60-100	81-135	8.3-13.9
1.0 in 25.4 mm	1-5/16-12	75-117	102-158	10.4-16.2
1-1/4 in 31.8 mm	1-5/8-12	125-165	169-223	17.3-22.8
1-1/2 in 38.1 mm	1-7/8-12	210-250	285-338	29.0-34.6

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
Straight Threads with O-ring				
1/4 in 6.4 mm	7/16-20	12-19	16-25	1.7-2.6
5/16 in 7.9 mm	1/2-20	16-25	22-33	2.2-3.5
3/8 in 9.5 mm	9/16-18	25-40	34-54	3.5-5.5
1/2 in 12.7 mm	3/4-16	42-67	57-90	5.8-9.3
5/8 in 15.9 mm	7/8-14	58-92	79-124	8.0-12.7
3/4 in 19.0 mm	1-1/16-12	80-128	108-174	11.1-17.8
7/8 in 22.2 mm	1-3/16-12	100-160	136-216	13.8-22.1
1.0 in 25.4 mm	1-5/16-12	117-187	159-253	16.2-25.9
1-1/4 in 31.8 mm	1-5/8-12	165-264	224-357	22.8-36.5
1-1/2 in 38.1 mm	1-7/8-12	250-400	339-542	34.6-55.3

Split Flange Mounting Bolts			
Size	Pound- Feet	Newton metres	Kilogram metres
5/16-18	15-20	20-27	2.1-2.8
3/8-16	20-25	26-33	2.8-3.5
7/16-14	35-45	47-61	4.7-6.2
1/2-13	55-65	74-88	7.6-9.0
5/8-11	140-150	190-203	19.4-20.7

2000

ENGINE STALL TESTS, ENGINE REMOVAL AND INSTALLATION, ENGINE ACCESSORIES


TABLE OF CONTENTS

Stall Tests	2000-2	Cleaning the Primary Element	2000-47
Specifications	2000-2	Secondary Element	2000-47
Procedure to Heat the Oil	2000-3	Precleaner	2000-47
Torque Converter	2000-3	Filter Fitting	2000-47
Hydraulic System	2000-3	Checking the Filter Fitting	2000-47
Test No. 1 - Torque Converter and Hydraulic Stall Together	2000-3	Restriction Indicator Check	2000-48
Understanding the Results of the Test	2000-4	Spark Arrester Muffler	2000-48
Test No. 2 - Torque Converter Stall	2000-4	Ether Injection System	2000-50
Understanding the Results of the Test	2000-4	General Information	2000-51
Test No. 3 - Hydraulic Stall	2000-4	Operating Procedure	2000-51
Understanding the Results of the Test	2000-4	Troubleshooting	2000-51
Engine Removal	2000-5	Radiator	2000-53
Torque Converter	2000-22	Removal	2000-53
Removal	2000-22	Installation	2000-58
Installation	2000-25	Turbocharger	2000-63
Engine Installation	2000-27	Priming the Turbocharger	2000-63
Air Cleaner	2000-43	Stopping the Engine	2000-64
Service Interval	2000-47	Causes of Turbocharger Failure	2000-64
Dust Cup	2000-47	Removal	2000-64
		Installation	2000-64

ENGINE REMOVAL

Because the only support for the torque converter is the engine, the torque converter must be removed with the engine.

1. If the machine is a loader, raise the loader frame and lower the strut onto the lift cylinder.




1. Strut

334934


2. If the machine is a dozer, lower the blade to the floor.

3. Loosen and remove the cap screws that hold the side panels in place.




335201

4. Remove both side panels.




335204

5. Loosen and remove the cap screws, bolts, lock washers, flat washers, and nuts that hold the bottom panels in place.




335206

6. Remove both bottom panels.




335209

7. Loosen the self-locking nuts on the front hood bolts.



335211

8. Loosen the self-locking nuts on the rear hood bolts.



335118

11. Loosen and remove the cap screws that hold the plate at the top of the radiator shroud.



335233

9. Loosen and remove the cap screws that hold the top half of the grille and screen. Do not let the grille and screen fall.



335143

12. Remove the plate.




335319

10. Remove the grille and screen.




335101

13. Loosen and remove the cap screws that hold the plate that supports the bottom half of the grille and screen.




334942

14. Loosen and remove the cap screws that hold the plate that supports the bottom half of the grille and screen.




334906

15. Loosen and remove the cap screws that hold the bottom half of the grille and screen. Do not let the grille and screen fall.



334909


16. Remove the grille, screen, and plate.



334910


17. Remove the front guard (photo, top right). Use an acceptable jack to hold the front guard in place. Loosen and remove the cap screws and flat washers that hold the front guard to the machine.

18. Lower the front guard to the floor and remove the front guard from under the machine.



335031

19. Use the same procedure to remove the center guard and both rear guards.




335032

20. Start the engine. Raise the loader frame, and move the strut rearward and install the two cap screws that hold the strut in place.

21. Lower the loader frame to the floor.


22. Stop the engine.

23. Attach acceptable lifting equipment to the brush guard.



335330

24. Loosen and remove the self-locking nuts and bolts that fasten the rear of the brush guard to the ROPS canopy.



335134

25. Loosen the nuts and bolts that hold the mounting plates for the front of the brush guard to the radiator shroud. Remove all of the nuts, bolts, and flat washers except the two that fasten the horns to the radiator shroud.




335323

26. Disconnect the harness wires from both horns.




335325

27. Remove the nuts that fasten the horns to the radiator shroud and remove the horns, bolts, and flat washers.



335326

28. Carefully remove the brush guard.




335332

29. If the machine has a turbocharger:

- a. Loosen the muffler clamp at the engine and remove the muffler.
- b. Loosen and remove the cap screw at the rear of the hood.
- c. Remove the hood.

30. If the machine does not have a turbocharger:

- a. Loosen and remove the cap screw at the rear of the hood.



335335

- b. Remove the hood.



335338

31. Start the engine. Raise the loader frame all the way and stop the engine. Remove the cap screws that hold the strut in place and move the strut forward onto the cylinder rod.


32. Lower the loader frame onto the strut.



335341

33. Loosen and remove the radiator cap.

34. Open the drain valve and drain the coolant from the radiator. The cooling system contains 13 U.S. gallons (49 litres) of coolant.




335503

1. Drain Valve

35. If the machine has a radiator with the transmission oil cooler on the side:


- a. Disconnect the top hose on the transmission oil cooler from the tube. Install a plug in the tube and a cap on the hose.
- b. Disconnect the bottom hose on the transmission oil cooler from the tube. Install a plug in the tube and a cap on the hose.



840100


36. If the machine has a radiator with the transmission oil cooler on the bottom:

- a. Disconnect the hose for the right side of the transmission oil cooler.



335507

- b. Install a plug in the tube and a cap on the hose.
- c. Disconnect the hose for the left side of the transmission oil cooler.



335505

- d. Install a plug in the tube and a cap on the hose.


37. If the machine is a dozer:

- a. Remove the snap rings from the pivot pins that fasten the rod end of the lift cylinders in place.
- b. Remove the pivot pins and spacers.
- c. Disconnect the tubes for the lift cylinders from the tubes at the rear of the engine. Install plugs in the tubes and caps on the fittings.

- d. Disconnect the tubes for the lift cylinders from the tee fittings at the radiator shroud. Install plugs in the tubes and caps on the fittings.


- e. Loosen the cap screws for the clamps that fasten the tubes to the bracket at the rear of the engine.

- f. Remove the tubes for the lift cylinders.




840101

38. Loosen and remove the cap screws, lock washers, and flat washers that hold the radiator to the radiator mounts.




335301

39. Loosen the clamp that holds the bottom radiator hose to the water pump.




335421

40. Remove the hose.




335423

41. Loosen the clamp that holds the top radiator hose to the radiator.




335424

42. Remove the hose.




335426

43. Attach acceptable lifting equipment to the radiator shroud and around the inlet tube at the top rear of the radiator.




335429

44. Loosen and remove the eight cap screws that hold the radiator shroud to the frame.




335418

45. Carefully lift the radiator shroud and the radiator.




335433

46. Move the radiator shroud forward until the radiator is free of the fan blades. Lift the radiator shroud and remove the radiator shroud from the machine.



335435


47. Close the shutoff valve in the fuel return line and the fuel supply line.



335816


1. Shutoff Valve (Fuel Return Line)
2. Shutoff Valve (Fuel Supply Line)

48. Disconnect the fuel line from the transfer pump.



335926


49. Remove the retaining clip for the clevis pin that connects the accelerator rod to the fuel injection pump, and remove the clevis pin.



335927

50. Pull out the fuel shutoff control until the fuel shutoff control stops moving.


51. Loosen the set screw that holds the fuel shutoff cable in place at the fuel injection pump. Loosen and remove the cap screws and clamps that fasten the cable to the engine.



335930

1. Set Screw
2. Cap Screws

52. Disconnect the fuel supply tube. Install a plug in the tube and a cap on the fitting.



1. Connector

335637

53. If the machine is a dozer and the engine has a turbocharger:

- a. Loosen the clamp that fastens the air cleaner hose to the turbocharger.
- b. Disconnect the line to the restriction indicator at the air cleaner.
- c. Loosen and remove the self-locking nuts, cap screws, lock washers, and flat washers that hold the air cleaner bracket in place.
- d. Remove the air cleaner and air cleaner hose from the engine.
- e. Remove any sealant from the inlet of the turbocharger.
- f. Cover or close the opening at the inlet of the turbocharger.

54. If the machine is a loader and the engine has a turbocharger:


- a. Loosen the clamp that fastens the air cleaner hose to the turbocharger.
- b. Remove the air cleaner hose from the turbocharger.
- c. Disconnect the line to the restriction indicator at the air cleaner.
- d. Loosen and remove the cap screws, lock washers, and flat washers that hold the air cleaner bracket in place.
- e. Remove the air cleaner from the engine.

f. Remove any sealant from the inlet of the turbocharger.

g. Cover or close the opening at the inlet of the turbocharger.


55. If the engine does not have a turbocharger:

a. Loosen the clamp that fastens the air cleaner hose to the intake manifold.




335931

b. Remove the air cleaner hose.




335933

c. Remove any sealant from the intake manifold, and cover or close the opening in the intake manifold.




335935

- d. If equipped with ether injection, disconnect the line at the front of the intake manifold.




335937

- e. Loosen and remove the cap screws, lock washers, flat washers, and clamp that fastens the ether injection line and air cleaner bracket to the engine.




335939

- f. Remove the air cleaner.



335941


56. Loosen and remove the nut, flat washer, and clamp from the rear valve cover stud. Loosen and remove the sensor for the engine temperature from the water manifold.



335944


1. *Clamp*
2. *Sensor*

57. Disconnect the ground cable from the battery.




836467

58. Disconnect the wire for the horns.




335906

59. Loosen and remove the nut, lock washer, and wire from the BAT terminal of the alternator.




335902

62. Loosen and remove the nut and battery ground cable from the starter.



336020


60. Loosen and remove the cap screw, lock washer, and clamp that fastens the front wiring harness to the engine. Loosen and remove the nut, lock washer, flat washer, and clamp that fastens the front wiring harness to the intake manifold.



1. Clamp

335904


63. Loosen and remove the nut and positive cable from the starter solenoid. Loosen and remove the nut and wire from the starter solenoid.



1. Positive Cable
2. Wire


336023

61. Disconnect the line to the restriction indicator at the intake manifold on engines without a turbo-charger.




335908

64. Loosen and remove the nuts and the wires to the circuit breakers.




336025

65. Loosen and remove the cap screw, lock washer, and clamp that fastens the cables to the bracket for the circuit breakers.




336027

66. Remove the boot and loosen and remove the tachometer cable from the engine.




336028

67. Loosen and remove the nut, lock washer, flat washer, and clamp for the tachometer cable. If equipped with ether injection, remove the temperature switch.



336030


68. Loosen and remove the nut and clamp that fastens the wiring and cables to the rear of the intake manifold.



335631


1. Clamp

69. Remove the spring for the accelerator pedal.



335526


70. Remove the cotter pin and clevis pin that connects the accelerator pedal to the throttle cross shaft. Remove the cotter pin and clevis pin that connects the hand throttle to the throttle cross shaft.



335530


1. Clevis Pin for Accelerator Pedal
2. Clevis Pin for Hand Throttle

71. Loosen and remove the cap screws that hold the floor plates for the accelerator pedal and the brake pedals. Remove the floor plates.




335924

72. Loosen and remove the nuts, lock washers, bolts, spacers, and retainers that hold the throttle cross shaft to the right side of the frame.



335533

73. Loosen and remove the nuts, lock washers, bolts, spacers, and retainers that hold the throttle cross shaft to the left side of the frame.




335629

74. Remove the throttle cross shaft.

75. Drain the oil from the transmission.


- a. The transmission holds approximately 14 U.S. gallons (53 litres) of oil.
- b. Put a container under the drain plug.
- c. Remove the drain plug.

76. Disconnect the hose from the top of the torque converter housing. Install a cap on the fitting and a plug in the hose.




335634

77. Disconnect the hose from the fitting below the starter. Install a cap on the fitting and a plug in the hose.




335633

78. Loosen the hose clamp on the hose for the tube to the transmission.




335639

79. Loosen and remove the hose fitting from the transmission. Install a plug in the transmission and a cap on the hose fitting.



335644

80. Loosen the hose clamp on the hose for the tube to the torque converter. Loosen and remove the hose fitting from the torque converter and remove the tube. Install a plug in the torque converter and a cap on the hose fitting.




335642

81. If the machine is a dozer:


- a. Loosen and remove the nuts that fasten the drive shaft guards to the transmission.
- b. Remove the drive shaft guards.

82. Loosen and remove the cap screws that hold the drive shaft to the torque converter.




335603

83. Loosen and remove the cap screws that hold the drive shaft to the transmission.




335609

84. Remove the drive shaft.




335813

85. Loosen and remove the nut that holds the sensor for the torque converter temperature gauge and remove the sensor.




335613

86. Disconnect the tube from the tee fitting in the torque converter. Install a plug in the tube and a cap on the tee fitting.




335614

87. Disconnect the hose at the bottom of the torque converter housing.




335734

88. Loosen and remove the self-locking nuts and flat washers at the bottom of the equipment pump. Loosen the self-locking nuts at the top of the equipment pump. Use a prybar to pull the equipment pump away from the torque converter and remove the self-locking nuts and flat washers.



335737

89. Loosen and remove the cap screws and lock washers that hold the charging pump. Pull the charging pump away from the torque converter.




335730

90. If the machine has air conditioning:


- a. Loosen and remove the self-locking nut, bolt, and flat washer that hold the air conditioning compressor to the adjusting bracket.
- b. Loosen and remove the self-locking nut and bolt that hold the air conditioning compressor to the mounting bracket.
- c. Remove the belt from the clutch of the air conditioning compressor.
- d. Disconnect the wire for the clutch from the wiring harness.
- e. Put the air conditioning compressor out of the way.

91. Install the lifting fixture on the engine.




336033

92. Loosen and remove the self-locking nut, bolt, and flat washer for the front motor mount.




336035

93. Loosen and remove the self-locking nut, flat washers, bolt, and insulator for the right motor mount.




335740

94. Loosen and remove the self-locking nut, flat washers, bolt, and insulator for the left motor mount.




335739

95. Connect acceptable lifting equipment to the lifting fixture.




336228

96. Carefully lift the engine and pull the engine forward. Make sure that the equipment pump and the charging pump are free of the torque converter.




336039

97. Lift the engine above the frame and carefully remove the engine.



336041



1. Front Engine Mount
2. Insulator

3. Spacer
4. Flat Washer


5. Self-Locking Nut

840102

TORQUE CONVERTER


Removal

1. Remove the old gaskets for the equipment pump and the charging pump from the torque converter. If necessary, remove the old gaskets from the equipment pump and the charging pump.



336042


2. Loosen and remove the cap screws and lock washers that hold the clamp for the fuel line and the cover to the top of the flywheel housing.



336136

3. Move the fuel line out of the way, and remove the cover.

4. Loosen and remove the two cap screws and special washers at the top of the opening.




336137

5. Turn the crankshaft to move two more cap screws to the top of the opening.


6. Repeat steps 4 and 5 until all of the cap screws have been removed.

7. Loosen and remove all but the top two cap screws and lock washers that hold the torque converter in place.



336140

8. Attach acceptable lifting equipment to the torque converter. Loosen and remove the two top cap screws and lock washers. Install cap screws in the threaded holes in both sides of the torque converter. Turn the cap screws into the threaded holes to pull the torque converter away from the flywheel housing. Carefully remove the torque converter.




1. Cap Screw

336142


9. If the flex plates need to be replaced:

- a. Make an identification mark on the outside flex plate. Use tape, paint, etc. This is necessary for the correct installation of the flex plates.




915823

- b. Loosen and remove the cap screws that hold the flex plates in place.




915824

- c. Remove the reinforcement ring.




915825

- d. Remove the flex plates.



915826


- e. Remove the shims.



915827

10. If the flex plates were replaced:

- a. Put the same number of shims on the hub as were removed during disassembly.



915827




Suggest:

If the above button click is invalid.

Please download this document first, and then click the above link to download the complete manual.


Thank you so much for reading

- b. Align a new flex plate with the flex plate that has the mark. Make a mark on the same side of the new flex plate. Align the remainder of the new flex plates with the flex plate that has the mark.




- c. Install the flex plates so that the flex plate that has the mark is on the outside.


- d. Put the reinforcement ring on the hub.



- e. Install the cap screws that fasten the flex plates to the hub.




- f. Use a punch to align the flex plates and tighten the cap screws.



- g. Tighten the cap screws that fasten the flex plates to the hub to 108 to 118 pound-feet (146 to 160 N m, 14.9 to 16.3 kg/m).

- h. Measure the distance from the front of the mounting flange of the torque converter to the front of the flex plates. This distance must be $2.180 \pm .020$ inch (71.4 ± 0.5 mm). If the distance is not as specified, add or remove shims as required.



1. $2.810 \pm .020$ INCHES
(71.4 ± 0.5 mm)
2. TORQUE CONVERTER HOUSING
3. TORQUE CONVERTER
4. SHIM(S)
5. FLEX PLATES

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>