

I 650L Crawler Dozer

SERVICE MANUAL

Part number 47998877B

3rd edition English

June 2018

© 2018 CNH Industrial Latin America LTDA. All Rights Reserved.



Link Product / Engine

Product	Market Product	Engine
1650L XLT, com cabine, Tier 3, lâmina Power Angle Tilt (PAT), feito no Brasil	Latin America	F4HE9684U*J101

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.400] Engine cooling system	10.2
[10.310] Aftercooler.....	10.3
[10.304] Engine lubrication system.....	10.4
Rear axle system.....	27
[27.120] Planetary and final drives	27.1
[27.126] Spur gear and final drives.....	27.2
Hydrostatic drive.....	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.202] Hydrostatic transmission	29.2
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.104] Fixed displacement pump.....	35.2
[35.310] Distributor and lines	35.3
[35.350] Safety and main relief valves	35.4
[35.741] Dozer blade cylinders	35.5
[35.742] Ripper hydraulic system.....	35.6
Tracks and track suspension.....	48
[48.130] Track frame and driving wheels.....	48.1
[48.110] Front suspension	48.2
[48.100] Tracks	48.3
[48.134] Track tension units	48.4

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

[48.138] Track rollers	48.5
Cab climate control	50
[50.100] Heating	50.1
[50.200] Air conditioning	50.2
Electrical systems	55
[55.013] Engine oil system	55.1
[55.000] Electrical system	55.2
[55.100] Harnesses and connectors.....	55.3
[55.525] Cab engine controls	55.4
[55.015] Engine control system.....	55.5
[55.201] Engine starting system	55.6
[55.301] Alternator.....	55.7
[55.302] Battery.....	55.8
[55.202] Cold start aid	55.9
[55.010] Fuel injection system	55.10
[55.012] Engine cooling system	55.11
[55.019] Hydrostatic drive control system	55.12
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system.....	55.13
[55.408] Warning indicators, alarms, and instruments	55.14
[55.101] Chassis harness	55.15
[55.014] Engine intake and exhaust system.....	55.16
[55.DTC] FAULT CODES.....	55.17
Dozer blade and arm.....	86
[86.110] Dozer blade	86.1
Tools	89
[89.128] Ripper assembly	89.1
Platform, cab, bodywork, and decals	90
[90.150] Cab.....	90.1

[90.114] Operator protections	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3



INTRODUCTION

Foreword - Important notice regarding equipment servicing

1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil	LA
--	----

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CASE CONSTRUCTION Sales and Service Networks.

Foreword - How to use and navigate through this manual

1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil	LA
--	----

This manual has been produced by a new technical information system. This new system is designed to deliver technical information electronically through web delivery (eTIM), DVD, and paper manuals. A coding system called SAP has been developed to link the technical information to other Product Support functions, e.g., Warranty.

Technical information is written to support the maintenance and service of the functions or systems on a customer's machine. When a customer has a concern on their machine it is usually because a function or system on their machine is not working at all, is not working efficiently, or is not responding correctly to their commands. When you refer to the technical information in this manual to resolve that customer's concern, you will find all the information classified using the SAP coding, according to the functions or systems on that machine. Once you have located the technical information for that function or system, you will then find all the mechanical, electrical or hydraulic devices, components, assemblies, and sub assemblies for that function or system. You will also find all the types of information that have been written for that function or system: the technical data (specifications), the functional data (how it works), the diagnostic data (fault codes and troubleshooting), and the service data (remove, install adjust, etc.).

By integrating SAP coding into technical information, you will be able to search and retrieve just the right piece of technical information you need to resolve that customer's concern on his machine. This is made possible by attaching 3 categories to each piece of technical information during the authoring process.

The first category is the Location, the second category is the Information Type and the third category is the Product:

- **LOCATION** - the component or function on the machine, that the piece of technical information is going to describe (e.g., Fuel tank).
- **INFORMATION TYPE** - the piece of technical information that has been written for a particular component or function on the machine (e.g., Capacity would be a type of Technical Data describing the amount of fuel held by the fuel tank).
- **PRODUCT** - the model for which the piece of technical information is written.

Every piece of technical information will have those three categories attached to it. You will be able to use any combination of those categories to find the right piece of technical information you need to resolve that customer's concern on their machine.

That information could be:

- the procedure for how to remove the cylinder head
- a table of specifications for a hydraulic pump
- a fault code
- a troubleshooting table
- a special tool

Safety rules

1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil	APAC
1650L	LA

Ecology and environment

Soil, air and water are vital factors of life in general. Disposing of waste improperly represents a danger for the environment.

NOTE: Some recommendations must be followed:

- Obtain information about the correct methods to recycle or dispose of waste from local authorities, collection centers or your dealer.
- Do not dispose of waste onto the ground, into drains, or in water beds.
- Do not fill reservoirs using cans or inappropriate pressurized fluid delivery systems, as they may cause considerable spillage.
- Use sealed containers when draining the fluids. Do not use containers for food or beverages which may induce ingestion.
- The air conditioning system is under pressure, and contains gases that should not be released into the atmosphere. Do not disconnect or remove any component from the pressure line of the air conditioning system. If you need repairs to the air conditioning system, contact a dealer.
- Immediately repair any leaks or defects in the machine's engine cooling and hydraulic systems.
- Generally avoid skin contact with any fuels, oils, fluids, acids, solvents, etc. Most of them contain substances which may be harmful to your health.
- Avoid spills when draining fluid. Store them safely until they can be disposed of properly in compliance with local legislation.
- Protect hoses and pipes during welding works, because the sparks generated during the welding work can damage them, allowing the fluid to leak.

Mandatory recycling

The battery is essentially composed of lead plates and sulfuric acid solution. Because the battery contains heavy metals such as lead, resolution 401 de 2008 of CONAMA orders that all used batteries must be returned to the battery dealer at the time of replacement. Do not dispose of the battery in the garbage. Points of sale are obliged to accept the return of your used battery, and to store it in a suitable place and return it to the manufacturer for recycling.

Improper disposal of batteries can contaminate the soil, groundwater and waterways. Consumption of contaminated water can cause serious health risks. Contact of the acid solution with the skin or eyes can cause serious injury and blindness. In case of accidental contact with the eyes or skin, immediately wash with running water and seek emergency medical care.



CUIL13TRO0091AA 1

Safety rules (Signal word definitions)

1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil	APAC --- LA
--	-------------

Personal Safety



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual and on machine safety signs, you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for your personal safety and for all those involved in the work activity during operation of the machine.

Read and understand all the safety messages in this manual before you operate or service the machine.

DANGER:

 Indicates an immediate danger that, if not avoided, will cause death or serious injury. The color associated with Danger is RED.

WARNING:

 Indicates a potential danger that, if not avoided, will cause serious injury. The color associated with Warning is ORANGE.

CAUTION:

 Indicates a potential danger that, if not avoided, can cause minor or moderate injury. ORANGE also alerts the operator to unsafe practices. The color associated with Caution is YELLOW.

FAILURE TO FOLLOW DANGER, WARNING AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.

Machine safety

NOTICE: Indicates a situation that, if not avoided, could result in machine or property damage. The color associated with Notice is BLUE.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

Information

NOTE: Indicates additional information which clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word NOTE followed by additional information about a step, procedure or other information in the manual. The word NOTE is not intended to address personal safety or property damage.

Safety rules

1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil	APAC --- LA
--	-------------

Standard safety precautions

Be informed and notify personnel of the laws in force regulating safety, and provide documentation available for consultation.

- Keep working areas as clean as possible.
- Ensure that working areas are provided with emergency boxes. They must be clearly visible and always contain adequate sanitary equipment.
- Fire extinguishers must be properly identified and always be clear of obstructions. Their efficiency must be checked on a regular basis and personnel must be trained on proper interventions and priorities.
- Keep all emergency exits free of obstructions and clearly marked.
- Smoking in working areas subject to fire danger must be strictly prohibited.

Prevention of injury

- Wear suitable work attire and safety glasses with no jewelry such as rings and chains when working close to engines and equipment in motion.
- Wear safety gloves and goggles when performing the following operations:
 - Topping off or changing lubrication oils.
 - Using compressed air or liquids at a pressure greater than **2 bar (29 psi)**.
- Wear a safety helmet when working close to hanging loads or equipment working at head level.
- Always wear safety shoes and fitting clothes.
- Use protection cream for hands.
- Change wet clothes as soon as possible.
- In the presence of voltages exceeding **48 – 60 V**, verify the efficiency of the ground and mass electrical connections. Ensure that hands and feet are dry and use isolating foot boards. Workers should be properly trained to work with electricity.
- Do not smoke or start an open flame close to batteries and any fuel material.
- Place soiled rags with oil, diesel fuel or solvents in specially provided anti-fire containers.
- Do not use any tool or equipment for any use other than what it was originally intended for. Serious injury may occur.
- If running an engine indoors, make sure there is a sufficient exhaust fan in use to eliminate exhaust fumes.

During maintenance

- Never open the filler cap of the cooling system when the engine is hot. High temperature liquid at operating pressure could result in serious danger and risk of burn. Wait until the temperature decreases under **50 °C (122 °F)**.
- Never add coolant to an overheated engine and use only appropriate liquids.
- Always work when the engine is turned off. Certain circumstances require maintenance on a running engine. Be aware of all the risks involved with such an operation.
- Always use adequate and safe containers for engine fluids and used oil.
- Keep engine clean of any spilled fluids such as oil, diesel fuel, and or chemical solvents.
- Use of solvents or detergents during maintenance may emit toxic vapors. Always keep working areas aerated. Wear a safety mask if necessary.
- Do not leave soiled rags that may contain any flammable substances close to the engine.
- Always use caution when starting an engine after any work has been performed. Be prepared to cut off intake air in case of engine runaway.
- Never disconnect the batteries while the engine is running.

- Disconnect the batteries prior to performing any work on the equipment.
- Disconnect the batteries to place a load on them with a load tester.
- After any work is performed, verify that the battery clamp polarity is correct and that the clamps are tight and safe from accidental short circuit and oxidation.
- Before disconnecting any pipelines (pneumatic, hydraulic, fuel pipes, etc.), verify that all pressure has been released. Take all necessary precautions bleeding and draining residual pressure. Always wear the proper safety equipment.
- Do not alter the lengths of any wires.
- Do not connect any electronic service tool to the engine electrical equipment unless specifically approved by CASE CONSTRUCTION.
- Do not modify the fuel system or hydraulic system unless approved by CASE CONSTRUCTION. Any unauthorized modification will compromise warranty assistance and may affect engine operation and life span.

For engine equipped with an electronic control unit


- Do not weld on any part of the equipment without removing the control unit.
- Remove the in case of work requiring heating over **80 °C (176 °F)**.
- Do not paint the components and the electronic connections.
- Do not alter any data filed in the electronic control unit driving the engine. Any manipulation or alteration of electronic components will void engine warranty assistance and may affect the correct working order and life span of the engine.

Respect of the Environment

- Respect of the environment should be of primary importance. Take all necessary precautions to ensure personnel's safety and health.
- Inform the personnel of the laws regarding the dispensing of used engine fluids.
- Handle batteries with care, storing them in a well ventilated environment and within anti-acid container.


Product overview - (Machine Components)

1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil | APAC --- LA



BRCE12DOCNH0004 1

- (1) Cab
- (2) Right rear access door
- (3) Travel reducer
- (4) Track
- (5) Top track roller
- (6) Lower track roller
- (7) Track tensioner wheel
- (8) Right-hand access door to the engine compartment and side shield panel
- (9) Blade
- (10) Radiator compartment door
- (11) Front handholds



BRCE12DOCNH0005 2

- (1) Left-hand access door to the engine compartment and side shield panel
- (2) Blade tilt link
- (3) Front step
- (4) Hand holds
- (5) Left rear access door
- (6) Fuel reservoir



SERVICE MANUAL

Engine


1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil

Engine - Remove

1650L XLT, With cab, Tier 3, Power Angle Tilt (PAT) Blade , Made in Brazil LA


NOTE: If the machine is equipped with a brush shield, continue to item 1. Otherwise, go to item 2.

1. Attach appropriate lifting equipment to the brush shield. Remove the two lower bolts and jam nuts. Remove the two upper bolts and washers that secure the upper brush shield. Remove the brush shield.
2. Open the engine side panels. Disconnect the hose from the coolant reservoir. Remove the engine side panels.
3. Make sure that the engine is cold. Slowly remove the radiator cap. Connect a hose to the drain valve. Drain the contents of the radiator into a suitable container.
4. Place a label on the wires. Disconnect the wires from the air filter restriction switch.




LAIL11CD0252A0A 1

5. Remove the after cooler line.




LAIL11CD0253A0A 2

6. Remove the air filter hose. Disconnect the crankcase ventilation hose.




LAIL11CD0254A0A 3

7. Remove the after cooler line.




LAIL11CD0255A0A 4

8. Remove the two plugs. Remove the front mounting bolts from the hood.




LAIL11CD0256A0A 5

9. Remove the two plugs. Remove the rear mounting bolts from the hood.
10. Connect the lifting equipment to the hood. Remove the hood from the machine.




LAIL11CD0257A0A 6

11. Remove the upper radiator hose.



LAIL11CD0258A0A 7

12. Disconnect the lower radiator hose.




LAIL11CD0259A0A 8

13. Remove the fan and the spacer from the engine.


(1) Spacer

(2) Fan mounting bolts (4)




LAIL11CD0369B0A 9

14. Tilt the cab or ROPS canopy. See **Roll Over Protective Structure (ROPS) frame - Tilt (90.114)**.
15. If the machine is equipped with a heater, loosen the fixing clamp. Connect the heater hose.




LAIL11CD0260A0A 10

16. Disconnect the alternator wires.




LAIL11CD0261A0A 11

17. Disconnect the battery cable and the electrical harness wires from the starter motor.




LAIL11CD0262A0A 12

18. Discharge the air-conditioning system, if the machine has one. See **Air conditioning - Charging (50.200)**. Disconnect the clutch electrical connector and the compressor hoses. Plug the hoses and cap the fittings.




LAIL11CD0263A0A 13

19. Disconnect the electrical connector from the engine controller.



LAIL11CD0264A0A 14

20. Connect a vacuum pump to the fuel tank. Turn on the pump. Disconnect the fuel lines. Cap the lines and fittings. Shut down the vacuum pump.



LAIL11CD0265A0A 15

21. Disconnect the ground cable from the drum.
22. Connect lifting equipment to the engine.
23. Remove the engine mounting bolts.
24. List the engine slightly. Move the engine forward. Slide the drive shaft out of the hydro pumps.
25. Remove the engine from the machine.


Engine - Disassemble

1650L

LA

Reconditioning the engine on the workbench


1. Remove the drain plug from the crankcase to drain the engine oil.
2. Use the supports to secure the engine to the trestle as follows (work from the left-hand side of the engine).
 - Use a suitable tool to remove the fuel filter (5) from its bracket (1).
 - Disconnect the low pressure lines (2), (3), and (4) from the fuel filter bracket (1).
 - Remove the fuel filter bracket (1) from the engine block.



LAIL11CD1407A0A 1

3.


NOTICE: Push the clamp (1), as shown in Fig. 2, to disconnect the low pressure fuel lines (2), (3), and (4) from the corresponding fittings. After you disconnect the lines, put the clamp (1) back in the position shown in Fig. 2 to prevent the deformation of the clamp.



LAIL11CD1408A0A 2


4. Disconnect the fuel line (1) from the "common rail" and from the high pressure pump (5). Remove the mounting bolts (2) to remove the fuel line.

NOTICE: When you loosen the fitting (3) of the fuel line (1), use an appropriate wrench so that the fitting (4) of the high pressure pump (5) does not turn.




LAIL11CD1409A0A 3

5. From the Right-hand Side:
Remove the mounting bolts (2) and the oil lines (3) from the Turbocharger (1) of the engine block.
Remove the starter (5) from the engine flywheel housing (4).
Secure the engine to an engine support.



LAIL11CD1410A0A 4



LAIL11CD1463F0A 5


- | | |
|---------------------------------------|-----------------------------------|
| 1. Injector fittings | 7. Pressure/temperature sensor |
| 2. Engine coolant temp sensor | 8. Camshaft sensor |
| 3. "Common rail" fuel pressure sensor | 9. Fuel heater temperature sensor |
| 4. Oil pressure-temperature sensor | 10. High pressure regulator |
| 5. Crankshaft rotation sensor | 11. Control unit EDC7UC31 |
| 6. Injector | |

6. Disconnect the battery cable. Disconnect the following connectors:

- Connectors (1) of the injector wiring (6).
- Engine coolant temperature sensor on the thermostat (2).
- "Common rail" fuel pressure sensor (3).
- Crankshaft rotation sensor (5).
- Temperature/pressure sensor (7).
- Camshaft sensor (8).
- High pressure regulator (10).
- Control unit EDC7UC31 (11).


7. Disconnect the "common rail" (2):

- Fuel line (4) according to the procedure in Step 3.
- Fuel lines (5).
- Injector manifolds (3).
- Remove the bolts (1). Disconnect the "common rail" (2).



LAIL11CD1411A0A 6


8. Disconnect the line (2) from the fuel return pressure limiter (1), as shown in Step 3. Remove the nut. Loosen the retaining collar. Disconnect the oil steam line (5). Remove the bolts (3). Remove the "blow-by" filter (4).



LAIL11CD1412A0A 7


9. Remove the nuts and the cover of the valve tappets, including the gasket. Remove the bolts (1). Disconnect the wiring housing of the injectors (2), along with the gasket. Remove the bolts (5). Shut down the pressure/temperature sensor (6). Remove the nuts (3). Remove the fuel inlet connectors (4).

NOTICE: The fuel inlet connectors (4) should not be re-used. The fuel inlet connectors should be replaced with new fuel inlet connectors.




LAIL11CD1413A0A 8

10. Loosen the adjustment nuts of the valve tappets **(1)**. Unscrew the adjusters. Remove the bolts **(2)**. Remove the rocker arm assembly **(3)**, which consists of the support **(6)**, the rocker arms **(4)**, and the shafts **(5)**. Remove the valve bridges **(7)**. Remove the rods **(8)**.




LAIL11CD1414A0A 9

11. Remove the injector mounting bolts. Use the Special Tool **380001099 (1)** to remove the injectors **(2)** from the poppet.




LAIL11CD1415A0A 10

12. If equipped, remove the deflector **(5)** from the turbocharger **(1)**. Disconnect the oil line **(3)** from the oil filter support of the heat exchanger. Remove the nuts **(2)**. Separate the turbocharger **(1)** from the exhaust manifold **(4)**.




LAIL11CD1416A0A 11

13. Remove the mounting bolts **(1)**. Remove the exhaust manifold in two sections **(2)** and **(3)** with the respective seals.




LAIL11CD1417A0A 12

14. Remove the bolts (1). Disconnect the intake manifold and the air deflector from the heater (2). Remove the bolts (4). Remove the thermostat housing (3). Remove the thermostat under the housing. Remove the mounting bolts (5) from the poppet (6).




LAIL11CD1418A0A 13

15. Install supports (1) on the poppet. Use a hoist to remove the poppet from the cylinder block.




LAIL11CD1419A0A 14

16. Remove the head gasket (1).




LAIL11CD1420A0A 15

17. Loosen the drive belt tensioner (2). Remove the drive belt (3) from the pulleys. Then remove the belt tensioner (2). Remove the bolts that secure the alternator to the bracket. Remove the alternator (1).




LAIL11CD1421A0A 16

18. Remove the bolts and the oil pressure/temperature sensor (2).
Remove the bolts. Then remove the heat exchanger support/oil filter (1), the intermediate plate (4), and the respective gaskets.
Remove the oil level sensor (3).




LAIL11CD1422A0A 17

19. Remove the bolts. Disconnect the control unit EDC7UC31 (1), including the heat exchanger.




LAIL11CD1423A0A 18

20. Remove the nut. Disconnect the timing sensor (1).
Remove the nuts. Disconnect the high pump (3), including the supply pump (2).



LAIL11CD1424A0A 19

21. Loosen the bolts from the engine flywheel (1). Do not remove the engine flywheel.



LAIL11CD1425A0A 20




Suggest:

If the above button click is invalid.

Please download this document first, and then click the above link to download the complete manual.


Thank you so much for reading

22. Remove the bolts (3), the flywheel vibration damper (2), and the pulley (1).




LAIL11CD1426A0A 21

23. Remove the bolts. Disconnect the water pump (1). Remove the bolt. Disconnect the engine rotation sensor (2).




LAIL11CD1427A0A 22

24. Install the special tool **380000665** (4) on the crankshaft (2).
Work through the guide holes of the Special Tool **380000665** (4) to drill the inner seal ring (1) with a **3.5 mm (0.14 in)** bit (A) to a depth of **5 mm (0.20 in)** (B).
Bolt the six bolts supplied with the tool to the front cover of the crankshaft to secure the Special Tool **380000665** (4) to the ring (1).
Now tighten the bolt (3) to extract the seal ring (1).



LAIL11CD1428A0A 23

25. Use the pry bar (3) and the lever (4) to remove the outer seal ring (2) from the front cover (1).



LAIL11CD1429A0A 24

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>