

---

# **FARMALL 65C, FARMALL 75C, FARMALL 85C, FARMALL 95C REPAIR MANUAL COMPLETE CONTENTS**

|                                                              |           |
|--------------------------------------------------------------|-----------|
| <b>SECTION 00 - GENERAL .....</b>                            | <b>2</b>  |
| <b>SECTION 10 - ENGINE .....</b>                             | <b>2</b>  |
| <b>SECTION 18 - CLUTCH .....</b>                             | <b>7</b>  |
| <b>SECTION 21 - GEAR TRANSMISSION .....</b>                  | <b>8</b>  |
| <b>SECTION 23 - DRIVE LINES .....</b>                        | <b>11</b> |
| <b>SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION .....</b> | <b>12</b> |
| <b>SECTION 27 - REAR AXLE MECHANICAL TRANSMISSION .....</b>  | <b>14</b> |
| <b>SECTION 31 - MECHANIAL POWER TAKE-OFF .....</b>           | <b>15</b> |
| <b>SECTION 33 - BRAKING SYSTEM .....</b>                     | <b>16</b> |
| <b>SECTION 35 - HYDRAULIC SYSTEMS .....</b>                  | <b>17</b> |
| <b>SECTION 41 - STEERING .....</b>                           | <b>23</b> |
| <b>SECTION 44 - AXLES AND WHEELS .....</b>                   | <b>26</b> |
| <b>SECTION 50 - CAB AIR CONDITIONING SYSTEM .....</b>        | <b>27</b> |
| <b>SECTION 55 - ELECTRICAL SYSTEM .....</b>                  | <b>29</b> |
| <b>SECTION 90 - PLATFORM, CAB, BODYWORK .....</b>            | <b>50</b> |

The following pages are the collation of the contents pages from each section and chapter of the Farmall 65C, Farmall 75C, Farmall 85C, Farmall 95C Repair manual. Complete Repair part # 87758598.

The sections used through out all Case IH product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the Farmall 65C, Farmall 75C, Farmall 85C, Farmall 95C Tractors.

**SECTION 00 - GENERAL****Chapter 1 - General****CONTENTS**

| <b>Section</b> | <b>Description</b>                                   | <b>Page</b> |
|----------------|------------------------------------------------------|-------------|
|                | General Instructions .....                           | 3           |
|                | Health and Safety .....                              | 5           |
|                | Precautionary Statements .....                       | 15          |
|                | Safety .....                                         | 16          |
|                | Ecology and the Environment .....                    | 19          |
|                | Minimum Hardware Tightening Torques .....            | 20          |
|                | Federal Emissions Warranty .....                     | 22          |
|                | California Emission Control Warranty Statement ..... | 23          |
|                | Consumables .....                                    | 25          |

---

**⚠ WARNING ⚠**

---

All maintenance and repair work described in this manual must be performed exclusively by CASE IH service technicians in strict accordance with the instructions given and using any specific tools necessary.

---

---

**⚠ WARNING ⚠**

---

Anyone who performs the operations described herein without strictly following the instructions is personally responsible for resulting injury or damage to property.

---

---

**⚠ WARNING ⚠**

---

The Manufacturer and all organizations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer. In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.

---

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

## GENERAL INSTRUCTIONS

### IMPORTANT NOTICE

All maintenance and repair operations described in this manual should be carried out exclusively by the authorized workshops. All instructions detailed should be carefully observed and special equipment indicated should be used if necessary.

Everyone who carries out service operations described without carefully observing these directives will be directly responsible for resulting consequences.

### SHIMMING

At each adjustment, select adjusting shims, measure them individually using a micrometer and then sum up recorded values. Do not rely on measuring the whole shimming set, which may be incorrect, or on the rated value indicated for each shim.

### ROTATING SHAFT SEALS

To correctly install rotating shaft seals, observe the following instructions:

- Let the seal soak into the same oil as it will seal for at least half an hour before mounting;
- Thoroughly clean the shaft and ensure that the shaft working surface is not damaged;
- Place the sealing lip towards the fluid. In case of a hydrodynamic lip, consider the shaft rotation direction and orient grooves in order that they deviate the fluid towards the inner side of the seal;
- Coat the sealing lip with a thin layer of lubricant (oil rather than grease) and fill the gap between the sealing lip and the dust lip of double lip seals with grease;
- Insert the seal into its seat and press it down using a flat punch. Do not tap the seal with a hammer or a drift;

- Take care to insert the seal perpendicular to its seat while you are pressing it. Once the seal is settled, ensure that it contacts the thrust element, if required;
- To prevent damaging the sealing lip against the shaft, place a suitable protection during installation.

### O RINGS

Lubricate the O rings before inserting them into their seats. This will prevent the O rings from roll over and twisting during mounting, which will jeopardize sealing.

### SEALERS

Apply silicone/gasket eliminator over the mating surfaces marked with an X.

Before applying the sealer, prepare the surface as follows:

- remove possible scales using a metal brush;
- thoroughly degrease the surfaces using one of the following cleaning agents: trichlorethylene, diesel fuel or a water and soda solution.

### BEARINGS

It is advisable to heat the bearings to 80° to 90°C (176° to 194°F) before mounting them on their shafts and cool them down before inserting them into their seats with external tapping.

### SPRING PINS

When mounting split socket spring pins, ensure that the pin notch is oriented in the direction of the effort to stress the pin.

Spiral spring pins should not be oriented during installation.

## GENERAL INSTRUCTIONS

### PRECAUTIONARY NOTICE

Only authorized workshops should carry out maintenance and repair operations on the tractor, or tractor components. Carefully observe all instructions, safety precautions, and the use of equipment such as special tools, as detailed in this manual. Damage to the tractor, or injury to personnel is the direct responsibility of anyone who fails to observe these precautions.

### EQUIPMENT NOTICE

The equipment proposed in this manual is:

- Designed and studied expressly for use on Case IH tractors
- Necessary for adequate and reliable repair of the tractor
- Strictly tested for the efficient and long lasting life cycle of the tractor

### SPARE PARTS NOTICE

Genuine CASE IH spare parts guarantee the same quality, safety and life cycle as original components. These parts bear the logo.

### GENERAL NOTICES

In this manual, the description 'FRONT', 'REAR', 'RIGHT-HAND' and 'LEFT-HAND' refer to the view seen by the operator while in the operator's seat, looking in the direction in which the tractor normally moves.

Wear limits detailed in this manual, although advised, are not binding.

**HEALTH AND SAFETY****CONTENTS**

| <b>Description</b>                                                                | <b>Page</b> |
|-----------------------------------------------------------------------------------|-------------|
| HEALTH AND SAFETY PRECAUTIONS .....                                               | 5           |
| ACIDS AND ALKALIS .....                                                           | 6           |
| ADHESIVES AND SEALERS - see Fire .....                                            | 6           |
| ANTIFREEZE - see Fire, Solvents e.g. Isopropanol, Ethylene Glycol, Methanol. .... | 6           |
| ARC WELDING - see Welding. ....                                                   | 7           |
| BATTERY ACIDS - see Acids and Alkalis. ....                                       | 7           |
| BRAKE AND CLUTCH FLUIDS (Polyalkylene Glycols) - see Fire. ....                   | 7           |
| BRAZING - see Welding. ....                                                       | 7           |
| CHEMICAL MATERIALS - GENERAL - see Legal Aspects. ....                            | 7           |
| DO'S .....                                                                        | 7           |
| DO NOTS .....                                                                     | 8           |
| CORROSION PROTECTION MATERIALS - see Solvents, Fire. ....                         | 8           |
| DUSTS .....                                                                       | 8           |
| ELECTRIC SHOCK .....                                                              | 8           |
| EXHAUST FUMES .....                                                               | 9           |
| FIBER INSULATION - see Dusts. ....                                                | 9           |
| FIRE - see Welding, Foams, Legal Aspects. ....                                    | 9           |
| FIRST AID .....                                                                   | 9           |
| FOAMS - Polyurethane - see Fire. ....                                             | 9           |
| FUELS - see Fire, Legal Aspects, Chemicals - General, Solvents. ....              | 10          |
| GAS CYLINDERS - see Fire. ....                                                    | 10          |
| GENERAL WORKSHOP TOOLS AND EQUIPMENT .....                                        | 11          |
| LEGAL ASPECTS .....                                                               | 11          |
| LUBRICANTS AND GREASES .....                                                      | 11          |
| PAINTS - see Solvents and Chemical Materials - General. ....                      | 12          |
| SOLDER - see Welding. ....                                                        | 12          |
| SOLVENTS - see Chemical Materials - General Fuels (Kerosene), Fire. ....          | 13          |
| SUSPENDED LOADS .....                                                             | 13          |
| WELDING - see Fire, Electric Shock, Gas Cylinders. ....                           | 13          |

**HEALTH AND SAFETY PRECAUTIONS**

Many of the procedures associated with vehicle maintenance and repair involve physical hazards or other risks to health. This section lists, alphabetically, some of these hazardous operations and the materials and equipment associated with them. The

precautions necessary to avoid these hazards are identified.

The list is not exhaustive and all operations and procedures and the handling of materials, should be carried out with health and safety in mind.

**ACIDS AND ALKALIS** - see Battery acids, e.g. caustic soda, sulfuric acid.

Used in batteries and cleaning materials.

Irritant to the skin, eyes, nose and throat. Causes burns.

Avoid splashes to the skin, eyes and clothing. Wear suitable protective gloves and goggles. Can destroy ordinary protective clothing. Do not breathe mists.

Ensure access to water and soap is readily available for splashing accidents.

**ADHESIVES AND SEALERS** - see Fire

Highly Flammable and combustible.

Generally should be stored in "No Smoking" areas; cleanliness and tidiness in use should be observed, e.g. disposable paper covering benches; should be dispensed from applicators where possible; containers, including secondary containers, should be labelled.

**Solvent based Adhesives/Sealers** - See Solvents.

Follow manufacturers instructions.

**Water based Adhesives/Sealers**

Those based on polymer emulsions and rubber lattices may contain small amounts of volatile toxic and harmful chemicals. Skin and eye contact should be avoided and adequate ventilation provided during use.

Follow manufacturers instructions.

**Resin based Adhesives/Sealers** - e.g. epoxide and formaldehyde resin based.

Mixing should only be carried out in well ventilated areas as harmful or toxic volatile chemicals may be released.

Skin contact with uncured resins and hardeners can result in irritation; dermatitis and absorption of toxic or harmful chemicals through the skin. Splashes can damage the eyes.

Provide adequate ventilation and avoid skin and eye contact. Follow manufacturers instructions.

**Anaerobic, Cyanoacrylate and other Acrylic Adhesives**

Many are irritant, sensitizing or harmful to the skin. Some are eye irritants.

Skin and eye contact should be avoided and the manufacturers instructions followed.

Cyanoacrylate adhesives (super-glues) must not contact the skin or eyes. If skin or eye tissue is bonded cover with a clean moist pad and get medical attention. do not attempt to pull tissue apart. Use in well ventilated areas as vapors can cause irritation of the nose and eyes.

For two-pack systems see Resin based adhesives/sealers.

**Isocyanate (Polyurethane) Adhesives/Sealers** - see Resin based Adhesives.

Individuals suffering from asthma or respiratory allergies should not work with or near these materials as sensitivity reactions can occur.

Any spraying should preferably be carried out in exhaust ventilated booths removing vapors and spray droplets from the breathing zone. Individuals working with spray applications should wear supplied air respirators.

**ANTIFREEZE** - see Fire, Solvents e.g. Isopropanol, Ethylene Glycol, Methanol.

Highly Flammable and Combustible.

Used in vehicle coolant systems, brake air pressure systems, screenwash solutions.

Vapors given off from coolant antifreeze (glycol) arise only when heated.

Antifreeze may be absorbed through the skin in toxic or harmful quantities. Antifreeze if swallowed is fatal and medical attention must be found immediately.

## SECTION 10 - ENGINE

### Chapter 1 - Engine

#### CONTENT

| Section   | Description                                                               | Page |
|-----------|---------------------------------------------------------------------------|------|
|           | Specifications .....                                                      | 4    |
|           | Torque .....                                                              | 12   |
|           | Special Tools .....                                                       | 14   |
|           | Sectional Views .....                                                     | 15   |
|           | Description and Operation .....                                           | 19   |
|           | Exhaust Gas Recirculation System (EGR) .....                              | 19   |
|           | Troubleshooting .....                                                     | 20   |
|           | Overhaul .....                                                            | 24   |
| 10 001 10 | Engine .....                                                              | 24   |
|           | Removal .....                                                             | 24   |
|           | Installation .....                                                        | 32   |
| 10 001 54 | Engine Disassembly .....                                                  | 34   |
|           | Removing the Crankshaft Front Seal .....                                  | 36   |
|           | Removing the Crankshaft Rear Seal .....                                   | 39   |
|           | Engine Assembly on the Bench .....                                        | 45   |
|           | Fitting the Bushings .....                                                | 45   |
|           | Fitting the Tappets .....                                                 | 46   |
|           | Fitting the Camshaft .....                                                | 46   |
|           | Fitting the Oil Nozzles .....                                             | 47   |
|           | Fitting the Crankshaft .....                                              | 47   |
|           | Fitting the Connecting Rod-Piston Assembly .....                          | 50   |
|           | Fitting the Piston Connecting Rod Assemblies in the Cylinder Liners ..... | 51   |
|           | Big End Cap Assembly .....                                                | 52   |
|           | Fitting the Thermostat Valve .....                                        | 53   |
|           | Fitting the Cylinder Head .....                                           | 53   |
|           | Fitting the Injectors .....                                               | 55   |
|           | Fitting the Rocker Arm Assembly .....                                     | 55   |
|           | Fitting the Timing Gear .....                                             | 56   |
|           | Fitting the Injection Pump .....                                          | 58   |
|           | Fitting the Additional Counterweights .....                               | 58   |
|           | Fitting the Hydraulic Pump Drive Gear .....                               | 59   |
|           | Fitting the Timing Gear Casing .....                                      | 60   |
|           | Fitting the Crankshaft Rear Seal .....                                    | 60   |

| Section                                | Description                                                                                                 | Page |
|----------------------------------------|-------------------------------------------------------------------------------------------------------------|------|
|                                        | Fitting the Flywheel .....                                                                                  | 60   |
|                                        | Fitting the Oil Pump .....                                                                                  | 61   |
|                                        | Fitting the Oil Sump .....                                                                                  | 62   |
|                                        | Fitting the Crankshaft Front Seal .....                                                                     | 62   |
|                                        | Fitting the Crankshaft Front Pulley .....                                                                   | 62   |
|                                        | Fitting the Cooling System Union .....                                                                      | 62   |
|                                        | Fitting the Coolant Pump .....                                                                              | 63   |
|                                        | Fitting the Fan-Alternator Pulley .....                                                                     | 63   |
|                                        | Fitting the Auxiliary Member Drive Belt .....                                                               | 65   |
|                                        | Fitting the Exhaust Manifold - Turbine .....                                                                | 65   |
|                                        | Fitting the Injector Feed Pipes .....                                                                       | 65   |
|                                        | Fitting the Fuel Pump - Feed Pipes .....                                                                    | 66   |
|                                        | Fitting the Pipes Between the Fuel Supply and Injection Pumps,<br>Pre-Heating System and Tappet Cover ..... | 66   |
|                                        | Fitting the Starter Motor .....                                                                             | 67   |
| Checks, Measurements and Repairs ..... |                                                                                                             | 68   |
|                                        | Crankcase, Cylinder Liners .....                                                                            | 68   |
|                                        | Checks and Measurements .....                                                                               | 68   |
|                                        | Crankshaft .....                                                                                            | 71   |
|                                        | Connecting Rods .....                                                                                       | 73   |
|                                        | Bushings .....                                                                                              | 73   |
|                                        | Checking Connecting Rods .....                                                                              | 74   |
|                                        | Checking Twisting .....                                                                                     | 74   |
|                                        | Checking Bending .....                                                                                      | 74   |
|                                        | Pistons .....                                                                                               | 75   |
|                                        | Measuring the Piston Diameter .....                                                                         | 76   |
|                                        | Piston Pins .....                                                                                           | 76   |
|                                        | Conditions for Correct Pin-piston Coupling .....                                                            | 77   |
|                                        | Piston Rings .....                                                                                          | 77   |
|                                        | Measuring the Clearance X of the V-Ring .....                                                               | 78   |
|                                        | Valves and Camshaft .....                                                                                   | 79   |
|                                        | Dimensions (mm) of Valves and Valve Guides .....                                                            | 79   |
|                                        | Decarbonizing, Checking and Grinding Valves .....                                                           | 79   |
|                                        | Valve Springs .....                                                                                         | 81   |
|                                        | Tappets .....                                                                                               | 81   |
|                                        | Camshaft .....                                                                                              | 82   |
|                                        | Checking Cam Lift and Pin Alignment .....                                                                   | 82   |
|                                        | Cylinder Head .....                                                                                         | 83   |
|                                        | Checking the Cylinder Head Mating Surface .....                                                             | 83   |


| Section   | Description                                            | Page |
|-----------|--------------------------------------------------------|------|
|           | Cylinder Head Thickness .....                          | 83   |
|           | Cylinder Head Hydraulic Seal Check .....               | 83   |
|           | Low Oil Pressure Indicator .....                       | 84   |
|           | Functional Checks .....                                | 84   |
|           | Oil Filter .....                                       | 84   |
|           | Replacement .....                                      | 84   |
|           | Cooling System .....                                   | 85   |
|           | Radiator .....                                         | 85   |
|           | Coolant Thermometer .....                              | 85   |
|           | Thermostat Valve .....                                 | 85   |
| 10 102 70 | Crankshaft Front Seal .....                            | 86   |
|           | Removal .....                                          | 86   |
|           | Installation .....                                     | 87   |
| 10 102 74 | Crankshaft Rear Seal .....                             | 88   |
|           | Removal .....                                          | 88   |
|           | Installation .....                                     | 89   |
| 10 106 12 | Valve/Rocker Arm Clearance .....                       | 91   |
|           | Removal .....                                          | 91   |
|           | Installation .....                                     | 92   |
| 10 218 30 | Injectors .....                                        | 93   |
|           | Removal .....                                          | 93   |
|           | Installation .....                                     | 95   |
| 10 246 14 | Bosch Injection Pump .....                             | 96   |
|           | Removal .....                                          | 96   |
|           | Installation .....                                     | 97   |
|           | Timing .....                                           | 99   |
|           | Fuel Circuit Air Bleeding .....                        | 101  |
| 10 402 10 | Coolant Pump .....                                     | 102  |
|           | Removal .....                                          | 102  |
|           | Installation .....                                     | 103  |
| 10 402 30 | Thermostatic Valve .....                               | 104  |
|           | Removal .....                                          | 104  |
|           | Installation .....                                     | 105  |
| 10 406 10 | Radiator .....                                         | 106  |
|           | Removal .....                                          | 106  |
|           | Installation .....                                     | 109  |
| 10 414 10 | 4-Cylinder Coolant Pump and Generator Drive Belt ..... | 110  |
|           | Tension Adjustment .....                               | 110  |
|           | Polyvee Belt Tensioning Instructions .....             | 110  |

## SPECIFICATIONS

| GENERAL SPECIFICATIONS                            |                                                                     |
|---------------------------------------------------|---------------------------------------------------------------------|
| Engine, technical type:                           |                                                                     |
| - mod. 85C type 44STA/MNG (BOSCH pump) .....      |                                                                     |
| - mod. 95C - type 44STA/MND (BOSCH pump) .....    |                                                                     |
| Cycle .....                                       | diesel, 4-stroke                                                    |
| Fuel injection .....                              | Direct                                                              |
| Number of cylinders in line .....                 | 4                                                                   |
| Piston diameter .....                             | 104 mm (4.09 in.)                                                   |
| Piston stroke .....                               | 132 mm (5.20 in.)                                                   |
| Total displacement .....                          | 4485 cm <sup>3</sup> (274 cu. in.)                                  |
| Compression ratio .....                           | 16.5:1                                                              |
| Maximum Power Output:                             |                                                                     |
| - mod. 85C - type 44STA/MNG .....                 | 63 kW (86 Hp)                                                       |
| - mod. 95C - type 44STA/MND .....                 | 71 kW (97 Hp)                                                       |
| Maximum power speed .....                         | 2300 rpm                                                            |
| - Maximum torque: mod. 85C - type 44STA/MNG ..... | 370 Nm (273 ft-lbs)                                                 |
| - Maximum torque: mod. 95C - type 44STA/MND ..... | 418 Nm (308 ft-lbs)                                                 |
| Maximum torque speed .....                        | 1300 rpm                                                            |
| Number of main bearings .....                     | 5                                                                   |
| Sump pan .....                                    | structural, cast iron                                               |
| <b>Lube</b> .....                                 | forced, with lobe pump                                              |
| Pump drive .....                                  | from crankshaft                                                     |
| Engine speed/oil pump speed ratio .....           | 1:1                                                                 |
| Oil filtration .....                              | mesh screen on oil pick-up and<br>filter cartridge in delivery line |
| Normal oil pressure with motor warmed-up          |                                                                     |
| at slow idling .....                              | 1.2 bar (17.40 psi)                                                 |
| at fast idling .....                              | 3.9 bar (56.56 psi)                                                 |


(continued)

## SECTIONAL VIEWS



MIF1096A


Engine view



### Engine lubrication diagram

Forced-circulation lubrication is accomplished by the following components:

- oil pump, housed at the front of the crankcase, driven by the grooved bushing keyed onto the shank of the crankshaft;
- water / oil cooler, housed in the crankcase;
- oil pressure control valve incorporated in the cooler assembly;
- by-pass valve to cut off clogged oil filter, incorporated in the cooler assembly;
- cartridge oil filter.




3

### Cooling diagram

The forced circulation, closed-circuit engine cooling system is composed of the following components:

- a lubricating oil cooler;
- a centrifugal coolant pump housed at the front of the crankcase;
- a thermostat valve governing coolant circulation.




MIF1102A

4

#### Additional counterweight diagram

- |                     |                  |
|---------------------|------------------|
| 1. Retaining bolts  | 6. Half bearings |
| 2. Support          | 7. Counter-shaft |
| 3. Retaining bolts  | 8. Gear          |
| 4. Gear             | 9. Ring          |
| 5. Balancing weight | 10. O-rings      |



5

**Camshaft view****A.** Inlet valve cam.**B.** Exhaust valve cam.

## DESCRIPTION AND OPERATION

### EXHAUST GAS RECIRCULATION SYSTEM (EGR)

On the TIER 3 version, the exhaust cam profile has been modified to permit partial opening of the related valve during the inlet phase (exhaust gas recirculation EGR) with the consequent re-introduction of some of the exhaust gases into the engine cylinders.

The exhaust gases can be partially redirected into the cylinders in order to reduce the maximum combustion temperature values which are responsible for the production of nitrogen oxide ( $\text{NO}_x$ ).

The exhaust gas recirculation system (EGR), reducing the temperature of combustion by decreasing the concentration of oxygen in the combustion chamber, is therefore an effective system to control emissions of  $\text{NO}_x$ .

The internal EGR system is not provided with any electronically controlled elements: the system is always on.

Its configuration needs no additional elements such as control valves, pipes or heat exchangers.

The exhaust cam (B) in addition to the main lobe has another lobe (see sect. A-A, fig. 5) with respect to the configuration without EGR.

The additional lobe, during the inlet phase of the cylinder under examination, permits briefly opening the exhaust valve generating recirculation due to the exhaust gases returning caused by the lower pressure created in the inlet phase inside the cylinder.

## OVERHAUL

Op. 10 001 10

## ENGINE

## Removal

**DANGER**


Lift and handle all heavy parts using suitable lifting equipment.

Make sure that assemblies or parts are supported by means of suitable slings and hooks. Ensure that no-one is in the vicinity of the load to be lifted.


**WARNING**

Use suitable tools to align the holes. NEVER USE FINGERS OR HANDS.

1. Remove the hood as described in operation **90 100 22**.
2. Extract the fixing pin and remove the ballast (1); unscrew the retaining screws and retrieve the ballast support (2).
3. Unscrew the retaining bolts and remove the side grille (1). Perform this operation on the other side of the tractor too.




6




7

4. Unscrew the related retaining bolt and loosen the guide (1), unhook the catch and take out the condenser (2).




8

5. Disconnect the electrical connection from the compressor (1) and unscrew the related retaining bolts. Remove the brackets fixing the pipes of the air conditioning system and take the condenser, compressor and pipes under the transmission without disconnecting the pipes.




9

6. Unscrew the bolts (3) securing the exhaust pipe (1), unscrew the exhaust silencer retaining bolts (2) and remove the entire assembly. Unscrew the retaining bolts and remove the heat shield.




10

7. Remove the guard (1) and disconnect the cables from the starter motor (2).




11

8. Disconnect the pipes (1) of the cab heating system and drain the engine cooling system.




12

9. Unscrew the plug and drain the oil from the rear transmission casing (the prescribed quantity is 42 liters or 11 gallons).




13

10. Disconnect the power steering pipes (2), unscrew the related retaining bolts and remove the bracket (1).




14

11. Disconnect the electrical connection from the brake fluid reservoir (1), unscrew the retaining bolts and remove the reservoir from the supporting bracket.




15

12. Unscrew the retaining bolts and remove the hood bracket (1).




16

13. Disconnect: the main electrical connections (1), the connection of the steering sensor and the cab ground, disconnect the throttle cable (2) from the injection pump.




17

14. Disconnect the diesel pipes (1) from the injection pump.  
Disconnect the pipe (2) from the pump.




18

15. Disconnect: the transmission oil cooler pipes (1) and the front axle differential lock pipe (2).




19

16. Unscrew the front, middle and rear retaining bolts and remove the propeller shaft guard (1).




20

17. Remove the circlip (2) and move the front sleeve (1) backwards in order to free it from the groove on the front axle.




21

18. Remove the circlip (2) and move the rear sleeve (1) in order to release it from the groove on the drive.




22

19. Remove the propeller shaft central support (1) retaining bolts and extract the shaft together with the support.




23

20. Loosen the retaining bolt and turn the bracket (1) through 90°.




24

21. For models fitted with brakes on the front axle it is necessary to drain the brake fluid tank and disconnect the pipes (1, 2 and 3) from the block.




25

22. Unscrew: the retaining bolts of the pipe (1) delivering oil to the pump and the bolts retaining the pipe (2) to the filter support.




26

23. Loosen the related clamps and remove the sleeve (2) from the pipe (1) and remove the transmission oil inlet pipe together with the above-mentioned sleeve.




27

24. Unscrew the retaining bolts and remove the guard (1). Do this on both sides.




28

25. Unscrew the retaining bolts and remove the cab mat guard (2).  
Remove the plastic pedal (1).




29

26. Unscrew the bolts (1) (on both sides), extract the spring pin (2) and remove the throttle pedal (3).




30

27. Raise the front part of the cab mat; remove the two plastic plugs and, through the hole (1), unscrew the four upper bolts securing the engine to the clutch casing.




31

28. Place a stand under the clutch casing, attach the rear portion of the engine to a hoist, using chains (1).




32

29. Unscrew the remaining bolts (1) securing the engine to the clutch casing and separate the engine with the front axle from the clutch casing.



33

30. Disconnect the connections (1) from the clogged air filter sensor.



34




**Suggest:**

**If the above button click is invalid.**

**Please download this document first, and then click the above link to download the complete manual.**


**Thank you so much for reading**

31. Set one fixed stand under the axle support at the rear and the other under the front side. Keeping the chains (1, fig. 32) connected, join one chain (5) to the front of the engine. Unscrew the clamps and remove: The engine oil vapor recirculation pipe (3), turbocharger intake pipe (2), and the intake air cooler pipes (1 and 4).



35

32. Disconnect the lower (1) and upper sleeves from the radiator, remove the bracket (2) fastening the power steering pipe.




36

33. Insert a wooden wedge on each side between the axle support and the axle. For all models, unscrew the bolts (1) on both sides and separate the engine from the axle-support assembly with the radiator and battery.

34. Rest the engine on an adequate support.

**WARNING**

Use suitable tools to align the holes. NEVER USE FINGERS OR HANDS.



37

**Installation**

To re-fit the engine, proceed as follows.

1. Apply the torque settings listed in torque table.
2. Connect the engine, with chains, to the hoist.

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**