

JOHN DEERE
WORLDWIDE COMMERCIAL & CONSUMER
EQUIPMENT DIVISION

Professional Greensmower
2500A and 2500E

OMTCU18501 H5

OPERATOR'S MANUAL



JOHN DEERE

Export Version
Litho in U.S.A.

INTRODUCTION

Thank You for Purchasing a John Deere Product

We appreciate having you as a customer and wish you many years of safe and satisfied use of your machine.

Using Your Operator's Manual

This manual is an important part of your machine and should remain with the machine when you sell it.

Reading your operator's manual will help you and others avoid personal injury or damage to the machine. Information given in this manual will provide the operator with the safest and most effective use of the machine. Knowing how to operate this machine safely and correctly will allow you to train others who may operate this machine.

If you have an attachment, use the safety and operating information in the attachment operator's manual along with the machine operator's manual to operate the attachment safely and correctly.

This manual and safety signs on your machine may also be available in other languages (see your authorized dealer to order).

Sections in your operator's manual are placed in a specific order to help you understand all the safety messages and learn the controls so you can operate this machine safely. You can also use this manual to answer any specific operating or servicing questions. A convenient index located at the end of this book will help you to find needed information quickly.

The machine shown in this manual may differ slightly from your machine, but will be similar enough to help you understand our instructions.

RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line (-----), the item referred to is hidden from view.

Before delivering this machine, your dealer performed a predelivery inspection to ensure best performance.

Machine Use

This machine is designed solely for use in customary lawn and turf mowing operations. Use in any other way is considered as contrary to the intended use.

The manufacturer accepts no liability for damage or injury resulting from this misuse, and these risks must be borne solely by the user. Compliance with and strict adherence to the conditions of operation, service and repair as specified by the manufacturer also constitute essential elements for

the intended use.

This machine should be operated, serviced and repaired only by persons familiar with all its particular characteristics and acquainted with the relevant safety rules (accident prevention). The accident prevention regulations, all other generally recognized regulations on safety and occupational medicine and the road traffic regulations must be observed at all times.

Setting fuel delivery beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this machine.

Any arbitrary modifications carried out on this machine will relieve the manufacturer of all liability for any resulting damage or injury.

Special Messages

Your manual contains special messages to bring attention to potential safety concerns, machine damage as well as helpful operating and servicing information. Please read all the information carefully to avoid injury and machine damage.



CAUTION: Avoid injury! This symbol and text highlight potential hazards or death to the operator or bystanders that may occur if the hazards or procedures are ignored.

IMPORTANT: Avoid damage! This text is used to tell the operator of actions or conditions that might result in damage to the machine.

NOTE: General information is given throughout the manual that may help the operator in the operation or service of the machine.

PRODUCT IDENTIFICATION

Record Identification Numbers

Greensmowers

2500A PIN (030001-)

2500E PIN (010001-)


If you need to contact an Authorized Service Center for information on servicing, always provide the product model and identification numbers.

You will need to locate the identification numbers for the product. Record the information in the spaces provided below.

DATE OF PURCHASE:


DEALER NAME:

DEALER PHONE:




MX18011

DIESEL ENGINE SERIAL NUMBER (C):



MX18009

PRODUCT IDENTIFICATION NUMBER (A):



MX18010

GAS ENGINE SERIAL NUMBER (B)

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

TABLE OF CONTENTS

Safety Labels	1
Safety	4
Operating - Machine	9
Operating - Cutting Units	22
Replacement Parts	33
Service Intervals	34
Service Lubrication	36
Service Engine	39
Service Transmission	58
Service - Hydraulics	61
Service Cutting Units	65
Service Electrical	77
Service Miscellaneous	82
Troubleshooting	86
Storage	95
Assembly	97
Specifications	105
Declaration of Conformity	110
Index	112

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 2005
Deere & Co.
John Deere Worldwide Commercial and
Consumer Equipment Division
All rights reserved
Previous Editions
COPYRIGHT© 2004

OMTCU18501 H5 - English

SAFETY LABELS


Pictorial Safety Signs



Safety-Alert Symbol

At several important places on this machine safety signs are affixed intended to signify potential danger. The hazard is identified by a pictorial in a warning triangle. An adjacent pictorial provides information how to avoid personal injury. These safety signs, their placement on the machine and a brief explanatory text are shown in this Safety section.


WARNING



MX18013, MT6523

To avoid injury, avoid quick stops and reduce speed on slopes.

DANGER




MX18013, MT6732

Picture Note: Two safety labels attached to each cutting reel.

To avoid injury from rotating blades, stay clear of reel.

Shut off engine and wait for cutting units to stop before servicing, lubricating or removing cutting unit.

CAUTION



MX18013, MT6494


HELP AVOID INJURY

- Operator training required.
- Read operator's manual.
- Keep shields in place and in proper working condition.
- Never carry riders.
- Keep people a safe distance away.
- Maintain all safety devices.
- Before leaving machine:
 - Stop engine.
 - Set park brake.

SAFETY LABELS

- Remove key.

WARNING




MX18013, M137684

Picture Note: Safety label attached to top of radiator.

Hot surface. Stay a safe distance from the machine.

DANGER/POISON



MX18013, MT6350

SHIELD EYES - EXPLOSIVE GASES can cause blindness or injury.

NO

- Sparks
- Flames

- Smoking


SULFURIC ACID can cause blindness or severe burns

Keep out of reach of children. Do not tip. Keep vent caps tight and level.

FLUSH EYES IMMEDIATELY WITH WATER. GET MEDICAL HELP FAST.

CAUTION: For safe jump starting follow instructions in vehicle owners manual. If not available seek service assistance.


Avoid Injury From Tipping



MX18013, MT6494

- Do not drive where machine could slip, tip, or rollover.
- Do not drive on a slope with more than a 14° (24%) incline.

CAUTION - Pinch Point




MX18013, MT6729

SAFETY LABELS

AVOID INJURY FROM PINCH POINT

Avoid hand injuries when opening or closing the operator seat platform. Do not perform service functions under seat platform unless properly secured in the raised position.

FREE-WHEELING TOW VALVE LABEL




MX18013, M123057

Read Using Free-Wheeling Tow Valve in the Operating section of this operator's manual before operating the tow valve.

Prevent hydrostatic damage. Push or pull greensmower by hand only. Do not use another vehicle to push or pull the greensmower.

BACKLAP VALVE LABEL



MX18013, MT6727



Picture Note: Open service access panel below operator seat platform to locate label attached to

backlap valve.

Read Backlapping Cutting Units in the Service-Cutting Units section of the operator's manual before operating the backlap valve.

Avoid injury from rotating blades. Keep hands and feet away while greensmower is running.

CE Certification, Specification and Sound Labels

(A) 	 [] 460 kg
(B) 	 [] 500 kg
(C)	2150 min ⁻¹ [] 35 kg

TCU16142, TCU16152, MT6583

A - Gas Model

B - Diesel Model

C - Reels

These labels on your machine indicate that these models have been certified and are in compliance with European Directive 98/37EC (89/392EEC) Standards and 2000/14/EC.

SAFETY

Training

- Read the instructions carefully. Be familiar with the controls and the proper use of the equipment.
- Never allow children or people unfamiliar with these instructions to use the lawnmower. Local regulations can restrict the age of the operator.
- Never mow while people, especially children, or pets are nearby.
- Keep in mind that the operator or user is responsible for accidents or hazards occurring to other people or their property.
- Do not carry passengers.
- All drivers should seek and obtain professional and practical instruction. Such instruction should emphasize:
 - the need for care and concentration when working with ride-on machines.
 - control of a ride-on machine sliding on a slope will not be regained by the application of the brake.
- The main reasons for loss of control are:
 - insufficient wheel grip;
 - being driven too fast;
 - inadequate braking;
 - the type of machine is unsuitable for its task;
 - lack of awareness of the effect of ground conditions, especially slopes;
 - incorrect hitching and load distribution.

Preparation

- While mowing, always wear substantial footwear and long trousers. Do not operate the equipment when barefoot or wearing open sandals.
- Thoroughly inspect the area where the equipment is to be used and remove all objects which can be thrown by the machine.
- **WARNING-Fuel is highly flammable.**
 - store fuel in containers specifically designed for this purpose.
 - refuel outdoors only and do not smoke while refueling.
 - add fuel before starting the engine. Never remove the cap of the fuel tank or add fuel while the engine is running or when the engine is hot.
 - if fuel is spilled, do not attempt to start the engine but move the machine away from the area of spillage and

avoid creating any source of ignition until fuel vapors have dissipated.

- replace all fuel tank and container caps securely.
- Replace faulty silencers.

Operation

- Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
- Mow only in daylight or in good artificial light.
- Before attempting to start the engine, disengage all blade attachment clutches and shift into neutral.
- Do not use on slopes of degrees more than recommended by the manufacturer.
- Remember there is no such thing as a safe slope. Travel on grass slopes requires particular care. To guard against overturning:
 - do not stop or start suddenly when going up or downhill;
 - engage clutch slowly, always keep machine in gear, especially when traveling downhill;
 - machine speeds should be kept low on slopes and during tight turns;
 - stay alert for humps and hollows and other hidden hazards;
 - never mow across the face of a slope, unless the machine is designed for this purpose.
- Use care when pulling loads or using heavy equipment:
 - use only approved drawbar hitch points;
 - limit loads to those you can safely control;
 - do not turn sharply. Use care when reversing;
 - use counterweights or wheel weights when suggested in the operator's manual.
- Watch out for traffic when crossing or near roadways.
- Stop the blades from rotating before crossing surfaces other than grass.
- Never direct discharge of material toward bystanders nor allow anyone near the machine while in operation.
- Never operate the machine with defective guards, or without safety protective devices in place.
- Do not change the engine governor settings or overspeed the engine. Operating the engine at excessive speed can increase the hazard of personal injury.
- Before leaving the operator's position:
 - disengage the drive to any attachments and lower

SAFETY


them;

- change into neutral and lock the parking brake;
- stop the engine and remove the key.
- Disengage drive to attachments when transporting or not in use.
- Stop the engine and disengage drive to attachment:
 - before refueling;
 - before removing the grass catcher;
 - before making height adjustment unless adjustment can be made from the operator's position;
 - before clearing blockages;
 - before checking, cleaning or working on the lawnmower;
 - after striking a foreign object. Inspect the lawnmower for damage and make repairs before restarting and operating the equipment.
- Read, understand and follow all instructions in the manual and on the machine before starting.
- Inspect machine before you operate. Repair or replace damaged, badly worn, or missing parts. Make any necessary adjustments before you operate.
- Be sure all drives are in neutral and parking brake is locked before starting engine. Only start engine from the operator's position.
- Check brake action before you operate. Adjust or service brakes as necessary.
- Stop machine if anyone enters the area.
- Do not leave machine unattended when it is running.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.
- Use only accessories and attachments approved by the manufacturer of the machine. Keep safety labels visible when installing accessories and attachments.
- Do not operate machine if you are under the influence of drugs or alcohol.
- Check before each use that operator presence controls are functioning correctly. Test safety systems. Do not operate unless they are functioning correctly.
- Always wear seat belt if provided on machine.
- Never raise mower decks when blades are running.
- Do not wear radio or music headphones. Safe service and operation requires your full attention.

Maintenance and Storage

- Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition.
- Never store the equipment with fuel in the tank inside a building where fumes can reach an open flame or spark.
- Allow the engine to cool before storing in any enclosure.
- To reduce the fire hazard, keep the engine, silencer, battery compartment and fuel storage area free of grass, leaves, or excessive grease.
- Check the grass catcher frequently for wear or deterioration.
- Replace worn or damaged parts for safety.
- If the fuel tank has to be drained, this should be done outdoors.
- Be careful during adjustment of the machine to prevent entrapment of the fingers between moving blades and fixed parts of the machine.
- On multi-cylinder machines, take care as rotating one cylinder can cause other cylinders to rotate.
- When machine is to be parked, stored or left unattended, lower the cutting means unless a positive mechanical lock is used.
- Use jack stands or lock service latches to support components when required. Securely support any machine elements that must be raised for service work.
- Before servicing machine or attachment, carefully release pressure from any components with stored energy, such as hydraulic components or springs.
- Release hydraulic pressure by lowering attachment or cutting units to the ground or to a mechanical stop and move hydraulic control levers back and forth.
- Disconnect battery or remove spark plug (for gas engines) before making any repairs. Disconnect the negative terminal first and the positive last. Reconnect positive first and negative last.
- Use care when checking reels. Wear gloves, and use caution when servicing them.
- Keep hands, feet, clothing, jewelry and long hair away from moving parts. If possible, do not make adjustments with the engine running.
- Charge batteries in an open well ventilated area, away from spark and flames. Unplug charger before connecting or disconnecting from battery. Wear protective clothing and use insulated tools.

SAFETY



Checking Mowing Area

- Clear mowing area of objects that might be thrown. Keep people and pets out of mowing area.

• Low-hanging branches and similar obstacles can injure the operator or interfere with mowing operation. Before mowing, identify potential obstacles such as low-hanging branches, and trim or remove those obstacles.

- Study mowing area. Set up a safe mowing pattern. Do not mow where traction or stability is doubtful.

Parking Safely

1. Stop machine on a level surface, not on a slope.
2. Disengage mower blades or any other attachments.
3. Lower attachments to the ground.
4. Lock the park brake.
5. Stop the engine.
6. Remove the key.
7. Wait for engine and all moving parts to stop before you leave the operator's seat.
8. Close fuel shut-off valve, if your machine is equipped.
9. Disconnect the negative battery cable or remove the spark plug wire (for gasoline engines) before servicing the machine.




Avoid Injury From Contacting Blades

- Rotating cutting cylinders can cut off arms and legs, and throw objects. Failure to observe safety instructions

could result in serious injury or death.

- Keep hands, feet and clothing away from rotating cutting cylinders when engine is running.
- Be alert at all times, drive forward carefully. People, especially children can move quickly into the mowing area before you know it.
- Before backing up, stop cutting cylinders and look down and behind the machine carefully, especially for children.
- Do not mow in reverse.
- Shut off cutting cylinders when you are not mowing.
- Park machine safely before leaving the operator's station for any reason including emptying the grasscatchers.

- Keep all parts of the body away from the cutting edges. Residual hydraulic pressure in the system can cause cutting cylinder rotation when the blockage is released.
- Use a long-handled brush when applying reel-sharpening compound.
- Keep bystanders away from cutting units when adjusting or servicing.
- Always wear gloves when manually rotating reel. Manually rotating one reel can cause another reel to rotate.



Protect Children


- Death or serious injury can occur when young children associate having fun with a lawn mowing machine simply because someone has given them a ride on a machine.

- Children are attracted to lawn mowing machines and mowing activities. They don't understand the

dangers of rotating blades or the fact that the operator is unaware of their presence.

- Children who have been given rides in the past may suddenly appear in the mowing area for another ride and be run over or backed over by the machine.
- Tragic accidents with children can occur if the operator is not alert to the presence of children, especially when a child approaches a machine from behind. Before and while backing up, stop mower blades and look down and behind the machine carefully, especially for children.
- Never carry children on a machine or attachment, even with the blades off. Do not tow children in a cart or trailer. They can fall off and be seriously injured or interfere with safe machine operation.
- Never use the machine as a recreational vehicle or to entertain children.
- Never allow children or an untrained person operate the machine. Instruct all operators not to give children a ride on the machine or in an attachment.
- Keep children indoors, out of the mowing area, and in the watchful eye of a responsible adult, other than the operator, when a mower is being operated.
- Stay alert to the presence of children. Never assume that children will remain where you last saw them. Turn the machine off if a child enters the work area.

SAFETY



Avoid Tipping

- Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. Operation on all slopes

requires extra caution.

- If you feel uneasy on a hillside, do not mow it.
- Mow up and down slopes, not across.
- Watch for holes, ruts, bumps, rocks, or other hidden objects. Uneven terrain could overturn the machine. Tall grass can hide obstacles.
- Choose a low ground speed so you will not have to stop or shift while on a slope.
- Do not mow or operate machine on wet grass. Tires may lose traction. Tires may lose traction on slopes even though the brakes are functioning properly.
- Avoid starting, stopping or turning on a slope. If the tires lose traction, disengage the reels and proceed slowly, straight down the slope.
- Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction, which could cause the machine to roll over.
- Do not mow near drop-offs, ditches, embankments, or bodies of water. The machine could suddenly roll over if a wheel goes over the edge or the edge caves in.
- Drive machine very slowly and avoid quick stops when cutting units are removed.
- Transport machine with cutting units lowered to improve stability.

Keep Riders Off

- Only allow the operator on the machine. Keep riders off.
- Riders on the machine or attachment may be struck by foreign objects or thrown off the machine causing serious injury.
- Riders obstruct the operator's view resulting in the machine being operated in an unsafe manner.

Checking Wheel Hardware

- A serious accident could occur causing serious injury if wheel hardware is not tight.
- Check wheel hardware tightness often during the first 100 hours of operation.
- Wheel hardware must be tightened to specified torque using the proper procedure anytime it is loosened.



Wear Appropriate Clothing

- Always wear safety goggles, or safety glasses with side shields, and a hard hat when operating the machine.

- Wear close fitting clothing and safety equipment appropriate for the job.
- While mowing, always wear substantial footwear and long trousers. Do not operate the equipment when barefoot or wearing open sandals.
- Wear a suitable protective device such as earplugs. Loud noise can cause impairment or loss of hearing.



Avoid High Pressure Fluids

- Hydraulic hoses and lines can fail due to physical damage, kinks, age, and exposure. Check hoses and lines regularly. Replace damaged hoses

and lines.

- Hydraulic fluid connections can loosen due to physical damage and vibration. Check connections regularly. Tighten loose connections.
- Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.
- Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.
- If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A. Information may be obtained in the United States and Canada only by calling 1-800-822-8262.

Prevent Fires

- Remove grass and debris from engine compartment and muffler area, before and after operating machine, especially after mowing or mulching in dry conditions.
- Empty the grasscatcher completely before storing.
- Always shut off fuel when storing or transporting machine, if the machine has a fuel shutoff.
- Do not store machine near an open flame or source of ignition, such as a water heater or furnace.

SAFETY


- Check fuel lines, tank, cap, and fittings frequently for cracks or leaks. Replace if necessary.



Tire Safety

Explosive separation of a tire and rim parts can cause serious injury or death:

- Do not attempt to mount a tire without the proper equipment and experience to perform the job.
- Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.
- When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly.
- Check tires for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



Handling Fuel Safely

To avoid personal injury or property damage, use extreme care in handling fuel. Fuel is extremely flammable and fuel vapors are explosive:

- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only approved non-metal, portable fuel containers. If using a funnel, make sure it is plastic and has

no screen or filter.

- Never remove the fuel tank cap or add fuel with the engine running. Allow engine to cool before refueling.
- Never add fuel to or drain fuel from the machine indoors. Move machine outdoors and provide adequate ventilation.
- Clean up spilled fuel immediately. If fuel is spilled on clothing, change clothing immediately. If fuel is spilled near machine, do not attempt to start the engine but move the machine away from the area of spillage. Avoid creating any source of ignition until fuel vapors have dissipated.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light such as on a water heater or other appliance.
- Prevent fire and explosion caused by static electric discharge. Static electric discharge can ignite fuel vapors in an ungrounded fuel container.

- Never fill containers inside a vehicle or on a truck or trailer bed with a plastic liner. Always place containers on the ground away from your vehicle before fueling.
- Remove fuel-powered equipment from the truck or trailer and refuel it on the ground. If this is not possible, then refuel such equipment with a portable container, rather than from a fuel dispenser nozzle.
- Keep the nozzle in contact with the rim of the fuel tank or container opening at all times until the fueling is complete. Do not use a nozzle lock-open device.
- Never overfill fuel tank. Replace fuel tank cap and tighten securely.
- Replace all fuel container caps securely after use.
- For gasoline engines, do not use gas with methanol. Methanol is harmful to your health and to the environment.

Handling Waste Product and Chemicals

Waste products, such as, used oil, fuel, coolant, brake fluid, and batteries, can harm the environment and people:

- Do not use beverage containers for waste fluids - someone may drink from them.
- See your local Recycling Center or authorized dealer to learn how to recycle or get rid of waste products.

OPERATING - MACHINE


Daily Operating Checklist

- ☐ Test safety systems.
- ☐ Check tire pressure.
- ☐ Check fuel level.
- ☐ Check engine oil level.
- ☐ Check hydraulic oil level.

Avoid Damage to Plastic and Painted Surfaces

- Do not wipe plastic parts unless rinsed first.
- Insect repellent spray may damage plastic and painted surfaces. Do not spray insect repellent near machine.
- Be careful not to spill fuel on machine. Fuel may damage surface. Wipe up spilled fuel immediately.


Console Controls



MX18003

Picture Note: 2500A Models

- A - Key Switch
- B - Glow Plug Indicator Light (Diesel Model)
- C - Indicator Lights
- D - Raise-Lower Lever
- E - Mow-Transport Lever
- F - Throttle Control Lever
- G - Leak Detector Indicator Light (Optional)




MX20433

Picture Note: 2500E Models

- A - Key Switch
- B - Glow Plug Indicator Light (Diesel Model)
- C - Indicator Lights
- D - Throttle Control Lever
- E - Mow-Transport Lever
- F - Raise-Lower Lever
- G - Reel Controller Diagnostic Light

Pedestal Controls




MX20345

- A - Tilt Steering Adjustment Pedal
- B - Choke Knob (Gas Model)

OPERATING - MACHINE

Foot - Platform Controls



M97302

- A - Park Brake Pedal/Emergency Brake
- B - Park Brake Lock
- C - Forward Travel Pedal
- D - Reverse Travel Pedal

A - Seat Adjustment Lever

B - Fuel Gauge

Adjusting Operator Seat


NOTE: If needed, use the front set of holes in the seat base to provide the most rearward seat position and increased leg room.



M97305


1. Sit on the seat and pull lever (A) to the left.
2. Slide seat forward or backward to desired position.
3. Release lever.

Miscellaneous Controls



M97305, M97389

Adjusting Tilt Steering Wheel



MX20345

1. Press and hold adjustment pedal (A).
2. Move steering wheel to desirable operating position.
3. Release pedal to lock steering wheel in position.

Adjusting Mowing Speed


NOTE: Greensmower is preset at the factory to operate

OPERATING - MACHINE

at approximately 7.1 km/h (4.4 mph).

Wheel RPM's necessary to meet the preset mow speed specification are 178 to 192. Wheel RPM's have been preset at the factory to assure proper forward mow speed regardless of tire size.

1. Park the vehicle safely. (See Park Safely in the SAFETY section.)




M97395

2. Locate mow speed adjustment (A).

3. Move Mow/Transport lever to the MOW position.

NOTE: Preliminary dimension (B) between top of mow speed adjustment and bottom of forward travel pedal linkage is 22 mm (0.87 in.) When mow speed adjustments change, record any dimension (B) changes for future reference.



M97396

4. Loosen jam nuts (C).

5. Adjust stop dimension.

- Increase dimension (B) for increased mowing speed.
- Decrease dimension (B) for decreased mowing speed.

6. Tighten jam nuts.

7. Move Mow/Transport lever to the TRANSPORT position.

8. Measure off 30.5 m (100 ft.)

9. Start engine.

10. Move Mow/Transport lever to the MOW position.

11. Move throttle lever to the FAST position. Depress FORWARD travel pedal fully.

12. Record the number of seconds it takes to travel the 30.5 m (100 ft.) length.

13. Refer to applicable cutting ratio table to determine ground speed and frequency of cut.


14. Continue adjustment process until desired mowing speed and frequency of cut is achieved.

Cutting Ratios

Ground Speed	Seconds to Travel 30.5m (100 ft)	Frequency of Cut	Frequency of Cut
		7 Blade	11 Blade
4 km/h (2.5 mph)	27.2	4.37 mm (.172 in.)	2.77 mm (.109 in.)
4.8 km/h (3.0 mph)	22.7	5.23 mm (.206 in.)	3.33 mm (.131 in.)
5.6 km/h (3.5 mph)	19.5	6.1 mm (.240 in.)	3.89 mm (.153 in.)
6.4 km/h (4.0 mph)	17.0	6.98 mm (.275 in.)	4.45 mm (.175 in.)
7.2 km/h (4.5 mph)	15.2	7.85 mm (.309 in.)	4.98 mm (.196 in.)

OPERATING - MACHINE

Testing Safety Systems



CAUTION: Avoid injury! Engine exhaust fumes contain carbon monoxide and can cause serious illness or death.

Move the machine to an outside area before running the engine.

Do not run an engine in an enclosed area without adequate ventilation.

- **Connect a pipe extension to the engine exhaust pipe to direct the exhaust fumes out of the area.**
- **Allow fresh outside air into the work area to clear the exhaust fumes out.**

The safety systems installed on your machine should be checked before each machine use. Be sure you have read the machine operator manual and are completely familiar with the operation of the machine before performing these safety system checks.

Use the following checkout procedures to check for normal operation of machine.

If there is a malfunction during one of these procedures, do not operate machine. **See your authorized dealer for service.**

Perform these tests in a clear open area. Keep bystanders away.

Testing Mow-Transport Lever Switch

Test 1

1. Sit on seat.
2. Lock the park brake.
3. Put transmission in NEUTRAL.
4. Move mow-transport lever to the MOW position.

5. Turn key switch to the START position.

Result: Engine must not start. The Sit-On-Seat indicator light should flash. If engine starts, there is a problem with the safety interlock circuit.

NOTE: Move mow-transport lever to the TRANSPORT position and turn the key to the STOP position before starting engine.

Test 2

1. Sit on seat.
2. Lock the park brake.
3. Put transmission in NEUTRAL.
4. Rise off seat.
5. Start engine.
6. Lower cutting units to the ground.
7. Move mow-transport lever to the MOW position.

Result: Engine must stop within two seconds with no rotation of cutting reels. If engine does not stop, there is a problem with the safety interlock circuit.

Testing Raise/Lower Lever Switch

1. Sit on seat.
2. Lock the park brake.
3. Move mow-transport lever to the TRANSPORT position.
4. Start engine.
5. Unlock the park brake.
6. Put the transmission in neutral.
7. Lower cutting units with the raise-lower lever.
8. Move mow-transport lever to the MOW position.

Result: Cutting reels must not rotate. If reels rotate, there is a problem with the safety interlock circuit.

Testing Seat Switch

Test 1

1. Sit on seat.
2. Lock the park brake.
3. Move mow-transport lever to the TRANSPORT position.
4. Start engine.
5. Unlock the park brake.
6. Put transmission in neutral.
7. Move mow-transport lever to the MOW position.

OPERATING - MACHINE



CAUTION: Avoid injury! Blades are sharp and rotate quickly:

- Keeps hands and feet away from cutting reels while machine is running.
- Always wear gloves while working on cutting reels.
- Watch for rotation of cutting reels. Rotating one cutting reel can cause another blade or cutting reel to rotate.

8. Push the raise-lower lever forward. Cutting reels should start rotating.

9. Rise off seat.

Result: Engine must stop within two seconds and reels should stop rotating. If engine does not stop, there is a problem with the safety interlock circuit.


Test 2

1. Sit on seat.
2. Lock the park brake.
3. Start engine and set at slow idle.
4. Unlock the park brake.
5. Put the transmission in neutral.
6. Move mow-transport lever to the TRANSPORT position.
7. Rise off seat.

Result: Engine must stop within two seconds. If engine does not stop, there is a problem with the safety interlock circuit.

Using Park Brake

Locking the Park Brake



M97302

1. Push and hold brake pedal (A) down.
2. Push park brake lock (B) down.
3. Release brake pedal.
4. Release park brake lock. Brake pedal should stay down and park brake lock should stay locked.


Unlocking the Park Brake

1. Push brake pedal (A) down. Park brake lock (B) should release immediately.
2. Release brake pedal.

Glow Plug

NOTE: Glow plugs preheat the combustion chamber for better starting performance.

1. Turn key switch to the RUN position.



MX14996


- The amber glow plug indicator light (A) should go on.
- The indicator light should go off in approximately

OPERATING - MACHINE

three seconds after the key switch is turned to the RUN position.


2. Turn the key switch to the START position to start the engine.

Using the Raise - Lower Lever



1. Push raise-lower lever (A) forward to lower cutting units.
 - If the mow-transport lever (B) is in the mow position, the cutting reels will begin to rotate.
 - If the mow-transport lever is in the transport position, the cutting units will lower but the reels will not rotate.
2. Pull lever (A) rearward to raise cutting units.
 - If the mow-transport lever is in the mow position, the cutting reels will stop rotating.

Using the Mow - Transport Lever



Picture Note: Model 2500E Shown


1. Pull the raise-lower lever (A) rearward to raise cutting units.

2. Move the mow-transport lever (B) to the mow position. Mow indicator lamp (C) will illuminate.
3. Push the raise-lower lever forward to lower cutting units.
 - Cutting reels will begin to rotate as the cutting units are lowered.
4. Pull raise-lower lever rearward to raise cutting units.
 - Cutting reels will stop rotating as the cutting units are raised. Mow indicator lamp (C) will go out on 2500E models.
5. Move the mow-transport lever to the transport position to disengage reel drive for cutting units.

Using the Key Switch

NOTE: To help prevent engine backfiring, the engine will continue to run approximately two seconds after key switch is turned to the stop position. After engine has stopped, an approximate two-second delay will prevent the engine from immediately being restarted.

Key Switch (A) Positions



- Run position (B) - the engine oil pressure indicator light and battery indicator light should come on. Engine is ready to start.
- Start position (C) - start engine.
- Stop position (D) - shut engine off.

Using Fuel Shut-Off Valve (Diesel Model)

1. Open rear engine cowling.
2. Locate fuel filter sediment bowl assembly on the left side of the engine.




Suggest:

If the above button click is invalid.

Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading

OPERATING - MACHINE



M97370

Picture Note: Fuel shut-off valve shown in the open position.

3. Rotate fuel shut-off valve lever (A) to the “O” (open) position or “C” (closed) position.

“C” (Closed) position:

- When performing any type of engine service.
- When transporting.
- During periods of extended storage.

“O” (Open) position:

- Fuel shut-off valve must be in the full OPEN position for proper fuel delivery to the engine.

Using the Hour Meter


NOTE: The hour meter, located under the console armrest, will run when key switch is in the RUN position.



M97368

- The hour meter (A) shows the approximate number of hours the greensmower has run.
- Use the hour meter and Service Interval Chart to determine when the greensmower will need service.

Indicator Lights



MIF

- **Hydraulic Oil Temperature Indicator (A)** will glow when hydraulic oil temperature is high. Stop all hydraulic functions immediately. Let hydraulic oil temperature cool by allowing greensmower engine to idle under a no load situation. This keeps the oil flowing through the oil cooler and cools the oil. Check oil level and make sure oil cooler coils are clean. Continued operation may cause higher temperatures, resulting in damage.
- **Engine Oil Pressure Indicator (B)** will glow when engine oil pressure is low. If lamp glows when engine is running, stop engine immediately. See your John Deere distributor.
- **Battery Discharge Indicator (C)** will glow when alternator is not producing adequate current. Stop engine and determine cause.
- **Engine Coolant Temperature Indicator (D)** will glow if engine temperature becomes excessive. Stop engine and determine cause.
- **Hydraulic Leak Detection System Indicator** will glow and an alarm will sound momentarily when the key switch is turned on. If a hydraulic leak is detected, the light will glow and the alarm will sound until the key switch is turned off.

Using Sit-On-Seat (SOS) Indicator Light Diagnostics

Sit-On-Seat (SOS) diagnostics are provided to help diagnose problems starting the greensmower.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>