

2653
Professional Utility
Mower
(Serial No. 030001 –)

OPERATOR'S
MANUAL

John Deere
Lawn & Grounds Care Division
OMMT1491 G5

North American Version
Litho in U.S.A
English

TABLE OF CONTENTS

	Page
Safety Signs	
Safety-Alert Symbol	1
Machine Safety Labels	1
Controls	
Dash/Platform Controls.....	3
Foot Controls	4
Miscellaneous Controls.....	5
Operating the Machine	
Operate Safely.....	6
Mount and Dismount Safely.....	6
Avoid Tipping.....	7
Operator Training Required	9
Keep Riders Off	9
Wear Appropriate Clothing	10
Transport Safely	10
Avoid High Pressure Fluids	11
ADJUSTMENTS:	
Adjusting Seat.....	11
DRIVING:	
Fuel Shut-Off Valve	12
Park Brake	12
Hydrostatic Ground Drive	13
Mow/Lift Lever	13
PTO Switch.....	14
Throttle Lever.....	14
Choke	14
Ignition Interlock System.....	15
Starting the Engine	16
Checking Indicator Lights	18
Warming and Idling Engine.....	19
Stopping Engine	19
Using Hydrostatic Transmission	20
Emergency Stopping	21

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

TABLE OF CONTENTS

	Page
Using Free Wheeling.....	21
Daily Operating Checklist.....	22
Testing Safety Systems	22
Checking Ignition Interlock Switches.....	23
Test 1	23
Test 2	24
Test 3	24
Using the Weight Transfer Control.....	25
Avoid Damage to Plastic and Painted Surfaces.....	25
 Operating the Cutting Units	
Check Ground Conditions	26
Avoid Injury from Contacting Blades	26
ADJUSTMENTS:	
Cutting Taller Grass (Front Rollers are Optional).....	27
Cutting Shorter Grass	28
Grass Deflector	29
Engaging Reel Drive	30
Dismounting to Inspect or Unplug Reels.....	31
 Replacement Parts	
Replacement Parts.....	32
 Service Machine Safely	
Practice Safe Maintenance	33
Wear Appropriate Clothing	34
Handling Waste Product and Chemicals.....	34
Avoid High Pressure Fluids.....	35
Avoid Injury from Contacting Blades	35
 Service Interval Chart	
Daily Service Required.....	36

TABLE OF CONTENTS

	Page
Service-Lubrication	
Grease	38
Grease Locations: All Locations Every 50 Hours	39
Grease Locations (continued):.....	40
Service-Engine	
Avoid Fumes.....	41
Engine Oil	41
Checking Engine Oil	42
Changing Engine Oil and Filter.....	43
Service Cooling System Safely.....	45
Engine Coolant	45
Checking Coolant Level.....	46
Cleaning Air Intake Screen and Radiator	47
Draining Cooling System	48
Flushing Cooling System	49
Filling Cooling System	50
Checking and Cleaning Air Cleaner Elements.....	51
Replacing Fuel Filter.....	53
Tightening or Replacing Fan Belt	54
Adjusting Carburetor Idle Mixture Screw	55
Service-Transmission	
Transmission and Hydrostatic Oil	56
Checking Hydraulic Oil Level	57
Change Hydrostatic Drive Oil	58
Replacing Hydrostatic Oil Filter	59
Adjusting Transmission Neutral	60
Adjusting Neutral Start Switch	62
Service-Cutting Units	
Avoid Injury from Contacting Blades.....	63
Adjusting Cutting Units	63
Adjusting Height-Of-Cut.....	64

TABLE OF CONTENTS

	Page
Adjusting Reel-to-Bed Knife Clearance.....	69
Backlapping Cutting Units	71
Readjust Reel-to-Bed Knife Clearance	73
Grinding the Bed Knife	74
Replacing Bed Knife.....	74
 Service-Electrical	
Cleaning or Replacing Battery	76
Checking Battery Electrolyte Level	77
Charge the Battery Safely	78
Charging Battery	79
Charging Rates	80
Using Booster Battery	81
Limited Battery Warranty.....	82
Replacing Fuses	83
Check Spark Plugs.....	83
Replacing an Indicator Light Bulb	84
 Service-Miscellaneous	
John Deere Tire Warranty.....	85
Checking Tire Pressure.....	85
Tighten Wheel Bolts	86
Refueling Machine	87
Before Filling Fuel Tank.....	88
Raising Hood.....	89
Removing Side panels	89
Adjusting Parking Brake.....	90
 Troubleshooting	
Using Troubleshooting Chart	91
Engine	91
Electrical.....	95
Hydraulic Drive System.....	96
Hydrostatic Drive.....	97

TABLE OF CONTENTS

	Page
Cutting Units	98
Steering	99
 Storing Utility Mower	
Storing Safety	100
Preparing Engine for Storage	100
Storing Vehicle.....	101
Storing Cutting Units.....	101
Removing Vehicle from Storage	102
Removing Cutting Units from Storage	102
 Assembly	
Assemble Professional Utility Mower.....	103
Install Front Roller.....	106
Checking Tire Pressure	108
 Specifications	
Engine.....	109
Fuel System.....	109
Electrical System	110
Capacities	110
Wheel Motor and Reel Drive.....	110
Travel Speeds.....	110
Steering and Brakes	111
Dimensions	111
Tires.....	111
Recommended Lubricants.....	112
Cutting Units	112
 John Deere Service Literature	
Order Form	113

SAFETY SIGNS


Safety-Alert Symbol

Read and recognize safety information.
Be alert to the potential for personal injury when you see this safety-alert symbol.

The words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards.



Machine Safety Labels



M56212





M56164



(2) One on each side


M34187

SAFETY SIGNS



CONTROLS

Dash/Platform Controls



- A - Mow/Lift Levers.....Raises/lowers mowers
- B - Throttle Lever..... Controls engine speed
- C - Indicator Lights..... Monitors machine functions
- D - Park Brake Lever Engages park brake
- E - Choke Lever.....Chokes engine for starting
- F - PTO Switch..... Engages attachments
- G - Key Starts engine
- H - Weight Transfer Valve..... Distributes machine weight

CONTROLS


Foot Controls




- A - Reverse Travel Pedal.....Backs machine
- B - Forward Travel Pedal Starts machine forward travel
- C - Speed Limiter (2WD Only)Limits forward speed

CONTROLS

Miscellaneous Controls



- A - Free-Wheeling Lever Allows machine to be moved
without the engine running
- B - Fuel Shut-Off Valve.....Turns fuel flow on and off



OPERATING THE MACHINE

SAFETY

Operate Safely

- Check brake action before you operate.
Adjust or service brakes as necessary.
- Inspect machine before you operate. Be sure hardware is tight. Repair or replace damaged, badly worn, or missing parts. Make any necessary adjustments before you operate.
- Clear work area of objects that might be thrown. Keep people and pets out of the work area. Stop machine if anyone enters the area.
- If you hit an object, stop the machine and inspect it. Make repairs before you operate. Keep machine and attachments properly maintained and in good working order. Keep all shields and guards in place.
- DO NOT leave machine unattended when it is running.
- Only operate during daylight or with good artificial light.
- Be careful of traffic when operating near or crossing roadways.
- Drive slowly over rough ground.
- Do not wear radio or music headphones while operating the machine. Safe operation requires your full attention.




Mount and Dismount Safely

- Do not step on pedals when mounting or dismounting.
- Keep step area and platform clean.
- Lock parking brake, stop engine, and remove key before dismounting.



OPERATING THE MACHINE

Park Safely



- Stop machine on a level surface, not on a slope.
- Disengage cutting units.
- Lower cutting units to the ground.
- Engage park brake.
- STOP engine.
- Remove key.
- Before you leave the operator's seat, wait for engine and all moving parts to STOP.

Avoid Tipping



- DO NOT drive where machine could slip or tip.
- Stay alert for holes and other hidden hazards in the terrain.
- Keep away from drop-offs.
- Slow down before you make a sharp turn or operate on a slope.
- Be careful when you change direction on a slope.
- DO NOT try to stabilize the machine by putting your foot on the ground.

OPERATING THE MACHINE

Rotating Blades Are Dangerous - Prevent Accidents



PROTECT OTHERS:

- Turn machine off if another person enters the mowing area.
- Use extra care when you come to blind corners, shrubs, trees, or other objects that may block your vision.
- DO NOT let untrained person operate the machine.
- DO NOT carry or let others ride on machine.

HELP PREVENT SERIOUS OR FATAL ACCIDENTS:

- Be alert at all times, drive forward carefully. People can move quickly into the mowing area before you know it.
- DO NOT operate machine if you are under the influence of drugs or alcohol.
- Back carefully. Shut off cutting units and look behind the machine carefully before you back up.
- DO NOT mow in reverse.
- Shut off cutting units when you are not mowing.
- Stop engine and wait for reels to stop turning before making any adjustments to the cutting units.
- Keep hands and feet away from cutting units while machine is running.

OPERATING THE MACHINE

Operator Training Required

- Study operation section of this manual before operating the machine.
- Operate machine in an open, unobstructed area under the direction of an experienced operator.
- Learn the use of all controls.
- Operator experience is required to learn the moving, stopping, turning and other operating characteristics of the machine.

Keep Riders Off



- Only allow the operator on the machine. Keep riders off.
- Riders on the machine may be struck by foreign objects or thrown off the machine causing serious injury.
- Riders obstruct the operator's view resulting in the machine being operated in an unsafe manner.

OPERATING THE MACHINE

Wear Appropriate Clothing



- Wear close fitting clothing and safety equipment appropriate for the job.
- Loud noise can cause impairment or loss of hearing, wear a suitable protective device such as earplugs.
- Do not wear radio or music headphones while operating the machine. Safe operation requires your full attention.

Check Wheel Bolts

- A serious accident could occur causing serious injury if wheel bolts are not tight.
- Check wheel bolt tightness often during the first 100 hours of operation.

Transport Safely



- Use safety lights and devices. Slow moving machines when driven on public roads are hard to see, especially at night. Avoid personal injury or death resulting from a collision with a vehicle.
- Flashing warning lights are recommended whenever driving on public roads to increase visibility. Extra flashing warning lights may need to be installed.

OPERATING THE MACHINE

Avoid High Pressure Fluids

- Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.
- Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.
- If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




ADJUSTMENTS

Adjusting Seat

Push lever (A) to the left.

Slide seat forward or backward to desired position.

Release lever.





Suggest:

If the above button click is invalid.

Please download this document first, and then click the above link to download the complete manual.


Thank you so much for reading

OPERATING THE MACHINE

DRIVING


Fuel Shut-Off Valve

The fuel tank is equipped with a fuel shut-off valve (A). This valve should be closed if the machine is placed in extended storage. OFF is shown with the handle across the direction of the fuel line and ON is in the direction of the fuel line.



Park Brake

ENGAGE Park brake (B) by pulling lever towards operator.



DISENGAGE Park brake (B) by pushing lever away from operator



<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>