


OPERATION MANUAL

YANMAR

MARINE DIESEL ENGINE

4JH3-TE/-TCE/-HTE/-DTE



Model 4JH3-DTE(with KMH4A marine gear)



**Be sure to read this manual for safe and proper operation.
Store this manual carefully after use.**

1 FOR SAFE OPERATION	1
1.1 Warning Symbols	1
1.2 Safety Precautions	2
1.3 Location of Product Safety Labels	4
2 PRODUCT EXPLANATION	5
2.1 Use & Driving System	5
2.2 Engine Specifications	6
2.2.1 4JH3-TE	6
2.2.2 4JH3-TCE	7
2.2.3 4JH3-HTE	8
2.2.4 4JH3-DTE	9
2.3 Names of Parts	10
2.4 Major Servicing Parts	11
2.5 Operation Equipment	12
2.5.1 Instrument Panel	12
2.5.2 Remote Control Handle	15
3 BEFORE OPERATION	18
3.1 Fuel Oil, Lube Oil and Cooling Water	18
3.1.1 Fuel Oil	18
3.1.2 Lube oil	19
3.1.3 Cooling Water	19
3.2 Supplying Fuel	20
3.2.1 Filling the Fuel Tank	20
3.2.2 Bleeding the Fuel System	20
3.3 Supplying Engine Lube Oil	21
3.4 Supplying Marine Gear Lube Oil	21
3.5 Supplying Cooling Water	22
3.6 Cranking	23
3.7 Checking the Lube Oil and Cooling Water	23
4 HOW TO OPERATE	24
4.1 Inspection Before Starting	24
4.2 Checking the Illumination Lamps of the Panel Meters	26
4.2.1 Checking the Illumination Lamps of the Panel Meters	26
4.2.2 Checking the Alarm Devices	26
4.2.3 Checking the Panel Meters	26
4.3 starting	27
4.3.1 Daily Starting	27
4.3.2 Starting Under Low Temperature Conditions	27
4.3.3 Restarting After Starting Failure	27
4.3.4 After the Engine has Started	28
4.4 Adjusting the Engine Speed	28
4.5 Clutch Operation for the Marine Gear	29
4.5.1 Forward, Neutral, Reverse	29
4.5.2 Switching to Trawling (Available for KMH4A only)	29
4.6 Check During Operation	30
4.7 Stopping the Engine	31
4.8 Operation Procedure	32
4.9 Long-Term Storage	33
4.9.1 Before storing for long periods of time, perform the following.	33
4.9.2 Checking the Engine for Reuse After a Long Storage Period	34

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

5 MAINTENANCE & INSPECTION	35
5.1 List of Periodic Inspections	36
5.2 Periodic Inspection Items	37
5.2.1 Inspection After Initial 50Hrs. Operation	37
5.2.2 Inspection Every 50 Hours	39
5.2.3 Inspection Every 250 Hrs. or 1 yr.	41
5.2.4 Inspection Every 500 Hrs.or 2 yrs.	44
5.2.5 Inspection Every 1000 Hrs. or 4 yrs.	45
6 TROUBLE AND TROUBLESHOOTING	47
6.1 Simple problems and the appropriate countermeasures	47
6.2 Emergency Repairs for Marine Gear Trouble	49
6.3 Consulting Your Yanmar Dealer or Distributor	50
7 SYSTEM DIAGRAM	52
7.1 Wiring diagram	52
7.1.1 B type Instrument Panel	52
7.1.2 C type / C type x B type(No.2 station) Instrument Panel	54
7.1.3 New B type Instrument Panel	56
7.1.4 New C type / New C type x New B type(No.2 station)	58
7.1.5 Instrument Panel	58

1. FOR SAFE OPERATION

Following the precautions described in this manual will enable you to use this engine with complete satisfaction. Failure to observe any of the rules and precautions, however, may result in injury, burns, fires, and engine damage. Read this manual carefully and be sure you fully understand it before beginning operation.

1.1 Warning Symbols

These are the warning signs which are used in this manual and on the products. Pay special attention to them.

 **DANGER**

DANGER- Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.

 **WARNING**

WARNING- Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.

 **CAUTION**

CAUTION- Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

- The descriptions captioned by **NOTICE** are for the particularly important cautions for handling. If you ignore them, the performance of your machine may deteriorate leading to trouble.

1.2 Safety Precautions

(Observe these instructions for your own safety.)

Precautions for Operation

⚠ DANGER



Burns from Scalding

- Never remove the filler cap of the fresh water cooler while the engine is still hot. Steam and hot water will spurt out and seriously burn you. Wait until the water temperature has dropped, then wrap a cloth around the cap and loosen it slowly.
- After inspection, refasten the filler cap firmly. If the cap is not secure, steam or scalding water may be emitted during operation causing burns.

⚠ DANGER



Proper Ventilation of the Battery Area

- Be sure the area around the battery is well-ventilated and there is nothing which could start a fire. During operation and charging, hydrogen gas is emitted from the battery and can be easily ignited.

⚠ DANGER



Fires from Oil Ignition

- Be sure to use the correct type of fuel when refueling. Mistakenly filling with gasoline or the like will result in ignition.
- Be sure to stop the engine before refueling. If you spill fuel, wipe such spillage carefully.
- Never place oils or other flammable material close to the engine as this could result in ignition.


⚠ WARNING



Exhaust Gas Poisoning

- Be sure to establish good ventilation in the engine room with windows, vents, or other ventilation equipment. Check again during operation to be sure that ventilation is good. Exhaust gas contains poisonous carbon monoxide and should not be inhaled.

⚠ WARNING



Moving Parts

- Do not touch the moving parts of the engine (propeller shaft, V-belt, PTO-pulley, etc.) during operation or let your clothing get caught in them as this can result in injury.
- Never operate the engine without the covers on the moving parts.
- Check before starting the engine to see that any tools or cloths used in maintenance have been removed from the area.

⚠ CAUTION



Burns from Contact with Hot Engine Parts

- The whole engine is hot during operation and immediately after stopping. The turbocharger, exhaust manifold, exhaust pipe, and engine are very hot. Never touch these parts with your body or clothing.

⚠ WARNING**Alcohol**

- Never operate the engine while you are under the influence of alcohol or when you are ill or feel unwell as this results in accidents.

Safety Precautions for Inspection**⚠ DANGER****Battery Fluid**

- Battery fluid is diluted sulfuric acid. It can blind you if it gets in your eyes, or burn your skin. Keep the fluid away from your body. Wash it off immediately with a large quantity of fresh water if you get any on you.

⚠ WARNING**Fire due to Electric Short-Circuits**

- Always turn off the battery switch or detach the earth cable (-) before inspecting the electrical system. Failure to do so could cause short-circuiting and fires.

⚠ WARNING**Precautions for Moving Parts**

- Stoop the engine before you service it. If you must inspect while the engine is operating, never touch moving parts. Keep your body and clothing well clear of all moving parts as this could result in injury.

⚠ CAUTION**Precautions for Removing Hot Oil and Water to Prevent Burns**

- If extracting oil from the engine while it is still hot, do not let the oil splash on you.
- Wait until the temperature has dropped before removing cooling water from the engine to avoid getting scalded.

NOTICE:**Do not alter the diesel engine.**

Rebuilding the engine or altering parts to increase the speed or the amount of fuel discharged, etc. will make operation unsafe, and result in damage and shortening of engine life.


NOTICE:**Disposal of waste materials**

- Put oil or liquids to be disposed in a container. Never dispose of waste oil or other fluids outside, in a sewer, river, or the sea.
- Treat waste materials safely observing all regulations and laws. Ask a waste recovery company to collect and dispose of it.

1.3 Location of Product Safety Labels

To insure safe operation, product safety labels have been attached. Their location is shown in the diagram below. Keep the labels from becoming dirty or torn and replace them if they are lost or damaged. Also replace labels when parts are replaced, ordering them in the same way as for the parts.

Product Safety Labels, Parts Code Numbers	
1	128377-07350
2	128296-07260
3	128296-07300
4	196630-12980



The above diagram shows a side view of the engine.

2. PRODUCT EXPLANATION

2.1 Use & Driving System

This is light, compact diesel engine for use in pleasure boats. The engine is equipped with a turbocharger and intercooler which insures maximum output while preserving lightness and compact size. (The 4JH3-TE /-TCE are equipped with the turbocharger only.)

Power output for this group of engines increases progressively from 4JH3-TE(4JH3-TCE), 4JH3-THE to 4JH3-DTE.

In case of engine with marine gear, connect the propeller shaft to the marine gear output shaft. The 4JH3-TCE is with drive SD40-4T. For the sail drive, please refer to its operation manual.

The different types of applicable marine gears for each engine are shown below.

Engine Marine gear	4JH3-TE	4JH3-THE	4JH3-DTE	Note
KBW21	○	○	×	○ : Applicable × : Not applicable
KM4A	○	○	×	
KMH4A	○	○	○	

The installation, fitting and surveying of this engine all require specialized knowledge and engineering skills. Additionally, boat and engine inspection may be required by the laws of some countries. Consult Yanmar's local subsidiary in your region or your distributor or dealer.

In order to get full performance from your engine, it is imperative that the size and structure of the boat be suited to the engine. It is equally important to use the correct driving device and a propeller of the appropriate size and specifications.

The engine must be installed correctly with safe cooling water and exhaust piping and electrical wiring. The PTO work should be easy to use for onboard equipment.

Consult your Yanmar dealer or distributor when selecting optional parts. Optional parts selections should take into account operational and surrounding conditions.

This Operation Manual explains the basic points for standard operation. Variations are explained under the specially marked sections.

This operation Manual explains the basic points for standard operation. Variations are explained under the letter emblems for easy reference.

MODEL : Explanation of indicated model only.

OPTION : Explanation of optional parts.

CUSTOMER : Explanation of use of parts from other boat manufacturers.

Where there are no letter emblem sections the explanation applies to all models.

Explanation for driving devices, propellers, etc. and optional parts are not included, and special attention should be paid to the explanations and safety precautions in the operation manuals provided by the boat and equipment manufacturers.

2.2 Engine Specifications

2.2.1 4JH3-TE

Engine model		4JH3-TE						
Use		Pleasure boat						
Type		Vertical water-cooled 4-cycle diesel engine						
No. of cyl.-bore×stroke		4-φ84×90						
Displacement L		1.995						
Aspiration		Turbocharged						
Cont. rating kW{hp}/rpm		50.7(69) / 3700						
Max. output kW{hp}/rpm (Crankshaft)		*55.2(75)/3800 **53.5(72.8)/3800						
High idling rpm		4300±25						
Low idling rpm		700±25						
Combustion system		Direct injection						
Starting system		Electric starting						
Cooling system		Constant high temperature fresh water cooling						
Lubricating system		Forced lubrication system with trochoid pump						
Marine gear	Model	KBW21		KM4A		KMH4A		-
	Type	Mechanical wet multiple disk clutch input/output eccentric parallel drive		Mechanical wet cone clutch 7° Down angle drive		Hydraulic wet multiple disk clutch 8° Down angle drive		
	Reduction ratio (Ahead/Astern)	2.17/3.06	2.62/3.06	1.47/1.47 2.63/2.63	2.14/2.14 3.30/3.30	2.04/2.04	2.45/2.45	
Direction of rotation	Crankshaft	Counterclockwise (Viewed from stern side)						
	Propeller shaft	Clockwise (Viewed from stern side)						
Fuel injection pump		Bosh-distributor type Model VE(ZEXEL)						
Fuel injection valve		Pinhole injection nozzle YDLLA-P(5-0.22×150°)						
Turbocharger		RHB52(IH) Water cooled and forced lubrication system						
Elec. devices	Starter	DC12V-1.4kW						
	Alternator	DC12V-55A						
Lube oil capacity (raked angle) L	Engine	Oilpan	5.2(7°)		6.4(0°)		Refer to the left	
		All	6.3(7°)		7.5(0°)			
	Marine gear	1.2	1.3	2.0		-		
Cooling water capacity L	Fresh water tank	6.0						
	Subtank	0.8						
Dimensions (L×W×H) mm		898×560×635	888×565×635	886×565×635	763×566×635			
Engine installation style		On the flexible rubber engine mount						
Recommended battery capacity		12V-120A or greater						
Recommended engine room ventilator		12m ³ /min or greater						
Dry mass kg		249	247	250	219			
Note: 1. Rating condition : ISO 3046-1, 8665 2. 1hp=0.7355kW 3. Fuel condition : Density at 15°C=0.860, Fuel oil temperature *:25°C at the fuel injection pump inlet ** : ISO 8665(Fuel oil temp. 40°C at the fuel injection pump inlet)								

2.2.2 4JH3-TCE

Engine model		4JH3-TCE	
Use		Pleasure boat (Sailing boat)	
Type		Vertical water-cooled 4-cycle diesel engine	
No. of cyl.-bore×stroke	mm	4-φ84×90	
Displacement	L	1.995	
Aspiration		Turbocharged	
Cont. rating	kW{hp}/rpm	50.7(69)/3700	
Max. output	kW{hp}/rpm (Crankshaft)	*55.2(75)/3800 **53.5(72.8)/3800	
High idling	rpm	4300±25	
Low idling	rpm	700±25	
Combustion system		Direct injection	
Starting system		Electric starting	
Cooling system		Constant high temperature fresh water cooling	
Lubricating system		Forced lubrication system with trochoid pump	
Sail drive	Model		SD40-4T
	Type		Mechanical wet cone clutch
	Reduction ratio		Refer to the operation manual for the sail drive
Direction of rotation	Crankshaft		Counterclockwise(Viewed from stern side)
	Propeller		Refer to the operation manual for the sail drive
Fuel injection pump		Bosh-distributor type Model VE(ZEXEL)	
Fuel injection valve		Pinhole injection nozzle YDLLA-P(5-0.22×150°)	
Turbocharger		RHB52(IHI) Water cooled and forced lubrication system	
Elec. devices	Starter		DC12V-1.4kW
	Alternator		DC12V-55A
Lube oil capacity (raked angle)	L	Engine	Oilpan
			All
		Drive	Refer to the operation manual for the sail drive
Cooling water capacity	L	Fresh water tank	
		Subtank	
Dimensions (L×W×H)		mm	1086×565×1238(Propeller shaft center)
Engine installation style		On the flexible nubber engine mount	
Recommended battery capacity		12V-120A or greater	
Recommended engine room ventilator		12m ³ /min or greater	
Dry mass		kg	219(Engine)
Note: 1. Rating condition : ISO 3046-1, 8665 2. 1hp=0.7355kW 3. Fuel condition : Density at 15°C=0.860, Fuel oil temperature *:25°C at the fuel injection pump inlet ** : ISO 8665(Fuel oil temp. 40°C at the fuel injection pump inlet)			

2.2.3 4JH3-HTE


Engine model		4JH3-HTE						
Use		Pleasure boat						
Type		Vertical water-cooled 4-cycle diesel engine						
No. of cyl.-bore×stroke	mm	4-φ84×90						
Displacement	L	1.995						
Aspiration		Turbocharged						
Cont. rating	kW{hp}/rpm	67.7(92)/3700						
Max. output	kW{hp}/rpm (Crankshaft)	*73.6(100)/3800 **71.4(97)/3800						
High idling	rpm	4300±25						
Low idling	rpm	700±25						
Combustion system		Direct injection						
Starting system		Electric starting						
Cooling system		Constant high temperature fresh water cooling						
Lubricating system		Forced lubrication system with trochoid pump						
Marine gear	Model	KBW21		KM4A		KMH4A		-
	Type	Mechanical wet multiple disk clutch input/output eccentric parallel drive		Mechanical wet cone clutch 7° Down angle drive		Hydraulic wet multiple disk clutch 8° Down angle drive		
	Reduction ratio (Ahead/Astern)	2.17/3.06	2.62/3.06	1.47/1.47 2.63/2.63	2.14/2.14 3.30/3.30	2.04/2.04	2.45/2.45	
Direction of rotation	Crankshaft	Counterclockwise (Viewed from stern side)						-
	Propeller shaft	Clockwise (Viewed from stern side)						
Fuel injection pump		Bosh-distributor type Model VE(ZEXEL)						
Fuel injection valve		Pinhole injection nozzle YDLLA-P(5-0.25×150°)						
Turbocharger		RHB52(IHI) Water cooled and forced lubrication system						
Elec. devices	Starter	DC12V-1.4kW						
	Alternator	DC12V-55A						
Lube oil capacity (raked angle)	Engine	Oilpan	5.2(7°)		6.4(0°)		Refer to the left	
		All	6.3(7°)		7.5(0°)			
	Marine gear	1.2	1.3	2.0		-		
Cooling water capacity	Fresh water tank	7.2						
	Subtank	0.8						
Dimensions (L×W×H)	mm	898×581×660	888×580×660	886×581×635	763×581×660			
Engine installation style		On the flexible rubber engine mount						
Recommended battery capacity		12V-120A or greater						
Recommended engine room ventilator		16m ³ /min or greater						
Dry mass	kg	258	256	259	228			
Note:								
1. Rating condition : ISO 3046-1, 8665								
2. 1hp=0.7355kW								
3. Fuel condition : Density at 15°C=0.860, Fuel oil temperature * :25°C at the fuel injection pump inlet								
** : ISO 8665(Fuel oil temp. 40°C at the fuel injection pump inlet)								

2.2.4 4JH3-DTE


Engine model		4JH3-DTE				
Use		Pleasure boat				
Type		Vertical water-cooled 4-cycle diesel engine				
No. of cyl.-bore×stroke	mm	4-φ84×90				
Displacement	L	1.995				
Aspiration		Turbocharged				
Cont. rating	kW{hp}/rpm	85.3(116)/3700				
Max. output	kW{hp}/rpm (Crankshaft)	*91.9(125)/3800 **89.1(121.3)/3800				
High idling	rpm	4300±25				
Low idling	rpm	700±25				
Combustion system		Direct injection				
Starting system		Electric starting				
Cooling system		Constant high temperature fresh water cooling				
Lubricating system		Forced lubrication system with trochoid pump				
Marine gear	Model	KMH4A			-	
	Type	Hydraulic wet multiple disk clutch 8° Down angle drive				
	Reduction ratio (Ahead/Astern)	2.04/2.04, 2.45/2.45				
Direction of rotation	Crankshaft	Counterclockwise (Viewed from stern side)			-	
	Propeller shaft	Clockwise (Viewed from stern side)				
Fuel injection pump		Bosh-distributor type Model VE(ZEXEL)				
Fuel injection valve		Pinhole injection nozzle YDLLA-P(5-0.26×150°)				
Turbocharger		RHB52(IHI) Water cooled and forced lubrication system				
Elec. devices	Starter	DC12V-1.4kW				
	Alternator	DC12V-55A				
Lube oil capacity (raked angle)	Engine	Oilpan	6.4(0°)		Refer to the left	
		All	7.5(0°)			
	Marine gear	2.0		-		
Cooling water capacity	Fresh water tank	7.2				
	Subtank	0.8				
Dimensions(L×W×H)		mm	898×581×660	888×581×660	886×581×635	763×581×660
Engine installation style		On the flexible rubber engine mount				
Recommended battery capacity		12V-120A or greater				
Recommended engine room ventilator		20m ³ /min or greater				
Dry mass	kg	260			229	
Note: 1. Rating condition : ISO 3046-1, 8665 2. 1hp=0.7355kW 3. Fuel condition : Density at 15°C=0.860, Fuel oil temperature *:25°C at the fuel injection pump inlet ** : ISO 8665(Fuel oil temp. 40°C at the fuel injection pump inlet)						

2.3 Names of Parts

- **Operation Side (Right side as viewed from the propeller.)** Contains the main parts necessary for operation



- **Non-Operation Side**



NOTE:

The 4JH3-DTE engine with KM4A is used as the example for the above drawings.
 The 4JH3-TE is not equipped with an intercooler (indicated by * mark in the above).

2.4 Major Servicing Parts

Name of part	Function
Fuel filter	Removes dust and water from fuel. The filter is a cartridge type, and the inner element should be replaced before clogging occurs. A water separator is on the bottom of the filter and should be drained periodically.
Fuel priming pump	This is a manual fuel pump. Moving the knob on the top of the fuel filter feeds the fuel. The pump is also used to bleed air from the fuel system.
Fuel feed pump	This is a mechanical pump used to feed fuel to the fuel injection pump. It is built into the fuel injection pump.
Filler port (engine oil)	Filler port for engine lube oil.
Filler port (marine gear oil)	Filler port for marine gear lube oil. Located on the top of the marine gear case.
Dipstick (engine oil)	Gauge stick for determining the level of the engine oil.
Lube oil filter	Filters fine metal fragments and carbon from the lube oil. The filter is a cartridge type, and the inner element should be replaced before clogging occurs.
[Cooling Water System]	This engine is cooled by 2 cooling systems: fresh water and seawater.
• Fresh water cooler (Built-in fresh water tank)	The tank stores the fresh cooling water and is built into the fresh water cooler. Cooling seawater passes through the fresh water cooler to cool the fresh water by heat exchange.
• Cooling water pump	Located on top of the fresh water tank the filler cap closes the filler port. It has two pressure regulating valves (pressure valve and vacume valve).
• Filler cap	When the cooling water temperature rises, the pressure inside the fresh water tank increases causing the pressure valve in the filler cap to open. Hot water and steam pass through a rubber hose to the subtank to condense the hot water. (The filler port and the subtank are connected by a rubber hose.)
• Subtank	When the load is reduced and the cooling water temperature falls, the pressure in the fresh water tank is lowered, and this activates the vacume valve in the filler cap causing the cool water in the subtank to return to the fresh water tank. This process reduces the consumption of cooling water.
Oil cooler (engine oil)	This heat exchanger cools the engine oil with seawater.
Oil cooler (marine gear oil)	This heat exchanger cools high temp. marine gear oil with seawater. (KBW21, KMH4A)
Turbocharger	With the pressurized intake air feeding device the exhaust gas turbine is rotated by exhaust gas, and the power is used to rotate the blower. This pressurizes the intake air for sending to the cylinder gives high power output.
Intercooler	This heat exchanger cools the pressurized intake air from the turbocharger with seawater and increases the intake air quantity.
Starter motor	This is a DC motor for electrical starting. Electric current causes the pinion gear to engage with the ring gear on the flywheel to start the engine.
Alternator	This is a AC generator built in the rectifier and regulator which rotates by V-belt drive to charge the battery during operation.

2.5 Operation Equipment


Explanation of the equipment used to operate the engine.

2.5.1 Instrument Panel


OPTION

The instrument panel is located in the cockpit, separate from the engine. The following instruments enable you to start and stop the engine and to monitor its condition during operation.


◆ B type




◆ New B type



◆ C type



◆ New C Type



No.	Model	B	C	New B	New C	
7	Switch unit	Key switch (Starter switch)	O	O	O	O
8		Engine stop switch	O	O	O	O
10		Alarm buzzer	O	O	O	O
9		Alarm buzzer stop switch	x	O	O	O
11		Illumination switch for meters	O	O	O	O
11		Lamp check	O	x	x	x
6	Alarm lamp unit	Battery not charging	O	O	O	O
		C.W. high temp.	O	O	O	O
		L.O. low press.(engine)	O	O	O	O
		Fuel filter	x	x	x	O
		Sail drive leak	x	x	Δ	O
		Fuel empty	x	x	O	Δ
1	Tachometer	Tachometer with hour meter	x	x	O	O
		Tachometer	O	O	-	-
2		Hour meter	x	O	-	-
4	Sub meter unit	C.W. temp. meter	x	O	x	O
3		L.O. press. meter	x	O	x	O
12	Clock unit	Quartz clock	x	x	Δ	Δ

O: Available x: Not available Δ: Optional

(1) Meters

The following meters are located in the upper center part of the instrument panel.

- ◆ B/C and New B/C type panels use analog electric systems and have a pointer indicator.

Turn the panel light switch (illumination switch) ON for easy viewing.

- Tachometer
The engine speed is indicated. Engine speed can be monitored.
- Hour meter
The number of hours of operation is indicated, and can be used as a guide for periodic maintenance checks.
- Cooling Water Temperature Meter (C, New C)
The cooling water temperature is indicated. Enables monitoring of the cooling condition of the engine.
- Lube Oil Pressure Meter (C, New C)
The engine oil pressure is indicated.
Enables monitoring of the condition of the engine's lube oil.

(2) Alarm Devices

When there is some problem during operation, the alarm buzzers and lamps will come on.

- Alarm buzzers
When the various alarm lamps come on, the alarm buzzers will come on at the same time and continue to sound. However, no alarm buzzer will sound when the charge lamp comes on.
- Buzzer stop switch
When the buzzer sound is no longer necessary, it can be turned off with the Buzzer stop switch.
- Alarm lamps
The alarm monitor window indicates the trouble spot when one of the symbols shown below lights up. When operation is normal the alarm lights are off; however, should some problem arise, the sensors will pick it up and cause the light behind the appropriate symbol to come on.



1. BATTERY CHARGE

When the charge is abnormal, the lamp will come on. When charging begins the lamp will go off. (Alarm buzzer will not sound when the lamp comes on.)



2. C.WATER TEMP

When the temperature of the cooling fresh water exceeds the maximum (95 degree C or higher), the lamp will light. Continuing operation at temperatures exceeding the maximum will result in damage and seizure. Check the load and the cooling system for any abnormalities.



3. LUB.OIL PRESS.

When the lube oil pressure falls below specified oil pressure sensor will detect this and the lamp will come on. Continuing operation with insufficient oil will result in damage and seizure. Check the oil level.



4. FUEL FILTER (New C)

When the drain inside the water separator in the fuel filter becomes excessive, the sensor will cause the lamp to come on. Clean out the drain in the water separator. If operation is continued without cleaning, it will become impossible to feed fuel to the engine or damage and seizure of the fuel injection pump will result.



5. SAIL DRIVE LEAK (New C, New B(optional))

When the seal rubber attached between sail-drive and hull is damaged and sea water leaks into between the seal rubbers, the lamp comes on. If this happens, stop the engine and quickly return to the nearest port under sail for repairs.




6. FUEL EMPTY (New B, New C(optional))

When the amount of fuel in the tank is insufficient, the sensor will activate the lamp. Fill with fuel.

(3) Starter Switch

This is the switch for starting engine operation. It is a rotary-type 3-step switch. Position is changed by turning the key in the switch.

- OFF is the position where the engine is stopped. All current is cut off. The key can be inserted and removed in this position.
- ON is the position for operation. Current flows to the instruments and alarm devices.
- START is the position for starting. When the starter motor turns, the engine starts. The key returns automatically to the ON position when you remove your hand.



GLOW is the position for turning on the air heater. The air heater (OPTION) aids starting during cold conditions by warming up the intake air before starting.


Note: Neutral Safety Switch

OPTION for KM4A KMH4A

The engine can only be started when the clutch is in Neutral. If an attempt is made to start the engine in any other position, the neutral safety switch will operate to make starting impossible.

(4) Stop button

The engine is stopped by pushing the stop button on the right of the control panel. When the stop button is pushed, the solenoid valve on the fuel injection pump works to cut off the fuel supply and stop the engine. Continue to push the stop button until the engine has come to a complete stop.





Suggest:

For more complete manuals. Please go to the home page.



<https://www.ebooklibonline.com>

If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading

2.5.2 Remote Control Handle

This engine is controlled by the remote control handle located in the cockpit. The speed control lever on the engine side and clutch lever on the marine drive are connected by remote control cable with the various remote control handles in the cockpit (We recommend you a single handle remote control device). There are the following kinds of remote control handles. When using other kinds of remote control devices, consult their operation manuals.





(1) Morse Remote Control Handle

OPTION

This is a single-handle remote control device connected by a remote control cable. It operates the clutch to neutral, forward, and reverse and controls the engine speed.

Model MT-3 : Top mounting type.

Model MV : Side mounting type.



The labels for operation on the handle are:

- ΔFWD: Forward
- NEUTRAL: Clutch disengaged position
- THROTTLE: Position to reduce engine speed
- ▽REV: Reverse

Operation of the handle is as follows:


- Starting and stopping
Put the handle in NEUTRAL.
This puts the clutch in the cut-off position (stop) and idles the engine at a low speed.
- Forward
Move the handle from NEUTRAL to ΔFWD(forward).
This engages the clutch in forward and simultaneously increases the engine speed.
Pushing the handle further in the same direction increases engine speed to full speed.
- Reverse
Move the handle from NEUTRAL to ∇REV(reverse).
This engages the clutch in reverse and simultaneously increases the engine speed.
Pushing the handle further in the same direction increases engine speed to full speed.
- Free throttle operation
When the boat is stopped (clutch is in neutral position), the idling speed of the engine can be increased in the following manner.

1. Leave the handle lever in **NEUTRAL**.
2. Disengage the clutch.

MT-3: Pull out the handle lever all the way.

MV: Pull out the free throttle button next to the handle lever.


3. With the lever or button pulled out, move the handle lever in either the forward or reverse direction to increase idling speed.



- Returning to normal operation from free throttle operation.

MT-3: Return the handle lever to NEUTRAL. The lever will return automatically to the normal position.

MV: Return the handle lever to NEUTRAL and push the free throttle button in.



<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>