



2000 HARLEY-DAVIDSON®

**FLT MODELS
SERVICE MANUAL**
OFFICIAL FACTORY MANUAL

2000 FL 1450cc 5-SPEED MODELS

SERVICE MANUAL

The maintenance and repair information in this manual
applies to all 2000 FL models.

©COPYRIGHT 1999
HARLEY-DAVIDSON MOTOR COMPANY
ALL RIGHTS RESERVED
P.N. 99483-00

MAINTENANCE 1

CHASSIS 2

ENGINE 3

FUEL SYSTEM 4

ELECTRIC STARTER 5

DRIVE 6

TRANSMISSION 7

ELECTRICAL 8

FUEL INJECTION 9

INDEX I

FOREWORD

This service and repair manual has been prepared with two purposes in mind. First, it will acquaint the reader with the construction of the Harley-Davidson motorcycle and assist him/her in performing basic maintenance and repair work. Secondly, it will introduce the professional Harley-Davidson technician to the latest field-tested and factory-approved repair methods. We hope that this manual makes your association with Harley-Davidson products both pleasant and profitable.

HOW TO USE THIS MANUAL

This manual is divided into nine sections, as identified on the first page of this book. For quick and easy reference, all page numbers are preceded by the section number. Therefore, if looking for the electrical section, simply open up the book to those pages preceded by "8-". If referencing the engine section, flip to those pages beginning with "3-," and so on.

NOTE

Carefully read all information on servicing a part or assembly before actually starting the repair work. This will save time by preventing needless disassembly.

PREPARATION FOR SERVICE

Proper preparation is very important for efficient service work. A clean work area at the start of each job will allow you to perform the repair as easily and quickly as possible, and reduce the incidence of misplaced tools and parts. A motorcycle that is excessively dirty should be cleaned before work is begun. Cleaning will often uncover trouble spots or areas that need attention. Gather tools, instruments and parts before work is started. Interrupting a job to collect these items results in needless delay and distraction. Special tools made available for service work are listed in Section 1.

WARNING

Gasoline is extremely flammable and highly explosive. Always stop engine and do not smoke or allow open flame or sparks when refueling or servicing the fuel system.

SERVICE BULLETINS

In addition to the information provided in this Service Manual, Service Bulletins are issued to Harley-Davidson Dealers on a periodic basis. Service Bulletins cover interim engineering changes and supplementary information. Consult the Service Bulletins to keep your product knowledge current and complete.

USE GENUINE REPLACEMENT PARTS

WARNING

When replacement parts are required, use only genuine Harley-Davidson parts, or at least parts with equivalent characteristics, including type, strength and material. Failure to do so may result in product malfunction and possible injury to the operator and/or passenger.

To ensure a satisfactory and lasting repair job, carefully follow the instructions in this manual and use only genuine Harley-Davidson replacement parts. Behind the emblem bearing the words GENUINE HARLEY-DAVIDSON is almost 100 years of design, research, manufacturing, testing and inspecting experience. This is your insurance that the parts you are using will fit right, operate properly and last longer.

PRODUCT REFERENCES

When reference is made in this manual to a specific brand name product, tool or instrument, an equivalent product, tool or instrument may be used in place of the one mentioned.

All tools mentioned in this SERVICE MANUAL with HD or J prefix must be ordered through Kent-Moore.

Direct all mail orders and general correspondence to the address below:

Kent-Moore
28635 Mound Road
Warren, Michigan 48092-3499
Telephone: 1-800-345-2233

Direct all product returns, warranty or otherwise, to the following address:

Kent-Moore
attn: Returned Goods
655 Eisenhower Drive
Owatonna, Minnesota 55060-0995

Loctite Products

Some procedures in this manual call for the use of Loctite products. If you have questions regarding correct use of Loctite products or where to obtain them, please call Loctite Corp. at 1- 800-323-5106.

WARNING

Follow the directions listed on all Loctite products. Read all labels, warnings and cautions carefully before use.

CONTENTS

Photographs and illustrations may not necessarily depict the most current model or component, but are based on the latest production information available at the time of publication.

Harley-Davidson Motor Company reserves the right to change specifications, equipment or designs at any time without notice and without incurring obligation.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

TABLE OF CONTENTS

	Page No.		Page No.
SECTION 1 – MAINTENANCE		Tools	1-13
Service Intervals		Scheduled Maintenance Table	1-28
Break-In Maintenance	1-1	Scheduled Maintenance Procedures	
Check at First 1000 Miles (1600 km)	1-1	Battery	1-33
Safe Operating Maintenance	1-1	Engine Oil/Engine Oil Filter	1-33
Regular Service Intervals	1-1	Primary Chain	1-34
Storage	1-1	Primary Chain Lubricant	1-35
Removal from Storage	1-2	Clutch Adjustment	1-36
		Transmission Lubricant	1-37
		Tires	1-37
Fluid Requirements		Steering Head Bearings	1-38
General	1-3	Front Fork Oil	1-38
United States System	1-3	Brake Fluid	1-38
British Imperial System	1-3	Brake Pad Linings and Discs	1-38
Metric System	1-3	Drive Belt	1-39
Silicone Brake Fluid	1-3	Rear Swingarm Pivot Shaft Nut	1-39
Front Fork Oil	1-3	Rear Shock Absorbers	1-39
Engine Oil	1-3	Air Cleaner (Carbureted)	1-40
Fuel	1-3	Fuel Tank Filter (Carbureted)	1-41
Transmission Lubricant	1-3	Fuel System Lines and Fittings	1-42
Primary Chaincase Lubricant	1-3	Enrichener Control	1-42
Cable Lubricant	1-3	Throttle Cables	1-43
Electrical Contact Grease	1-3	Lubrication	1-43
		Adjustment	1-45
		Engine Mounts	1-46
Fastener Torque Values		Spark Plugs	1-47
English	1-4	Electrical Components	1-47
Equivalents for English Fasteners	1-4	Engine Idle Speed	1-47
Metric Conversion Table	1-5	Fasteners	1-48
		Road Test	1-48
		SECTION 2 – CHASSIS	
Troubleshooting		Specifications	
General	1-6	Dimensions	2-1
Engine	1-6	Weight	2-1
Lubrication System	1-7	Capacities	2-1
Electrical System	1-7	Tire Data	2-2
Carburetor	1-8	Rear Wheel Sprocket	2-2
Transmission	1-8	Torques	2-2
Brakes	1-8	Vehicle Identification Number (VIN)	2-3
Handling	1-8		
		Front Wheel	
Shop Practices		General	2-4
Repair Notes	1-9	Preliminary Inspection	2-4
Repair and Replacement Procedures	1-9	Removal	2-4
Cleaning	1-10	Disassembly	2-4
		Cleaning and Inspection	2-5
		Assembly	2-5
		Installation	2-7
		Rear Wheel	
Tool Safety		General	2-9
Air Tools	1-11	Preliminary Inspection	2-9
Wrenches	1-11	Removal	2-9
Pliers/Cutters/Prybars	1-11		
Hammers	1-11		
Punches/Chisels	1-11		
Screwdrivers	1-11		
Ratchets and Handles	1-11		
Sockets	1-11		
Storage Units	1-12		

Disassembly	2-9
Cleaning and Inspection	2-10
Assembly	2-10
Installation	2-12

Checking Cast Rim Runout	2-14
---------------------------------------	-------------

Wheel Lacing - 16 Inch Rim	2-15
---	-------------

Truing Laced Wheel	2-18
---------------------------------	-------------

Tires and Tubes

General	2-20
Removal	2-20
Cleaning and Inspection	2-20
Installation	2-20
Checking Tire Radial Runout	2-22
Checking Tire Lateral Runout	2-22
Wheel Balancing	2-23

Vehicle Alignment	2-24
--------------------------------	-------------

Front Brake Master Cylinder

General	2-27
Removal/Disassembly	2-27
Cleaning and Inspection	2-29
Assembly/Installation	2-29

Rear Brake Master Cylinder

Removal/Installation	
Preliminary Instructions	2-31
Brake Pedal/Master Cylinder Assembly	2-31
Rear Brake Line	2-32
Final Instructions	2-33
Master Cylinder Assembly	
Disassembly	2-35
Cleaning and Inspection	2-35
Assembly	2-37

Front Brake Caliper

Inspection	2-39
Front Brake Pad Replacement	2-39
Caliper Removal	2-41
Caliper Disassembly	2-41
Cleaning and Inspection	2-42
Caliper Assembly	2-43
Caliper Installation	2-43

Rear Brake Caliper

Inspection	2-45
Rear Brake Pad Replacement	2-45
Caliper Removal	2-46
Caliper Disassembly	2-47
Cleaning and Inspection	2-48
Caliper Assembly	2-49
Caliper Installation	2-49

Bleeding Hydraulic Brake System	2-51
--	-------------

Front Forks

Changing Fork Oil	2-52
Removal/Disassembly	2-53
Cleaning and Inspection	2-55
Assembly/Installation	2-55

Fork Stem and Bracket Assembly

Lubrication	2-56
Adjustment	2-56
Removal	2-57
Cleaning and Inspection	2-57
Assembly	2-57
Installation	2-58
Steering Head Bearing Race Removal	2-58

Front/Rear Air Suspension

General	2-59
Front Air Suspension	2-59
Rear Air Suspension	2-59
System Check/Removal/Installation	2-59
Front Fork Air Control	2-61
Rear Shock Air Control	2-62

Rear Shock Absorbers

Adjustment	2-64
Removal	2-64
Disassembly	2-64
Cleaning and Inspection	2-64
Assembly	2-64
Installation	2-64

Rear Swing Arm

Removal	2-66
Disassembly	2-67
Assembly	2-67
Installation	2-68
Engine Front Rubber Mount	2-69

Throttle Cables (Non-Ultra)

Adjustment	2-70
Removal	
Throttle Side	2-70
Carburetor/Induction Module Side	2-72
Cleaning and Inspection	2-72
Installation	
Throttle Side	2-72
Carburetor/Induction Module Side	2-73
Lubrication	2-74

Clutch Cable

Adjustment	2-75
Removal	2-75
Installation	2-76

Seat

Removal/Installation	
FLHT	2-78
FLHTC/U	2-78
FLHR	2-79

	Page No.
FLHRC	2-79
FLTR	2-80
Seat Retention Nut Replacement	2-80
Saddlebags	
Opening	2-81
Closing	2-81
Removal	2-82
Installation	2-82
Inspection and Repair	2-82
Tour-Pak	
Removal/Installation	
FLHTC	2-84
FLHTCU	2-84
Tour-Pak Lights/Backrest/Speaker	
Side Marker Lights - FLHTC/U	2-86
Wrap-Around Light Assembly - FLHTCU	2-87
Passenger Backrest - FLHTCU	2-88
Speaker Box - FLHTCU	2-88
Lower Fairing/Glove Boxes	
Removal/Installation	2-89
Upper Fairing/Windshield (FLHT/C/U)	
Removal/Installation	
Outer Fairing/Windshield	2-90
Fairing Cap	2-91
Inner Fairing	2-92
Upper Fairing/Windshield (FLTR)	
Removal/Installation	
Windshield Only	2-97
Outer Fairing	2-97
Bezel	2-99
Instrument Nacelle	2-100
Inner Fairing	2-101
Glove Box Door/Hinge	2-105
Windshield/Headlamp Nacelle (FLHR)	
Removal/Installation	
Windshield	2-107
Headlamp Nacelle	2-107
Front Fender	
Removal	2-109
Installation	2-109
Rear Fender	
Removal	2-111
Installation	2-112
Jiffy Stand	
General	2-114
Removal	2-114
Installation	2-115
Exhaust System	
Removal	2-116
Installation	2-116

SECTION 3 – ENGINE

Specifications

Specifications	3-2
Service Wear Limits	3-4
General Information	3-5
How to Use This Section	3-14
Stripping Motorcycle for Service	3-16
Assembling Motorcycle After Stripping	3-17
Removing Engine From Chassis	3-20
Installing Engine in Chassis	3-25
New Tools	3-31

Top End Overhaul

Disassembly	3-35
Assembly	3-39

Bottom End Overhaul

Disassembly	3-47
Assembly	3-49

Subassembly Service and Repair

Top End

Breather Assembly	3-55
Rocker Arm Assembly	3-56
Push Rods/Lifters/Covers	3-58
Cylinder Head	3-61
Valve Guide Replacement	3-63
Valve and Seat Refacing	3-66
Cylinder	3-71
Piston	3-73
Upper Connecting Rod	3-76
Upper Connecting Rod Bushing	3-76
Reaming Upper Rod Bushing	3-77
Honing Upper Rod Bushing	3-78

Bottom End

Cam Support Plate	3-81
Crankshaft Bushing	3-81
Reaming Crankshaft Bushing	3-82
Camshafts/Camshaft Bearings	3-83
Cam Chain Tensioners	3-87
Oil Pressure Relief Valve	3-87
Cam Needle Bearings	3-88
Oil Pump	3-91
Crankcase	3-93
Crankshaft (Roller) Bearing	3-93
Piston Jets	3-94
Sprocket Shaft (Timken) Bearing	3-94
Cylinder Studs	3-100
Pipe Plug and Oil Fittings	3-100
Flywheel/Connecting Rod Assembly	3-102

SECTION 4 – FUEL SYSTEM

Specifications

CVH Carburetor Jet Sizes	4-1
Fuel Tank Capacity	4-1
Torques – All Models	4-1

Carburetor

General	4-2
Troubleshooting	4-3
Operation	4-5
Adjustments	4-7
Operation Check – Vacuum Piston	4-7
Removal	4-9
Disassembly	4-9
Cleaning and Inspection	4-9
Assembly	4-11
Installation	4-12

Air Cleaner (Carbureted Models)

General	4-13
Removal	4-13
Cleaning and Inspection	4-13
Installation	4-14

**Vacuum Operated Fuel Valve
(Carbureted Models)**

General	4-15
Troubleshooting	4-15
Removal/Draining Fuel Tank	4-15
Cleaning and Inspection	4-16
Installation	4-16
Diaphragm Replacement	4-17
Vacuum Test	4-17

Fuel Tank

FLHT/C, FLTR (Carbureted)	
Complete Removal	4-18
Cleaning and Inspection	4-18
Installation (After Complete Removal)	4-19
Partial Removal	4-19
Installation (After Partial Removal)	4-20
FLHR (Carbureted)	
Complete Removal	4-21
Installation (After Complete Removal)	4-21
Partial Removal	4-22
Installation (After Partial Removal)	4-22

**Evaporative Emissions Control System—
California Models Only**

General	4-23
Troubleshooting	4-24
Vapor Valve	4-24
Charcoal Canister	4-24

SECTION 5 – ELECTRIC STARTER**Specifications**

Starter	5-1
Service Wear Limits	5-1
Torques	5-1

Starter System

General	5-2
Operation	5-2
Starting System Diagnosis (Flow Chart)	5-4

Diagnostics/Troubleshooting

General	5-6
Voltage Drops	5-6
Starting Activation Circuits	5-7
Troubleshooting	5-8

Starter Relay

Removal/Installation	5-10
Relay/Starter Tests	5-10
Starter Relay Test #1	5-10
Starter Relay Test #2	5-10
Starter Current Draw Test	5-11

Starter

Removal	5-12
Installation	5-12
Testing Assembled Starter	5-12
Disassembly, Testing and Repair	5-15
Assembly	5-18

Starter Solenoid

General	5-20
Disassembly	5-20
Assembly	5-20

Starter Jackshaft

Removal/Disassembly	5-21
Assembly/Installation	5-22

SECTION 6 – DRIVE**Specifications**

General	6-1
Chains and Belts	6-1
Sprockets	6-1
Clutch	6-1
Torques	6-1

Primary Chain and Sprockets

Primary Chain Adjustment	6-2
Adjuster Shoe Replacement	6-2
Disassembly	6-4
Cleaning and Inspection	6-4
Assembly	6-4

Clutch

Adjustment	6-5
Removal/Installation	6-6
Partial Disassembly (Clutch Pack Only)	6-6
Assembly (Clutch Pack Only)	6-6
Cleaning and Inspection	6-6
Complete Disassembly (Clutch Pack and Bearing) ..	6-8
Assembly (Clutch Pack and Bearing)	6-9

Secondary Drive Belt and Sprockets

Adjustment and Alignment	6-10
Inspection	6-10
Belt Replacement	
Removal	6-11
Installation	6-11

	Page No.
Transmission Sprocket	
Removal	6-13
Cleaning and Inspection	6-14
Installation	6-14
Rear Wheel Sprocket	
Removal	6-15
Cleaning and Inspection	6-16
Installation	6-16

Primary Chaincase

General	6-17
Lubrication	6-17
Removal	6-18
Inspection and Repair	6-19
Disassembly/Assembly	
Mainshaft Bearing and Lip Seal	6-20
Mainshaft Bearing Inner Race	6-20
Starter Jackshaft Bushing and Lip Seal	6-21
Shifter Bracket Bushings	6-22
Installation	6-23

SECTION 7 – TRANSMISSION

Specifications

General	7-1
Shifter Forks	7-1
Shifter Cam Assembly	7-1
Mainshaft	7-1
Countershaft	7-2
Torques	7-2

Shifter Linkage

Adjustment	7-3
----------------------	-----

Shifter Cam Assembly/Shifter Forks

Disassembly	7-5
Cleaning and Inspection	7-6
Assembly	7-7

Clutch Release Cover

Removal/Disassembly	7-10
Cleaning and Inspection	7-10
Assembly/Installation	7-10

Mainshaft/Countershaft

Removal	7-12
Disassembly	7-12
Cleaning and Inspection	7-13
Assembly	7-13
Installation	7-16

Main Drive Gear

Removal	7-18
Cleaning and Inspection	7-18
Needle Bearing Replacement	7-19
Installation	7-19
Countershaft Needle Bearing Replacement	7-22

Transmission Case/Oil Pan

General	7-23
-------------------	------

Removal	
Transmission Case and Oil Pan	7-23
Oil Pan Only	7-25
Cleaning and Inspection	7-25
Installation	
Oil Pan Only	7-25
Transmission Case and Oil Pan	7-26

SECTION 8 – ELECTRICAL

Specifications

Ignition Timing	8-1
Alternator System	8-1
Battery	8-1
Fuses	8-1
Spark Plug	8-1
Bulb Chart	8-2

Ignition System (Carbureted)

General	8-3
-------------------	-----

System Diagnostics

Checking for Trouble Codes	8-5
Retrieving Trouble Codes	8-5
Breakout Box Installation	8-9
Diagnosing System Problems	
Diagnostic Check	8-10
Chart A-1, Check Engine Lamp Not Illuminated	8-12
Chart A-2, Check Engine Lamp On Continuously	8-14
Chart A-3, Engine Cranks But Will Not Start	8-16
Chart A-4, No Spark and No Check Engine Lamp	8-20
Chart C, Misfire	8-22
Trouble Code 12, MAP Sensor	8-24
Trouble Code 16, Battery Voltage	8-26
Trouble Codes 24 and 25, Ignition Coil	8-28
Trouble Code 35, Tachometer	8-32
Trouble Code 41, Crank Position Sensor	8-34
Trouble Code 42, Cam Position Sensor	8-36
Trouble Code 44, Bank Angle Sensor	8-38
Trouble Codes 52, 53, 54, 55, Ignition Module Failure	8-39
Code 56, Crank Position and Cam Position Sensor Timing	8-39

Ignition Module

Removal	8-40
Installation	8-40

Engine Sensors

Manifold Absolute Pressure Sensor	8-40
Camshaft Position Sensor	8-41
Crankshaft Position Sensor	8-41
Bank Angle Sensor	8-41

Spark Plugs/Spark Plug Cables

Spark Plugs	
Removal	8-42
Inspection	8-42
Cleaning	8-42

Adjustment	8-42
Installation	8-42
Spark Plug Cables	
Removal	8-43
Inspection	8-43
Installation	8-43

Ignition Coil

General	8-43
Troubleshooting	8-43
Removal	8-44
Installation	8-44

Charging System

General	8-45
Troubleshooting (Carbureted)	8-46

Alternator/Stator

Removal	8-50
Cleaning and Inspection	8-51
Installation	8-51

Voltage Regulator

Removal	8-54
Installation	8-54

Battery

General	8-57
Battery Testing- Voltmeter Test	8-57
Disconnection and Removal	8-58
Cleaning and Inspection	8-58
Battery Charging	8-58
Battery Testing- Load Test	8-59
Battery Cable Routing	8-60
Battery Installation and Connection	8-60
Storage	8-61

Headlamp (FLHR/C, FLHT/C/U)

Removal	8-62
Installation	8-62
Bulb Replacement	8-62
Adjustment	8-63

Headlamp (FLTR)

Removal	8-65
Installation	8-65
Bulb Replacement	8-65
Adjustment	8-66

Passing Lamps

Adjustment	8-68
Passing Lamp Bulb Replacement	8-68
Passing Lamp Bracket Removal/Installation	8-68
Passing Lamp Removal/Installation	8-70

Tail Lamp

Removal	8-71
Installation	8-71
Circuit Board/Tail Lamp Bracket Assembly	
Removal	8-71
Installation	8-72

Fender Tip Lamps

Front Fender Tip Lamp	
Removal	8-73
Installation	8-73
Front Fender Tip Lamp Jumper Harness	
Removal	8-73
Installation	8-74
Rear Fender Tip Lamp	
Removal	8-75
Installation	8-76

Turn Signal Lamps

General	8-78
Bulb Replacement	8-78
Front Turn Signal Lamp	
Removal	8-78
Installation	8-79
Rear Turn Signal Lamp	
Removal	8-80
Installation	8-80

Turn Signal Module

General	8-82
Distance Test	8-82
Alternate Time Test	8-83
Rider Control	8-83
Removal/Installation	8-83
Troubleshooting	8-84

Ignition Light Key Switch and Fork Lock Assembly

Troubleshooting	8-88
Removal/Installation	
FLHT/C/U (Domestic)	8-88
FLHT/C/U (International)	8-90

Fairing Cap Switches (FLHTC/U)

Removal	8-92
Installation	8-93

Instrument Nacelle Switches (FLTR)

Removal	8-95
Installation	8-97

Handlebar Switches

General	8-100
Removal	8-100
Installation	8-101
Switch Repair/Replacement	8-105

Stoplight Switches

Front Stoplight Switch	8-116
Rear Stoplight Switch	8-116

Neutral Switch

General	8-117
Removal	8-117
Installation	8-117

Horn

Troubleshooting	8-118
Removal	8-118
Installation	8-118

Cigarette Lighter

Troubleshooting	8-119
Removal	8-119
Installation	8-119

Gauges/Instruments

General	8-120
Fuel Level Gauge	8-120
Fuel Gauge - FLHR/C	8-121
Low Fuel Level Lamp - FLHTCU, FLTR	8-121
Low Fuel Level Lamp - FLHR/C	8-121
Oil Pressure Gauge and Indicator Light	8-122
Ambient Air Temperature Gauge	8-122
Voltmeter	8-123
Speedometer	8-123
Tachometer	8-123
Indicator Lights - FLHR/C	8-124
Removal/Installation (FLHT/C/U)	
2 Inch Diameter Gauges	8-124
4Inch Diameter Gauges	8-125
Speedometer Speed Sensor	8-125
Speedometer (FLHT/C/U, FLTR)	8-126
Speedometer (FLHR/C)	8-126
Indicator Lamps (FLHT/C/U, FLTR)	8-127
Indicator Lights (FLHR/C)	8-128

Electronic Speedometer Diagnostics

General	8-129
Onboard Diagnostics	8-129
Reset Switch	8-129
Diagnostic Mode	8-129
Diagnostic Flow Charts	8-131

Electronic Speedometer Performance

General	8-134
Speedometer Tests	
Frequency Input Test	8-134
Needle Sweep Test	8-135
Speedometer Sensor Test	8-135

Fuel Level Gauge Sending Unit (Carbureted)

Removal/Installation	
All Models Except FLHR	8-137
FLHR Models	8-138

Cruise Control (FLHTCU)

General	8-140
System Operation	8-140
Troubleshooting	8-140
Cruise Inoperative Diagnostics	8-141
Cruise Dropout Diagnostics	8-143
Cable Adjustment	8-157
Cable Lash Initialization	8-157
Removal/Installation	

Throttle/Idle Cables	8-158
Cruise Cable	8-160
Cruise Control Module	8-161
Ultra Overlay Harness	8-162
Cruise Control Switches	8-162

Premium Sound System (FLHTC/U, FLTR)

Symptoms	8-163
Diagnostic Mode Overview	8-163
Diagnostic Mode Group 1	8-164
Diagnostic Mode Group 2	8-165
1. Audio Control Inoperative	8-166
2. Mode Control Inoperative	8-168
3. No Sound in One or More Speakers	8-172
4. Automatic Volume Control (AVC) Inoperative	8-175
5. Poor Stereo Reception	8-177
6. No Power	8-178
7. Tape Will Not Eject	8-180
8. No Sound in One or More Headsets	8-182
9. Rear Headset Volume/PTT Inoperative	8-184
10. Intercom Inoperative	8-188
11. CB Receiver Inoperative	8-190
12. CB Transmitter Inoperative	8-192
13. PTT/Squelch Control Inoperative	8-196
14. Handheld Microphone PTT Inoperative	8-198
15. No CB Audio in Headset in Center Position	8-200

Removal/Installation

Radio	8-201
Front Fairing Speakers	8-202
Console Pod Assembly	8-203
Intercom/CB Switches	8-204
Front Headset Receptacle	8-204
Rear Headset Receptacle	8-205
Rear Passenger Switches	8-206
Rear Speakers	8-208
Fuse Blocks	8-208
CB Loading Coil	8-209
Ultra Overlay Harness	8-209
Radio Antenna Cable	8-209
CB Antenna Cable	8-209

Wiring Harnesses and Cables**Removal/Installation**

Main Harness	8-210
Interconnect Harness	8-215
Ultra Overlay Harness	8-218
Radio Antenna Cable	8-222
CB Antenna Cable	8-224

SECTION 9 – FUEL INJECTION**Introduction**

Sequential Port Fuel Injection System	9-5
General Information	9-5
Component Descriptions	9-5
EFI Component Schematic	9-6
EFI Pictorial Schematic	9-7

System Diagnostics

Introduction	9-12
Checking for Trouble Codes	9-13

Retrieving Trouble Codes	9-15
Tools	9-19
Diagnosing System Problems	9-22
Diagnostic Check	9-26
Chart A-1, No Check Engine Lamp	9-28
Chart A-2, Check Engine Lamp On Continuously ..	9-30
Chart A-3, Engine Cranks But Will Not Start	9-32
Chart A-4, No ECM Power	9-36
Chart B-1, Fuel System Electrical Test	9-39
Chart B-2, Fuel Pressure Test	9-44
Chart C-1, Idle Speed Control	9-48
Chart C-2, Misfire at Idle or Under Load	9-50
Trouble Code 11, Throttle Position Sensor	9-52
Trouble Code 12, Barometric Pressure Sensor	9-54
Trouble Code 14, Engine Temperature Sensor	9-56
Trouble Code 15, Intake Air Temperature Sensor ..	9-58
Trouble Code 16, Battery Voltage	9-60
Trouble Codes 23 and 32, Fuel Injector	9-62
Trouble Codes 24 and 25, Ignition Coil	9-65
Trouble Code 33, Fuel Pump Relay	9-68
Trouble Code 35, Tachometer	9-70
Trouble Code 41, Crank Position Sensor	9-72
Trouble Code 42, Cam Position Sensor	9-74
Trouble Code 44, Bank Angle Sensor	9-76
Trouble Codes 52, 53, 54, 55, ECM Failure	9-77
Trouble Code 56, Crank Position and Cam Position Sensor Timing	9-77

Removal/Replacement

Electrical Bracket Assembly

General	9-81
Side Cover	9-81
Data Link Connector	9-82
Electrical Relays	9-82
Fuses	9-82
Electronic Control Module	9-83
Barometric Pressure Sensor	9-83
EFI Wire Harness	9-84
EFI Wire Harness Connector Terminal Repair	9-87

Sensors

General	9-88
Barometric Pressure Sensor	9-88
Throttle Position Sensor	9-88
Intake Air Temperature Sensor	9-88
Camshaft Position Sensor	9-88
Crankshaft Position Sensor	9-90
Engine Temperature Sensor	9-91
Bank Angle Sensor	9-91

Fuel Tank Assembly

General	9-93
Fuel Tank , Complete Removal	
FLHTC/U-I, FLTR-I	9-93
FLHR/C-I	9-95
Fuel Tank, Partial Removal	
FLHTC/U-I, FLTR-I	9-97
FLHRC-I	9-98
Console Pod/Canopy, FLHTC/U-I, FLTR-I	9-100
Instrument Console/Canopy, FLHR/C-I	9-101
Fuel Filter Canister	9-104
Fuel Pump	9-104

Fuel Pump Wiring	9-105
Fuel Level Sender	9-106
Canopy Connector/O-Ring	9-106
Fuel Supply/Return Check Valves	9-107

Air Cleaner Assembly

General	9-109
Air Cleaner	9-109
Warm-Slow Idle Speed Adjustment	9-110
Cold Idle Speed Adjustment (Domestic Models) ..	9-110
Charcoal Canister (California Models Only)	9-111

Induction Module Assembly

General	9-113
Induction Module	9-113
Fuel Supply/Return Lines	9-115
Fuel Injectors	9-116
Fuel Pressure Regulator	9-117
Intake Air Temperature Sensor	9-118
Throttle Position Sensor	9-118
Idle Speed Control Actuator	9-120
Cam Lever Assembly	9-121

Ignition System

General	9-124
Ignition Coil	9-124

APPENDIX A—ELECTRICAL CONNECTOR SERVICE AND REPAIR

Deutsch Electrical Connectors

General	A-3
Removing/Disassembling	A-3
Removing/Installing Sockets	A-3
Removing/Installing Pins	A-6
Assembling/Installing	A-6
Crimping Instructions	A-6
Solid Barrel Contact Crimping Instructions	A-8

Amp Multilock Electrical Connectors

Removing Socket/Pin Terminals	A-9
Installing Socket/Pin Terminals	A-9
Crimping Instructions	A-12

Packard Electrical Connectors

General	A-14
Pull-to-Seat Terminals	A-14
Push-to-Seat Terminals	A-17
Crimping Instructions	A-17

Sealed Butt Splice Connectors

A-19

Amp Electrical Connectors

1-Place Connector	A-20
-------------------------	------

Electrical Connector Locations

FLHT/C/U	A-25
FLHR/C	A-31
FLTR	A-33

Wiring Diagrams

A-37

INDEX

I-1

SUBJECT	PAGE NO.
1. Service Intervals	1-1
2. Storage	1-1
3. Fluid Requirements	1-3
4. Fastener Torque Values	1-4
5. Metric Conversion Table	1-5
6. Troubleshooting	1-6
7. Shop Practices	1-9
8. Tool Safety	1-11
9. Tools	1-13
10. Scheduled Maintenance Table	1-28
11. Scheduled Maintenance Procedures	1-33

SERVICE INTERVALS

BREAK-IN MAINTENANCE

WARNING

For the personal welfare of the rider, be sure to follow all of the listed service and maintenance recommendations, since they can affect the safe operation of the motorcycle. Neglect can adversely affect motorcycle operation and handling, which could result in death or serious injury.

The performance of new motorcycle initial service is required to keep new motorcycle warranty in force and to ensure proper emissions system operation.

After a new motorcycle has been driven the first 1000 miles (1600 km), initial service operations should be performed by an authorized Harley-Davidson dealer.

CHECK AT FIRST 1000 MILES (1600 km)

After the first 1000 miles (1600 km), a Harley-Davidson dealer should perform the 1000 mile (1600 km) maintenance listed in the Owner's Manual (or see Scheduled Maintenance Table in this section, page 1-28).

SAFE OPERATING MAINTENANCE

Good maintenance means a safe machine. A careful check of certain equipment must be made after periods of storage

and frequently between the regular service intervals to determine if additional maintenance is necessary.

Check the following items:

1. Tires for correct pressure, abrasions, cuts and wear.
2. Belt for proper tension.
3. Brakes, steering and throttle for responsiveness.
4. Brake fluid level and condition. Hydraulic lines and fittings for leaks. Also, check brake pads and discs for wear.
5. Cables for fraying or crimping and free operation.
6. Engine oil, primary chaincase and transmission fluid levels. Do not overfill oil pan.
7. Wheel spoke tightness, if applicable.
8. Headlight, taillight and turn signal operation.

REGULAR SERVICE INTERVALS

Regular lubrication and maintenance is required to keep Harley-Davidson motorcycles operating at peak performance levels. In addition, regular maintenance will provide for longer motorcycle life and greater riding pleasure.

NOTE

Any alterations to the emission system components, such as carburetor and exhaust system, may be in violation of federal and state laws.

STORAGE

GENERAL

If the motorcycle will not be operated for several months, such as during the winter season, there are several things which should be done to protect parts against corrosion, to preserve the battery and to prevent the buildup of gum and varnish in the carburetor.

This work should be performed by your local Harley-Davidson dealer or other qualified technician following Service Manual procedures.

WARNING

Gasoline is extremely flammable and explosive under certain conditions. Use care when handling gasoline. Do not store motorcycle having gasoline in tank within the home or garage where open flames, pilot lights, sparks or electric motors are present. Doing so may cause an explosion or fire which could result in death or serious injury.

1. Fill fuel tank and add a gasoline stabilizer. Use one of the commercially available gasoline stabilizers following the manufacturer's instructions. Turn fuel supply valve off. Drain all gasoline from carburetor by loosening fuel bowl drain screw one full turn; gasoline will drain through fuel overflow fitting. Retighten drain screw after all gasoline has been drained from carburetor.

OR

1. Drain all gasoline from the fuel tank. Spray the inside of the fuel tank with one of the commercially available rust preventatives. Follow the manufacturer's instructions.
2. Fill the oil pan with clean engine oil.
3. Remove the spark plugs, inject a few squirts of engine oil into each cylinder and crank the engine 5-6 revolutions. Reinstall spark plugs.
4. Grease wheel bearings and install new seals.

5. Adjust primary chain.
6. Check tire inflation. If the motorcycle will be stored for an extended period of time, securely support the motorcycle under the frame so that all weight is off the tires.
7. Wash painted and chrome-plated surfaces. Apply a light film of oil to exposed unpainted surfaces.

⚠ WARNING

Do not apply any oil to brake discs or pads. Oil on discs or pads degrades braking efficiency and can lead to an accident, which could result in death or serious injury.

8. Remove the battery from the motorcycle and fully charge. See CHARGING BATTERY, page 8-58. Charge the battery every month if stored at temperatures below 60° F. (16° C). Charge the battery more frequently if stored in a warm area above 60° F. (16° C).

NOTE

The H-D Battery Tender Automatic Battery Charger (P/N 99863-93TA) may be used to maintain battery charge for extended periods of time without risk of overcharging or boiling.

⚠ WARNING

Always unplug or turn OFF the battery charger before connecting the charger clamps to the battery. Connecting clamps with the charger ON could cause a spark resulting in a battery explosion. A battery explosion may rupture the battery case causing a discharge or spray of sulfuric acid that could result in death or serious injury.

⚠ WARNING

Store the battery out of the reach of children. Inadequate safety precautions could result in death or serious injury.

9. If the motorcycle is to be covered, use a material that will breathe, such as light canvas. Plastic materials that do not breathe promote the formation of condensation, which then leads to corrosion.

REMOVAL FROM STORAGE

NOTE

After extended periods of storage and prior to starting vehicle, place transmission in gear, disengage clutch, and push vehicle back and forth a few times to ensure proper clutch disengagement.

1. Fully charge battery. See CHARGING BATTERY, page 8-58. Install battery in motorcycle.
2. Remove and inspect the spark plugs. Replace if necessary.
3. Clean the air cleaner element.
4. If fuel tank was drained, fill fuel tank with fresh gasoline.
5. If oil feed line was pinched off or plugged, unplug it and reconnect.
6. Start the engine and run until it reaches normal operating temperature.
7. Check engine oil level. Check the transmission lubricant level. Fill to proper levels with correct fluids, if required.
8. Perform all of the checks in the PRE-RIDING CHECKLIST in the Owner's Manual.



Suggest:

For more complete manuals. Please go to the home page.

<https://www.ebooklibonline.com>

If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading

FLUID REQUIREMENTS

GENERAL

United States System

Unless otherwise specified, **all fluid volume measurements in this Service Manual are expressed in United States (U.S.) units-of-measure.** See below:

- 1 pint (U.S.) = 16 fluid ounces (U.S.)
- 1 quart (U.S.) = 2 pints (U.S.)
- 1 gallon (U.S.) = 4 quarts (U.S.)

British Imperial System

Fluid volume measurements in this Service Manual do not include the British Imperial (Imp.) system equivalents. The following conversions exist in the British Imperial system:

- 1 pint (Imp.) = 20 fluid ounces (Imp.)
- 1 quart (Imp.) = 2 pints (Imp.)
- 1 gallon (Imp.) = 4 quarts (Imp.)

Although the same unit-of-measure terminology as the U.S. system is used in the British Imperial (Imp.) system, the actual volume of each British Imperial unit-of-measure differs from its U.S. counterpart. The U.S. fluid ounce is larger than the British Imperial fluid ounce. However, the U.S. pint, quart, and gallon are smaller than the British Imperial pint, quart, and gallon, respectively. Should you need to convert from U.S. units to British Imperial units (or vice versa), refer to the following:

- fluid ounces (U.S.) x 1.042 = fluid ounces (Imp.)
- pints (U.S.) x 0.833 = pints (Imp.)
- quarts (U.S.) x 0.833 = quarts (Imp.)
- gallons (U.S.) x 0.833 = gallons (Imp.)
- fluid ounces (Imp.) x 0.960 = fluid ounces (U.S.)
- pints (Imp.) x 1.201 = pints (U.S.)
- quarts (Imp.) x 1.201 = quarts (U.S.)
- gallons (Imp.) x 1.201 = gallons (U.S.)

Metric System

Fluid volume measurements in this Service Manual include the metric system equivalents. In the metric system, 1 liter (l) = 1,000 milliliters (ml). Should you need to convert from U.S. units-of-measure (or vice versa), refer to the following:

- fluid ounces (U.S.) x 29.574 = milliliters
- pints (U.S.) x 0.473 = liters
- quarts (U.S.) x 0.946 = liters
- gallons (U.S.) x 3.785 = liters
- milliliters x 0.0338 = fluid ounces (U.S.)
- liters x 2.114 = pints (U.S.)
- liters x 1.057 = quarts (U.S.)
- liters x 0.264 = gallons (U.S.)

SILICONE BRAKE FLUID

Use only D.O.T. 5 SILICONE HYDRAULIC BRAKE FLUID, Harley-Davidson Part No. 99902-77 (12 ounce bottle).

FRONT FORK OIL

Use only HYDRAULIC FORK OIL TYPE "E", Harley-Davidson Part No. 99884-80 (16 ounce bottle).

ENGINE OIL

Use proper grade of oil for the lowest temperature expected before next oil change as follows:

Harley-Davidson Type	Viscosity	Harley-Davidson Rating	Lowest Ambient Temperature	Cold Weather Starts Below 50°F (10°C)
HD Multi-grade	SAE 10W40	HD 360	Below 40°F (4°C)	Excellent
HD Multi-grade	SAE 20W50	HD 360	Above 40°F (4°C)	Good
HD Regular Heavy	SAE 50	HD 360	Above 60°F (16°C)	Poor
HD Extra Heavy	SAE 60	HD 360	Above 80°F (27°C)	Poor

FUEL

Use a good quality leaded or unleaded gasoline (87 pump octane or higher). Pump octane is the octane number usually shown on the gas pump.

CAUTION

Using gasolines that have alcohol additives (such as methanol) may cause failure of rubber components in the fuel system and/or internal engine damage.

Transmission Lubricant

Use Harley-Davidson TRANSMISSION LUBRICANT, Part No. 98853-96 (quart) or Part No. 98852-96 (gallon).

Primary Chaincase Lubricant

Use Harley-Davidson PRIMARY CHAINCASE LUBRICANT, Part No. 99887-84 (quart) or Part No. 99886-84 (gallon).

Cable Lubricant

Use Harley-Davidson SUPER OIL, Part No. 94968-85TV, to lubricate clutch and throttle cables.

Electrical Contact Grease

Use Harley-Davidson ELECTRICAL CONTACT GREASE, Part No. 99861-90 (2 ounce tube), on any unsealed connectors.








FASTENER TORQUE VALUES

Torque specifications for specific components are listed in each section at the point of use. When converting to Newton-meters, use the formulas given under the metric chart. For all other fasteners, use the values listed in one of the tables below. In the English table, torque figures are listed in ft-lbs, except those marked with an asterisk (*), which are listed in in-lbs. In the metric table, figures are listed in Newton-meters.

WARNING








The fasteners used on Harley-Davidson motorcycles have specific strength, finish and type requirements to perform properly in the assembly and operating environment. Use only genuine Harley-Davidson replacement fasteners tightened to the proper torque. Substitution can cause fastener failure, which could result in death or serious injury.

ENGLISH

FASTENER	TYPE	MINIMUM TENSILE STRENGTH	MATERIAL	BODY SIZE OR OUTSIDE DIAMETER																	
				# (number)						in. (inches)											
				2	3	4	5	6	8	10	1/4	5/16	3/8	7/16	1/2	9/16	5/8	3/4	7/8	1	
	SAE 2 STEEL	74,000 PSI	LOW CARBON									6	12	20	32	47	69	96	155	206	310
	SAE 5 STEEL	120,000 PSI	MEDIUM CARBON HEAT TREAT							14*	22*	10	19	33	54	78	114	154	257	382	587
	SAE 7 STEEL	133,000 PSI	MEDIUM CARBON ALLOY									13	25	44	71	110	154	215	360	570	840
	SAE 8 STEEL	150,000 PSI	MEDIUM CARBON ALLOY									14	29	47	78	119	169	230	380	600	900
	SAE 8 STEEL	150,000 PSI	MEDIUM CARBON ALLOY									14	29	47	78	119	169	230	380	600	900
	SOCKET SET SCREW	212,000 PSI	HIGH CARBON QUENCHED TEMPERED					9*	16*	30*	70*	140*	18	29	43	63	100	146			
	STUDS			Use SAE 2, 5 and 8 values when grade is known, with nut of sufficient strength.																	

*These marked torque values are listed in in-lbs.

EQUIVALENTS FOR ENGLISH FASTENERS

FASTENER	TYPE	MINIMUM TENSILE STRENGTH	MATERIAL	BODY SIZE OR OUTSIDE DIAMETER																		
				# (number)						mm (millimeters)												
				2	3	4	5	6	8	10	6.4	7.9	9.5	11.1	12.7	14.3	15.9	19.1	22.2	25.4		
	SAE 2 STEEL	5,202 kg/cm ²	LOW CARBON																			
	SAE 5 STEEL	8,436 kg/cm ²	MEDIUM CARBON HEAT TREAT							1.6	2.5	13.8	26.3	45.6	74.7	107.9	157.7	213.0	355.4	528.3	811.8	
	SAE 7 STEEL	9,350 kg/cm ²	MEDIUM CARBON ALLOY									18.0	34.6	60.8	98.2	152.1	213.0	297.3	497.9	788.3	1161.7	
	SAE 8 STEEL	10,545 kg/cm ²	MEDIUM CARBON ALLOY									19.4	40.1	65.0	107.9	164.6	233.7	318.1	525.5	829.8	1220.0	
	SAE 8 STEEL	10,545 kg/cm ²	MEDIUM CARBON ALLOY									19.4	40.1	65.0	107.9	164.6	233.7	318.1	525.5	829.8	1220.0	
	SOCKET SET SCREW	14,904 kg/cm ²	HIGH CARBON QUENCHED TEMPERED					1.0	1.8	3.4	8.1	16.1	24.9	40.1	59.5	87.1	138.3	201.9				
	STUDS			Use SAE 2, 5 and 8 values when grade is known, with nut of sufficient strength.																		

foot-pounds (ft-lbs) x 1.356 = Newton-meters (Nm)

inch-pounds (in-lbs) x 0.113 = Newton-meters (Nm)

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>