

**JX60 STRADDLE**  
**JX70 STRADDLE**  
**JX80 STRADDLE**  
**JX90 STRADDLE**  
**JX95 STRADDLE**  
Tractor

**SERVICE MANUAL**

Part number 48047634

English

July 2016

© 2016 CNHI International. All Rights Reserved.





## **SERVICE MANUAL**

**JX60 STRADDLE  
JX70 STRADDLE  
JX80 STRADDLE  
JX90 STRADDLE  
JX95 STRADDLE**

# Link Product / Engine

---

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
JX60 STRADDLE	Middle East Africa	8045.45.747
JX60 STRADDLE	Asia Pacific	8045.45.747
JX70 STRADDLE	Middle East Africa	8045.45.747
JX70 STRADDLE	Asia Pacific	8045.45.747
JX80 STRADDLE	Asia Pacific	8045.45.747
JX80 STRADDLE	Middle East Africa	8045.45.747
JX90 STRADDLE	Asia Pacific	8045.45.747
JX90 STRADDLE	Middle East Africa	8045.45.747
JX95 STRADDLE	Asia Pacific	8045.45.747
JX95 STRADDLE	Middle East Africa	8045.45.747

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
Clutch .....	18
[18.110] Clutch and components .....	18.1
Transmission.....	21
[21.114] Mechanical transmission .....	21.1
[21.120] Gearbox.....	21.2
[21.160] Creeper .....	21.3
Four-Wheel Drive (4WD) system .....	23
[23.304] Four-Wheel Drive (4WD) gearbox .....	23.1
Front axle system .....	25
[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.108] Final drive hub, steering knuckles, and shafts .....	25.3
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential.....	27.2
Power Take-Off (PTO).....	31
[31.101] Rear mechanical control .....	31.1
Brakes and controls .....	33
[33.202] Hydraulic service brakes .....	33.1
[33.110] Parking brake or parking lock .....	33.2
[33.220] Trailer brake hydraulic control.....	33.3
Hydraulic systems.....	35
[35.204] Remote control valves .....	35.1

[35.100] Main lift system.....	35.2
<b>Steering.....</b>	<b>41</b>
[41.101] Steering control .....	41.1
[41.216] Cylinders .....	41.2
<b>Wheels.....</b>	<b>44</b>
[44.511] Front wheels.....	44.1
<b>Electrical systems.....</b>	<b>55</b>
[55.100] Harnesses and connectors.....	55.1
[55.201] Engine starting system.....	55.2
[55.302] Battery.....	55.3
[55.408] Warning indicators, alarms, and instruments .....	55.4
[55.301] Alternator.....	55.5
<b>Platform, cab, bodywork, and decals.....</b>	<b>90</b>
[90.150] Cab.....	90.1



# INTRODUCTION

# Contents

---

## INTRODUCTION

Note to the Owner .....	3
Safety rules .....	5
Safety rules .....	8
Consumables .....	9

---

## Note to the Owner

### General instructions

#### Important notice

All maintenance and repair operations described in this manual should be carried out exclusively by the CASE IH authorised workshops. All instructions detailed should be carefully observed and special equipment indicated should be used if necessary.

Everyone who carries out service operations described without carefully observing these prescriptions will be directly responsible of deriving damages.

#### Shimming

At each adjustment, select adjusting shims, measure them individually using a micrometer and then sum up recorded values. Do not rely on measuring the whole shimming set, which may be incorrect, or on rated value indicated for each shim.

#### Rotating shaft seals

To correctly install rotating shaft seals, observe the following instructions:

- Let the seal soak into the same oil as it will seal for at least half an hour before mounting.
- Thoroughly clean the shaft and ensure that the shaft working surface is not damaged.
- Place the sealing lip towards the fluid. In case of a hydrodynamic lip, consider the shaft rotation direction and orient grooves in order that they deviate the fluid towards the inner side of the seal.
- Coat the sealing lip with a thin layer of lubricant (oil rather than grease) and fill with grease the gap between the sealing lip and the dust lip of double lip seals.
- Insert the seal into its seat and press it down using a flat punch. Do not tap the seal with a hammer or a drift.
- Take care to insert the seal perpendicularly to its seat while you are pressing it. Once the seal is settled, ensure that it contacts the thrust element if required.
- To prevent damaging the sealing lip against the shaft, place a suitable protection during installation.

#### O-rings

Lubricate the O-rings before inserting them into their seats. This will prevent the O-rings from rolling over and twine during mounting which will jeopardise sealing.

#### Sealers

Apply one of the following sealers: RTV SILMATE, RHODORSIL CAF 1, or **LOCTITE® PIASTIC GASKET** over the mating surfaces marked with an X.

Before applying the sealer, prepare the surface as follows:

- Remove possible scales using a metal brush.
- Thoroughly degrease the surfaces using one of the following cleaning agent: trichlorethylene, petrol or a water and soda solution.

#### Bearings

It is advisable to heat the bearings to **80 - 90 °C (176 - 194 °F)** before mounting them on their shafts and cool them down before inserting them into their seats with external tapping.

#### Roll pins

When fitting straight roll pins, ensure that the pin notch is oriented in the direction of the effort to stress the pin. Coil roll pins can be installed in any position.

## Notes for spare parts

Use exclusively genuine CASE IH spare parts.

Only genuine parts guarantee same quality, life, safety as original components as they are the same as mounted in production.

Only the CASE IH genuine spare parts can offer this guarantee.

All spare parts orders should be complete with the following data:

- Tractor model (commercial name) and frame number.
- Engine type and number.
- Part number of the ordered part, which can be found on the "Microfiches" or the "Spare parts catalogue", which is the base for order processing.

## Notes for equipment

Equipment which CASE IH proposes and shows in this manual are as follows:

- Studied and designed expressly for use on CASE IH tractors.
- Necessary to make a reliable repair.
- Accurately built and strictly tested to offer efficient and long-lasting working means.

We also remind the repair personnel that having these equipment means:

- Work in optimal technical conditions.
- Obtain best results.
- Save time and effort.
- Work more safely.

## Notices

Wear limits indicated for some details should be intended as advised, but not binding values. The words "front", "rear", "right hand", and "left hand" referred to the different parts should be intended as seen from the operator's seat oriented to the normal sense of movement of the tractor.

## How to move the tractor with the battery removed

Cables from the external power supply should be connected exclusively to the respective terminals of the tractor positive and negative cables using pliers in good condition which allow proper and steady contact.

Disconnect all services (lights, wind-shield wipers, etc.) before starting the tractor

If it is necessary to check the tractor electrical system, check it only with the power supply connected. At check end, disconnect all services and switch the power supply Off before disconnecting the cables.

---

## Safety rules

### Pay attention to this symbol



This warning symbol points out important messages involving personal safety. Carefully read the safety rules contained herein and follow advised precautions to avoid potential hazards and safeguard your safety and personal integrity. In this manual you will find this symbol together with the following key-words:

**WARNING** – It gives warning about improper repair operations and deriving potential consequences affecting the service technician's personal safety.

**DANGER** – It gives specific warning about potential dangers for personal safety of the operator or other persons directly or indirectly involved.

### To prevent accidents

Most accidents and personal injuries taking place in workshops are due from non-observance of some simple and essential prudential rule and safety precautions. For this reason, **IN MOST CASES THEY CAN BE AVOIDED**. It suffices to foresee possible causes and act consequently with necessary caution and care.

The possibility that an accident might occur with any type of machines should not be disregarded, no matter how well the machine in question was designed and built.

A wise and careful service technician is the best precautions against accidents.

Careful observance of this only basic precaution would be enough to avoid many severe accidents.

**DANGER:** Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

## Safety rules

### Generalities

- Carefully follow specified repair and maintenance procedures.
- Do not wear rings, wristwatches, jewels, unbuttoned or flapping clothing such as ties, torn clothes, scarves, open jackets or shirts with open zips which could get hold into moving parts. We advise to use approved safety clothing such as anti-slipping footwear, gloves, safety goggles, helmets, etc.
- Never carry out any repair on the machine if someone is sitting on the operator's seat, except if they are certified operators to assist in the operation to be carried out.
- Never operate the machine or use attachments from a place other than sitting at the operator's seat.
- Never carry out any operation on the machine when the engine is running, except when specifically indicated.
- Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- All repair and maintenance operations should be carried out with the greatest care and attention.
- Service stairs and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- Disconnect the batteries and label all controls to warn that the tractor is being serviced. Block the machine and all equipment which should be raised.
- Never check or fill fuel tanks and accumulator batteries, nor use starting liquid if you are smoking or near open flames as such fluids are flammable.
- Brakes are inoperative when they are manually released for maintenance purposes. In such cases, the machine should be kept constantly under control using blocks or similar devices.
- The fuel filling gun should remain always in contact with the filler neck. Maintain this contact until the fuel stops flowing into the tank to avoid possible sparks due to static electricity buildup.
- Use exclusively specified towing points for towing the tractor. Connect parts carefully. Ensure that foreseen pins and/or locks are steadily fixed before applying traction. Do not stop near towing bars, cables or chains working under load.

## INTRODUCTION

---

- To transfer a failed tractor, use a trailer or a low loading platform trolley if available.
- To load and unload the machine from the transportation mean, select a flat area providing a firm support to the trailer or truck wheels. Firmly tie the machine to the truck or trailer platform and block wheels as required by the forwarder.
- For electrical heaters, battery-chargers and similar equipment use exclusive auxiliary power supplies with a efficient ground to avoid electrical shock hazard.
- Always use lifting equipment and similar of appropriate capacity to lift or move heavy components.
- Pay special attention to bystanders.
- Never pour gasoline or diesel oil into open, wide and low containers.
- Never use gasoline, diesel oil or other flammable liquids as cleaning agents. Use nonflammable nontoxic proprietary solvents.
- Wear protection goggles with side guards when cleaning parts using compressed air.
- Do not exceed a pressure of **2.1 bar (30.45 psi)**, in accordance with local regulations.
- Do not run the engine in a closed building without proper ventilation.
- Do not smoke, use open flames, cause sparks in the nearby area when filling fuel or handling highly flammable liquids.
- Do not use flames as light sources when working on a machine or checking for leaks.
- Move with caution when working under a tractor, and also on or near a tractor. Wear proper safety accessories: helmets, goggles and special footwear.
- During checks which should be carried out with the engine running, ask an assistant to seat at the operator's seat and keep the service technician under visual control at any moment.
- In case of operations outside the workshop, drive the tractor to a flat area and block it. If working on an incline cannot be avoided, first block the tractor carefully. Move it to a flat area as soon as possible with a certain extent of safety.
- Ruined or plied cables and chains are unreliable. Do not use them for lifting or trailing. Always handle them wearing gloves of proper thickness.
- Chains should always be safely fastened. Ensure that fastening device is strong enough to hold the load foreseen. No persons should stop near the fastening point, trailing chains or cables.
- The working area should be always kept CLEAN and DRY. Immediately clean any spillage of water or oil.
- Do not pile up grease or oil soaked rags, as they constitute a great fire hazard. Always place them into a metal container. Before starting the tractor or its attachments, check, adjust and block the operator's seat. Also ensure that there are no persons within the tractor or attachment operating range.
- Do not keep into your pockets any object which might fall unobserved into the tractor's inner compartments.
- Whenever there is the possibility of being reached by ejected metal parts or similar, use protection eye mask or goggles with side guards, helmets, special footwear and heavy gloves.
- Wear suitable protection such as tinted eye protection, helmets, special clothing, gloves and footwear whenever it is necessary to carry out welding procedures. All persons standing in the vicinity of the welding process should wear tinted eye protection. NEVER LOOK AT THE WELDING ARC IF YOUR EYES ARE NOT SUITABLY PROTECTED.
- Metal cables with the use get frayed. Always wear adequate protections (heavy gloves, eye protection, etc.)
- Handle all parts with the greatest caution. Keep your hands and fingers far from gaps, moving gears and similar. Always use approved protective equipment, such as eye protection, heavy gloves and protective footwear.

### Start up

- Never run the engine in confined spaces which are not equipped with adequate ventilation for exhaust gas extraction.
- Never bring your head, body, arms, legs, feet, hands, fingers near fans or rotating belts.

### Engine

- Always loosen the radiator cap very slowly before removing it to allow pressure in the system to dissipate. Coolant should be topped up only when the engine is stopped or idle if hot.
- Do not fill up fuel tank when the engine is running, mainly if it is hot, to avoid ignition of fires in case of fuel spilling.
- Never check or adjust the fan belt tension when the engine is running. Never adjust the fuel injection pump when the tractor is moving.
- Never lubricate the tractor when the engine is running.

### Electrical systems

- If it is necessary to use auxiliary batteries, cables must be connected at both sides as follows: (+) to (+) and (–) to (–). Avoid short circuiting the terminals. GAS RELEASED FROM BATTERIES IS HIGHLY FLAMMABLE. During charging, leave the battery compartment uncovered to improve ventilation. Avoid checking the battery charge by means of “jumpers” made by placing metallic objects across the terminals. Avoid sparks or flames near the battery area. Do no smoke to prevent explosion hazards.
- Prior to any service, check for fuel or current leaks. Remove these leaks before going on with the work.
- Do not charge batteries in confined spaces. Ensure that ventilation is appropriate to prevent accidental explosion hazard due to build up of gases released during charging.
- Always disconnect the batteries before performing any type of service on the electrical system.

### Hydraulic systems

- Some fluid slowly coming out from a very small port can be almost invisible and be strong enough to penetrate the skin. For this reason, NEVER USE YOUR HANDS TO CHECK FOR LEAKS, but use a piece of cardboard or a piece of wood to this purpose. If any fluid is injected into the skin, seek medical aid immediately. Lack of immediate medical attention, serious infections or dermatosis may result.
- Always take system pressure readings using the appropriate gauges.

### Wheels and tires

- Check that the tires are correctly inflated at the pressure specified by the manufacturer. Periodically check possible damages to the rims and tires.
- Keep off and stay at the tire side when correcting the inflation pressure.
- Check the pressure only when the tractor is unloaded and tires are cold to avoid wrong readings due to over-pressure. Do not reuse parts of recovered wheels as improper welding, brazing or heating may weaken the wheel and make it fail.
- Never cut, nor weld a rim with the inflated tire assembled.
- To remove the wheels, block both front and rear tractor wheels. Raise the tractor and install safe and stable supports under the tractor in accordance with regulations in force.
- Deflate the tire before removing any object caught into the tire tread.
- Never inflate tires using flammable gases as they may originate explosions and cause injuries to bystanders.

### Removal and installation

- Lift and handle all heavy components using lifting equipment of adequate capacity. Ensure that parts are supported by appropriate slings and hooks. Use lifting eyes provided to this purpose. Take care of the persons near the loads to be lifted.
- Handle all parts with great care. Do not place your hands or fingers between two parts. Wear approved protective clothing such as safety goggles, gloves and footwear.
- Do not twine chains or metal cables. Always wear protection gloves to handle cables or chains.

## Safety rules

### Cab air conditioning system

Refrigerant must be handled with extreme care to avoid injury, always wear safety gloves and goggles.

Liquid refrigerant can cause freezing of the skin and serious damage to the eyes, even blindness in some cases.

Keep refrigerant containers away from heat sources, as the increase of internal pressure due to heating could cause the container to explode.

In contact with a naked flame or hot metal surfaces the refrigerant may give off a toxic gas. If inhaled this gas can cause serious harm.

To avoid the possibility of accidents take the simple precautions described below.

The operation of emptying the system must be carried out in a well-ventilated area, well away from any naked flames.

During the charging and emptying operations, take the necessary precautions to protect the face and above all the eyes from accidental contact with refrigerant.

In case of accident, proceed as follows:

- If has entered the eyes, wash immediately with a few drops of mineral oil, then wash them thoroughly with a solution of boric acid and water (one spoonful of acid in 1/4 cup of water) and seek medical assistance immediately.
- Freezing of the skin caused by contact with liquid refrigerant can be treated by gradually warming the injured area with cold water followed by application of a greasy cream. Seek medical assistance.
- The air-conditioning system contains a mixture of refrigerant and oil under high pressure, under no circumstances loosen pipe fittings/couplings or work on pipes without having first evacuated the system.
- For the same reason, never unscrew the compressor oil level plug when the system is charged.
- Do not heat the refrigerant container. Above **50 °C (122 °F)** the pressure increases very rapidly.
- Keep the air-conditioning system away from heat sources to prevent possible explosion due to the increase of pressure in the system.

When transferring refrigerant from one container to another, only use homologated liquid refrigerant containers equipped with safety valves.

Never fill liquid refrigerant containers over 80% of their maximum capacity.

Do not modify the settings of safety valves and the control devices.

Never connect the recovery/recycling and evacuation/charging stations to electrical power outlets with voltages other than those specified, do not leave the stations powered on unless they are to be used immediately.

## Consumables

Component to be filled or topped up	Qty.	Recommended products	International specification
Cooling system: JX60, and JX70	<b>12.0 L (3.2 US gal)</b>	Water & liquid <b>CASE IH AKCELA PREMIUM ANTI-FREEZE</b>	-
JX80, JX90 and JX95	<b>14.0 L (3.7 US gal)</b>	50% + 50% <b>NH900A</b>	-
Fuel tank JX60, JX70, JX80, JX90 JX95	<b>78.0 L (20.6 US gal)</b> <b>90.0 L (23.8 US gal)</b>	Decanted and filtered diesel fuel	—
Engine sump: without filter : JX60, and JX70 JX80, JX90 and JX95	<b>7.3 L (1.9 US gal)</b> <b>11.7 L (3.1 US gal)</b>	<b>CASE IH AKCELA NO. 1™ ENGINE OIL SAE 15W-40 NH330H</b>	<b>API CH-4 ACEA E5</b>
with filter : JX60, and JX70 JX80, JX90 and JX95	<b>8.3 L (2.2 US gal)</b> <b>12.4 L (3.3 US gal)</b>		
Hydrostatic steering circuit	<b>2.0 L (0.5 US gal)</b>	<b>CASE IH AKCELA NEXPLORE™ FLUID NH410B</b>	<b>API GL-4 ISO 32/46 SAE 10W - 30</b>
Front axle: Axle housing JX60, and JX70 JX80, JX90 and JX95	<b>4.5 L (1.2 US gal)</b> <b>7.0 L (1.8 US gal)</b>		
Final drives (each) JX60, and JX70 JX80, JX90 and JX95	<b>0.8 L (0.2 US gal)</b> <b>1.25 L (0.33 US gal)</b>		
Rear transmission (bevel drive and brakes), gearbox, hydraulic lift and PTO	<b>46 l (12.15 US gal)</b>		
Rear final drives (each) JX60, and JX70 JX80, JX90 JX95	<b>4.0 L (1.1 US gal)</b> <b>5.5 L (1.5 US gal)</b> <b>6.5 L (1.7 US gal)</b>		
Front wheel hubs	-		
Grease fittings	-	<b>CASE IH AKCELA 251H EP MULTI- PURPOSE GREASE NH710A</b>	<b>NLGI 2</b>

**NOTICE:** Use only heavy-duty, low silicate coolant such as **CASE IH AKCELA ACTIFULL™ OT EXTENDED LIFE COOLANT**. Automotive antifreeze purchased at local supply store outlets most likely is not low silicate and must not be used in heavy-duty diesel engines. Always have a minimum of 50% ethylene glycol coolant in the cooling system, adjusting the concentration based on ambient temperature, according to coolant label instructions. Use good quality water. Deionized water is ideal for cooling systems and is contained in some prepackaged coolants labeled as pre-mixed with water. If the low silicate ethylene glycol coolant is not pre-charged with supplemental diesel coolant additive/inhibitor, this must be added to the solution to provide protection against corrosion and pitting.

# CONSUMABLES INDEX

---

<b>Consumable</b>	<b>Reference</b>	<b>PAGE</b>
Loctite® Plastic Gasket	Note to the Owner	3
CASE IH AKCELA PREMIUM ANTI-FREEZE	Consumables	9
CASE IH AKCELA NO. 1™ ENGINE OIL SAE 15W-40	Consumables	9
CASE IH AKCELA NEXPLORE™ FLUID	Consumables	9
CASE IH AKCELA 251H EP MULTI-PURPOSE GREASE	Consumables	9
CASE IH AKCELA ACTIFULL™ OT EXTENDED LIFE COOLANT	Consumables	9



# **SERVICE MANUAL**

## **Engine**

**JX60 STRADDLE  
JX70 STRADDLE  
JX80 STRADDLE  
JX90 STRADDLE  
JX95 STRADDLE**

# Contents

---

## Engine - 10

[10.001] Engine and crankcase .....	10.1
-------------------------------------	------

# CONSUMABLES INDEX

---

<b>Consumable</b>	<b>Reference</b>	<b>PAGE</b>
Loctite®	Engine and crankcase - Install	10.1 / 10



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**



## **Engine - 10**

### **Engine and crankcase - 001**

**JX60 STRADDLE  
JX70 STRADDLE  
JX80 STRADDLE  
JX90 STRADDLE  
JX95 STRADDLE**

# Contents

---

## Engine - 10

### Engine and crankcase - 001

#### SERVICE

##### Engine and crankcase

Remove .....	4
Install .....	10

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**