

---

# WD1903, WD2303 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION .....	2
SECTION 10 - ENGINE .....	3
SECTION 25 - FRONT MECHANICAL DRIVE .....	5
SECTION 29 - HYDROSTATIC TRANSMISSION .....	5
SECTION 33 - BRAKES AND CONTROLS .....	10
SECTION 35 - HYDRAULIC SYSTEMS .....	11
SECTION 44 - REAR AXLE .....	16
SECTION 50 - CLIMATE CONTROL .....	18
SECTION 55 - ELECTRICAL SYSTEMS .....	22
SECTION 58 - HEADER ATTACHMENTS .....	38
SECTION 88 - OPTIONAL EQUIPMENT .....	42
SECTION 90 - PLATFORM, CAB AND DECALS .....	43

The following pages are the collation of the contents pages from each section and chapter of the WD1903, WD2303 Repair manual. Complete Repair part # 87738738.

The sections used through out all Case IH product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the WD1903, WD2303 Self-Propelled Windrowers.

---

# SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87738739

## Chapter 1 - General Information

### CONTENTS

Section	Description	Page
	Precautionary Statements .....	2
	Safety .....	3
	General Safety Information .....	5
	Introduction .....	8
	About Improvements .....	8
	Product Identification Numbers (PIN) .....	9
	Engine PIN Number .....	9
	Company Policy .....	10
	Parts and Specification .....	10
	Lubrication .....	10
	Minimum Hardware Tightening Torques .....	11
	Installation of Adjustable Fittings in Straight Thread O-ring Bosses .....	13
	Standard Torque Data for Hydraulic Tubes and Fittings .....	13
	Pipe Thread Fitting Torque .....	14
	Installation of ORFS (O-ring Flat Faced) Fittings .....	14
	Specifications .....	15

---

## SECTION 10 - ENGINE

BOOK 1 - 87738739

### Chapter 1 - Engine

#### CONTENTS

Section	Description	Page
	Specifications .....	2
	Description of Operation .....	3
	Cylinder Block Assembly .....	3
	Engine Overhaul - Introduction .....	4
	Overhaul .....	5
	Engine .....	5
	Removal .....	5
	Installation .....	13
	Troubleshooting .....	23

## SECTION 10 - ENGINE

BOOK 1 - 87738739

### Chapter 2 - Fuel System

#### CONTENTS

Section	Description	Page
	Specifications .....	2
	Fuel System .....	2
	Fuel Tank .....	3
	Bleeding Air From Filter .....	3
	Injection System Bleeding .....	3
	Air Leakage Test .....	4
	Cold Start Assist .....	5
	Fuel Tanks .....	6
	Removal .....	6
	Installation .....	9
	Connecting Fuel Tanks .....	10

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

---

## SECTION 10 - ENGINE

BOOK 1 - 87738739

### Chapter 3 - Air Intake

#### CONTENTS

Section	Description	Page
	Specifications .....	2
	Air Cleaner .....	2
	Description of Operation - Air Cleaner .....	3
	Air Cleaner .....	3
	Inner Element .....	3
	Troubleshooting - Air Cleaner .....	4
	Description of Operation .....	5
	Air Filter .....	5
	Inspection .....	5
	Air Intake Hoses .....	8
	Removal .....	8
	Installation .....	10
	Troubleshooting - Air Filter .....	11

## SECTION 10 - ENGINE

BOOK 1 - 87738739

### Chapter 4 - Cooling System

#### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Cooling System (NEF Tier III 6 cyl. engine) .....	2
	Troubleshooting .....	4
	Overhaul .....	5
	Radiator .....	5
	Removal .....	5
	Installation .....	8

---

## SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 1 - 87738739

### Chapter 1 - Front Mechanical Drive

#### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Special Tools .....	2
	Overhaul .....	7
	Front Mechanical Drive .....	7
	Removal .....	7
	Installation .....	9
	Planetary Gearbox Drive .....	12
	Disassembly .....	13
	Assembly .....	17

## SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 1 - 87738739

### Chapter 1 - Ground Drive

#### CONTENTS

Section	Description	Page
	Specifications .....	4
	Hydrostatic Transmission Identification .....	5
	Torque Specifications .....	6
	Torque Chart .....	6
	Motor Area .....	6
	Description of Operation .....	7
	Pumps .....	8
	High Pressure Relief Valves .....	9
	Check Valves .....	9
	Charge Pump .....	10
	Charge Relief Valve (Pump) .....	10

---

# SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 1 - 87738739

## Chapter 1 - Ground Drive (Continued)

### CONTENTS

Section	Description	Page
	Header Lift Pump .....	10
	Motors .....	10
	Variable Displacement Motor .....	10
	Reservoir .....	12
	Oil Flow .....	12
	Neutral .....	12
	Forward/Reverse .....	12
	Hydraulic Diagram .....	13
	Hydraulic Diagram - Installed Draper Kit .....	15
	Solenoid Valve .....	17
	Low-Range Operation .....	17
	High-Range Operation .....	17
	Cooling Circuit .....	17
	Relief Valve .....	17
	Operation .....	17
	Linkage .....	18
	Operation .....	18
	Sauer-Danfoss Authorized Service Centers - North America .....	19
	Troubleshooting .....	23
	Excessive Noise .....	23
	Overheating Transmissions .....	23
	Loss of Propulsion .....	23
	Control Linkage Inspection .....	24
	High-Pressure Relief Valve Check .....	24
	Charge Pump Relief Valve .....	24
	Check Valve .....	25
	Pressure Testing .....	25
	Port Locations .....	27
	Charge Pressure .....	28
	Charge Pressure System Test .....	28
	Tandem Pump Charge Pressure Test .....	28
	Complete Charge System Test .....	31

---

# SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 1 - 87738739

## Chapter 1 - Ground Drive (Continued)

### CONTENTS

Section	Description	Page
	High Pressure Relief Valve Test .....	33
	Gage Port and Relief Valve Locations .....	33
	Pressure Port Locations .....	35
	Case Pressure Test (Pump) .....	36
	Case Pressure Test (Motor) .....	36
	Suction Test .....	37
	Case Flow Test .....	37
	Ground Speed Circuit .....	38
	Operation .....	38
	Troubleshooting .....	38
	Ground Speed Display Does Not Function .....	39
	Troubleshooting Charts .....	41
	Windrower Will Not Shift into High Range .....	41
	Windrower Will Not Shift into Low Range .....	42
	Charge Pump .....	43
	Hydrostatic System .....	44
	Explanation of Terms Used in Failure Analysis .....	47
	Lack of Lubrication .....	47
	Operating at Excessive Temperature Levels .....	47
	Use of Improper Fluid .....	47
	Cavitation .....	47
	Overspeeding of the Unit .....	47
	Parts Worn or Scored From Contamination .....	47
	Abrasive Contaminants .....	47
	Plates Scored from Water in Oil (Non-Particle Contaminants) .....	47
	Minor Repairs .....	48
	Tandem Pump .....	49
	Port Locations .....	49
	Rear Half Pump Breakdown .....	50
	Front Half Pump Breakdown .....	52

---

# SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 1 - 87738739

## Chapter 1 - Ground Drive (Continued)

### CONTENTS

Section	Description	Page
	Shaft Seal Replacement .....	54
	Charge Pump Removal .....	55
	Charge Pump Inspection .....	56
	Charge Pump Assembly .....	57
	O-ring Seals .....	58
	Trunnion Seal (Control Shaft Side) .....	59
	Trunnion Cover (Plain) .....	61
	Tandem Pump Removal .....	62
	Tandem Pump Installation .....	65
	Ground Drive Motor .....	66
	Removal .....	66
	Installation .....	69
	Shaft Seal Replacement .....	69
	Start-Up .....	70
	Maintenance .....	71
	Worm Shaft .....	72
	Removal .....	72
	Installation .....	73

---

## SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 1 - 87738739

### Chapter 2 - Propulsion System

#### CONTENTS

Section	Description	Page
	Theory of Operation .....	2
	Pintle Arm Position Sensor (B-02) .....	3
	Removal .....	3
	Installation .....	3
	Testing .....	4
	Adjustment .....	5
	Propulsion Rotary Position Sensor (R-23) .....	6
	Removal .....	6
	Installation .....	6
	Testing .....	7
	MFH Rotary Position Sensor (R-18) .....	8
	Removal .....	8
	Installation .....	9
	Testing .....	10
	Neutral Adjustment .....	11

## SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 1 - 87738739

### Chapter 3 - Active Calibrations

#### CONTENTS

Section	Description	Page
	Active Calibrations .....	2

---

## SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 1 - 87738739

### Chapter 4 - MFH Calibration

#### CONTENTS

Section	Description	Page
	Dealer Setup Menu Navigation .....	2
	MFH Calibration .....	2

## SECTION 33 - BRAKES AND CONTROLS

BOOK 1 - 87738739

### Chapter 1 - Brakes and Controls

#### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Special Tools .....	2
	Overhaul .....	2
	Brake Assembly .....	2
	Removal .....	2
	Installation .....	4
	Disassembly .....	6
	Rotating, Stationary, and Primary Disc Assembly .....	12
	Installation .....	12
	Brake Bleeding Procedure .....	16

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 87738740

## Chapter 1 - Hydraulic Systems

### CONTENTS

Section	Description	Page
	Introduction .....	5
	System Component Locations .....	6
	Reading Diagram Symbols .....	7
	Hydraulic System Diagram .....	12
	Theory of Operation - Ground Drive .....	14
	Ground Drive .....	14
	Hydraulic Bleed Procedure .....	16
	Circuit Diagrams .....	19
	Service Techniques .....	24
	General .....	24
	Oil Level .....	24
	Hoses and Tubes .....	25
	O-Ring Flat Face Seal Fittings .....	25
	O-Ring Flat Face Seal Fitting Torque Values .....	25
	Theory of Operation - Header Drive .....	26
	Header Drive .....	26
	Electronic Displacement Control (EDC) .....	28
	Circuit Diagrams .....	29
	Theory of Operation - Header Lift System .....	33
	Header Lift System .....	33
	Neutral State .....	34
	Header Lift .....	34
	Accumulator Charge .....	34
	Header Lower/Flotation .....	34
	Flotation/Accumulators .....	35
	Theory of Operation .....	35
	Increase/Decrease Flotation .....	35
	Circuit Diagrams .....	36
	Header Tilt System .....	41
	Theory of Operation .....	41
	Circuit Diagrams .....	42
	Auxiliary Hydraulic Pump .....	45
	Theory of Operation .....	45
	Independent Control Valve (ICV) Manifold .....	46
	Service Parts .....	46
	Valve Identification Codes .....	47

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 87738740

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	Component Identification and Location .....	48
	Right-hand (RH) View .....	48
	Plan View .....	49
	Front View .....	50
	Rear View .....	51
	Bottom View .....	52
	Left-hand (LH) View (Hidden Against Mounting Plate) .....	53
	Energized Solenoid Chart .....	54
	Zero-Leak Plugs .....	55
	Removal .....	55
	Install .....	55
	Plug Torque Requirements .....	56
	Zero-Leak Plug to SAE J514 ORB Plug Cross Reference .....	56
	Auxiliary Control Valve (Speed Control) Manifold .....	57
	Service Parts .....	57
	Valve Identification Codes .....	58
	Auxiliary Control Valve .....	59
	Component Identification and Location .....	59
	Right-Hand (RH) View .....	59
	Plan View .....	60
	Bottom View .....	61
	Left-hand (LH) View (Hidden Against Mounting Plate) .....	62
	Theory of Operation - Cartridge Valves .....	63
	Cartridge Valves (Solenoid-operated) .....	63
	Two-way Two-position (Normally Closed) Poppet Valves .....	64
	Three-way Two-position Spool Valve .....	66
	Two-way Two-position (Normally Open) Poppet Valve .....	67
	(Normally Open) Pressure Reducing/Relieving Valves .....	68
	(Normally Open) Solenoid-operated Relief Valves .....	69
	(Normally Closed) Solenoid-operated Proportional Flow Control .....	70
	Main Manifold – Cartridge Torque Requirements .....	71
	Replacement .....	73
	Installation .....	74
	Solenoid Coils .....	75
	Removal .....	75
	Installation .....	76

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 87738740

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	Cartridge Valves (Non-solenoid-operated) .....	77
	Direct-acting Flow Control Needle Valve .....	77
	Pilot-operated Relief Valve .....	78
	Differential-Pressure-Sensing Valve .....	79
	Replacement .....	79
	Adjustment .....	80
	Minor Repairs .....	81
	Header Drive Pump .....	81
	Multifunction Valve Cartridge .....	81
	Charge Pressure Relief Valve .....	82
	Diagnosing the EDC and Pilot Control Valve Assembly .....	83
	Dealer Setup Menu Navigation .....	84
	EDC and PCP Valve Assembly .....	86
	Removal .....	86
	Installation .....	87
	Charge Cooling Circuit Manifold .....	89
	Removal .....	89
	Installation .....	90
	Major Components .....	91
	Header Drive Pump .....	91
	Removal .....	91
	Pump Shaft Seal .....	96
	Inspection .....	98
	Installation .....	99
	Splitter Gear Box .....	101
	Disassembly .....	101
	Assembly .....	103
	Start-up Procedure .....	108
	Pressure Checks - Header Drive System .....	112
	Test Equipment .....	112
	Pressure Readings .....	113
	Charge Pressure - Header Drive Pump .....	113
	Charge Pressure - Header Drive Motor .....	113
	Pump Gauge Information .....	114
	Case Pressure .....	115

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 87738740

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	High Pressure .....	115
	Motor Gauge Information .....	116
	Inlet Vacuum .....	117
	Case Drain Flow .....	118
	Cooling Circuit Bypass Pressure .....	119
	Hydraulic Oil Temperatures .....	120
Adjustments .....		121
	Header Drive Pump .....	121
	Neutral Adjustment .....	121
	Multifunction Valves .....	125
	Diagnosing .....	125
	Charge Pressure Relief Valve .....	126
	Diagnosing .....	126
	Header Drive Motors .....	127
	Header Drive Speed Sensor Gap .....	127
	Sauer-Danfoss Authorized Service Centers - North America .....	128
	Header Lift Pump .....	132
	Removal .....	132
	Disassembly .....	132
	Inspection .....	134
	Assembly .....	134
	Installation .....	137
	Adjustment Instructions .....	138
	LH Header Lift Relief Valve (L-04) Pressure .....	142
	Adjustment .....	142
	Accumulators - Header Lift .....	146
	Removal .....	146
	Inspection .....	147
	Installation .....	147
	Accumulator - Surge Suppression .....	149
	Specifications .....	149
	Hydraulic Accumulator Breakdown .....	150
	Checking Pre-Charge .....	151
	Pre-charging Procedure .....	152
	Removal .....	153
	Installation .....	153

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 87738740

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	Lift Cylinders .....	154
	Removal .....	154
	Inspection .....	158
	Assembly .....	159
	Tilt Cylinder .....	163
	Removal .....	163
	Inspection .....	167
	Assembly .....	168
	Maintenance .....	171
	Auxiliary Engine Mounted Hydraulic Pump (optional) .....	172
	Removal .....	172
	Inspection .....	172
	Installation .....	173
	Hydraulic Reservoir .....	174
	Replacement .....	174
	Removal .....	174
	Installation .....	174
	Troubleshooting .....	177
	General Information .....	177
	Reduced System Pressure .....	177
	Reduced Hydraulic Flow .....	177
	Excessive Noise .....	177
	Overheating .....	177
	Power Loss .....	177
	Explanation of Terms Used In Failure Analysis .....	178
	Parts Evaluation .....	179
	Discoloration .....	179
	Scratches or Grooves .....	179
	Rework .....	179
	Repeat Failures .....	179
	Header Drive System .....	180
	Header Drive Pump .....	184
	Charge Pump .....	185
	Header Drive Motor .....	186

---

# SECTION 44 - REAR AXLE

BOOK 2 - 87738740

## Chapter 1 - Non-Suspended Rear Axle

### CONTENTS

Section	Description	Page
44 000	Introduction .....	2
	Overview .....	2
	Special Tools .....	2
	Specifications .....	3
	Description of Operation .....	4
	Extensions and Axle Tube .....	4
	Adjustments .....	8
	Wheel Width .....	8
	Extension Widths (Spindle to Spindle) .....	8
	Axle Extension Position .....	8
	Overhaul .....	9
	Wheel, Axle Shaft and Hub .....	9
	Removal .....	9
	Inspection .....	11
	Installation .....	12
	Axle Support Fork .....	14
	Removal .....	14
	Inspection .....	14
	Installation .....	15
	Extension .....	16
	Removal .....	16
	Inspection .....	18
	Installation .....	18
	Axle Tube and Pivot Pin .....	20
	Removal .....	20
	Inspection .....	21
	Installation .....	22

---

# SECTION 44 - REAR AXLE

BOOK 2 - 87738740

## Chapter 2 - Suspended Rear Axle

### CONTENTS

Section	Description	Page
44 000	Introduction .....	2
	Overview .....	2
	Special Tools .....	2
	Specifications .....	3
	Description of Operation .....	4
	Extensions and Axle Tubes .....	4
	Adjustments .....	7
	Wheel Width .....	7
	Extension Widths (Spindle to Spindle) .....	7
	Axle Extension Position .....	7
	Overhaul .....	8
	Wheel, Axle Shaft and Hub .....	8
	Removal .....	8
	Inspection .....	10
	Installation .....	11
	Axle Support Fork .....	13
	Removal .....	13
	Inspection .....	14
	Installation .....	14
	Extension .....	15
	Removal .....	15
	Inspection .....	16
	Installation .....	17
	Air Spring .....	18
	Removal .....	18
	Inspection .....	19
	Installation .....	19
	Axle Tubes and Pivot Pins .....	20
	Removal .....	20
	Inspection .....	21
	Installation .....	22

---

# SECTION 50 - CLIMATE CONTROL

BOOK 2 - 87738740

## Chapter 1 - Climate Control

### CONTENTS

Section	Description	Page
	Specifications .....	4
	Compressor .....	4
	Refrigerant .....	4
	Refrigerant Oil .....	4
	Special Tools .....	4
	Description of Operation .....	5
	The Basics of Refrigeration .....	5
	Air Conditioning Process .....	6
	R134a Refrigerant Information .....	7
	Refrigerant Ingredients .....	7
	Lubricants .....	7
	Refrigerant (R134a) .....	7
	Cab Air Flow .....	8
	System Components .....	10
	Compressor Pump .....	10
	Compressor Clutch (L-27) .....	10
	External Cab Filter .....	11
	Removal/Replacement .....	11
	Recirculation Filter .....	13
	Removal .....	14
	Cleaning With Air .....	15
	Condenser .....	15
	Receiver/Drier .....	16
	Expansion Valve .....	17
	Description .....	17
	Valve Components .....	17
	Operation .....	18
	Port Identification .....	21
	Evaporator .....	21
	Blower Fan .....	21
	Description of Operation - Climate Controls .....	22
	Control Panel – Manual Temperature Control (A-05) .....	22
	Blower Fan Switch .....	22
	Temperature Control Switch .....	22
	Control Panel – (ATC) Automatic Temperature Control (If Equipped) .....	23

---

# SECTION 50 - CLIMATE CONTROL

BOOK 2 - 87738740

## Chapter 1 - Climate Control (Continued)

### CONTENTS

Section	Description	Page
	Control Operation Specifications .....	23
	ATC Operator Controls .....	24
	ON/OFF .....	24
	LED Display .....	24
	AUTO .....	24
	DEF .....	24
	Fan UP/DOWN .....	24
	Temperature UP/DOWN .....	24
	Celsius/Fahrenheit Button .....	24
	ECON (Economy Mode) .....	24
	Compressor Protection Switches .....	25
	High-pressure Cutout Switch (S-40) .....	25
	Low-pressure Cutout Switch (S-39) .....	25
	Troubleshooting and Servicing Air Conditioning System .....	26
	General Safety and Service Precautions .....	26
	Cleanliness .....	27
	Preliminary Troubleshooting and Testing .....	27
	Operational Checks .....	27
	ATC Troubleshooting Fault Code Chart .....	28
	Display Fault Codes .....	28
	Advanced Diagnostics .....	31
	Diagnosis Charts – Air Conditioning System .....	35
	Test Procedure: Stabilizing the System .....	39
	Test Ports .....	39
	Pressure/Temperature Relationships .....	40
	Leak Testing .....	40
	Refilling .....	40
	Contaminants .....	41
	General .....	41
	Preventing Mixing of Service Equipment .....	41
	Refrigerant Extraction and Recycling Equipment .....	41
	Using Extraction Equipment .....	42
	Using Recycling Equipment .....	42
	Recycling vs. Reclaiming .....	42

---

# SECTION 50 - CLIMATE CONTROL

BOOK 2 - 87738740

## Chapter 1 - Climate Control (Continued)

### CONTENTS

Section	Description	Page
	Containment of Air Conditioning Refrigerants .....	42
	Recovery .....	43
	Flushing .....	43
	Recharging/Refilling .....	43
	Using a Manifold Gauge Set .....	44
	Checking Refrigerant for Excess Air .....	44
	Containers for Storing Recycled Refrigerant .....	45
	Disposal of Empty or Near-Empty Disposable Containers .....	45
	Applicable SAE Standards .....	45
	Manifold Gauge Readings and Interpretations .....	46
	Performance Test Examples .....	46
	Overhaul .....	57
	Condenser .....	57
	Removal .....	57
	Inspection and Repair .....	57
	Installation .....	57
	Receiver/Drier .....	58
	Removal .....	58
	Installation .....	58
	High (S-40) Pressure Switches .....	58
	Removal .....	58
	Installation .....	58
	Low (S-39) Pressure Switches .....	58
	Removal .....	58
	Installation .....	58
	Blower Motor .....	59
	Removal .....	59
	Inspection .....	61
	Assembly .....	62
	Installation .....	63
	Blower Fan Resistor .....	65
	Removal .....	65
	Installation .....	65

---

# SECTION 50 - CLIMATE CONTROL

BOOK 2 - 87738740

## Chapter 1 - Climate Control (Continued)

### CONTENTS

Section	Description	Page
	Expansion Valve .....	66
	Removal .....	66
	Installation .....	66
	HVAC Cores .....	67
	Inspection and Cleaning .....	67
	Removal .....	67
	Installation .....	68
	Heater Core and/or Evaporator Core .....	70
	Removal .....	70
	Inspection .....	71
	Installation .....	72
	Compressor and Clutch .....	75
	Compressor Clutch Components .....	75
	Removal .....	75
	Installation .....	76
	Checking Compressor Oil for Contamination .....	77
	Adding Compressor Oil .....	77
	Overhaul - Compressor .....	78
	Clutch and Seal Replacement .....	78
	Removal .....	78
	Inspection and Assembly .....	82

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

## Chapter 1 - General Information

### CONTENTS

Section	Description	Page
	Introduction .....	3
	Troubleshooting .....	3
	Fault Codes and Fault Finding .....	4
	Electrical Terms and Equipment .....	5
	Definitions .....	5
	Electrical System Components .....	7
	Electrical Components Chart .....	7
	Rocker Switches .....	13
	Momentary Rocker Switches .....	13
	Circuit Breakers .....	13
	Location of Circuit Breakers .....	14
	Fuses .....	15
	Fuse Panel Identification Tables .....	16
	Basic Circuitry/Component Testing .....	17
	Continuity Test for Open Circuits .....	17
	Continuity Test for Short to Ground .....	18
	Resistance Test for Electrical Components .....	19
	Measuring Voltage .....	20
	Diodes .....	21
	Test Procedure .....	21
	Electro-hydraulic Solenoid Valve Coils .....	22
	Test Procedure .....	22
	Operational Check .....	22
	Relays .....	23
	Test Procedure .....	24
	Welding on the Machine .....	24
	Protecting The Electronic/Electrical Systems During Charging or Welding .....	25
	6 Cylinder Main Fuse / Relay Panel .....	26
	Options Relay .....	27
	Wiring Harnesses and Connectors - All Models .....	28
	Connectors .....	28
	Harness Splices .....	28

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

## Chapter 1 - General Information (Continued)

### CONTENTS

Section	Description	Page
	Fuses, Relays, and Switches .....	28
	Switch and Relay Contacts .....	28
	Grounds .....	28
	Power Sources .....	28
	Wire Harness Identification .....	28
	Wire Color Codes .....	29
	Ground Distribution System .....	30
	Ground Points .....	30
	Ground Point R .....	31
	Ground Point 1 .....	31
	Ground Point 4 .....	32
	Ground Point 5 .....	33
	Ground Point 7 .....	34
	Ground Point 8 .....	34
	Electronic Components .....	35
	Function Monitoring, Machine Configuration, and Diagnostics Menus .....	36
	Selectable Functions Monitoring .....	36
	Machine Configuration/User Setup Menu .....	38
	Critical Warning Displays - Automatic Shutdown .....	43
	Critical Warning Displays - No Shutdown .....	45
	Non-Critical Warning Displays .....	46
	Electrical Fault Codes .....	46
	System Monitoring .....	47

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

## Chapter 2 - Power Distribution

### CONTENTS

Section	Description	Page
	Description, Power Distribution, and Troubleshooting . . . . .	2
	XCM Power . . . . .	2
	Unswitched XCM Power . . . . .	2
	Operation . . . . .	2
	Switched XCM Power . . . . .	3
	Operation . . . . .	3
	Power Distribution . . . . .	4
	Main Distribution Panel - Fuse Block . . . . .	5
	Unswitched Power . . . . .	6
	Q-29 #2 Main Circuit Breaker . . . . .	6
	Q-30 #4 Main Circuit Breaker Busbar . . . . .	6
	Battery Busbar . . . . .	6
	Q-31 #1 Main Circuit Breaker Busbar . . . . .	7
	Switched Power . . . . .	7
	K-33 VI Supply Busbar . . . . .	7
	K-38 IGN Control Busbar . . . . .	7
	K-04 ACC Control Busbar . . . . .	8

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

## Chapter 3 - Air Conditioning Systems

### CONTENTS

Section	Description	Page
	Air Conditioning Systems .....	2
	Introduction .....	2
	General Principles of Operation (Manual and ATC Systems) .....	2
	Manual HVAC System (Standard) .....	4
	Operation .....	4
	Troubleshooting .....	4
	A/C Clutch Circuit (Manual HVAC) .....	8
	Operation .....	8
	Troubleshooting .....	8
	Automatic (ATC) HVAC System .....	12
	Operation .....	12
	Control Operation Specifications .....	12
	General Operation .....	13
	Heater Operation .....	13
	Heater Operation – Sequence of Events .....	13
	Defrosting/Defogging Operation .....	14
	Air Conditioner (A/C) Operation .....	14
	Ventilation .....	14
	System Component Functions .....	14
	Automatic Fan Speed Control (AUTO) .....	14
	Manual Mode Fan Speed Control (Up/Down) .....	14
	A/C Compressor Clutch Control .....	14
	Heater Water Valve .....	15
	Cab Air Temperature Sensor .....	15
	Evaporator Probe .....	15
	ATC HVAC Component Usage .....	15
	Troubleshooting .....	16
	Fault Codes .....	16
	Advanced Diagnostics Display Mode .....	19
	Revision Level .....	20
	Setting Parameters .....	21
	ATC Troubleshooting Quick-Checks .....	21
	A/C Clutch Circuit (ATC HVAC) .....	27
	Operation .....	27
	Troubleshooting .....	27

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

## Chapter 4 - Lighting Systems

### CONTENTS

Section	Description	Page
	Introduction .....	2
	Lamp Replacement Chart .....	2
	Flashing Lights and Turn Signals .....	2
	General .....	2
	Operation .....	2
	Troubleshooting .....	3
	Road Lights, Tail Lights and Console Light Circuits .....	10
	Operation .....	10
	Troubleshooting .....	10
	Work Lights Circuits .....	19
	Operation .....	19
	Troubleshooting .....	19
	Exit Lighting (Left Side Stubble Light) .....	27
	Operation .....	27
	Procedure .....	27
	Console and Dome Lights Circuits .....	28
	Operation .....	28
	Troubleshooting .....	28

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

## Chapter 5 - Engine Electrical Systems

### CONTENTS

Section	Description	Page
	Introduction .....	2
	Electrical Components .....	2
	Electronic Control Unit .....	3
	Pinout Diagram - Connector A .....	3
	Pinout Diagram - Connector B (X034) .....	4
	Pinout Diagram - Connector C .....	5
	Crankshaft Sensor .....	6
	Camshaft Sensor .....	6
	Boost Temperature-Pressure Sensor .....	7
	Engine Oil Temperature - Pressure Sensor .....	8
	Rail Fuel Pressure Sensor .....	9
	Electro-Injectors .....	10
	Grid Heater .....	11
	Grid Heater Control Relay .....	11
	Engine Starting Motor Circuit .....	12
	Coolant Temperature Sensor .....	17
	4-Line Display - Engine Coolant Temperature Scale .....	18
	A-Pillar Display - Engine Coolant Temperature Scale .....	18
	Fuel Temperature Sensor .....	19
	Filter Heater Relay .....	20
	Pressure Regulator .....	20
	Air Filter Switch .....	20
	Troubleshooting .....	21
	Fuel Level Gauge Circuit .....	24
	Sender Resistance Chart .....	25
	Troubleshooting .....	26
	Fuel Water Switch .....	28
	Replacing the Filter .....	29
	Rotary Radiator Screen Cleaner .....	32
	Troubleshooting .....	32

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

## Chapter 6 - Charging Electrical Systems

### CONTENTS

Section	Description	Page
	Introduction .....	3
	Battery .....	5
	Size and Rating .....	5
	How a Battery Works .....	5
	Battery Troubleshooting .....	5
	Determining the Cause of Failure .....	6
	Application and Installation .....	6
	Service History .....	6
	Visual Inspection .....	6
	Troubleshooting Summary .....	8
	Testing The Battery - General .....	9
	"Key Off" Current Drain .....	10
	Voltage Drop Test .....	11
	Charging the Battery .....	12
	Determining Battery Charge Procedure .....	12
	Slow Charge Procedure: For Batteries with Charges Below 11.0V .....	12
	Selecting Battery Charging Method .....	13
	Slow Charge Procedure .....	14
	Standard Charge Procedure: Preferred Method for Batteries with Voltage of 11 - 12.5 V .....	15
	Fast Charge Procedure: Alternative Method for Batteries with Voltages of 11 - 12.5 V .....	15
	Battery Charging Precautions .....	16
	Battery Specifications .....	16
	Alternator .....	17
	Charging System Excitation Circuit Operation .....	17
	Alternator and Voltage Regulator .....	17
	Maintaining the Alternator .....	18
	Alternator Connections .....	19
	Alternator and Voltage Regulator Precautions .....	19
	Belts - Engine .....	20
	Belt Inspection (check every 1200 hours) .....	20
	Compressor Belt Replacement .....	21
	Drive Belt Replacement .....	22

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

### Chapter 6 - Charging Electrical Systems (Continued)

#### CONTENTS

Section	Description	Page
	Welding On the Machine .....	23
	Troubleshooting .....	23
	Testing the Alternator .....	23
	Alternator Removal .....	25
	Alternator Installation .....	27

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

### Chapter 7 - Electro-Hydraulic Systems

#### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Introduction .....	2
	Hydraulic Oil Level Switch Circuit .....	2
	Troubleshooting .....	4
	Hydraulic Oil Temperature Switch Circuit .....	6
	Troubleshooting .....	7
	Hydraulic Charge Pressure Switch Circuit .....	9
	Troubleshooting .....	10
	Seat Occupied Circuit .....	12
	Troubleshooting .....	13
	Header Drive Circuit .....	15
	Header Reverse Circuit .....	17
	Header Speed Circuit .....	19
	Master Hydraulic Solenoid Circuit .....	21
	Header Raise/Lower Circuit .....	23
	Header Raise Circuit .....	23
	Header Lower Circuit .....	23

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

### Chapter 7 - Electro-Hydraulic Systems (Continued)

#### CONTENTS

Section	Description	Page
	Header Tilt Up/Tilt Down Circuit .....	28
	Header Tilt Up Circuit .....	28
	Header Tilt Down Circuit .....	28
	Header Flotation Trim Circuit .....	30
	Hydrostatic High Speed Circuit .....	33

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

### Chapter 8 - Dealer Setup/Diagnostics Tests

#### CONTENTS

Section	Description	Page
	Accessing Diagnostic Mode .....	2
	Inputs .....	3
	Engine Inputs .....	4
	Fuel Inputs .....	5
	Header Inputs .....	5
	Hydraulics Inputs .....	6
	Lights Inputs .....	7
	Preheat Inputs .....	7
	Propulsion Inputs .....	8
	PTO Inputs .....	8
	Reel Inputs .....	9
	Outputs .....	9
	Header Outputs .....	10
	HVAC Outputs .....	11
	Preheat Outputs .....	12
	Wiggle Test .....	12
	Display (LCD) Test .....	12
	Fault History Screen .....	13

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

### Chapter 9 - Audible Alarm

#### CONTENTS

Section	Description	Page
	Enable/Disable the Low and Medium Priority Fault/Warning Messages .....	2
	Select Audible Alarm Volume .....	2
	Audible Alarm Priorities .....	2
	Low Priority Warnings .....	2
	Medium Priority Warnings .....	2
	High Priority Warnings .....	3

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 3 - 87738741

### Chapter 10 - Controller Area Network (CAN)

#### CONTENTS

Section	Description	Page
55 000	CAN Network Basics .....	2

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87738742

## Chapter 11 - Fault Codes

### CONTENTS

Section	Description	Page
	Introduction .....	4
	Fault Code Format (SPN/FMI Codes) .....	5
	SPN/FMI Code Charts .....	5
	FMI Codes .....	5
	SPN Codes .....	6
	Engine Fault Code .....	11
	FAULT CODE - 102-03 Air Filter Restriction Switch Shorted to High Source ....	11
	Fuel Fault Codes .....	14
	FAULT CODE - 301-04 Fuel Water Switch Shorted to Low Source .....	14
	Hydraulic Fault Codes .....	17
	FAULT CODE - 001-03 Hydraulic Charge Pressure Switch Shorted to High Source .....	17
	FAULT CODE - 002-03 Hydraulic Reservoir Level Sensor Shorted to High Source .....	20
	FAULT CODE - 003-03 Hydraulic Oil Temperature Switch Shorted to High Source .....	23
	Propulsion Fault Codes .....	26
	FAULT CODE - 404-03 MFH Position Sensor Shorted to High Source .....	26
	FAULT CODE - 404-04 MFH Position Sensor Shorted to Low Source .....	30
	FAULT CODE - 404-14 MFH Position Sensor Special Instructions .....	34
	FAULT CODE - 405-03 Pintle Arm Position Sensor Shorted to High Source ....	38
	FAULT CODE - 405-04 Pintle Arm Position Sensor Shorted to Low Source ....	41
	FAULT CODE - 406-03 Propulsion Cylinder Position Pot A Shorted to High Source .....	44
	FAULT CODE - 406-04 Propulsion Cylinder Position Pot A Shorted to Low Source .....	48
	FAULT CODE - 406-13 Propulsion Cylinder Position Pot A and Pot B Needs Calibration .....	52
	FAULT CODE - 407-03 Propulsion Cylinder Position Pot B Shorted to High Source .....	56
	FAULT CODE - 407-04 Propulsion Cylinder Position Pot B Shorted to Low Source .....	60
	FAULT CODE - 407-13 Propulsion Cylinder Position Pot A and Pot B Needs Calibration .....	64

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87738742

## Chapter 11 - Fault Codes (Continued)

### CONTENTS

Section	Description	Page
	FAULT CODE - 408-03 MFH Neutral Switch Shorted to High Source . . . . .	68
	FAULT CODE - 408-07 MFH Neutral Switch Mechanical Out of Range . . . . .	70
	FAULT CODE - 409-03 Park Brake Switch Shorted to High Source . . . . .	72
	FAULT CODE - 411-13 Propulsion Cylinder Position Pot A Needs Calibration . . . . .	75
	FAULT CODE - 412-13 Propulsion Cylinder Position Pot A Needs Calibration . . . . .	79
	FAULT CODE - 413-13 Propulsion Cylinder Position Pot A Needs Calibration . . . . .	83
	FAULT CODE - 414-13 Propulsion Cylinder Position Pot B Needs Calibration . . . . .	87
	FAULT CODE - 415-13 Propulsion Cylinder Position Pot B Needs Calibration . . . . .	91
	FAULT CODE - 416-13 Propulsion Cylinder Position Pot B Needs Calibration . . . . .	95
	FAULT CODE - 418-03 MFH Position Sensor Shorted to High Source . . . . .	99
	FAULT CODE - 418-04 MFH Position Sensor Shorted to Low Source . . . . .	103
	FAULT CODE - 418-13 MFH Position Sensor Needs Calibration . . . . .	107
	FAULT CODE - 419-03 MFH Position Sensor Shorted to High Source . . . . .	110
	FAULT CODE - 419-04 MFH Position Sensor Shorted to Low Source . . . . .	114
	FAULT CODE - 419-07 MFH Position Sensor Mechanical Out of Range . . . . .	118
	FAULT CODE - 419-13 MFH Position Sensor Needs Calibration . . . . .	121
	FAULT CODE - 420-03 MFH Position Sensor Shorted to High Source . . . . .	124
	FAULT CODE - 420-04 MFH Position Sensor Shorted to Low Source . . . . .	128
	FAULT CODE - 420-07 MFH Position Sensor Mechanical Out of Range . . . . .	132
	FAULT CODE - 420-13 MFH Position Sensor Needs Calibration . . . . .	135
	FAULT CODE - 421-03 MFH Position Sensor Shorted to High Source . . . . .	138
	FAULT CODE - 421-04 MFH Position Sensor Shorted to Low Source . . . . .	142
	FAULT CODE - 421-13 MFH Position Sensor Needs Calibration . . . . .	146
	FAULT CODE - 424-03 Propulsion Forward Solenoid L-14p Shorted to High Source . . . . .	149
	FAULT CODE - 424-04 Propulsion Forward Solenoid L-14p Shorted to Low Source . . . . .	152
	FAULT CODE - 424-13 Propulsion Forward Coil Needs Calibration . . . . .	154

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87738742

## Chapter 11 - Fault Codes (Continued)

### CONTENTS

Section	Description	Page
	FAULT CODE - 425-03 Propulsion Forward Solenoid L-14t Shorted to High Source .....	156
	FAULT CODE - 425-04 Propulsion Forward Solenoid L-14t Shorted to Low Source .....	159
	FAULT CODE - 425-13 Propulsion Forward Coil Needs Calibration .....	161
	FAULT CODE - 426-03 Propulsion Reverse Solenoid L-15p Shorted to High Source .....	163
	FAULT CODE - 426-04 Propulsion Reverse Solenoid L-15p Shorted to Low Source .....	166
	FAULT CODE - 426-13 Propulsion Reverse Coil Needs Calibration .....	168
	FAULT CODE - 427-03 Propulsion Reverse Solenoid L-15t Shorted to High Source .....	170
	FAULT CODE - 427-04 Propulsion Reverse Solenoid L-15t Shorted to Low Source .....	173
	FAULT CODE - 427-13 Propulsion Reverse Coil Needs Calibration .....	175
	FAULT CODE - 428-03 Propulsion Cylinder Position Sensor R-23A Shorted to High Source .....	177
	FAULT CODE - 429-03 Propulsion Cylinder Position Sensor R-23A Shorted to High Source .....	182
	FAULT CODE - 430-03 Propulsion Cylinder Position Sensor R-23A Shorted to High Source .....	187
	FAULT CODE - 431-03 MFH Position Sensor R-18 Shorted to High Source ..	191
	FAULT CODE - 432-03 MFH Position Sensor R-18 Shorted to High Source ..	194
	FAULT CODE - 433-03 Propulsion Cylinder Shorted to High Source .....	197
	FAULT CODE - 434-03 Propulsion Cylinder Shorted to High Source .....	201
	FAULT CODE - 435-03 Propulsion Enable Relay K-35 Shorted to High Source .....	205
	FAULT CODE - 435-04 Propulsion Enable Relay K-35 Shorted to Low Source .....	207
	PTO Fault Codes .....	209
	FAULT CODE - 200-12 Header Speed Sensor Bad Intelligent Device .....	209

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87738742

### Chapter 12 - Wiring Harnesses

#### CONTENTS

Section	Description	Page
	Standard Wiring Harnesses .....	2
	FM Harness (Front) .....	3
	FM Harness (Rear) .....	4
	FM Harness (Engine LH) .....	5
	LL and RL Harnesses (Lighting) .....	6
	CM Harness (Electrical Panel) .....	7
	CM Harness (Inside Cab) .....	8
	CM Harness (Seat and Right Hand Console) .....	9
	OR Harness (Outside Roof) .....	10
	RM Harness (Inside Roof) .....	11
	SC-D Harness (Steering Column) .....	12

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 5 - 87738743

### Chapter 13 - Standard Wire Harness Connector Information

#### CONTENTS

Section	Description	Page
	Standard Wire Harnesses .....	2

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 5 - 87738743

## Chapter 14 - Troubleshooting Optional Equipment

### CONTENTS

Section	Description	Page
	A-Pillar Display .....	2
	Wire Harness Routing/Connections .....	3
	Troubleshooting .....	4
	Automatic Temperature Control (ATC) .....	7
	Cold Start (Thermostart) .....	7
	Circuit Description .....	7
	Switch Removal .....	7
	Switch Connections .....	8
	Wire Harness Routing .....	8
	Troubleshooting .....	9
	Deluxe Mirrors .....	12
	Circuit Description .....	12
	Switch Removal .....	13
	Switch Connectors and Circuitry .....	13
	Accessing the Outer Roof (OR) Harness .....	14
	Roof Panel Installation .....	15
	Wiring Harness Routing .....	15
	Troubleshooting .....	17
	Beacon Mount .....	21
	Circuit Description .....	21
	Switch Removal .....	21
	Connectors and Circuitry .....	22
	Accessing the Outer Roof (OR) Harness .....	23
	Roof Panel Installation .....	24
	Wiring Harness Routing and Connections .....	24
	Troubleshooting .....	26
	Adjustable Windrow Shields .....	29
	Circuit Description .....	29
	Windrow Shields Wide (Open) .....	30
	Windrow Shields Narrow (Close) .....	30
	Switch Connection .....	30

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 5 - 87738743

### Chapter 14 - Troubleshooting Optional Equipment (Continued)

#### CONTENTS

Section	Description	Page
	Troubleshooting .....	31
	Position Sensor Potentiometer Test .....	32
	Sickle Header Drive Adapter (2300 and HS Series) .....	36
	Troubleshooting .....	37
	Draper Header Drive Adapter .....	37

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 5 - 87738743

### Chapter 15 - Electrical Schematics

#### CONTENTS

Section	Description	Page
	Introduction .....	2
	Electrical Components Index .....	3
	Using Schematics .....	8
	Power .....	9
	Grounds .....	9
	Connections .....	9
	Harnesses .....	10
	Standard Harnesses .....	10
	Optional Harnesses .....	10
	Wire Harness Routing .....	11
	Circuit Identification .....	11
	Windrower Electrical Schematic .....	12

---

# SECTION 58 - HEADER ATTACHMENTS

BOOK 6 - 87738744

## Chapter 1 - General Information

### CONTENTS

Section	Description	Page
	Overview .....	2
	Draper Floatation .....	2
	Operation .....	2
	Overhaul .....	3
	Cut Height Cylinders .....	3
	Removal .....	3
	Inspection .....	4
	Installation .....	5
	Control Valve Manifold .....	6
	Remove and Replace .....	6
	Hydraulic System Check .....	7
	Hydraulic System Check with Header Installed .....	7
	Electrical System - Fuse and Relay .....	7
	Removal .....	7
	Switches .....	8
	Removal .....	8
	Solenoid Connectors .....	8
	Inspection .....	8
	Energized Components .....	9
	Header to Machine Connector .....	10
	Theory of operation – Flow Divider .....	11
	Hydraulic Components, Flow Divider Circuit .....	12
	Height Control Logic .....	13
	Valves Energized During Indicated Function .....	13
	Troubleshooting .....	36
	Diagnostic Charts .....	36
	Preliminary Diagnostic Chart .....	36

---

# SECTION 58 - HEADER ATTACHMENTS

BOOK 6 - 87738744

## Chapter 2 - Factory Installed Draper Header

### CONTENTS

Section	Description	Page
	Cartridge Valves .....	2
	Removal .....	2
	Installation .....	2
	Valve Component location .....	2
	Hydraulic System Check .....	4
	Hydraulic System Check with Header Installed .....	4
	Electrical System - Fuse And Relay .....	4
	Removal .....	4
	Wire Harnesses .....	6
	Schematics .....	7

---

# SECTION 58 - HEADER ATTACHMENTS

BOOK 6 - 87738744

## Chapter 3 - Dealer Installed Draper Header

### CONTENTS

Section	Description	Page
	Cartridge Valves .....	2
	Removal .....	2
	Installation .....	2
	Valve Component Location .....	2
	Reel Lift Valve .....	3
	Removal .....	3
	Draper Cut Height Control Valve Manifold .....	3
	Remove and Replace .....	3
	Flow Divider Manifold .....	4
	Removal .....	4
	Replacement .....	5
	Hose Routing - Cut Height Cylinders .....	7
	Hydraulic System Check .....	8
	Hydraulic System Check with Header Installed .....	8
	Electrical System - Fuse and Relay .....	8
	Removal .....	8
	Switches .....	9
	Removal .....	9
	Solenoid Connectors .....	9
	Inspection .....	9
	Wire Harnesses .....	11
	Schematics .....	12

---

# SECTION 58 - HEADER ATTACHMENTS

BOOK 6 - 87738744

## Chapter 4 - Draper Setup

### CONTENTS

Section	Description	Page
	Accessing Dealer Setup .....	2
	New Holland Multi-Function Handle (MFH) .....	2
	Dealer Setup Navigation .....	2
	Dealer Setup Menu .....	3
	DIA Options Menu .....	3
	User Configure Menu .....	4
	Draper Head PTO Calibration .....	5

---

# SECTION 88 - OPTIONAL EQUIPMENT

BOOK 6 - 87738744

## Chapter 1 - Optional Equipment

### CONTENTS

Section	Description	Page
	Optional Kits .....	2
	Deluxe Cab Upgrade Package .....	2
	A-Pillar Display .....	2
	Automatic Temperature Control (ATC) .....	3
	Window Screen Kit .....	3
	Premium Speaker Kit .....	3
	Radio (A-11) .....	4
	Service Floodlight .....	4
	Cold Start Kit .....	5
	Deluxe Mirror .....	5
	Beacon Mount Kit .....	6
	Adjustable Windrow Shield .....	6
	Deck Shift Draper Header Adapter Kit .....	6
	Hydraulic Reel Drive Kit .....	7
	Engine Mounted Auxiliary Hydraulic Pump .....	7
	Model HDX2 Sickle Header Drive Adapter Kit .....	7
	Model HDX1 Sickle Header Drive Adapter Kit .....	8
	Draper Header Drive Adapter Kit .....	8
	Swath Roller Hitch .....	8
	Rear Suspended Damper .....	9
	Rear Suspended Axle .....	9
	Weight Carrier Kit .....	10
	Chaff Wiper Kit .....	10



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

---

# SECTION 90 - PLATFORM, CAB AND DECALS

BOOK 6 - 87738744

## Chapter 1 - Platform, Cab and Decals

### CONTENTS

Section	Description	Page
	Description of Operation - Platform .....	3
	Deluxe Operator's Seat .....	3
	Controls .....	3
	Armrest Height .....	3
	Height/Weight Adjustment .....	3
	Backrest Angle .....	3
	Fore/Aft Position .....	3
	Lumbar Adjustment Knob .....	4
	Seat Belt .....	4
	Cleaning .....	4
	Replacement .....	4
	Lower Seat .....	5
	Removal of Seat from Seat Base .....	5
	Disassembly .....	5
	Upper Seat .....	6
	Removing Armrest .....	6
	Armrest .....	6
	Removal .....	7
	Replacing Seat Height Switch .....	8
	Removing Bottom Seat Cushion .....	10
	Removing Seat Back Cushion .....	10
	Fore/Aft Adjustment Rails .....	10
	Removing Seat from Slide Rails .....	10
	Removing Slide Rails from Suspension .....	11
	Seat Suspension System .....	11
	Seat Air Compressor .....	11
	Height Adjustment .....	11
	Overhaul - Platform .....	12
	Seat Suspension .....	12
	Disassembly .....	12
	Seat Suspension Components .....	15

---

# SECTION 90 - PLATFORM, CAB AND DECALS

BOOK 6 - 87738744

## Chapter 1 - Platform, Cab and Decals (Continued)

### CONTENTS

Section	Description	Page
	Rubber Bumpers .....	15
	Inspection .....	15
	Release Valve/Solenoid .....	15
	Inspection .....	15
	Air Compressor .....	16
	Inspection .....	16
	Fore/Aft Adjustment Lever .....	17
	Inspection .....	17
	Damping Shock Absorber .....	17
	Inspection .....	17
	Scissors Suspension .....	18
	Inspection .....	18
	Troubleshooting .....	19
	Seat Air Compressor Does Not Run .....	19
	Overhaul - Cab .....	20
	Cab Door .....	20
	Removal .....	20
	Installation .....	20
	Cab Door Handle .....	20
	Removal .....	20
	Installation .....	20
	Cab Floor Mat .....	21
	Removal .....	21
	Inspection .....	21
	Cab Suspension .....	21
	Removal and Replacement .....	22
	Cab Roof .....	23
	Removal .....	23
	Inspection .....	26
	Installation .....	26
	Safety Decals .....	29

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**