


**PRIMARY SHAFT**



## Primary shaft


### General presentation

The primary shaft and its pinions form the upper line of the gearbox. The primary shaft supports the 1<sup>st</sup>, 2<sup>nd</sup>, 3<sup>rd</sup> and 4<sup>th</sup> gear driven pinions. The rear teeth is in constant mesh with the Turtle pinion. The shaft front is supported by the tapered bearing at the rear of the input housing and by the bearing fitted in the housing rear bearing assembly.

The 1<sup>st</sup> and 4<sup>th</sup> gear pinions are maintained in position by 2 spacers. The axial clearance of the pinions is achieved by the fitting of the shims between the 1<sup>st</sup> and 2<sup>nd</sup> gear pinions.

### Removal/installation of the primary shaft

#### Step 7




B1-013


Fig. 1

### Preliminary operations

To properly shim the bearings when replacing the primary shaft, it is required to remove the gearbox.



**Primary shaft**



B1-079

Fig. 2

**Description**

- |                                 |                                  |
|---------------------------------|----------------------------------|
| (1) Needle bearing              | (9) 4 <sup>th</sup> gear pinion  |
| (2) Primary shaft               | (10) Spacer                      |
| (3) Inner cage bearing          | (11) 1 <sup>st</sup> gear pinion |
| (4) Cup bearing                 | (12) Shims                       |
| (5) Shims                       | (13) 2 <sup>nd</sup> gear pinion |
| (6) Deflector                   | (14) Circlip                     |
| (7) 3 <sup>rd</sup> gear pinion | (15) Inner cage bearing          |
| (8) Spacer                      | (16) Cup bearing                 |

**<https://www.ebooklibonline.com>**


Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**



## Primary shaft

### Removal



- Remove the deflector, the shims and the cup. Extract the assembled shaft (Fig. 3).
- Extract the bearing cones.
- Note: couple the cones and the cups in case of reuse.**
- Remove the circlip.
- Remove the 2<sup>nd</sup> gear pinion, the shims, the 1<sup>st</sup> gear pinion and the spacer.
- Remove the 4<sup>th</sup> and 3<sup>rd</sup> gear pinion.
- Extract the needle bearing and discard it.

### Installation

- Clean and inspect the parts, replace all faulty parts.
- Fit the needle bearing in contact on the shaft shoulder using a press.
- Note: after fitting, make sure that the needle normally turn in the cage.**
- Install the 3<sup>rd</sup> gear pinion and the 4<sup>th</sup> gear pinion.
- Slide the spacer. Fit the 1<sup>st</sup> gear pinion and the 2<sup>nd</sup> gear pinion.
- Fit the circlip
- Using a set of feeler gauges, measure the space between the 1<sup>st</sup> gear pinion and the 2<sup>nd</sup> gear pinion. Depending on the measure, determine a thickness of shims to obtain a clearance (Fig. 4) :  
**J1 = 0 to 0.25 mm.**
- Remove the circlip and the pinion.
- Slide the previously selected shims on the shaft. Fit the pinion and the circlip.
- Fit the cones to the press using an appropriate fitting.
- Install the assembled shaft and the cup.
- Note: As it is not required to adjust again the bearings when replacing the pinions, the disassembling of the primary shaft can be performed without removing the gearbox of the rear axle according to the following method.**


### Removal

- Remove the 1<sup>st</sup> - 2<sup>nd</sup> gear synchroniser lock and position the lock in order to release the fork.
- Remove the lubrication tube and the spring. Loosen the nut.
- To facilitate the disengaging of the 1<sup>st</sup> gear pinion to remove the assembled shaft, advance the input pinion fitted with its bearing, the 1<sup>st</sup> - 2<sup>nd</sup> gear pinion and the synchro.
- Remove the pinions.



### Installation

- Perform the removal operations in the reverse order.
- Replace the nut.
- Torque tighten the nut of the synchroniser lock to 25 to -30 daN.m.
- Check the axial clearance of the 1<sup>st</sup> - 2<sup>nd</sup> gear pinions and the synchro operation.




## Primary shaft

### Installation of the input housing and adjustment of the primary shaft

- Input housing installation.
- Chock the primary shaft (Fig. 5) to obtain a clearance:  $J2 = 0.04 / 0.12 \text{ mm}$  (Fig. 6).
- Fit the locally manufactured tool in the primary shaft (Fig. 7).
- Slightly compress the spring tightening the nut of the tool in order to properly seat the cones in the cups.
- Slightly rotate the shaft.
- Using a depth gauge, measure the dimension «X» between the face «A» of the cup and the face «B» of the casing (Fig. 6).
- Measure the thickness «Y» of the deflector.
- Calculate the difference between «X» and «Y».
- Determine the required thickness of shims to achieve  $J2$ .
- Remove the compression tool.
- Position the previously selected shims.
- Fit the deflector in the casing.
- Install the selection cover.
- Install the power take off shaft (with the big shoulder in the front)


**Note: do not forget to position the screw on the casing before installing the cover.**

- Couple the gearbox to the engine.
- Couple the tractor between the gearbox and the rear axle.
- Check :
  - the sealing of the circuits,
  - the operation of the electric circuits.
- Road test of all the controls.
- Check the sealing of the unions and seal faces (selection cover, gearbox on the rear axle).




B1-082

Fig. 5




B1-083

Fig. 6




B1-084

Fig. 7




## Primary shaft

Personal notes:



**REAR INTERMEDIATE SHAFT**



## Rear intermediate shaft

### General presentation

The output shaft transmits the movement provided by the different gear ratios to the gear shaft of the rear axle. It is fitted on the transmission lower line at the rear of the housing.


At the front it is supported by a needle bearing centred in the bore of the front intermediate shaft, and at the rear by two tapered bearings fitted opposite each other.

The rear intermediate shaft supports:

- the 3<sup>rd</sup> gear driving pinion, mounted free on the combined bearings.
- The 4<sup>th</sup> gear and range pinion assembly, mounted free.
- the Hare/Turtle synchroniser splined integral in rotation.


### Removal/installation of the rear intermediate shaft

#### Step 8



B1-014


Fig. 1



## Rear intermediate shaft

To ensure a proper operation of the assembly depending on the efforts undergone by the transmission, several adjustments are required:

- **J3 adjustment:** using the adjusting shim(s): it makes it possible to suppress the clearance of the bearings at the rear of the shaft.
- **J4 adjustment:** the adjustment shim(s) positioned between the shaft shoulder and the bearing enable(s) an axial clearance of the 3<sup>rd</sup> gear driving pinion.




B1-086

Fig. 2

### Description

- |                             |                            |
|-----------------------------|----------------------------|
| (1) Needle cage             | (16) Circlip               |
| (2) Rear intermediate shaft | (17) "Turtle" pinion       |
| (3) Circlip                 | (18) Bush                  |
| (4) Cup                     | (19) Dog clutch            |
| (5) Bearing                 | (20) Synchro rings         |
| (6) Bearing                 | (21) Double cone           |
| (7) Cup                     | (22) Full synchro          |
| (8) Circlip                 | (23) Synchro rings         |
| (9) Screw                   | (24) Double cone           |
| (10) Stop plate             | (25) Dog clutch            |
| (11) Thickness shims        | (26) Needle cage           |
| (12) Adjustment shims       | (27) Cone                  |
| (13) Adjustment shims       | (28) Needle cage           |
| (14) "Hare" pinion          | (29) Needle thrust bearing |
| (15) Needle thrust bearing  | (30) Synchro rings         |



## Rear intermediate shaft

### Remove the output shaft

Remove the crawler speed housing (A), if fitted.


- Remove the 3 screws.
- Remove the stop plate.
- Remove the bearing cup.


**Note: couple the cones and the cups in case of reuse.**

- Remove the circlip.
- Remove the thickness shim and the adjustment shims.
- Remove the bearing cone.
- Remove the cone.
- Remove the adjustment shims.
- Pull the shaft backwards.
- Remove the shaft.
- Through the opening of the selection cover, extract the synchro, the synchro rings, the Hare pinion with the cones, the ring, the two stop washers and the Turtle pinion.

**Note: couple the synchro rings with the cones. Identify the installation direction of the synchro.**

- Remove the cup and the circlip.
- Remove the needle bearing.





## Rear intermediate shaft

### Installation and adjustment of the rear intermediate shaft

- Clean and inspect the parts, replace all faulty parts.
- Position the circlip and the cup.
- On the shaft, install the needle bearing, the washer and the circlip. Engage the shaft in the casing with the pinions and hub without the sliding gears and without the double-cone rings.
- Slide the bearings on the shaft.

#### J3 adjustment:

- This operation aims at preparing the **J3** adjustment. Keep the bearings in contact on the shaft shoulder applying them a manual pressure.
- Fill in the «Y» space (Fig. 4) between the rear of the bearing cone and the circlip groove with the shims and the thickness shim. Choose a new circlip so that it enters slightly firm in the groove (Fig.6).
- Perform the adjustment (Fig. 5) to achieve: **J3 = 0.05 preload to 0.05 clearance.**




The adjustment consists in suppressing the clearance between the bearings observing the adjustment tolerance indicated above.


If the number of shims «in Y» does not enable to achieve the proper **J3** adjustment, it is possible to adapt the adjustment with the circlip (rectified circlip with different thicknesses to make up for the shim thicknesses).

- Fit the circlip

**Note: position the thickness shim on the circlip side.**

- Fit the cup and the stop plate.
- Torque tighten the screws to 2.7 to -3.2 daNm.





## Rear intermediate shaft

- Position the plunger of the dial gauge at the end of the shaft (Fig. 7).
- Note: for the housing fitted with crawler speeds, use the housing plate (Fig. 10) to replace the stop plate. Torque tighten the screws to 34 to -52 daNm.**
- Pull the shaft turning it alternately clockwise and anticlockwise in order to properly "seat" the cones in the cups.
- Set the dial gauge to zero and repeat the operation by pulling.
- If the read axial clearance exceeds 0.05 mm, determine a shim thickness «X» to achieve J3 (0.05 preload to 0.05 clearance).

### J4 adjustment

The adjustment consists in achieving an axial clearance on the pinion of 0.20 to 0.40.

- Position the dial gauge in order to measure the J4 clearance before adjustment. Read the «Y» value = **0.50 mm**.

Determine the number of shims to insert between the shaft and the bearing in (A).

Perform the operation:


$$Y - 0.30 = 0.50 - 0.30 = 0.20 \text{ mm}$$

(0.30 is the average from 0.20 to 0.40).

Extract the «X» thickness, 0.20 mm of shims then remove the shaft and the pinions to perform the proper installation of the pinions and sliding gears with the double-cone synchro assembly.


**NOTE: perform a "blank" adjustment of the shaft without the sliding gear or the double-cone rings. For the final installation, place the range pinion against the casing as shown on the view. Set the circlip aside with the bearing cage. After passing the assembly, push the shaft.**

**IMPORTANT: first adjust the primary shaft before adjusting the rear intermediate shaft.**




B1-091

Fig. 7



B1-092

Fig. 8




B1-094

Fig. 10




B1-093

Fig. 9



**FRONT INTERMEDIATE SHAFT**



## Front intermediate shaft

### General presentation

The transmitter shaft is fitted on the two taper roller bearings located in the two lower bearing assemblies of the main housing. At the front, it receives the input pinion.


Between the two lower bearing assemblies, it supports the 1<sup>st</sup> and 2<sup>nd</sup> gear driving pinions, mounted free, as well as the 1<sup>st</sup>, 2<sup>nd</sup> gear synchroniser assembly whose hub is splined integral. At the rear, it supports the 4<sup>th</sup> gear driving pinion and the 3<sup>rd</sup> - 4<sup>th</sup> gear synchroniser assembly.

The rear bore has a needle bearing supporting the front end of the output shaft. The lubrication of the rotating parts is ensured by a central duct and radial holes.

The tapered bearings are fitted with preload achieved by the adjustment shims positioned between the washers.

### Removal/installation of the front intermediate shaft

#### Step 9




B1-015

Fig. 1


### Preliminary operations

To remove the transmitter shaft, it is required to remove the gearbox.

- Disconnect the tractor between the gearbox and the rear axle.
- Disconnect the gearbox from the engine.
- Remove the selection cover.
- Disassemble the guide rod and the forks.
- Remove the input housing assembly.
- Remove the primary shaft.
- Remove the rear intermediate shaft.



**Front intermediate shaft**




B1-096

Fig. 2

**Description**

- |                                  |                                  |
|----------------------------------|----------------------------------|
| (1) Nut                          | (17) Double-cone synchro rings   |
| (2) Input pinion                 | (18) Dog clutch                  |
| (3) Bearing                      | (19) 1 <sup>st</sup> gear pinion |
| (4) Cup                          | (20) Circlip                     |
| (5) Washer                       | (21) Cup                         |
| (6) Adjustment shims             | (22) Bearing                     |
| (7) Adjustment shims             | (23) Circlip                     |
| (8) Circlip                      | (24) Full synchro                |
| (9) Sliding gear                 | (25) Double-cone synchro rings   |
| (10) Double-cone synchro rings   | (26) Double-cone synchro rings   |
| (11) Double-cone synchro rings   | (27) Dog clutch                  |
| (12) Dog clutch                  | (28) 3 <sup>rd</sup> gear pinion |
| (13) 2 <sup>nd</sup> gear pinion | (29) Front intermediate shaft    |
| (14) Bush                        | (30) Spring                      |
| (15) Washer                      | (31) Clip                        |
| (16) Double-cone synchro rings   | (32) Lubrication tube            |



## Front intermediate shaft

### Removal/installation and reassembly of the front intermediate shaft

#### Disassembly




- Remove the circlip.
- Remove the 3<sup>rd</sup> - 4<sup>th</sup> gear synchro. Identify the installation direction.
- Remove the synchro rings (21).
- Remove the pinion (18).


**Note: couple the ring and the synchro cone in case of reuse.**

- Position the locking tool Ref. 60 05 006 141 (Fig. 3) and the retaining sleeve, locally manufactured, of the transmitter shaft (Fig. 4).
  - Remove the lubrication tube and the spring.
  - Unlock the nut and loosen it using the socket Ref. 60 05 006 140 (Fig. 5).
  - Remove the input pinion and the cone.
  - Remove the washers and the shims.
  - Remove the tool and the sleeve (Fig. 4 and 5).
  - Extract the shaft from the casing backwards maintaining the 1<sup>st</sup> and 2<sup>nd</sup> gearing assembly.
- Remove in sequence inside the casing: the 2<sup>nd</sup> gear pinion with the bush, the cone, the 2<sup>nd</sup> gear synchro rings, the 1<sup>st</sup>, 2<sup>nd</sup> gear synchro, the 1<sup>st</sup> gear synchro rings, the cone, the 1<sup>st</sup> gear pinion.
- Extract the cups.

**Note: couple the cups and the cones in case of reuse.**

- Measure the thickness of the adjustment shims to adjust the transmitter shaft during the installation operations.
- Remove the cone and the clip.








## Front intermediate shaft

### Installation

- Clean the casing and the seal faces.
- Using a compressed air jet, check that all the ducts of the gearbox and of the shaft are not obstructed. Clean and inspect all parts, replace all faulty parts.
- Lubricate the cones, the cups, the bearing bores, the bush.
- Fit with the press the bearing cone on the shaft.
- Fit the clip.
- Position the outer cage in the casing.
- Increase of about 0.3 mm the thickness of the shims measured when removing, in order to achieve an axial clearance.
- Fit the outer cage.
- In the casing assemble in sequence the 1<sup>st</sup> gear pinion, the cones, the 1<sup>st</sup>/2<sup>nd</sup> gear synchro, the synchro rings, the cones and the 2<sup>nd</sup> gear pinion with the bush and the shims.
- Engage the shaft at the rear of the casing maintaining the pinions/synchro assembly (Fig. 6).
- Note: check that the bush is properly fitted in the pinion.**
- Fit the locking tool and the retaining sleeve (Fig. 3 and 4).
- Fit the washers.
- Fit the cone on the pinion.
- Fit the pinion on the shaft.
- Screw on the nut using the socket. Torque tighten to 13 -17 daNm (Fig. 7).
- Chock the shaft. Remove the unlocking tool and the sleeve (Fig. 3 and 4).






## Front intermediate shaft

- Position the plunger of the dial gauge at the end of the shaft (Fig. 8).
- Through the front of the casing, pull the shaft turning it alternately clockwise and anticlockwise in order to properly seat the cones in the cups. Set the dial gauge to zero.
- Repeat the operation by pushing on the shaft.
- Depending on the «X» clearance read, select the required thickness of shims to achieve a preload: **P1 = 0.14 / 0.20**,
  - a) **X + 0.14** if same bearing,
  - b) **X + 0.20** if new bearing.
- Fit the locking tool and the retaining sleeve (Fig.3 and 4).
- Unlock the nut. Remove the pinion.
- Extract the cup.
- Position the appropriate adjustment shims.
- Install the cup and the pinion.
- Degrease the thread of the shaft with a solvent.
- Slightly coat the nut with Loctite FREINFILET then torque tighten to 13 - 17 daNm.
- Lock the nut by deforming the flange in the groove using an appropriate drift punch.
- Introduce the spring and the lubrication tube in the shaft.
- Remove the locking tool and the retaining sleeve.
- Fit the pinion and the synchro cone, the ring and the 3<sup>rd</sup> and 4<sup>th</sup> gear synchro.
- Install the circlip.
 

**Note: pay attention to the installation direction of the synchro.**
- Manually check:
  - a) the axial clearance of the pinions,
  - b) the rotation of the shaft and its gearing.
- Check that the 1<sup>st</sup> - 2<sup>nd</sup> gear synchro operates normally.




### Final operations

- Install and chock the front intermediate shaft.
- Install the rear intermediate shaft.
- Install the input housing assembly.
- Chock the rear intermediate shaft.
- Install the forks and the guide rod.
- Adjust the reverser selector.
- Install the selection cover.


**Note: do not forget to position the screw on the casing.**



**IMPORTANT: first adjust the front intermediate shaft and then adjust the rear intermediate shaft.**



**RIGHT COVER  
AND FORKS**



## Right cover and forks

### Operating principles

The mechanically-controlled selection cover, fitted on the right cover of the gearbox casing has a lever which is used only to select the four basic speeds.

#### Gearbox lever

##### 1<sup>st</sup> - 2<sup>nd</sup> gear selection (A)

As the gearbox lever is pushed, the finger is engaged in the 1<sup>st</sup> - 2<sup>nd</sup> gear fork inside the grid which prevents the 3<sup>rd</sup> - 4<sup>th</sup> gear fork from displacing.


The 1<sup>st</sup> gear ratio is achieved by displacing the lever forwards according to **(A)** and the 2<sup>nd</sup> gear ratio backwards.

##### 3<sup>rd</sup> - 4<sup>th</sup> gear selection (A and B)

By pushing the gearbox lever to the right, the integral finger of the lever is engaged in the 3<sup>rd</sup> - 4<sup>th</sup> gear fork outside the grid preventing the 1<sup>st</sup> - 2<sup>nd</sup> gear fork from moving. Displacement according to **(A)** and **(B)**


The 3<sup>rd</sup> gear ratio is achieved by displacing the lever forwards and the 4<sup>th</sup> gear ratio backwards.

To shift the 4 mechanical gears, the fork displacement is also limited by the range locking cam **(V)**.



B1-103

Fig. 1




B1-104

Fig. 2

#### Hare/Turtle function (C)

The Hare/Turtle position is performed with the gearbox lever in neutral position and a press on the range contactor. The **(C)** contactor is located on the gearshift lever knob which controls the "Hare/Turtle" solenoid valve through the DRIVETRONIC.



B1-105

Fig. 3




**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**



## Right cover and forks

### Hare position

The «E» solenoid valve (Fig. 4), fitted on the lower part of the right cover (rear axle) opens and supplies the chamber (a) located at the rear of the piston (Fig. 6). The piston is moving forwards and pushes the fork. The oil contained in the chamber (b) is pumped up in the Turtle duct and returns to the 17-bar circuit.


### Turtle position

A new prompting of the contactor on the gearbox lever contactor triggers the closing of the solenoid valve and a pressure drop in the chamber (a) (Fig. 6). The piston is pushed back under the 17-bar pressure action prevailing on the annular face.

The oil contained in the chamber (a) returns to the casing through the hare duct and the duct of the solenoid valve «E» (Fig. 4).


### Hare/Turtle lock (Fig. 5)

The new system preventing from shifting gears at the same time as changing range makes it possible to avoid the simultaneous displacement of the slider driven by the range fork and of the gearbox which is then locked at the neutral point by means of the cam.




B1-106

Fig. 4




B1-107

Fig. 5




B1-108

Fig. 6



**Right cover and forks**

**Tightening torques of the screws on the cover (in daNm)**



**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**