

TABLE OF CONTENTS

380B Tractor

SERIES	SECTION	DESCRIPTION	PUBLICATION
10		GENERAL	
	1000	General Specifications	8 - 57670
	* 1005	Special Service Tools	8 - 58920
	** 1230	Fuel System Specifications	8 - 57721
	1250	Steering System Specifications	8 - 57570
	1280	Hydraulic System Specifications	8 - 56930
20		ENGINE	
	2201	Engine Troubleshooting	8 - 56590
	2215	3 Cylinder Engine Cylinder Head, Valves and Rockers	8 - 57110
	2225	3 Cylinder Engine Cylinder Block, Pistons and Conrods	8 - 57120
	2235	3 Cylinder Engine Crankshaft and Bearings	8 - 57130
	2240	3 Cylinder Engine Camshaft and Idler Gear	8 - 57140
	2245	3 Cylinder Engine Lubrication System	8 - 57170
	* 2310	Separating Tractor - Tractor with Adjustable Front Axle	8 - 56660
	* 2310	Separating Tractor - Tractor with Fixed Cast Front Axle	8 - 58950
	* 2355	Engine Cooling System	8 - 56640
	* 2410	Engine Removal - Tractor with Adjustable Front Axle	8 - 56670
	* 2415	Engine Removal - Tractor with Fixed Cast Front Axle	8 - 58910
30		FUEL SYSTEM	
	3310	Fuel System	8 - 56650
	* 3311	Fuel Injection Pumps - VE Type	8 - 59020
	3312	Fuel Injection Pumps - VA Type	8 - 57630
	3313	Fuel Injectors	8 - 57640
40		ELECTRICAL	
	* 4201	Electrical Troubleshooting	8 - 57010
	* 4210	Wiring Diagram	8 - 57050
	4235	Battery Servicing and Testing	8 - 56980
	4240	Lucas A115 and A127 45 Ampere Alternators and Regulators	8 - 57030
	4330	Bosch JF Starter Motor	8 - 57020
50		STEERING	
	5015	Steering Pump Removal	8 - 57600
	5020	Steering System Oil Pump	8 - 56470
	5025	Steering System Tests and Troubleshooting	8 - 57540
	* 5330	Front Axle - Adjustable Type	8 - 56700
	* 5340	Front Axle - Cast Heavy Duty	8 - 58940
	* 5420	Steering Cylinder - Adjustable Axle	8 - 57410
	* 5430	Steering Cylinder - Fixed Cast Axle	8 - 58930

* New Sections
** Revised Sections

SERIES	SECTION	DESCRIPTION	PUBLICATION
60		POWER TRAIN	
	6001	Clutch Controls, Linkage and Release Bearing	8 - 56520
	6030	Rear Axles	8 - 56480
	6241	Clutch 12 inch (Rockford Type)	8 - 56680
	6306	Steering Support Removal	8 - 57240
	6310	Transmission Speedbox	8 - 56950
	6315	Transmission Rangebox - with Light Duty Park Brake	8 - 56960
	6325	Forward/ Reverse Transmission	8 - 56980
	* 6326	Forward/ Reverse Transmission Troubleshooting	8 - 59380
	6330	Differential - Transmission with Light Duty Park Brake	8 - 57290
	6340	Power Take Off (PTO) Clutch and Lower Shaft	8 - 56540
	6341	Clutch, 11 inch (Laycock Type)	8 - 56690
	* 6342	Power Take Off Troubleshooting	8 - 58220
	6410	Speedbox Removal	8 - 56830
	6411	Rangebox Removal	8 - 57370
70		BRAKES	
	7105	Disc Brakes	8 - 57480
	7110	Brake Master Cylinders and Controls	8 - 57660
	7115	Park Brake	8 - 58250
80		HYDRAULIC SYSTEM	
	8001	Hydraulic Troubleshooting	8-57581
	8005	Hitch Adjustments	8-56920
	8010	Multiple Control Valve (MCV)	8 - 56870
	8015	Unloading and Flow Control Valve	8 - 56880
	8020	Filter and Pump	8 - 56860
	8025	Bosch Remote Valves	8 - 56890
	8030	Draft Cylinder and Rockshaft	8 - 56900
	8035	Control Levers and Raise Rate Valve	8 - 56910
	8040	Hydraulic Housing Removal	8 - 57250
90		CHASSIS AND ACCESSORIES	
	9240	Hood, Fenders and Seatdeck	8 - 56810
100		HOW IT WORKS	
	* 10050	Steering System	8 - 59390
	10080	Hydraulic System	8 - 56940

* New Sections
** Revised Sections

Section 1000

GENERAL SPECIFICATIONS 85 Series Tractors

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

SERIAL NUMBERS

Compiled in this manual are the operating and maintenance instructions for the 85 Series Agricultural Tractors

When in need of service parts always quote the tractor, transmission unit, and engine serial numbers, including prefix and suffix letters.

If information is required that is not available in this manual see the nearest authorized Case Dealer.

Transmission Serial Number

EXAMPLE: 293805 BTY

The suffix letters, BTY denote the build of the unit.

The first letter denotes the type of drive train, B = fast speed transmission, A or D = slow speed transmission.

The second letter denotes the bevel gear ratio,
T = 11:52, S = 14:51 and R = 12:53.

The third letter denotes the operating speeds for the PTO and the number of splines on the upper and lower shafts as shown below.

U	=	555 r/min	6 splines upper shaft
V	=	1000 r/min	6 splines lower shaft
W	=	580 r/min	6 splines upper shaft
X	=	606 r/min	6 splines upper shaft
Y	=	611 r/min	6 splines upper shaft
Z	=	614 r/min	6 splines upper shaft

V denotes that only the lower PTO shaft is fitted, as for compressor drive. When applicable, dual speed installations are indicated by a fourth suffix letter D.

GENERAL SPECIFICATIONS

Specifications for each machine are under individual headings which follow these GENERAL SPECIFICATIONS.

Capacities

Fuel Tanks	UK Value	U.S. Value	Metric Value
XL Tractors	24.6 gal	29.6 gal	112 litres
Non XL Tractors	17 gal	20.3 gal	77 litre
2WD Transmission	7.5 gal	8.9 gal	34 litre
MFD Transmissions	8 gal	9.6 gal	36.5 litre

NOTE: These capacities are only a guide to the quantities. Always use the dipstick or level plug to make sure that units are filled to the correct level.

Electrical System

Type of System	12 Volt, Negative ground
Battery (Rating IEC/BS)	
Standard	Reserve Capacity
Cold Cranking Amperes	420 ampere
Heavy Duty	Reserve Capacity
Cold Cranking Amperes	510 ampere
Heavy Duty Plus	Reserve Capacity
Cold Cranking Amperes	510 ampere
Alternators	
XL Tractors	65 amp
Non XL Tractors	45 amp
North America with Simms Cab	75 amp

XL Tractors

Head Lamps (2)	12 Volt, 37.5/60 watt sealed beam or 40/45 watt British prefocus cap (export)
Side Lamps (2)	12 Volt, 10 watt small bayonet cap
Stop Lamps (2)	12 Volt, 21 watt small bayonet cap
Tail Lamps (2)	12 Volt, 10 watt small bayonet cap
Work Lamps	12 Volt, 55 watt Halogen
Registration Number Plate Lamp	12 Volt, 10 watt small bayonet cap
Direction Indicator Lamps (2)	12 Volt, 21 watt small bayonet cap
Instrument Warning Lamps	12 Volt, 1.2 watt capless wedge
Tachometer Lamp	12 Volt, 3 watt capless wedge
Speedometer Lamp	12 Volt, 3 watt capless wedge
Speed Decal Lamp	12 Volt, 1.5 watt capless wedge

Non XL Tractors

Head Lamps	12 Volt, 37.5/60 watt sealed beam 40/45 watt British prefocus cap (export)
Side Lamps (2)	12 Volt, 5 watt festoon
Stop/Tail Lamps (2)	12 Volt, 21/5 watt small bayonet cap
Work Lamp	12 Volt, 35 watt sealed beam
Direction Indicator Lamps (2)	12 Volt, 21 watt small bayonet cap
Registration Number Plate Lamp	12 Volt, 5 watt miniature center contact
Instrument Warning Lamps	12 Volt, 3 watt capless wedge
Tachometer Lamp	12 Volt, 3 watt capless wedge
Speedometer Lamp	12 Volt, 3 watt capless wedge
Panel Lamp	12 Volt, 5 watt festoon

Pistons and Rods

Rings Per Piston	3
Compression Rings Per Piston	2
Oil Rings Per Piston	1
Type of Piston Pin	Full Float
Type of Bearings	Replacement Bearings Available Steel Back with Copper and Lead Liners

Main Bearings

Tractors 385 and 485	3
Tractors 585 685 and 885	5
Type of Bearings	Replacement Bearings Available Steel Back with Copper and Lead Liners

Engine Lubrication System

Type of System	Pressure Spray
Oil Pump	Gear Type
Oil Filter	Full Flow, Turn on Type, Bypass

Fuel System

Fuel Injection Pump	Robert Bosch Type CR
Fuel Transport Pump	None
Governor	Variable Speed, Part of the Fuel Injection Pump
First Stage Fuel Filter	Full Flow Element Type or Turn on Type
Second Stage Fuel Filter	Full Flow Element Type or Turn on Type
Water Trap and Drain for the Fuel Tank	Location is in the Bottom of the Fuel Filters
Fuel Gauge	Location is On the Instrument Panel
Fuel Level Gauge	Location is on the Instrument Panel
Fuel Strainer	None

Air Intake System

Type	Dry Type Air Induction System, Two Stage, with Dust Unloader
------	--

Cooling System

Type	Pressure System, Thermostat Controlled Bypass, Impeller Type Pump
Radiator	Fin and Tube Type
Thermostat	Starts to Open at Approximately 180 Degrees F (82 Degrees C) Fully Open at 203 Degrees F (94 Degrees C)
PressureCap	9 to 12 PSI (62 to 82 kPa)
Water Level Monitor	None
Water Temperature Gauge	Location is on the Instrument Panel

Tractor Brakes

Type	Wet, Hydraulic, Self-Adjusting, Single Disc
------	---

Clutch

Type	Hydraulic Operated, Self Adjusting (XL only), Single Dry Plate
	U.S Value Metric Value
Plate Diameter	385, 485 and 585 11 in 280 mm
	685 and 885 .12 in 305 mm

Transmissions

BASIC

Type 4 Speed Synchromesh with High/Low Ranges and Reverse
 Number of Gears 8 Forward, 4 Reverse
 Controls 2 Levers

OPTIONAL (Not 885/885XL)

Type Forward/Reverse
 Same as Synchromesh, plus a Hydraulically Operated Forward
 and an Increased Speed Reverse
 Number of Gears 8 Forward, 8 Reverse
 Controls 3 Levers

OPTIONAL

Type 2 Speed Power Shift
 Same as Synchromesh, Plus Hydraulically
 Operated Speed Decrease in all Gears
 Number of Gears 16 Forward, 8 Reverse
 Controls 2 Levers and an Electrical Switch

Foot Brakes

Type Hydraulic, Self Adjusting, Oil Cooled Discs

	U.S Value	Metric Value
Disc Diameter	10 in	254 mm

Hydraulic System

Type Independent, with Fully Live
 Hydraulic Pump in the Transmission
 Operating Pressure 175 kg/cm² (2500 lb/in²)

Steering

Type Hydrostatic
 Turning Radius with Brake Assistance: 2WD 132 in 3352 mm
 (with MFD engaged) MFD 146 in 3708 mm
 Turning Radius without Brake Assistance: 2WD 151 in 3835 mm
 (with MFD engaged) MFD 171 in 343 mm

Differential Lock

Type Mechanical Actuated by the Operators Right Foot

Hitch system

Type of Sensing Upper Link
 Type of Control Hand Lever
 Type of Valve Four-Position, Hold, Lift, Lower, and Float
 Type of Draft Arms Rigid, Swing Type, Manual Float Adjuster
 Type of Hitch 385and 485 Three Point, Category one and Two
 585, 685 and 885 Three Point, Category Two
 Quick Hitch Coupler (Available)

Section 2215

CYLINDER HEAD, VALVES and ROCKER ARM

3 Cylinder Engine

85 Series Tractors

TABLE OF CONTENTS

SPECIFICATIONS	3
SPECIAL TORQUES	4
STANDARD TORQUES	4
SPECIAL TOOLS	5
CYLINDER HEAD SERVICING	6
Cylinder Head Removal	6
Cylinder Head Disassembly	12
Cylinder Head Inspection	14
Replacement of Expansion Plug	15
Replacement of Nozzle Holder Sleeves	16
Replacement of Valve Guides	17
Inspection of Valves and Seats	18
Valve Seat Replacement	21
Refacing Intake and Exhaust Valves and Seats	22
Cylinder Head Assembly	26
Rocker Shaft Disassembly and Inspection	28
Rocker Shaft Assembly	30
Cylinder Head Installation	32



WARNING: *This safety symbol is used in this manual to indicate important safety messages. When you see this symbol, read the message carefully. It is shown when possible injury or death can be caused.*

SPECIFICATIONS

	U.S. Value	Metric Value
Cylinder Head Maximum Warpage	0.0047 inch	0.12 mm
Cylinder Head Height		
Standard	3.8902 inch to 3.9098 inch	98.81 to 99.31 mm
Minimum	3.8795 inch	98.54 mm
NOTE: <i>The maximum amount of material that can be removed is 0.030 inch (0.77 mm)</i>		
Intake Valve Stem Diameter	0.3912 to 0.3915 inch	9.935 to 9.945 mm
Exhaust Valve Stem Diameter	0.3920 to 0.3924 inch	9.995 to 9.965 mm
Maximum Stem Clearance in Guide Before Reconditioning	0.006 inch	0.15 mm
Valve Clearances (Engine Warm)	0.012 inch	0.30 mm
Valve Seat Angle	45°	45°
Distance of Cylinder Head Face to Valve Face		
Intake	0.04 to 0.05 inch	1.00 to 1.40 mm
Exhaust	0.047 to 0.06 inch	1.20 to 1.60 mm
Valve guides		
Outside Diameter	0.6323 to 0.6330 inch	16.060 to 16.078 mm
Inside Diameter	0.3883 to 0.3893 inch	9.865 to 9.901 mm
Inside Diameter (Reamed)	0.3940 to 0.3945 inch	10.00 to 10.02 mm
Distance from Top of Valve Guide to		
Bottom of Valve Spring Recess	1.102 inch	28.0 mm
Seat Insert Thickness	0.344 inch	8.75 mm
Seat Outside Diameter		
Standard	1.656 to 1.657 inch	42.07 to 42.09 mm
0.006 inch (0.15mm) Oversize	1.662 to 1.663 inch	42.22 to 42.24 mm
0.016 inch (0.40 mm) Oversize	1.672 to 1.673 inch	42.47 to 42.49 mm
Minimum Valve Seat Contact Width	0.059 inch	1.5 mm
Cylinder Head Counterbore Diameter for Valve Seat Insert		
Standard	1.653 to 1.654 inch	42.000 to 42.020 mm
0.006 inch (0.15mm) Oversize	1.659 to 1.660 inch	42.150 to 42.170 mm
0.016 inch (0.40 mm) Oversize	1.669 to 1.670 inch	42.400 to 42.420 mm
Counterbore Depth from Cylinder Head Face	0.482 to 0.484 inch	12.24 to 12.29 mm
Valve Springs		
Free Length	2.125 ± 0.059 inch	54 ± 1.5 mm
Test Length	1.346 inch	34.2 mm
Test Load	145.5 to 158.7 lb	66 to 72 kg
Rocker Arm Shaft Diameter	0.848 to 0.850 inch	21.56 to 21.59 mm
Rocker Arm Bushing Diameter	0.850 to 0.851 inch	21.671 to 21.63 mm
Rocker Shaft Spring		
Free Length	1.484 inch	37.7 mm
Test Length	0.984 inch	25 mm
Test Load	6.614 lb	3 kg

SPECIAL TORQUES

	U.S. Value	Metric Value
Cylinder Head Bolts (Tighten in three stages)		
First Stage	29 lb ft	40 Nm
Second Stage	58 lb ft	80 Nm
Third Stage	101 to 109 lb ft	140 to 150 Nm
Rocker Arm Shaft Bracket Bolts	43.5 to 50.7 lb ft	60 to 70 Nm
Rocker Arm Shaft Bracket Clamping Bolts	7.4 to 8.8 lb ft	10 to 12 Nm
Exhaust Manifold Nuts	25.4 to 29 lb ft	35 to 40 Nm
Injector Nozzle Retaining Bolts	16.6 to 19.5 lb ft	24 to 27 Nm
Injection Pipe Union Nuts	14.5 to 18.1 lb ft	20 to 25 Nm


STANDARD TORQUES

STANDARD TORQUE DATA FOR NUTS AND BOLTS


Where no special torque data is specified, the following torque figures should be applied. Threads should be lubricated with engine oil or chassis grease. Apply the minimum figure to bolts that have previously been used.

BOLT		TYPE 5				TYPE 8			
		MIN		MAX		MIN		MAX	
SIZE									
inch	(mm)	Nm	lb ft	Nm	lb ft	Nm	lb ft	Nm	lb ft
1/4	6	12	9	14	10	22	12	19	14
5/16	8	26	19	28	21	36	27	41	30
3/8	9	45	33	50	37	61	45	68	50
7/16	11	72	53	81	60	102	75	115	85
1/2	13	108	80	122	90	156	115	176	130
9/16	15	156	115	176	130	224	165	251	185
5/8	16	217	160	244	180	298	220	339	250
3/4	19	393	290	434	320	542	400	610	450
7/8	22	569	420	637	470	881	650	990	730
1	25	854	630	963	710	131	970	1478	1090
1-1/8	28	1152	850	1288	950	187	1380	2102	1550
1-1/4	31	1627	1200	1830	1350	263	1940	2956	2180


SPECIAL TOOLS




1. TORQUE WRENCH




6. VALVE SPRING COMPRESSOR




2. MICROMETER




7. BORE GAUGE




3. CRANKED WRENCH 3055 795 R2



4. DIAL INDICATOR



5. FEELER GAUGES



8. VALVE SPRING TESTER CAS-1357

For the Following Tools, Refer to the Engine Parts Catalog;

- | | |
|--|---|
| 9. VALVE SEAT HOUSING REAMER: 3132 359 R1, 0.006 INCH (0.015 MM) OVERSIZE, OR
3132 358 R1, 0.016 INCH (0.400 MM) OVERSIZE | 14. VALVE GUIDE DRIFT PUNCH: 3055 699 R1 |
| 10. VALVE SEAT INSTALLATION DRIFT PUNCH: 3055 698 R1 | 15. EXPANSION PLUG DRIFT PUNCH: 3055 688 R11 |
| 11. VALVE SEAT CUTTING TOOL: 3132 120 R91 | 16. NOZZLE SLEEVE DRIFT PUNCH: 3055 696 R1 |
| 12. 45° ANGLED REAMER (USED WITH 3132 120 R91): 3132 363 R1 | 17. SLIDE HAMMER ADAPTOR FOR PLT-509
(FES-25-12): OTC 12-M |
| 13. NOZZLE SLEEVE EXTRACTOR BOLT: PLT-509 (FES-25-12) | |

CYLINDER HEAD Removal

NOTE: Some illustrations in this section show the engine removed from the tractor. It is not necessary to remove the engine to service the cylinder head and valves.


WARNING: If the engine has been running, the exhaust will be hot. Use protective gloves to remove the exhaust.

STEP 1




Remove the hood. Refer to Section 9240.

STEP 2




Remove the air cleaner.

STEP 3




Open the radiator drain valve and drain the cooling system. Close the valve when coolant has drained.

STEP 4




Drain coolant from the cylinder block.


STEP 5




Disconnect the top coolant hose.

STEP 6


Loosen the breather pipe clip and pull the pipe clear of the rocker arm cover.

STEP 7


Remove the exhaust elbow.

STEP 8


Remove the gasket, spacer and gasket.

STEP 9

If fitted with a coolant filter/conditioner, disconnect the front pipe.


STEP 10

If fitted with a coolant filter/conditioner, remove the rear pipe.

STEP 11


If fitted with a coolant filter/conditioner, remove the filter and its bracket.

STEP 12




Remove the exhaust manifold and its gaskets.

STEP 15




Remove the coolant manifold.

STEP 13



Loosen the coolant manifold hose clip.

STEP 16




Remove the coolant manifold gaskets.

STEP 14




Remove the coolant manifold bolts.


STEP 17




Disconnect the injector pipes at the injection pump.

STEP 18


Disconnect the injector pipes at the injectors. Remove the pipes

STEP 19


Remove the banjo bolts and two copper washers from the injector back leak unions.

STEP 20

Disconnect the thermostart pipe (or ether start pipe, North America) and the thermostart electrical connection.

STEP 21

Remove the inlet manifold.


STEP 22

Remove the inlet manifold gasket.

STEP 23


Remove the rocker arm cover bolts.

STEP 24




Remove the rocker arm cover.

STEP 27




Remove the push rods.

STEP 25




Remove the rocker arm pedestal bolts.

STEP 28



Remove the cylinder head bolts.


STEP 26



Lift off the rocker arm shaft assembly.


NOTE: *The cylinder head bolts are of two different lengths. The two outer rows are shorter than the two inner rows.*

STEP 29



Attach the cylinder head to a lifting hoist and lift off the cylinder head.

STEP 30




Remove and discard the cylinder head gasket.

Disassembly


NOTE: During disassembly, each part must be put on the workbench in removal order so that on assembly parts can be fitted to the original positions.

STEP 31




Put the cylinder head on a clean workbench.

STEP 32




Remove the bolts and injector retainers.

STEP 33




Remove the injectors. Remove and discard the o-rings.

STEP 34




Use a valve spring compressor to compress the springs.

STEP 35




Remove the valve keepers.


STEP 36




SLOWLY release and remove the valve spring compressor. Remove the valve spring retainer.

STEP 37


Remove the valve spring.

STEP 38

Remove and discard the valve stem seal.

STEP 39

Remove the valve spring seat or rotorcap.

STEP 40

Remove the valve from the cylinder head.

STEP 41


Repeat steps 34 to 41 to remove the other valves. Store all parts in removal order, so that on reassembly parts can be returned to the original positions in the cylinder head.

NOTE: Valve sequence from front to rear of the engine is as follows;

Exhaust, Intake, Exhaust, Intake, Exhaust, Intake

Inspection



STEP 42



Clean the cylinder head, completely removing all carbon and other deposits.

NOTE: Check for cracks or other damage.

STEP 43




Check the cylinder head for warpage using a heavy, accurate straight edge and feeler gauges to the pattern shown in the diagram.

IMPORTANT: If the measurement under the straight edge at the line 1 is more than 0.0047 inch (0.12 mm) the cylinder head must be machined or replaced. If the cylinder head height is less than 3.8795 inch (98.54 mm) after machining, the head must be replaced.


IMPORTANT: The maximum amount of material that can be removed from a cylinder head is 0.030 inch (0.77 mm).

STEP 44




Use a steel spiral brush to remove carbon deposits from the valve guides.

STEP 45




Use a bore gauge to check the valve guide bore in three positions as shown. If the internal diameter is more than 0.3951 inch (10.17 mm), replace the guide.

STEP 46




Check the valve springs. Refer to specifications.

STEP 47



If the expansion plug needs replacing, the plug must be drilled and pulled out.

STEP 48




Apply a heat resistant sealer to the new expansion plug then install the plug level into the cylinder head.

Replacement of Injector Nozzle Sleeves

NOTE: *Injector nozzle sleeves can be removed from the cylinder head without removing or disassembling the head.*

IMPORTANT: *If the cylinder head has not been removed from the tractor, be sure to drain coolant below the level of the cylinder head before removing the sleeves.*

STEP 49




Screw in special bolt (7/8 X 4 inch) PLT- 509-11 (FES 25-12)

NOTE: *The bolt will cut a thread in the brass sleeve.*

Screw a slide hammer adapter OTC-12M (7/16 X 14 NC) into the end of the bolt and use the slide hammer to remove the injector sleeve.


NOTE: *Clean and inspect the sleeve bore.*

STEP 50



Apply "Loctite" Grade B to the sealing surfaces of the new sleeve.

STEP 51



Use special tool 3055 344 R1 to drive in the new sleeve.

NOTE: *Be sure that the sleeve is completely bottomed in the cylinder head.*



Suggest:

If the above button click is invalid.

Please download this document


first, and then click the above link

to download the complete manual.

Thank you so much for reading


Replacement of Valve Guides

STEP 52



Drive out the old guides.


STEP 53



Use special tool 3055 699 R1 to make sure of correct depth when installing the guide.


NOTE: Check dimension *B*. This should be 1.102 inch (28 mm). Grind if necessary.

STEP 54



Install new valve guides, stepped end upward.

STEP 55



Ream the guides to between 0.3940 and 0.3945 inch (10.00 and 10.02 mm).

NOTE: Clean the guides after reaming.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>