

I221F
Tier 4
Wheel Loader

SERVICE MANUAL

Part number 47544213
1st edition English
August 2013



1. STRUCTURE

This service manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This service manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into the following sections.

Structure and function

This group explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

Operational checks and troubleshooting

This group explains the system operational checks and troubleshooting charts correlating problem to remedy.

Tests and adjustments

This group explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Disassembly and assembly

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your Case distributor for the latest information.

2. HOW TO READ THE SERVICE MANUAL

Distribution and updating

Any additions, amendments or other changes will be sent to Case distributors.

Get the most up-to-date information before you start any work.

Filing method


1. See the page number on the bottom of the page.

File the pages in correct order.

2. Following examples shows how to read the page number.

Example 1

3 - 3



3. Additional pages : Additional pages are indicated by a hyphen(-) and number after the page number. File as in the example.

10 - 4

10 - 4 - 1

10 - 4 - 2

10 - 5

Added pages

Revised edition mark (①②③...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

Revisions

Revised pages are shown at the list of revised pages on the between the contents page and section 1 page.

Symbols

So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
		Extra special safety precautions are necessary when performing the work because it is under internal pressure.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications	1-13
Group 3 Operational Checkout Record Sheet	1-26

SECTION 2 ENGINE

Group 1 Structure and Function	2-1
Group 2 Engine speed and Stall rpm	2-15
Group 3 Fuel Warmer System-----	2-16

SECTION 3 POWER TRAIN SYSTEM

Group 1 Structure and Function	3-1
Group 2 Operational Checks and Troubleshooting	3-69
Group 3 Test and Adjustments	3-80
Group 4 Disassembly and Assembly	3-82

SECTION 4 BRAKE SYSTEM

Group 1 Structure and Function	4-1
Group 2 Operational Checks and Troubleshooting	4-30
Group 3 Tests and Adjustments	4-37
Group 4 Disassembly and assembly	4-39

SECTION 5 STEERING SYSTEM

Group 1 Structure and Function	5-1
Group 2 Operational Checks and Troubleshooting	5-18
Group 3 Tests and Adjustments	5-26
Group 4 Disassembly and Assembly	5-34

SECTION 6 WORK EQUIPMENT

Group 1 Structure and Function	6-1
Group 2 Operational Checks and Troubleshooting	6-39
Group 3 Tests and Adjustments	6-50
Group 4 Disassembly and Assembly	6-64

SECTION 7 ELECTRICAL SYSTEM

Group 1 Component Location	7-1
Group 2 Electrical Circuit	7-3
Group 3 Monitoring System	7-21
Group 4 Electrical Component Specification	7-64
Group 5 Connectors	7-71
Group 6 Troubleshooting	7-92

SECTION 1 GENERAL

Group 1 Safety Hints	1-1
Group 2 Specifications	1-13
Group 3 Operational Checkout Record Sheet	1-26

Foreword - Ecology and the environment

Soil, air, and water are vital factors of agriculture and life in general. When legislation does not yet rule the treatment of some of the substances required by advanced technology, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

NOTE: *The following are recommendations that may be of assistance:*

- Become acquainted with and ensure that you understand the relative legislation applicable to your country.
- Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, antifreeze, cleaning agents, etc., with regard to their effect on man and nature and how to safely store, use, and dispose of these substances.
- Agricultural consultants will, in many cases, be able to help you as well.

Helpful hints

- Avoid filling tanks using cans or inappropriate pressurized fuel delivery systems that may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of them contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when draining off used engine coolant mixtures, engine, gearbox and hydraulic oils, brake fluids, etc. Do not mix drained brake fluids or fuels with lubricants. Store them safely until they can be disposed of in a proper way to comply with local legislation and available resources.
- Modern coolant mixtures, i.e. antifreeze and other additives, should be replaced every two years. They should not be allowed to get into the soil, but should be collected and disposed of properly.
- Do not open the air-conditioning system yourself. It contains gases that should not be released into the atmosphere. Your [Brand] dealer or air conditioning specialist has a special extractor for this purpose and will have to recharge the system properly.
- Repair any leaks or defects in the engine cooling or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding as penetrating weld splatter may burn a hole or weaken them, allowing the loss of oils, coolant, etc.

Personal safety

Most accidents involving machine operation and maintenance can be avoided by following basic safety rules and precautions. Read and understand all the safety messages in this manual, the safety manual and the safety signs on the machine before you operate or service the machine. See your dealer if you have any questions.


READ THIS MANUAL COMPLETELY and make sure you understand the controls. All equipment has a limit. Make sure you understand the speed, brakes, steering, stability, and load characteristics of the machine before you start to operate this machine.

DO NOT remove this manual or the safety manual from the machine. See your dealer for additional manuals. Also see the manual information on the Title pages (first and second pages in front of the Table of Contents) of this manual.

The safety information given in this manual does not replace safety codes, insurance needs, federal, state, or local laws. Make sure that your machine has the correct equipment according to these rules or laws.

Additional safety messages are used in the text of the manual to show specific safety hazards.

NOTICE: *The safety messages in this chapter point out conditions which can happen during the normal operation and maintenance of your machine. These safety messages also give possible ways of dealing with these conditions.*



RCPH11WHL0030AA 1

Safety rules – California Proposition 65 Warning

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.

RCIL08CCH001EAA 1

California Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.

Safety rules

General Safety Rules

Use caution when operating the machine on slopes. Raised equipment, full tanks and other loads will change the center of gravity of the machine. The machine can tip or roll over when near ditches and embankments or uneven surfaces.

Never permit anyone other than the operator to ride on the machine.

Never operate the machine under the influence of alcohol, drugs, or while otherwise impaired.

Never allow riders on the machine.

When digging or using ground engaging attachments, be aware of buried cables. Contact local utilities to determine the locations of services.

Pay attention to overhead power lines and hanging obstacles. High voltage lines may require significant clearance for safety.

Hydraulic oil or diesel fuel leaking under pressure can penetrate the skin, causing serious injury or infection.

- DO NOT use your hand to check for leaks. Use a piece of cardboard or paper.
- Before connecting or disconnecting fluid lines, always stop the engine, remove the key, and relieve the fluid line pressure.
- Ensure all components are in good condition. Tighten all connections before starting the engine or pressurizing the system.
- If the hydraulic fluid or diesel fuel penetrates the skin, seek medical attention immediately.
- Continuous long term contact with hydraulic fluid may cause skin cancer. Avoid long term contact and promptly wash the skin with soap and water.

Keep clear of moving parts. Loose clothing, jewelry, watches, long hair, and other loose or hanging items can become entangled in moving parts.

Wear protective equipment when appropriate.

DO NOT attempt to remove material from any part of the machine while it is being operated or components are in motion.

Ensure all guards and shields are in good condition and properly installed before operating the machine. Never operate the machine with shields removed. Always close access doors or panels before operating the machine.

Dirty or slippery steps, ladders, walkways, and platforms can cause falls. Ensure these surfaces remain clean and clear of debris.

A person or pet within the operating area of a machine can be struck or crushed by the machine or its equipment. DO NOT allow anyone to enter the work area.

Raised equipment and/or loads can fall unexpectedly and crush persons underneath. Never allow anyone to enter the area underneath raised equipment during operation.

Never operate the engine in enclosed spaces, as harmful exhaust gases may build up.

Before starting the machine, ensure that all controls are in neutral or park lock position.

Start the engine only from the operator's seat. If the safety start switch is bypassed, the engine can start with the transmission in gear. DO NOT connect or short across terminals on the starter solenoid. Attach jumper cables as described in the manual. Starting in gear may cause death or serious injury.

Always keep windows, mirrors, all lighting, and the Slow Moving Vehicle (SMV) emblem clean to provide the best possible visibility while operating the machine.

Operate controls only when seated in the operator's seat, except for those controls expressly intended for use from other locations.

⚠ Parking the Machine ⚠

Before leaving the machine, do the following:

1. Park the machine on a firm, level surface.
2. Put all controls in the neutral or park lock position.
3. Engage the park brake. Use wheel chocks, if required.
4. Lower all of the hydraulic equipment.
5. Turn the engine OFF. Remove the key.

If required to keep the engine running, do the following:

1. Bring the engine to low idle speed.
2. Disengage all the drive systems.
3. Shift the transmission into neutral.
4. Apply the parking brake.

⚠ General Maintenance Safety ⚠

Keep the area used for servicing the machine clean and dry. Clean up spilled fluids.

Service the machine on a firm, level surface.

DO NOT attempt repairs unless trained. Refer to manuals and experienced personnel for help.

If you doubt your ability to complete maintenance procedures correctly, contact your authorized dealer.

Observe proper maintenance intervals and procedures. Pay close attention to all safety messages.

Install guards and shields after servicing the machine.

Close all access doors and install all panels after servicing the machine.

Do not attempt to clean, lubricate, clear obstructions, or make adjustments to the machine while it is in motion or while the engine is running.

Always ensure the working area is clear of tools, parts, other persons and pets before you start operating the machine.

Unsupported hydraulic cylinders can lose pressure and drop the equipment causing a crushing hazard. DO NOT leave equipment in a raised position while parked or during service, unless securely supported.

Jack or lift the machine only at jack or lift points indicated in this manual.

Incorrect towing procedures can cause accidents. When towing a disabled machine follow the procedure in Operator's Manual. Use only rigid tow bars.

Towing the machine is not recommended. When absolutely necessary to tow, DO NOT exceed the recommended towing speed. Ensure the towing machine has sufficient braking capacity to stop the towed load. If the towed machine cannot be braked, a tow bar must be used. Do not use chains to tow a machine without braking ability.


Before disconnecting or connecting fluid lines, always stop the engine, remove key, and relieve fluid line pressure.

Release all pressure before working on systems with an accumulator. It is your responsibility know the quantity of accumulators and their locations on the machine.

Before disconnecting or connecting electrical connections, stop the engine and remove key.

GROUP 2 SPECIFICATION


1. MAJOR COMPONENT



1221F


2. SPECIFICATIONS

1) 1) WITH BOLT-ON CUTTING EDGE TYPE BUCKET (1221F)




Description		Unit	Specification	
Operating weight		kg (lb)	30300 (66800)	
Bucket capacity	Struck	m ³ (yd ³)	4.6 (6.0)	
	Heaped		5.4 (7.1)	
Overall length	A	mm (ft-in)	9630 (31' 7")	
Overall width	B		3450 (11' 4")	
Overall height	C		3865 (12' 8")	
Ground clearance	D		495 (1' 7")	
Wheelbase	E		3700 (12' 2")	
Tread	F		2440 (8' 0")	
Dump clearance at 45°	G		3300 (10' 10")	
Dump reach (full lift)	H		1430 (4' 8")	
Width over tires	I		3220 (10' 7")	
Dump angle	J		degree (°)	47
Roll back angle (carry position)	K			48
Cycle time	Lift (with load)	sec	6.1	
	Dump (with load)		1.4	
	Lower (empty)		4.1	
Maximum travel speed		km/hr (mph)	36.0 (22.4)	
Braking distance		m (ft-in)	12 (39' 4")	
Minimum turning radius (center of outside tire)			6.43 (21' 1")	
Gradeability		degree (°)	30	
Breakout force		kg (lb)	23750 (52360)	
Travel speed	Forward	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
		Third gear	17.9 (11.1)	
		Fourth gear	36.0 (22.4)	
	Reverse	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
Third gear		24.8 (15.4)		

WITH BOLT-ON CUTTING EDGE TYPE BUCKET (1221F XR)




Description		Unit	Specification	
Operating weight		kg (lb)	31100 (68560)	
Bucket capacity	Struck	m ³ (yd ³)	4.6 (6.0)	
	Heaped		5.4 (7.1)	
Overall length	A	mm (ft-in)	10060 (33' 0")	
Overall width	B		3450 (11' 4")	
Overall height	C		3865 (12' 8")	
Ground clearance	D		485 (1' 7")	
Wheelbase	E		3700 (12' 2")	
Tread	F		2440 (8' 0")	
Dump clearance at 45°	G		3670 (12' 0")	
Dump reach (full lift)	H		1480 (4' 10")	
Width over tires	I		3220 (10' 7")	
Dump angle	J		degree (°)	47
Roll back angle (carry position)	K			49
Cycle time	Lift (with load)	sec	6.1	
	Dump (with load)		1.4	
	Lower (empty)		4.1	
Maximum travel speed		km/hr (mph)	36.0 (22.4)	
Braking distance		m (ft-in)	12 (39' 4")	
Minimum turning radius (center of outside tire)			6.43 (21' 1")	
Gradeability		degree (°)	30	
Breakout force		kg (lb)	23130 (50990)	
Travel speed	Forward	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
		Third gear	17.9 (11.1)	
		Fourth gear	36.0 (22.4)	
	Reverse	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
Third gear		24.8 (15.4)		

2) 2) WITH TOOTH TYPE BUCKET (1221F)



Description		Unit	Specification	
Operating weight		kg (lb)	30300 (66800)	
Bucket capacity	Struck	m ³ (yd ³)	4.4 (5.8)	
	Heaped		5.2 (6.8)	
Overall length	A	mm (ft-in)	9820 (32' 3")	
Overall width	B		3500 (11' 6")	
Overall height	C		3865 (12' 8")	
Ground clearance	D		495 (1' 7")	
Wheelbase	E		3700 (12' 2")	
Tread	F		2440 (8' 0")	
Dump clearance at 45°	G		3145 (10' 4")	
Dump reach (full lift)	H		1560 (5' 1")	
Width over tires	I		3220 (10' 7")	
Dump angle	J		degree (°)	47
Roll back angle (carry position)	K			48
Cycle time	Lift (with load)	sec	6.1	
	Dump (with load)		1.4	
	Lower (empty)		4.1	
Maximum travel speed		km/hr (mph)	36.0 (22.4)	
Braking distance		m (ft-in)	12 (39' 4")	
Minimum turning radius (center of outside tire)			6.43 (21' 1")	
Gradeability		degree (°)	30	
Breakout force		kg (lb)	25280 (55730)	
Travel speed	Forward	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
		Third gear	17.9 (11.1)	
		Fourth gear	36.0 (22.4)	
	Reverse	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
Third gear		24.8 (15.4)		

WITH TOOTH TYPE BUCKET (1221F XR)



Description		Unit	Specification	
Operating weight		kg (lb)	31100 (68560)	
Bucket capacity	Struck	m ³ (yd ³)	4.4 (5.8)	
	Heaped		5.2 (6.8)	
Overall length	A	mm (ft-in)	10250 (33' 8")	
Overall width	B		3500 (11' 6")	
Overall height	C		3865 (12' 8")	
Ground clearance	D		495 (1' 7")	
Wheelbase	E		3700 (12' 2")	
Tread	F		2440 (8' 0")	
Dump clearance at 45°	G		3520 (11' 7")	
Dump reach (full lift)	H		1600 (5' 3")	
Width over tires	I		3220 (10' 7")	
Dump angle	J		degree (°)	47
Roll back angle (carry position)	K			49
Cycle time	Lift (with load)	sec	6.1	
	Dump (with load)		1.4	
	Lower (empty)		4.1	
Maximum travel speed		km/hr (mph)	36.0 (22.4)	
Braking distance		m (ft-in)	12 (39' 4")	
Minimum turning radius (center of outside tire)			6.43 (21' 1")	
Gradeability		degree (°)	30	
Breakout force		kg (lb)	24630 (54300)	
Travel speed	Forward	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
		Third gear	17.9 (11.1)	
		Fourth gear	36.0 (22.4)	
	Reverse	First gear	6.1 (3.8)	
		Second gear	11.4 (7.1)	
Third gear		24.8 (15.4)		

3. WEIGHT

Item		kg	lb
Front frame assembly		2695	5940
Rear frame assembly		3282	7240
Front fender (LH & RH)		48	106
Counterweight (1221F)		1200	2650
Additional counterweight (3EA, 1221F XR)		550	1210
Cab assembly		1050	2320
Engine assembly		1269	2800
Transmission assembly		835	1840
Drive shaft (front)		25	55
Drive shaft (center)		62	137
Drive shaft (rear)		30	66
Drive shaft (upper)		13	29
Front axle (include differential)		1814	4000
Rear axle (include differential)		1820	4010
Tire (29.5-25, 22PR, L3)		430	948
Hydraulic tank assembly		280	617
Fuel tank assembly		485	1070
Main pump		45	99
Steering pump		45	99
Fan & brake pump assembly		12	26
Main control valve (2/3 spool)		88/104	194/229
Flow amplifier		29	64
Boom assembly	1221F	2050	4520
	1221F XR	2260	4980
Bell crank assembly		282	620
Bucket link		60	132
5.4 m ³ bucket, with bolt on cutting edge		2750	6060
5.2 m ³ bucket, with tooth		2585	2430
Boom cylinder assembly (2EA)		290	639
Bucket cylinder assembly (2EA)		130	287
Steering cylinder assembly (2EA)		60	132
Seat		40	88
Battery		55	121

4. SPECIFICATION FOR MAJOR COMPONENTS

1) ENGINE

Item	Specification
Model	Cummins QSX 11.9
Type	4-cycle turbocharged, charge air cooled diesel engine
Control type	Electronic control
Cooling method	Water cooling
Number of cylinders and arrangement	6 cylinders, in-line
Firing order	1-5-3-6-2-4
Combustion chamber type	Direct injection type
Cylinder bore × stroke	130 × 150 mm (5.12" × 5.91")
Piston displacement	11900 cc (726 cu in)
Compression ratio	16.6
Rated gross horse power	360 ps at 2000 rpm
Maximum gross torque at 1400 rpm	173 kgf · m (1250 lbf · ft)
Engine oil quantity	43 l (11.4 U.S. gal)
Wet weight	1269 kg (2797 lb)
High idling speed	2130 ± 50 rpm
Low idling speed	800 ± 25 rpm
Rated fuel consumption	162 g/ps·hr
Starting motor	Delco Remy 39MT HO (24 V-7.5 W)
Alternator	Delco Remy 28SI (24 V - 80 Amp)
Battery	2 × 12V × 220Ah

2) STEERING PUMP / MAIN PUMP

Item	Specification	
	Steering pump	Main pump
Type	Variable piston pump	
Capacity	110 cc/rev	100 cc/rev
Maximum operating pressure	280 kgf/cm ² (3980 psi)	
Rated oil quantity	220 l /min (58.1 U.S.gpm)	200 l /min (52.8 U.S.gpm)
Rated speed	2000 rpm	

3) FAN & BRAKE PUMP

Item	Specification
Type	Piston pump
Capacity	45 cc/rev
Maximum operating pressure	250 kgf/cm ² (3560 psi)
Rated oil quantity	90 l /min (23.8 U.S.gpm)
Rated speed	2000 rpm

4) MAIN CONTROL VALVE

Item	Specification
Type	2 spool
Operating method	Hydraulic pilot assist
Main relief valve pressure	280 kgf/cm ² (3980 psi)
Overload relief valve pressure	340 kgf/cm ² (4840 psi)
Overload relief valve pressure (dump)	310 kgf/cm ² (4410 psi)

5) REMOTE CONTROL VALVE

Item	Specification	
Type	Pressure reducing type	
Operating	Minimum	5 kgf/cm ² (71 psi)
	Maximum	30 kgf/cm ² (427 psi)
Single operation angle	degree	17

6) CYLINDER

Item	Specification
Boom cylinder	Bore dia × Rod dia × Stroke ø 180 × ø 105 × 863 mm
Bucket cylinder	1221F Bore dia × Rod dia × Stroke ø 140 × ø 75 × 575 mm
	1221F XR ø 140 × ø 75 × 570 mm
Steering cylinder	Bore dia × Rod dia × Stroke ø 105 × ø 55 × 480 mm

7) DYNAMIC POWER TRANSMISSION DEVICES

Item		Specification	
4-speed transmission (std)	Model	ZF 4WG 310	
	Type	Converter	Single-stage, double-phase
		Transmission	Full-automatic power shift
	Converter stall ratio	2.51 : 1	
	Gear shift	Forward fourth gear, reverse third gear	
	Control	Electrical single lever type, kick-down system Automatic kick down from 2nd to 1st gear FNR switch on joystick lever (option)	
	Pump rated flow	135 ℓ /min (35.7 U.S.gpm) at 2000 rpm	
Travel speed	See the page 2-2.		
5-speed transmission (opt)	Model	ZF 5WG 310	
	Type	Converter	Single-stage, double-phase (with lock up clutch)
		Transmission	Full-automatic power shift
	Converter stall ratio	2.51 : 1	
	Gear shift	Forward fifth gear, reverse third gear	
	Control	Electrical single lever type, kick-down system Automatic kick down from 2nd to 1st gear FNR switch on joystick lever (option)	
	Pump rated flow	135 ℓ /min (35.7 U.S.gpm) at 2000 rpm	
Travel speed	Forward 1/2/3/4/5	6.1 / 11.8 / 18.3 / 26.6 / 41.0 km/hr	
	Reverse 1/2/3	6.1 / 11.8 / 26.6 km/hr	
Axle	Drive devices	4-wheel drive	
	Front	Front fixed location	
	Rear	Oscillation ± 13° of center pin-loaded	
Wheels	Tires	29.5-25, 22PR (L3)	
Brakes	Travel	Four-wheel, wet-disc type, full hydraulic	
	Parking	Spring applied, hydraulic released brake on T/M	
Steering	Type	Full hydraulic, articulated	
	Steering angle	40° to both right and left angle, respectively	



SECTION 2 ENGINE

Group 1 Structure and Function	2-1
Group 2 Engine speed and Stall rpm	2-15
Group 3 Fuel warmer system	2-16

SECTION 2 ENGINE

GROUP 1 STRUCTURE AND FUNCTION

1. STRUCTURE




- Direct 4-stroke, 6-cylinders, water-cooling and charge air cooled diesel engine in installed, cylinder block and cylinder head are made of case iron and turbocharger is attached.

2. SYSTEM DIAGRAMS


The following drawings show the flow through the engine systems.

1) FUEL SYSTEM



- | | | | |
|----|----------------------------------|----|--|
| 1 | Fuel supply connection | 16 | Fuel rail supply line |
| 2 | Fuel lift pump supply line | 17 | Fuel rail |
| 3 | Fuel lift pump | 18 | Fuel pressure sensor |
| 4 | Fuel lift pump line | 19 | High-pressure injector supply lines |
| 5 | Fuel pump gear pump supply lines | 20 | High-pressure fuel connector |
| 6 | Fuel pump gear pump inlet | 21 | Fuel injector |
| 7 | Fuel pump gear pump | 22 | Fuel injector drain check valve (banjo type) |
| 8 | Fuel pump gear pump outlet | 23 | High-pressure relief valve |
| 9 | Pressure side fuel filter inlet | 24 | Injector drain line |
| 10 | Fuel filter head | 25 | High-pressure relief valve drain line |
| 11 | Pressure side fuel filter | 26 | Fuel pump drain line |
| 12 | Pressure side fuel filter outlet | 27 | Fuel drain manifold |
| 13 | High-pressure fuel pump inlet | 28 | OEM fuel return connection |
| 14 | Fuel pump actuator | 29 | Lift pump OFF (check valve open) |
| 15 | High-pressure fuel pump | 30 | Lift pump ON (check valve closed) |


FUEL SYSTEM



- 1 Fuel supply from fuel filter head to the aftertreatment fuel injector fuel manifold
- 2 Aftertreatment fuel injector fuel manifold
- 3 Fuel shutoff valve
- 4 Fuel pressure sensor
- 5 Fuel drain valve
- 6 Fuel supply to aftertreatment fuel injector
- 7 Aftertreatment fuel injector


2) LUBRICATING OIL SYSTEM

LUBRICATING OIL SYSTEM




- | | | | |
|----|--|----|--|
| 1 | Lubricating oil supply from the lubricating oil pan | | |
| 2 | Lubricating oil pump | | |
| 3 | Lubricating oil pressure sensing line from the main oil rifle | | |
| 4 | Lubricating oil pressure regulator | | |
| 5 | High pressure relief valve | | |
| 6 | Oil return to the lubricating oil pan | | |
| 7 | Lubricating oil transfer tube | | |
| 8 | Lubricating oil transfer connection | | |
| 9 | Oil flow through the cylinder block to the lubricating oil filter head | | |
| 10 | Oil flow from the filter head to the main oil rifle | | |
| 11 | Right oil rifle | 21 | Cam followers |
| 12 | Oil flow to the rear idler gear | 22 | Lubricating oil flow to the camshaft |
| 13 | Left oil rifle | 23 | Lubricating oil flow around the camshaft |
| 14 | Oil flow to the overhead | 24 | Lubricating oil flow to the main bearings |
| 15 | Oil flow to rocker lever shaft | 25 | Crankshaft main bearing journal |
| 16 | Rocker lever shaft | 26 | Crankshaft connecting rod journal |
| 17 | Rocker levers | 27 | Connecting rod |
| 18 | Lubricating oil flow to the push tubes | 28 | Lubricating oil flow around the piston pin |
| 19 | Oil supply to crosshead | 29 | Front gear housing |
| 20 | Lubricating oil supply to the cam followers | 30 | Lubricating oil flow to the air compressor |

LUBRICATING OIL SYSTEM




- 1 Lubricating oil flow from the lubricating oil pump
- 2 Lubricating oil thermostat closed
- 3 Lubricating oil through the oil filter head to the oil filter
- 4 Lubricating oil filter
- 5 Lubricating oil flow to the main oil rifle
- 6 Lubricating oil thermostat open
- 7 Lubricating oil flow to the lubricating oil cooler
- 8 Lubricating oil flow through the lubricating oil cooler core
- 9 Lubricating oil flow to the lubricating oil filter head

LUBRICATING OIL SYSTEM




- 1 Lubricating oil supply to the turbocharger bearing housing
- 2 Lubricating oil return to the lubricating oil pan
- 3 Lubricating oil main rifle
- 4 Lubricating oil passage from the cylinder block to the rear gear housing
- 5 Lubricating oil flow through the rear gear housing
- 6 Lubricating oil supply to the fuel pump
- 7 Fuel pump




- 1 Lubricating oil supply from the lubricating oil cooler
- 2 Lubricating oil filter bypass valve closed
- 3 Lubricating oil flow to the lubricating oil filter
- 4 Filtered lubricating oil flow to the main oil rifle
- 5 Lubricating oil filter bypass valve open
- 6 Unfiltered lubricating oil flow to the main oil rifle

3) COOLING SYSTEM



- 1 Coolant inlet flow from radiator
- 2 Coolant inlet connection
- 3 Coolant from inlet to water pump
- 4 Coolant from coolant filter to water pump
- 5 Coolant filter
- 6 Coolant from water pump to coolant filter
- 7 Coolant from water pump to cylinder block inlet
- 8 Coolant from water pump to exhaust gas recirculation (EGR) cooler
- 9 EGR cooler
- 10 Coolant from EGR cooler to lubricating oil cooler
- 11 Lubricating oil cooler
- 12 Coolant from rocker lever housing
- 13 Thermostat closed
- 14 Coolant through bypass tube to coolant connection
- 15 Thermostat open
- 16 Coolant to radiator

COOLING SYSTEM



- 1 Coolant inlet from radiator
- 2 Coolant inlet to water pump
- 3 Coolant from water pump to cylinder block
- 4 Coolant to lubricating oil cooler
- 5 Lubricating oil cooler
- 6 Coolant flow around cylinder liners
- 7 Coolant to lower cylinder head
- 8 Coolant to upper cylinder head
- 9 Coolant to rocker lever housing
- 10 Coolant from cylinder head to coolant manifold
- 11 Coolant manifold supply
- 12 Coolant manifold



Suggest:

If the above button click is invalid.


Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading

COOLING SYSTEM



- 1 Coolant from lubricating oil cooler to turbocharger bearing housing
- 2 Turbocharger bearing housing
- 3 Coolant from turbocharger bearing housing to rocker lever housing
- 4 Coolant from turbocharger bearing housing to turbocharger actuator
- 5 Turbocharger actuator
- 6 Coolant from cylinder block to aftertreatment fuel injector
- 7 Aftertreatment fuel injector
- 8 Coolant from aftertreatment fuel injector to turbocharger actuator outlet
- 9 Coolant from turbocharger actuator outlet to EGR mass measurement flow assembly
- 10 EGR mass measurement flow assembly
- 11 Coolant from EGR mass measurement flow assembly to rocker lever housing

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>