

**CX18C**  
Mini Excavator

**SERVICE MANUAL**

**Part number 48139721**

English  
June 2017





## **SERVICE MANUAL**

**CX18C Cab - Tier IV Engine  
CX18C Canopy - Tier IV Engine**

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.106] Valve drive and gears .....	10.2
[10.101] Cylinder heads .....	10.3
[10.105] Connecting rods and pistons.....	10.4
[10.103] Crankshaft and flywheel.....	10.5
[10.216] Fuel tanks .....	10.6
[10.206] Fuel filters .....	10.7
[10.220] Throttle linkage .....	10.8
[10.218] Fuel injection system.....	10.9
[10.202] Air cleaners and lines .....	10.10
[10.254] Intake and exhaust manifolds and muffler .....	10.11
[10.400] Engine cooling system .....	10.12
[10.414] Fan and drive .....	10.13
[10.304] Engine lubrication system.....	10.14
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.106] Variable displacement pump .....	35.3
[35.359] Main control valve.....	35.4
[35.357] Pilot system .....	35.5
[35.355] Hydraulic hand control .....	35.6
[35.356] Hydraulic foot control.....	35.7
[35.352] Hydraulic swing system .....	35.8
[35.353] Hydraulic travel system .....	35.9
[35.354] Hydraulic central joint .....	35.10

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

[35.735] Track frame widening system .....	35.11
[35.736] Boom hydraulic system .....	35.12
[35.737] Dipper hydraulic system.....	35.13
[35.738] Excavator and backhoe bucket hydraulic system.....	35.14
[35.734] Tool quick coupler hydraulic system .....	35.15
[35.739] Swing arm hydraulic system .....	35.16
[35.741] Dozer blade cylinders .....	35.17
<b>Frames and ballasting .....</b>	<b>39</b>
[39.140] Ballasts and supports .....	39.1
<b>Tracks and track suspension.....</b>	<b>48</b>
[48.130] Track frame and driving wheels.....	48.1
[48.100] Tracks .....	48.2
[48.134] Track tension units .....	48.3
[48.138] Track rollers .....	48.4
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.100] Harnesses and connectors.....	55.2
[55.525] Cab engine controls.....	55.3
[55.015] Engine control system.....	55.4
[55.201] Engine starting system .....	55.5
[55.301] Alternator.....	55.6
[55.302] Battery.....	55.7
[55.202] Cold start aid .....	55.8
[55.011] Fuel tank system .....	55.9
[55.014] Engine intake and exhaust system.....	55.10
[55.012] Engine cooling system .....	55.11
[55.013] Engine oil system .....	55.12
[55.512] Cab controls.....	55.13

[55.524] Cab controls (Lift arm, Boom, Dipper, Bucket) .....	55.14
[55.518] Wiper and washer system.....	55.15
[55.404] External lighting .....	55.16
[55.405] External lighting switches and relays .....	55.17
[55.514] Cab lighting .....	55.18
[55.408] Warning indicators, alarms, and instruments .....	55.19
<b>Booms, dippers, and buckets .....</b>	<b>84</b>
[84.910] Boom.....	84.1
[84.912] Dipper arm .....	84.2
[84.100] Bucket.....	84.3
<b>Dozer blade and arm.....</b>	<b>86</b>
[86.110] Dozer blade .....	86.1
<b>Platform, cab, bodywork, and decals.....</b>	<b>90</b>
[90.160] Cab interior trim and panels.....	90.1
[90.114] Operator protections .....	90.2
[90.120] Mechanically-adjusted operator seat.....	90.3
[90.100] Engine hood and panels .....	90.4
[90.105] Machine shields and guards .....	90.5



## **INTRODUCTION**

---

## **Foreword - Important notice regarding equipment servicing**

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The manufacturer reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication but are subject to change without notice.

In case of questions, refer to your CASE CONSTRUCTION Sales and Service Networks.

## Safety rules

### Personal safety



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

 CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

**FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.**

### Machine safety

**NOTICE:** Notice indicates a situation that, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

### Information

**NOTE:** Note indicates additional information that clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

## **Safety rules - General information**

### **Cleaning**

Clean the metal parts with cleaning solution that meets the standard and steam cleaning. (except for bearings)

After cleaning, dry well, and inject oil in all parts.

Also inject oil into the bearings after drying.

### **Inspection**

When disassembling parts, check all the parts.

If there are any worn or damaged parts, replace them.

Inspect carefully to prevent initial breakdowns.

### **Bearing**

Replace any loose bearings.

Air dry bearings before installing them.

### **Needle bearing**

When inserting needle bearings, be very careful not to damage them.

Apply grease to the section where the needle bearing will be inserted.

### **Gear**

Check that there is no wear and no damage.

### **Oil seal, O-ring, gasket**

Always install new oil seals, O-rings, and gaskets.

Apply grease to sections where oil seals and O-rings will be inserted.

### **Shaft**

Check that there is no wear and no damage.

Check the bearings and check for damaged oil seals on the shaft.

### **Service parts**

Install CASE CONSTRUCTION genuine service parts.

When placing an order, check the parts catalog. It contains the CASE CONSTRUCTION genuine part numbers.

Any breakdowns arising from the installation of non-genuine parts are not covered by the warranty.

### **Lubricants (fuel, hydraulic oil)**

Use the oil from the specified company or specified in the operator's manual or service Manual.

Any breakdowns arising from any fuel or hydraulic oil other than those specified are not covered by the warranty.

## Safety rules - Personal safety

### Preliminary warnings to maintenance operation

#### **⚠ WARNING**

**Avoid injury!**

**Shut off the engine, remove the key, and make sure all machine motion stops before you service the machine.**

**Failure to comply could result in death or serious injury.**

W1128B

#### **⚠ WARNING**

**Improper operation or service of this machine can result in an accident.**

**Assign a supervisor to direct worksite operations. Agree on all safety measures, procedures, and suitable hand signals.**

**Failure to comply could result in death or serious injury.**

W0287A

#### **⚠ CAUTION**

**Pinch hazard!**

**Always use suitable tools to align mating parts. DO NOT use your hand or fingers.**

**Failure to comply could result in minor or moderate injury.**

C0044A

### Personal Protective Equipment (PPE)

#### **⚠ WARNING**

**Avoid injury!**

**Use Personal Protective Equipment (PPE), including protective goggles, gloves, and safety footwear.**

**Failure to comply could result in death or serious injury.**

W1036A

### Lifting operation

#### **⚠ WARNING**

**Crushing hazard!**

**The lifting systems must be operated by qualified personnel who are aware of the correct procedures to follow. Make sure all lifting equipment is in good condition, and all hooks are equipped with safety latches.**

**Failure to comply could result in death or serious injury.**

W0256A

#### **⚠ WARNING**

**Heavy objects!**

**Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders.**

**Failure to comply could result in death or serious injury.**

W0398A

#### **⚠ WARNING**

**Improper operation or service of this machine can result in an accident.**

**Raised equipment or machine movement without an operator can cause serious injury. Always do the following before performing any maintenance:**

**Park the machine on flat, level ground.**

**Lower the attachment to the ground.**

**Shut down the engine and remove the ignition key.**

**Lock the tracks.**

**Failure to comply could result in death or serious injury.**

W0944D

**⚠ WARNING**

Tip-over hazard!  
Only raise the track as little as necessary.  
Failure to comply could result in death or serious injury.

W0276A

**Hydraulic system**

**⚠ WARNING**

Burn hazard!  
Before performing any service on the hydraulic system, you must allow it to cool. Hydraulic fluid temperature should not exceed 40 °C (104 °F).  
Failure to comply could result in death or serious injury.

W0241A

**⚠ WARNING**

Pressurized fluid can penetrate the skin and cause severe injuries.  
The grease in the cylinder is under high pressure. Never loosen the grease fitting adaptor completely in order to speed up the flow of grease.  
Failure to comply could result in death or serious injury.

W0261A

**⚠ WARNING**

Pressurized system!  
Before attempting any service procedure, it is your responsibility to know the number of accumulators on the machine, and the correct procedure for releasing the pressure of each accumulator.  
Failure to comply could result in death or serious injury.

W0136A

**Battery**

**⚠ WARNING**

Battery acid causes burns. Batteries contain sulfuric acid.  
Avoid contact with skin, eyes or clothing. Antidote (external): Flush with water. Antidote (eyes): flush with water for 15 minutes and seek medical attention immediately. Antidote (internal): Drink large quantities of water or milk. Do not induce vomiting. Seek medical attention immediately.  
Failure to comply could result in death or serious injury.

W0111A

**⚠ WARNING**

Battery gas can explode!  
To prevent an explosion: 1. Always disconnect the negative (-) battery cable first. 2. Always connect the negative (-) battery cable last. 3. Do not short circuit the battery posts with metal objects. 4. Do not weld, grind, or smoke near a battery.  
Failure to comply could result in death or serious injury.

W0011A

**Fluids**

**⚠ WARNING**

Hazardous chemicals!  
Coolant can be toxic. Avoid contact with skin, eyes, and clothing. Antidotes:  
EXTERNAL - Rinse thoroughly with water. Remove soiled clothing.  
INTERNAL - Rinse the mouth with water. DO NOT induce vomiting. Seek immediate medical attention.  
EYES - Flush with water. Seek immediate medical attention.  
Failure to comply could result in death or serious injury.

W0282A

**⚠ WARNING**

**Burn hazard!**

Hot coolant can spray and scald if you remove the radiator or deaeration tank cap while the system is hot. To remove the cap: allow the system to cool, turn the cap to the first notch, and wait for all pressure to release. Remove the cap only after all pressure has released.

Failure to comply could result in death or serious injury.

W0367A

**⚠ WARNING**

**Escaping fluid!**

Hydraulic fluid or diesel fuel leaking under pressure can penetrate the skin and cause infection or other injury. To prevent personal injury: Relieve all pressure before disconnecting fluid lines or performing work on the hydraulic system. Before applying pressure, make sure all connections are tight and all components are in good condition. Never use your hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see your doctor immediately.

Failure to comply could result in death or serious injury.

W0178A

**⚠ WARNING**

**Chemical hazard!**

When handling fuel, lubricants, and other service chemicals, follow the manufacturer's instructions. Wear Personal Protective Equipment (PPE) as instructed. Do not smoke or use open flame. Collect fluids in proper containers. Obey all local and environmental regulations when disposing of chemicals.

Failure to comply could result in death or serious injury.

W0371A



# **SERVICE MANUAL**

## **Engine**

**CX18C Cab - Tier IV Engine  
CX18C Canopy - Tier IV Engine**

## Engine - General specification


Engine model			Mitsubishi L3E	
Main specifications	Type		Vertical type, water-cooled, 4 cycle diesel	
	Number of cylinders		3	
	Combustion type		Swirl chamber type	
	Valve mechanism		Overhead valve type	
	Cylinder bore x stroke		<b>76 mm (3.0 in) x 70 mm (2.8 in)</b>	
	Total displacement		<b>0.952 L (0.251 US gal)</b>	
	Compression ratio		23 : 1	
	Order of ignition		1 – 3 – 2	
	Direction of rotation		Counterclockwise as viewed from flywheel side	
	Dry mass		<b>75 kg (165 lb)</b>	
Basic engine	Piston ring	Number	Compression ring: 2 Oil rings (with expander): 1	
	Valve timing (when warm)	Inlet valve	Open	BTDC 18°
			Close	ABDC 46°
		Exhaust valve	Open	BBDC 46°
			Close	ATDC 18°
Starting system		Electric starting		
Fuel system	Fuel injection pump	Type	ND-PFR type	
		Plunger diameter	<b>5.5 mm (0.22 in), 6.0 mm (0.24 in)</b>	
		MS retard (crank angle)	4°, 8°	
		Cam lift	<b>6.0 mm (0.24 in)</b>	
	Governor	Speed governing type	Centrifugal weight system	
	Fuel injection nozzle	Type	Throttle type	
		Spray angle	15°	
		Valve opening pressure	<b>12.73 – 14.73 MPa (1846.49 – 2136.59 psi)</b>	
	Fuel filter	Type	Paper-element cartridge or paper-element switch cock	
	Fuel pump	Type	Electromagnetic plunger type	
		Discharge rate	<b>1 L/min (0.26 US gpm) or more (at 12 V - 1.5 A)</b>	
	Fuel pump (option)	Type	Electromagnetic plunger type (compact type)	
Discharge rate		<b>0.4 L/min (0.11 US gpm) or more (at 12 V - 1.5 A)</b>		
Lubrication system	Lubrication system		Pressure feed, full flow filter system	
	Engine oil	Capacity (engine total)	Upper limit: <b>4.2 L (1.11 US gal)</b> Lower limit: <b>3.0 L (0.79 US gal)</b>	
			(Upper limit: <b>4.7 L (1.24 US gal)</b> Lower limit: <b>3.5 L (0.92 US gal)</b> )	
	Oil pump	Type	Gear type (internal and external teeth engagement), built into gear case	
		Discharge rate	<b>3 L/min (0.79 US gpm) or more (at 1000 RPM)</b>	
	Relief valve	Type	Plunger valve type	
		Valve opening pressure	<b>0.261 – 0.319 MPa (37.858 – 46.271 psi) ( 1000 RPM)</b>	
Oil filter	Type	Paper-element cartridge		

Engine - Engine and crankcase

Engine model		Mitsubishi L3E	
Cooling system	Cooling system	Forced-feed circulation type	
	Coolant capacity (main unit of engine)	<b>1.8 L (0.48 US gal)</b>	
	Water pump	Type	Centrifugal volute type
		Discharge rate	<b>50 L/min (13.21 US gpm)</b> at pump rotation of <b>4500 RPM</b>
	Thermostat	Type	Wax pellet
		Valve opening pressure	<b>75 – 78 °C (167 – 172 °F)</b>
Cooling fan	Type	Suction (PP fan)	
	Outside diameter	<b>320 mm (12.6 in)</b>	
Inlet system	Air cleaner	Type Paper element	
Electrical system	Engine starter	Type	M001T68381
		Pinion engagement type	Pinion shift (reduction type)
		Output	<b>12 V - 1.7 kW</b>
		Number	1
		Pinion/ring gear ratio	14 / 106
	Alternator	Type	A007TA0171B
		Type	Three-phase current generator, integral with IC regulator
		Output	<b>12 V - 40 A</b>
		Rated voltage generating speed	<b>5000 RPM</b> at <b>13.5 V, 37 A</b> , when hot
		Regulator adjusting voltage	<b>14.4 – 15 V</b>
	Glow plug	Type	Sheathed
		Rated voltage - current	<b>10.5 V, 8.7 – 10.7 A</b> (30 seconds duration)
	Stop solenoid	Working voltage	<b>12 V</b>
		Insulation resistance	<b>100 MΩ</b> or more at DC <b>500 V</b> megger (normal temperature, normal relative humidity)
		Stroke	<b>9.5 – 10.5 mm (0.374 – 0.413 in)</b>
		Ambient temperature for use	<b>-30 – 120 °C (-22 – 248 °F)</b>

# Engine - Engine horse power

## Performance curve



SMIL17MEX1190HB 1


1. Engine speed (RPM)
  2. Fuel consumption (g/kWh)
  3. Output (kW)
  4. Torque (Nm)
- A. **57.1 N·m / 2100 RPM**
  - B. **14 kW / 2400 RPM**
  - C. **NL / 2570 – 2630 RPM**

## Engine - Special tools

Piston pin setting tool

Part number: 30L91–10010

For pulling out and press fitting the piston pins




SMIL17MEX1277AA 1

Compression gauge adapter

Part number: ST332270

For measuring compression




SMIL17MEX1278AA 2

Oil pressure switch socket wrench

Part number: MD998054

For removal and installation of oil pressure switch




SMIL17MEX1279AA 3

Piston ring pliers

Part number: 31391-12900

Range applicable for removal and installation of the piston rings: **60 – 95 mm (2.36 – 3.74 in)**




SMIL17MEX1280AA 4

## Engine - Service limits

Item		Standard	Limit	Remark
Compression pressure at <b>280 RPM</b>		<b>2.7 MPa (391.6 psi)</b>	Not acceptable at or below <b>2.2 MPa (319.1 psi)</b>	When oil and water temperatures at <b>20 – 30 °C (68 – 86 °F)</b>
Lubricating oil pressure	Rotating speed	<b>0.29 – 0.39 MPa (42.06 – 56.57 psi)</b>		Oil temperature at <b>60 – 70 °C (140 – 158 °F)</b>
	Low idling	<b>0.1 MPa (14.5 psi)</b>		
Valve timing	Inlet open	BTDC <b>18°</b>		Values for checking valve timing Different from actual valve opening and closing timing
	Inlet open	ABDC <b>46°</b>		
	Exhaust open	BBDC <b>46°</b>		
	Exhaust open	ATDC <b>18°</b>		
Valve clearance	Inlet	<b>0.25 mm (0.01 in)</b>		When engine is cold
	Exhaust	<b>0.25 mm (0.01 in)</b>		
Fuel injection timing (before TDC)		(Varies depending on specification)		

ABCD – After Bottom Dead Center  
 BBDC – Before Bottom Dead Center  
 ATDC – After Top Dead Center  
 BTDC – Before Top Dead Center

## Engine - Component identification




SMIL17MEX1271FB 1

### Left-hand view

- |               |                     |
|---------------|---------------------|
| A. Front      | 5. V-belt           |
| B. Rear       | 6. Oil pan          |
| 1. Oil filler | 7. Flywheel         |
| 2. Thermostat | 8. Engine starter   |
| 3. Fan        | 9. Exhaust manifold |
| 4. Alternator | 10. Rear eye-bolt   |




## Engine - Exploded view



SML17MEX1295F 1

### Gear case, timing gears, and camshaft

- |                         |                                        |
|-------------------------|----------------------------------------|
| 1. Tappet               | 18. Governor lever                     |
| 2. Oil pump cover       | 19. Governor spring lever              |
| 3. Gear pump housing    | 20. Grooved pin                        |
| 4. Crankshaft pulley    | 21. Speed control lever                |
| 5. Gear case            | 22. Idler gear                         |
| 6. Ball bearing         | 23. Camshaft gear                      |
| 7. PTO gear             | 24. Ball bearing                       |
| 8. Ball bearing         | 25. Camshaft                           |
| 9. Oil pump housing     | 26. Sliding shaft                      |
| 10. Oil pump outer gear | 27. Governor weight                    |
| 11. Oil pump inner gear | 28. Fuel injection pump camshaft gears |
| 12. Plug                | 29. Ball bearing                       |
| 13. Relief spring       | 30. Snap ring                          |
| 14. Relief plunger      | 31. Ball bearing                       |
| 15. Grooved pin         | 32. Fuel injection pump camshaft       |
| 16. Governor shaft      | 33. Torque spring set                  |
| 17. Tension lever       | 34. Front plate                        |



SMIL17MEX1312GB 2

**Cylinder block, crankshaft, piston, and oil pan**

- |                                 |                          |
|---------------------------------|--------------------------|
| 1. Oil pan                      | 9. Oil ring              |
| 2. Oil screen                   | 10. Piston               |
| 3. Connecting rod cap           | 11. Upper connecting rod |
| 4. Lower connecting rod bearing | 12. Main bearing cap     |
| 5. Connecting rod               | 13. Lower main bearing   |
| 6. Piston pin bearing           | 14. Crankshaft           |
| 7. Compression number 1         | 15. Upper main bearing   |
| 8. Compression number 2         | 16. Cylinder block       |

## Engine - Remove

### **⚠ WARNING**

**Avoid injury!**

Shut off the engine, remove the key, and make sure all machine motion stops before you service the machine.

Failure to comply could result in death or serious injury.

W1128B

### **⚠ WARNING**

**Chemical hazard!**

Use caution when opening the quick coupler cap from the load port. There may be product left in the port.

Failure to comply could result in death or serious injury.

W1039A

### **⚠ WARNING**

**Crushing hazard!**

The lifting systems must be operated by qualified personnel who are aware of the correct procedures to follow. Make sure all lifting equipment is in good condition, and all hooks are equipped with safety latches.

Failure to comply could result in death or serious injury.

W0256A

### **⚠ WARNING**

**Heavy objects!**

Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders.

Failure to comply could result in death or serious injury.

W0398A

### **⚠ WARNING**

**Burn hazard!**

Before performing any service on the hydraulic system, you must allow it to cool. Hydraulic fluid temperature should not exceed 40 °C (104 °F).

Failure to comply could result in death or serious injury.

W0241A

### **⚠ WARNING**

**Escaping fluid!**

Hydraulic fluid or diesel fuel leaking under pressure can penetrate the skin and cause infection or other injury. To prevent personal injury: Relieve all pressure before disconnecting fluid lines or performing work on the hydraulic system. Before applying pressure, make sure all connections are tight and all components are in good condition. Never use your hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see your doctor immediately.

Failure to comply could result in death or serious injury.

W0178A

### **⚠ WARNING**


**Chemical hazard!**

When handling fuel, lubricants, and other service chemicals, follow the manufacturer's instructions. Wear Personal Protective Equipment (PPE) as instructed. Do not smoke or use open flame. Collect fluids in proper containers. Obey all local and environmental regulations when disposing of chemicals.

Failure to comply could result in death or serious injury.


W0371A

1. Set the battery disconnect switch to O position (OFF position) to cut off any power supply in the electrical system of the machine (refer to **Mechanical battery isolator - Dynamic description (55.302)**).
2. Remove the right-hand side shields (refer to **Side shields - Remove (90.105)**).
3. Remove the left-hand side shields (refer to **Side shields - Remove (90.105)**).
4. Remove the engine hood (refer to **Hood - Remove (90.100)**).
5. Remove the cab or the canopy (refer to **Canopy assembly - Remove (90.114)**).
6. Remove the operator seat (refer to **Operator seat - Remove (90.120)**).
7. Remove the operator seat base trim panel (refer to **Operator seat base trim panel - Remove - Platform (90.160)**).
8. Remove the radiator (refer to **Radiator - Remove (10.400)**).
9. Remove the windshield washer reservoir (3) from the bracket.
10. Use a wrench [ 13 mm] to remove the two bolts (2), and then remove the bracket with the battery disconnect switch (1).




SMIL17MEX1990BB 1

11. Disconnect the electrical connector **CD-10 (1)** from the air cleaner.




SMIL17MEX1991AB 2

12. Loosen the clamp and remove the air hose (1) from the engine.
13. Use a wrench [ **13 mm** ] to remove the bolts (3), and then remove the air cleaner (2).
14. Use a wrench [ **13 mm** ] to remove the bolt (4) and then remove the fuel filter (5).




SMIL17MEX1992AB 3

15. Use a wrench [ **17 mm** ] to remove the six bolts (1) that fix the platform support.




SMIL17MEX1993AB 4

16. Install two eye-bolts into the platform support, and then use the wire rope or chain and lift-crane to secure the platform support.
17. Remove the platform support (1).




SMIL17MEX1994BB 5

18. Disconnect the electrical connector **CD-8 (2)** of the engine coolant temperature sensor.
19. Disconnect the electrical connector **CD-9 (1)** of the overheat switch.




SMIL17MEX1995BB 6

20. Move the protective cap.
21. Remove the nut and disconnect the electrical connector **CN-80 (1)** of the pre-heater.




SMIL17MEX1996AB 7

22. Disconnect the electrical connector **CN-145 (1)** of the fuel feed pump.




SMIL17MEX1997AB 8

23. Disconnect the electrical connector **CN-79 (1)** of the engine stop solenoid.




SMIL17MEX1998BB 9

24. Disconnect the electrical connector **CD-18 (1)** of the engine oil pressure switch.




SMIL17MEX1999AB 10

25. Use a wrench [ **17 mm** ] to remove the bolt (1) and then disconnect the earth strap (2) from the upper frame.




SMIL17MEX2000AB 11

26. Move the protective cap.  
27. Use a wrench [ **13 mm** ] to remove the nut and then remove the wires (2) from the engine starter.  
28. Disconnect the electrical connector **CN-45 (1)** from the engine starter.




SMIL17MEX2001AB 12

29. Disconnect the electrical connectors **CN-74 (2)** from the alternator **(3)**.
30. Move the protective cap.
31. Use a wrench [ **10 mm**] to remove the nut and disconnect the wire **(1)**.



SMIL17MEX2002BB 13

32. Loosen the clamps and remove the fuel hoses **(1)** from the engine.




SMIL17MEX2003BB 14

33. Use a wrench [ **22 mm** ] to disconnect the hoses ( **1** ) from the pump.


34. Use a wrench [ **19 mm** ] to disconnect the hose ( **2** ).

- Mark the pump and hoses so that the connectors match at the time of assembly.
- Use protective caps and plugs to cover the pump and hoses to prevent any entry of water, dust or dirt.
- Clean the pump and hoses by spraying them with a parts cleaner to prevent scratches and prevent accumulation of dirt on the hydraulic connectors.



SMIL17MEX2004BB 15

35. Use a hexagon wrench [ **8 mm** ] to remove the four bolts ( **1** ) and then separate the suction hose ( **2** ) from the hydraulic pump.



SMIL17MEX2005AB 16



**Suggest:**

**If the above button click is invalid.**


**Please download this document**

**first, and then click the above link**

**to download the complete manual.**


**Thank you so much for reading**

36. Install the two eye-bolts into the engine lift bracket, and then use the wire rope or chain and lift-crane to secure the engine.
37. Use a box wrench [ **19 mm**] to remove the four bolts (1).



SMIL17MEX2006BB 17

38. Remove the engine (1).



SMIL17MEX2007BB 18

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**