






**TABLE OF CONTENTS**  
**2470 TRACTORS**  
**PRIOR TO SN 8762940**

<b>SERIES</b>	<b>SECTION</b>	<b>DESCRIPTION</b>	<b>FORM NUMBER</b>
<b>10</b>	<b>GENERAL</b>		
	1010	General Specifications .....	9-75405
	1011	Detailed Specifications .....	9-75335
	1012	Lubrication .....	9-75345
<b>20</b>	<b>ENGINE</b>		
	2010	Cylinder Heads and Valves .....	9-75315
	2011	Engine Block Assemblies .....	9-75225
	2012	Air Intake System .....	9-75255
	2013	Cooling System - Engine Oil Filter .....	9-74995
	2165	Servicing the Turbocharger .....	9-78435
	2565	Turbocharger Failure Analysis .....	9-78235
<b>30</b>	<b>FUEL SYSTEM</b>		
	3010	Fuel System and Filters .....	9-75297
	3012	Robert Bosch Fuel Injection Pumps .....	9-74937
	3013	Roosa Master Fuel Injectors .....	9-74959
<b>40</b>	<b>HYDRAULICS</b>		
	4010	Hydraulic Oil Filters .....	9-75055
	4011	Triple Hydraulic Pump .....	9-74775
	4012	Pressure Regulator Valve .....	9-74795
	4013	Separator Valve .....	9-74905
	4014	Remote Hydraulic Valves .....	9-74885
	4015	PTO Control Valve .....	9-75035
	4016	Three Point Hitch System .....	9-75185
	4017	Three Point Hitch Valve .....	9-74975
	4018	Hitch Cylinders .....	9-74835
	4019	Break-Away Couplings and Portable Cylinders .....	9-74197
<b>50</b>	<b>STEERING</b>		
	5010	Steering Column and Pump-Valve .....	9-74855
	5011	Steering Cylinders .....	9-74826
	5012	Rear Steering Valve .....	9-75015
	5013	Steering Lines, Linkage and Cables .....	9-74726
	5014	Front and Rear Steering Adjustments .....	9-76015
<b>60</b>	<b>POWER TRAIN</b>		
	6001	Trouble Shooting RPS-34 Power Shift .....	9-76037
	6010	Power Shift and Four Speed Transmission .....	9-74756
	6011	Conventional Front Differential and Drive Shaft .....	9-75005
	6012	Axles and Planetaries .....	9-74735
	6013	Torque Limiter Clutch .....	9-75245
	6014	Hydraulic PTO .....	9-74696
	6015	No-Spin Rear Differential and Drive Shaft .....	9-75285
	6016	Torque Proportional Differentials and Drive Shaft .....	9-78326
<b>70</b>	<b>BRAKES</b>		
	7010	Brake Pedal, Master Cylinder, Service and Parking Brake .....	9-74715

SERIES	SECTION	DESCRIPTION	FORM NUMBER
<b>80</b>	<b>ELECTRICAL</b>		
	8010	Basic Tractor Wiring Diagram .....	9-77035
	8011	Basic Cab Wiring Diagram .....	9-77696
	8012	Starting or Cranking Motors .....	9-75366
	8013	Battery Servicing and Testing .....	9-75377
	8014	Prestolite Alternator System .....	9-75399
	8020	Neutral Start Switch Adjustment .....	9-76045
<b>90</b>	<b>ACCESSORIES</b>		
	9010	Air Conditioning System .....	9-75105
<b>100</b>	<b>HOW IT WORKS</b>		
	10010	Remote Hydraulic Valves .....	9-74875
	10011	Separator Valve .....	9-74915
	10012	Pressure Regulator Valve .....	9-74865
	14017	Three Point Hitch Valve .....	9-77805
	10014	Steering Hand Pump and Valve .....	9-74845
	10015	Rear Steering Valve .....	9-75025
	10016	PTO Clutch, Valve and Dropbox .....	9-74705
	10018	Triple Hydraulic Pump .....	9-74815
	10018	Hydraulic Service Brake .....	9-75195
	10019	Power Shift .....	9-74765
	10022	Hydraulic Steering and System Tests - Specifications .....	9-75265
	19010	Air Conditioning - Theory of Operation .....	9-78615

# Section 1010

## GENERAL SPECIFICATIONS SERIAL NUMBERS



**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

## DIESEL ENGINE

### General

Type .....	6 Cylinder, 4 Stroke Cycle, Valve-In-Head Turbocharged Diesel Engine
Firing Order .....	1-5-3-6-2-4
Bore .....	4-5/8 Inches (117.5mm)
Stroke .....	5 Inches (127mm)
Piston Displacement .....	504 Cubic Inches (8 257cm <sup>3</sup> )
Compression Ratio .....	16.5 to 1
Cylinder Sleeves .....	Removable Wet Type
No Load Governed Speed .....	2340-2380 RPM
Rated Engine Speed .....	2200 RPM
Engine Idling Speed .....	775-825 RPM
*Valve Tappet Clearance (Exhaust) .....	(Hot) .020 Inch (0.508mm) (Cold) .025 Inch (0.635mm)
	(Intake) (Hot and Cold) .015 Inch (0.381mm)

\*Hot Settings Are Made After The Engine Has Operated At Thermostat Controlled Temperature For At Least Fifteen Minutes.

### Piston and Connecting Rod

Rings per Piston .....	3
Number of Compression Rings .....	2
Number of Oil Rings .....	1
Type Pins .....	Full Floating Type
Type Bearings .....	Replaceable Precision, Steel Back with Aluminum or Copper-Lead Alloy Liners.

### Main Bearings

Number of Bearings .....	7
Type Bearings .....	Replaceable Precision, Steel Back with Aluminum or Copper-Lead Alloy Liners.

### Engine Lubrication System

Oil Pressure .....	45 to 60 PSI (3.2 to 4.2 kg/cm <sup>2</sup> ) with Engine Warm and Operating at Rated Engine Speed.
Type System .....	Pressure and Spray Circulation
Oil Pump .....	Gear Type
Oil Filter (2) .....	Full Flow Spin on Type
Oil Capacity .....	With Filters, 23 U.S. Qts. (21.8 liters) Without Filters, 19 U.S. Qts. (17.9 liters)

## DIESEL ENGINE

### Fuel System

Fuel Injection Pump .....	Robert Bosch, Type PES (Multiple Plunger).
Pump Timing .....	30 Degrees Before Top Dead Center (Port Closing).
Fuel Injectors .....	Pencil Type (Opening Pressure 3200 PSI). (225 kg/cm <sup>2</sup> )
Fuel Transfer Pump .....	Plunger Type, Integral Part of Injection Pump.
Governor .....	Variable Speed, Fly-Weight Centrifugal Type; Integral Parts of Injection Pump.
1st Stage fuel filter .....	Full Flow Spin on Type
2nd Stage fuel filter .....	Full Flow Spin on Type
Fuel Tank Water Trap and Drain (2) .....	Located in Base of Each Fuel Tank.
Fuel Tank Capacity .....	(55 U.S. Gallons - 208.2 liters - each tank).
Fuel Level Gauge .....	Electric, Located on Instrument Panel.
Hand Primer Pump .....	Located on Top of the Fuel Transfer Pump.
Preliminary Fuel Filter .....	Located At The Bottom Of The Fuel Transfer Pump.

### Cooling System

Capacity of System .....	44 U.S. Quarts (41.6 liters)
Type of System .....	Pressurized, Thermostat Controlled By-Pass Type: Forced Circulation, (Impeller Type Pump).
Radiator .....	Heavy Duty Fin and Tube Type
Thermostat (2) .....	Starts to Open at Approximately 175°F. (79°C), Fully Open at 202°F. (94°C.)
Pressure Cap Required .....	7 PSI (0.492 kg/cm <sup>2</sup> )

### Electrical System

Type of System .....	12 Volt Negative Ground
Batteries .....	(2) 12 Volt Batteries Connected in parallel Group Size 30H, Rated in 1.255 to 1.265 Specific Gravity. Discharge Rate 300 Amps at 0°F. Voltage Drops to 9.2 after 10 seconds. Voltage drops 1.0 Volt per cell after 4 min.
Alternator .....	12 Volt 55 Amp Output, Negative Ground
Voltage Regulator .....	12 Volt, Solid Stage, Mounted on Alternator.
Starter Motor .....	12 Volt with Solenoid Switch
Head Lights (2) .....	12 Volt, 40/40 Watt Sealed High-Low Beam
Front Flood Lights (2) (optional) .....	12 Volt, 35 Watt Sealed Beam
L.H. Rear Flood and Tail Light (1) .....	12 Volt, 60 Watt Sealed Beam Combination Tail and Flood Lamp.
R.H. Rear Flood (optional) (1) .....	12 Volt, 35 Watt Sealed Beam
Circuit Breaker System over Load Check .....	12 Volt Twin 40 AMP Breakers connected in parallel, 80 AMP rating. 60 Amp. Min. Continuous capacity.

## GENERAL SPECIFICATIONS

### Electrical System (Cont'd)

Lights Circuit Breaker ..... 40 Amp., Located on Light Switch  
 Parking Brake Warning Light ..... 12 Volt, Red Flasher Type  
 Fuel Shut-Off Solenoid ..... 12 Volt, Rotary Type

### Hydraulic Brakes

Type ..... Self-Adjusting Multiple Disc  
 Wet Type Transmission Brakes.

### Parking Brake

Type ..... Cable Actuated by over center  
 Type Handle - Adjustable from  
 Operator's Seat. Multiple Disc. Type.

### Power Shift Transmission

Type ..... 3 Speed Compound Planetary  
 With Hydraulically Actuated Clutches  
 and a 4 Speed Gear Range Section.  
 Gear Selection ..... 12 Speeds Forward and 4 Speeds Reverse.  
 Shifting ..... Hydraulic Power Shifting Controlled  
 By a Lever on Operator's Console.  
 4 Speed Range Controlled by a  
 Mechanical Shifter From a Lever  
 on Operator's Console.  
 Oil Type ..... Case TFD (Transmission-Final Drive)  
 Oil Capacity ..... 56 U.S. Quarts (52.9 liters)

### Hydraulic Pump

Type ..... Direct Drive, Gear Type,  
 Triple Hydraulic Pump  
 First Section ..... Charging Pump, Capacity at  
 2200 Engine RPM - 39 GPM (147.6 l/mn)  
 Intermediate Section ..... Supplies oil to the Transmission  
 Hydraulic and PTO. Capacity at 2200  
 Engine RPM - 17 GPM (64.4 l/mn)  
 Third Section ..... Supplies oil to the Steering  
 System. Capacity at 2200 Engine RPM  
 17 GPM (64.4 l/mn)  
 Front Steering ..... 7 GPM (26.5 l/mn)  
 Rear Steering ..... 10 GPM (37.9 l/mn)

### Hydrostatic Front Power Steering


Oil Supply ..... Triple Hydraulic Pump  
 HGA Hydrostatic Type ..... Integral and Bi-Directional  
 Gerotor Metering Section, Actuated  
 By the Steering Wheel.  
 Front Steering Cylinders ..... Two Double Acting Cylinders



**APPROXIMATE TRAVEL SPEEDS  
IN MPH & KM/H AT 2200 RPM  
12 Speed Power Shift Transmission**

TRANSMISSION RANGE	POWER SHIFT			TIRE SIZE
	1	2	3 AND REVERSE	
1	1.9 mph (3.1 km/h)	2.5 mph (4.0 km/h)	3.1 mph (5.0 km/h)	18.4-30
2	2.8 mph (4.6 km/h)	3.8 mph (6.1 km/h)	4.8 mph (7.7 km/h)	
3	4.0 mph (6.4 km/h)	5.4 mph (8.7 km/h)	6.7 mph (10.5 km/h)	
4	7.4 mph (11.9 km/h)	9.8 mph (15.8 km/h)	12.3 mph (19.8 km/h)	
1	2.0 mph (3.2 km/h)	2.7 mph (4.4 km/h)	3.4 mph (5.5 km/h)	23.1-30
2	3.1 mph (5.0 km/h)	4.1 mph (6.6 km/h)	5.1 mph (8.2 km/h)	
3	4.3 mph (6.9 km/h)	5.8 mph (9.3 km/h)	7.2 mph (11.6 km/h)	
4	8.0 mph (12.9 km/h)	10.6 mph (17.1 km/h)	13.3 mph (21.4 km/h)	
1	2.0 mph (3.2 km/h)	2.7 mph (4.4 km/h)	3.3 mph (5.3 km/h)	18.4-34
2	3.0 mph (4.8 km/h)	4.1 mph (6.6 km/h)	5.1 mph (8.2 km/h)	
3	4.3 mph (6.9 km/h)	5.7 mph (9.2 km/h)	7.1 mph (11.4 km/h)	
4	7.9 mph (10.7 km/h)	10.5 mph (16.9 km/h)	13.1 mph (21.1 km/h)	
1	2.1 mph (3.4 km/h)	2.8 mph (4.5 km/h)	3.5 mph (5.6 km/h)	20.8-34
2	3.2 mph (5.2 km/h)	4.2 mph (6.8 km/h)	5.3 mph (8.5 km/h)	
3	4.4 mph (7.1 km/h)	5.9 mph (9.5 km/h)	7.4 mph (11.9 km/h)	
4	8.2 mph (13.2 km/h)	10.9 mph (17.5 km/h)	13.6 mph (21.9 km/h)	

## APPROXIMATE OVERALL MEASUREMENTS



TIRE		WHEEL RIM
A	23.1-30 R1	W20L-30

<b>B</b>	127 Inches (3 226mm)	<b>D</b>	216 Inches (5 486mm)	<b>F</b>	206 Inches (5 232mm)
----------	----------------------	----------	----------------------	----------	----------------------

<b>C</b>	102 Inches (2 591mm)	<b>E</b>	165 Inches (4 191mm)	<b>G</b>	15 Inches (381mm)
----------	----------------------	----------	----------------------	----------	-------------------

Overall Width ..... 108 Inches (2 743mm)  
 Turning Radius Minimum ..... 192 Inches (4 877mm)  
 Overall Length (w/Hitch Coupler) ..... 223 Inches (5 664mm)

## APPROXIMATE SHIPPING WEIGHT

2 WHEEL STEER W/STD. EQUIPMENT ..... 14,800 Pounds (6 713 kg)

# Section 2010

## CYLINDER HEAD AND VALVES

### SPECIFICATIONS

	Decimal System	Metric System
CYLINDER HEAD		
Warpage .....	(Max. Limit Incl. wear) .005"	0.127mm
EXHAUST VALVE		
Tappet clearance (COLD) .....	.025"	.635mm
Tappet clearance (HOT) .....	.020"	.508mm
Face angle .....	44°	44°
Fan run-out .....	(Max. Limit Incl. wear) .002"	.051mm
O.D. of head .....	1.745" to 1.755"	44.323 to 44.577mm
O.D. of stem end .....	.402" to .403"	10.211 to 10.236mm
(max. limit Incl. wear) .....	.002"	.051mm
O.D. of taper 4.2675" (108.3947mm) .....	.401" to .402"	10.185 to 10.211mm
(max. limit Incl. wear) .....	.002"	.051mm
Length .....	6.4195" to 6.4405"	163.0557 to 163.5887mm
Insert seat angle .....	45°	45°
Seat contact width .....	.0800" to .1000"	2.032 to 2.540mm
Seat run-out (max. limit Incl. wear) .....	.002"	.051mm
Insert height .....	.313" to .316"	7.95 to 8.026mm
O.D. of insert .....	1.9455" to 1.9465"	49.4157 to 49.4407mm
I.D. of insert .....	1.571" to 1.577"	39.903 to 40.056mm

## SPECIFICATIONS (Continued)

	Decimal System	Metric System
<b>INTAKE VALVE</b>		
Tappet clearance (COLD and HOT) .....	.015"	3.81mm
Face angle .....	44°	44°
Face run-out (max. limit Incl. wear) .....	.002"	.051mm
Length .....	6.4195" to 6.4405"	163.0557 to 163.5887mm
O.D. of stem .....	.402" to .403"	10.211 to 10.236mm
(max. limit Incl. wear) .....	.002"	.051mm
O.D. of head .....	1.995" to 2.005"	50.673 to 50.927mm
Seat angle .....	45°	45°
Seat contact width .....	.0775" to .0975"	1.9687 to 2.4767mm
Seat run-out (max. limit Incl. wear) .....	.002"	.051mm
Insert height .....	.2775" to .2825"	7.0487 to 7.1757mm
O.D. of insert .....	2.0990" to 2.1000"	53.315 to 53.34mm
I.D. of insert .....	1.805" to 1.815"	45.847 to 46.101mm
<b>INTAKE AND EXHAUST VALVE GUIDES</b>		
Length .....	3.219"	81.763mm
O.D. ....	.7510" to .7515"	19.075 to 19.202mm
I.D. (installed and reamed) .....	.4045" to .4055"	10.2747 to 10.2997mm
(max. limit Incl. wear) .....	.001"	.025mm
Protrusion above cylinder head .....	.953"	24.206mm
<b>VALVE SPRING</b>		
Free length .....	2.28"	57.912mm
Total coils .....	7.75	
Wire diameter .....	.171"	4.343mm
Compressed to 1.48" (30.480mm) (valve open) .....	135 to 145 lbs.	61.24 to 65.78 kg.
Compressed to 1.94" (49.276mm)(valve closed) .....	40 to 50 lbs.	18.14 to 22.68 kg.

**SPECIFICATONS (Continued)**

	Decimal System	Metric System
<b>ROCKER ARM ASSEMBLY</b>		
O.D. of shaft .....	.872" to .873"	22.149 to 22.174mm
I.D. of arm bore .....	.8745" to .8755"	22.2127 to 22.2377mm
Shaft assembly end play (both ends) .....	.010" to .030"	.254 to .762mm
Shaft spring:		
Total coils (working coils) .....	4	4
Wire diameter .....	.080"	2.033mm
Compressed to 1.562" (39.675mm) .....	8.5 to 11.5 lbs.	3.86 to 5.22 kg.
Lubrication .....	Engine oil, camshaft metering	
Shaft oil holes .....	Toward valve side of engine. shaft cannot be rotated.	

**Special Torques**

	Decimal System	Metric System
Cylinder head bolts .....	200 to 210 ft. lbs.	27.660 to 29.043 m-kp.
Intake and Exhaust manifold stud nut .....	25 to 30 ft. lbs.	3.456 to 4.148 m-kp.
Cylinder head valve cover stud nut .....	5 to 6 ft. lbs.	.691 to .830 m-kp.
Rocker arm bracket stud nut .....	40 to 45 ft. lbs.	5.530 to 6.221 m-kp.

## CHECKING COMPRESSION PRESSURE

**(Refer to Figure 1)**

1. Clean the engine thoroughly, preferably by steam cleaning.
2. Before cranking the engine make sure all operating controls are in neutral, brakes are set and the wheels are securely blocked.
3. There are two methods of checking compression pressure - the cranking method and the engine running method. **NOTE:** The engine must be at operating temperature for either method used.

**CRANKING METHOD** - Close the needle valve at the fuel tank. Disconnect all high pressure fuel lines and leak-off lines between injectors. Remove all of the injectors. Refer to the chart.

**RUNNING METHOD** - Disconnect the high pressure fuel line and leak-off lines from the number one injector. Using an appropriate length of tubing or hose, route the fuel from these lines back to the fuel tank or a clean container. Remove the number one injector. Refer to chart.

4. Clean the injector bores of loose carbon and residue. Replace the compression seal in the injector bore of the cylinder to be checked and install a Bacharach 70-314 (D-558) Compression Gauge Adapter. Secure with an original injector clamp assembly

and spacer, Inset A. Tighten bolt to 20 ft. lbs. (2.765 m-kg). Connect Case No. CD-504 Compression Gauge to the adapter.

**IMPORTANT:** It is very important that all cylinder pressures be approximately alike. For the allowable compression pressure variation, refer to the chart.

5. If the compression is greater than the figure mentioned, carbon deposits are indicated. If the reading is below these figures, leaking valves or excessive ring clearance is indicated. **NOTE:** To make a simple check when a compression leak is indicated, squirt a small amount (1 oz.) (28.4g) of oil into the cylinder and recheck the compression. If the pressure rises to near normal, compression loss is past the rings. Very little change in compression indicates leakage past the valves. A low pressure reading will cause difficulty in starting, particularly at low temperatures.

**NOTE:** Take several compression readings on each cylinder. This is done by pressing the vent valve button to relieve gauge pressure. When the button is released, the gauge will again indicate compression pressure.

**IMPORTANT:** Replace the compression seal and carbon seal on all injectors at the time of installation.

	ENGINE SPEED	NORMAL COMPRESSION PRESSURE	ALLOWABLE VARIATION BETWEEN CYLINDERS
<b>CRANKING</b>	Approximately 200 RPM	400 PSI (28.123 kg/cm <sup>2</sup> )	25 PSI (1.758 kg/cm <sup>2</sup> )
<b>RUNNING</b>	800 RPM	480 PSI (33.748 kg/cm <sup>2</sup> )	20 PSI (1.406 kg/cm <sup>2</sup> )

**NOTE:** \*A 4% reduction in PSI (kg/cm<sup>2</sup>) must be allowed for every 1000 ft. (304.800mm) above sea level.






Figure 1

## CYLINDER HEAD AND COMPONENTS

(Refer to Figure 2 and 3)

Remove the muffler and hood from the vehicle. Steam clean the engine thoroughly before doing any service work or removing any components.

1. Drain the cooling system. Disconnect and remove the turbocharger oil supply tube (1). Disconnect the oil drain tube (2) from the turbocharger (3). Disconnect the air cleaner from the turbocharger. Loosen clamps (4) on hose (5) on the intake manifold elbow (6). Remove the turbocharger and connector (7). Remove the exhaust elbow (8) from the water manifold (9) and the intake elbow (6) from the intake manifold (10). Discard gaskets (11, 12 and 13).
2. Remove the intake manifold (10) and discard gaskets (14). Remove the exhaust manifolds (15) and discard gaskets (16). Disconnect the hoses from the thermostat housing

and water manifold. Remove the water manifold (9) and discard gasket (17).

3. Disconnect the high pressure fuel lines to the injectors and the front leak-off tubes between each cylinder head. Cap them to prevent the entry of foreign material.
4. Disconnect and remove the breather tube (18) from the cylinder head covers and discard gasket (19). Remove the rocker arm covers (20) and discard gaskets (21 and 22).
5. Remove the rocker arm assemblies (23) push rods (24) and tag them for proper installation. See Page 2010-12, for servicing of the rocker arm assemblies.
6. Remove the cylinder head bolts (25) and cylinder heads (26). Discard the cylinder head gaskets (27).

**NOTE:** For turbocharger service see Section 2014.




Figure 2




Figure 3

## CYLINDER HEAD AND COMPONENTS (Continued)

(Refer to Figure 4)

- Place new cylinder head gaskets (27) on the engine block. **NOTE:** Two of the capscrew holes in the head gaskets are slightly smaller and act as guides to position the head gasket. Regular line-up studs can be used. In some instances it may be difficult to install the rear cylinder head due to limited spacer in which to locate the head when lowering it down over the longer guide studs.
- For difficult installations, the use of dowel pins and a tong are recommended, Inset A. These can be purchased through the Case Co. Service Parts Supply or a local Snap-On Tool Dealer under the following part numbers.



**CASE PART NO. SNAP-ON TOOL NO.**

<b>Tong</b>	<b>A40952</b>	<b>CF83-1</b>
<b>Dowel</b>	<b>A43450</b>	<b>CF83-5</b>

- Install the cylinder heads (26) and several bolts and washers (25). Remove A43450 dowels using A40952 tong or guide studs, whichever was used. Install the remaining cylinder head bolts and washers. Torque the cylinder head bolts in the proper sequence as illustrated in Inset B. Using wrench A42393, Inset C, which can be purchased through the Case Co. Service Parts Supply. The three recommended torque steps are 70 ft. lbs. (9.678 m-kg), 140 ft. lbs. (19.356 m-kg) and 210 ft.

lbs. (29.034 m-kg).

- Coat all push rods (24) with clean engine oil and install in their original location.
- Install the rocker arm assemblies (23) in their original location. Make sure all the push rods (24) are engaged with the adjusting screws. Install the bracket studs and tighten. Torque the bracket stud nuts 40 to 45 ft. lbs. (5.530 to 6.221 m-kg).
- Check the clearance at both ends of the rocker arm shafts, Inset D. Keep the clearance between .010" to .030" (.254 to .762mm) at each end. Adjust the valve taper clearance, refer to Page 2010-19.
- Install the exhaust manifold sections (15) with new gaskets (16). Torque the manifold nuts 25 to 30 ft. lbs. (2.765 to 4.148 m-kg).
- Install the intake manifold (10) with new gaskets (14). Torque the manifold nuts 25 to 30 ft. lbs. (3.456 to 4.148 m-kg).
- Install the water manifold (9) with new gaskets (17). Torque the manifold bolts 25 to 30 ft. lbs. (3.456 to 4.148 m-kg).
- Connect the water hoses to the thermostat housing and water manifold. Clamp securely.
- Connect the fuel injection lines and injection bleed off lines.






Figure 4

## CYLINDER HEAD AND COMPONENTS (Continued)

### (Refer to Figure 5)

1. Install the turbocharger (3) with a new gasket (12) on the exhaust manifold (15). Torque the retaining nuts 35 to 42 ft. lbs. (4.839 to 5.807 m-kg). Install the exhaust elbow connector (7) between the turbocharger and exhaust elbow (8). Secure the exhaust elbow to the water manifold. Torque the retaining bolts 80 to 96 ft. lbs. (11.060 to 13.273 m-kg). **NOTE:** Exhaust elbow connector (7) must be free to turn 360°. Install the turbocharger intake elbow (6) with a new gasket (11) on the intake manifold (10) and torque bolt 35 to 42 ft. lbs. (4.839 to 5.807 m-kg). Connect the elbow to the turbocharger with hose (5) and clamps (4). Clamp securely. Install the turbocharger supply line (1). Connect the turbocharger oil drain tube (2) with a new gasket (13) to the turbocharger.
2. Fill the cooling system, make sure the drain valves are closed. Apply clean engine oil to the rocker arms and start the engine.
3. Operate the engine for approximately one (1) hour, (under load if possible) to thoroughly warm up the engine and seat the head gaskets.
4. Shut the engine off. Using wrench A42393, Inset A, back off each cylinder head bolt individually 1/4 turn and retorque to 210 ft. lbs. (29.034 m-kg) in the proper sequence, Inset B. **NOTE:** DO NOT BACK OFF ALL BOLTS AT THE SAME TIME. Recheck the torque to make sure all cylinder head bolts have retained the 210 ft. lbs. (29.034 m-kg). Recheck rocker arm bracket stud nuts to make sure they have retained 25 to 30 ft. lbs. torque (2.765 to 4.148 m-kg). Check and readjust the tappets if required. Install new valve cover gaskets (22), cylinder head cover (20), stud gaskets (21) and washers. Torque the cylinder head cover nuts 5 to 6 ft. lbs. (.691 to .830 m-kg) DO NOT over torque nuts.
5. Install the breather tube (18) with new gaskets (19).




Figure 5

## ROCKER ARM ASSEMBLY

### (Refer to Figure 6)

Be sure the rocker arm assemblies are tagged so they are installed on the same cylinder head they were removed from. Tag component parts for proper assembly. Do not intermix parts from one assembly to another.

1. Remove the oil tube (1) with the "O" ring (2). Remove the "O" ring and discard it. Remove the snap rings (3) and spacer washers (4). Keep count of the number of washers used at each end of the shaft (5). Tag each rocker arm for original location. Remove the exhaust rocker arms (6) and the shaft brackets (7) from the shaft (5).
2. Remove the intake rocker arms (8) and shaft spring (9).

Check the shaft spring for damage and proper tension.

#### Spring Specifications:

Total coils (working coils) ..... 4  
 Wire diameter ..... .080" (2.032mm)  
 Compressed to 1.562" (39.675mm).. 10 lbs.  
 (4.54 kg)

Flush the shaft to remove any residual material. Inspect the shaft for worn spots on the bottom side of the shaft. Replace the shaft if a worn condition exists.

Inspect the rocker arms by installing each rocker arm on the shaft in its proper location. The rocker arm must be free on the shaft without any side wobble. If any is noted, replace the rocker arms. Clean the oil holes in the rocker arms to insure free oil flow. Inspect the valve stem contact area on the

rocker arm for wear. Replace if worn. Inspect the tappet adjusting screw for wear marks or pitting.

With all components parts cleaned thoroughly and worn parts replaced, coat them with clean engine oil.

1. Install the shaft spring (9) and the two intake rocker arms (8) on the shaft (5). When installing the rocker arms, keep the shaft oil holes toward the valves, Inset A.
2. Install the shaft brackets (7) on the shaft (5) with the split side toward the push rod side of the engine.
3. Install the exhaust rocker arms (6) on the shaft (5). Install the same number of spacer washers (4) at each end of the shaft as were removed during disassembly.
4. Install the snap rings (3) at each end of the shaft. Check the rocker arms for free movement. Install the oil tube (1) with a new "O" ring (2). Install the adjusting screws (10) and lock nuts (11) if they were removed for replacement.
5. Install the rocker arm and shaft assembly as instructed on Page 2010-8.
6. Check the exhaust rocker arms for excessive end play. One or more spacer washers can be used between the exhaust rocker arms (6) and snaprings (3) to remove excessive end play. A clearance of .010" to .030" (.254 to .762mm) must be maintained at each end of the shaft and can be checked in the areas shown in Inset B.







Figure 6

## CYLINDER HEAD ASSEMBLY

### (Refer to Figure 7)

1. Using a valve spring compressor, compress the spring (1) enough to remove the valve retainer locks (2). Release the spring compressor and remove the intake valve rotator (3) or exhaust valve rotator (4). Remove the valve springs (1), valve stem oil seals (5) and valve spring seats. Remove any carbon from the valve stems before they are removed from the cylinder head.
2. Remove the intake valves (7) and the exhaust valves (8) from the cylinder head (9) and set them in a rack or holder. Mark them on removal so they may be installed in their original location.
3. Drive the intake valve guide (10) and exhaust valve guide (11) down through the head using an arbor.
4. The exhaust valve seats (12) and intake valve seats (13) can be removed with a special seat removing tool, Inset A. **NOTE:** Never attempt to remove a valve seat with a center punch, cold chisel or pry bar.
5. To remove the expansion plugs (14) and 15) they must be drilled and pryed out.

**NOTE:** Refer to Pages 2010-16-19 for inspection and servicing prior to assembly.

1. If the valve guides have been replaced, install the new guides (10 and 11) using an arbor. Press the guides into the head from the top of the cylinder head. The guides must protrude above the cylinder head (intake and exhaust) .953" (24.206mm), Inset B.
2. To install new exhaust seats (12) and intake valve seats (13), clean the recess in the cylinder head. Place the valve seats in dry

ice to shrink them. Insert the valve seats in the head and press them in place using a suitable press.

3. Lubricate the intake valves (7) and exhaust valves (8) with clean engine oil and install them in their original locations.
4. Install the valve spring seats (6), valve springs (1), the intake valve rotators (3) and exhaust valve rotators (4). Compress the valve springs so the valve stem seals (5) can be installed in the lower grooves of the valve stems. Install the valve retainer locks (2). Remove the spring compressor carefully.



**IMPORTANT:** Assemble the valve rotators with the original valves because they tend to wear in as matched parts. If it is necessary to install a new valve, always install a new rotator and retainer locks .

5. Install new plugs (14, Inset C and 15, Inset D) if they were removed. If the manifold studs (15) are to be replaced, install as indicated in Inset E.

**NOTE:** When engine assembly is complete, a check of the operation of the rotators must be made. It is impossible to determine whether or not the rotator is turning without an identifying mark.

Place a dab of white paint on each of the rotators and note its position. Start the engine and observe whether or not the rotator is turning. DO NOT attempt repairs on rotators.

There is no set speed at which the rotators should turn. Some rotators will turn faster than others. As long as the rotator is turning the valve, it is functioning properly.



## INSPECTION OF VALVES, GUIDES, HEAD AND SPRINGS


Clean the cylinder head completely. Remove all traces of carbon and other deposits. Check for cracks and any evidence of fretting or erosion existing in the area of fire ring contact. Check the head for evidence of warpage. If warpage exists and is more than .005" (.127mm), the cylinder head must be resurfaced or replaced.

Valve springs should be checked for flat squared ends, broken coils and correct spring pressure. Use a Valve Spring Tester referring to the spring specifications below.

Free length ..... 2.28" (57.912mm)  
 Total coils ..... 7.75  
 Wire diameter ..... .171" (4.343mm)


Valve Position	Compressed Height	Spring Pressure	Replace if Less than
Valve Open	1.48" 37.592mm	140 lbs. 63.50 kg	135 lbs. 61.24 kg
Valve Closed	1.23" 31.242mm	45 lbs. 20.41 kg	40 lbs. 18.14 kg

Remove all carbon from the bore of the valve guides with a five wire brush and blow clean with compressed air. Valve guides can be checked for wear or by using a bore gauge and micrometer, refer to Figure 8, Inset A. The valve guides should be checked at the Top, middle and bottom of the guide bore for wear, Figure 8. If the diameter is greater than .4056" (10.3022mm) at any point along the bore, the guide must be replaced. Use an arbor equal to the inside diameter of the valve guide to keep the guide from collapsing when pressed into place. Press in from the top of the head until the guide (Intake and exhaust) protrudes a distance of .953" (24.206mm) above the head, refer to Figure 7, Inset B, Page 2010-15. Replacement guides must be rebored after installation. Rebore the guide area, as shown in Figure 8, .4045" to .4055" (10.2747 to 10.2997 mm) with reamer A43113.




CHECK WEAR OF GUIDE AT THREE POINTS  
**Figure 8**

Clean the valves with a power driven fine wire brush, being very careful not to scratch the valve stems. Refer to Figure 9 for valve nomenclature.




**Figure 9**

Inspect the valves for excessive wear or necked stems, Figure 10. This can be caused by lack of lubrication, plugged water passages or operating the engine under continuous overload at excessive engine RPM. Replace valves if this condition exists.




**Figure 10**

Inspect the valves for deep grooves in the face, Figure 11. This can be caused by abrasives entering the engine through the intake system or not servicing the air intake system regularly. If grinding the valve face will not correct this condition, replace the valve.



**Figure 11**


Inspect the valve face and stem for rust or pitting, Figure 12. Rust or pitting can usually be removed by grinding the valve face. If rust or pitting on the valve stem exists, replace the valve. These conditions can be caused by using poor quality engine oil or fuel that does not meet the specifications given in the General Specifications Section 1010 and by improper engine storage.




**Figure 12**

# INSPECTION OF VALVES, GUIDES, HEAD AND SPRINGS (Cont'd)


Heavy carbon or varnish deposits on the valves, Figure 13, should be removed before valves are ground. This condition is usually caused by worn piston rings and sleeves which allow too much oil to reach the combustion chamber. This condition could also be caused by worn valve guides or bad seals on the valves. Low operating temperature is still another cause.



Inspect the valve head for dishing and the valve face for deep burned spots, Figure 14. These conditions cannot be corrected by grinding the valves. The valves must be replaced. These conditions are usually caused by running the engine under excessive loads at high engine temperature.




Valves with worn keeper grooves or if the stem tip is worn or dished beyond the chamfer, replace the valves, Figure 15.




The checking of the valve stem diameter can best be done with a good accurate micrometer, Figure 16. The intake valve stem being straight, should be measured at three points along the stem, Figure 16. Wear limit must not exceed .002" (.051mm) at all points of measurement. If the wear is greater, replace the valve.


The exhaust valve, being a tapered stem, must have two diameter readings as shown in Figure 16. Wear limit must not exceed .002" (.051mm) at both points of measurement. If the wear is greater, replace the valve.



The checking of the valve face runout should be done after the valves have been ground. A Vee block type holder with a dial indicator, Figure 17, can be used to check the valve face and stem runout. The valve face runout should not exceed .002" (.051mm). The valve stem runout should not exceed .002" (.051mm). If the valve face and/or valve stem runout is greater, the valve must be replaced.




**NOTE:** Small amounts of very fine pitting, Figure 18, may be found on the surfaces of the valve faces and seats after the valves are cleaned. These are normal and will not affect engine performance. This fine pitting is caused by a normal oxidation process and can happen on any engine during the run-in period. It is not necessary to grind valves or seats if this fine pitting is found as the pitting will generally reoccur after the engine is run for a few hours.



## REFACING INTAKE AND EXHAUST VALVES

Before refacing the valves, they should be wire brushed, cleaned and inspected. A 44° angle is the correct valve face grinding angle. Set the refacing machine protractor at this angle. Be sure the chuck of the machine is clean before installing the valve. Dress the grinding wheel before starting to reface the valves. Take only light cuts as the valve is refaced. The last cut must be very fine so the valve face will have a polished finish.


**IMPORTANT:** Replace any valve that has a thin edge or margin, Figure 19. If the margin on the ground valve is less than half the margin on a new valve, replace the valve.



**Figure 19**

The tip end of the valve should be checked for roughness or wear. Usually this can be removed with some very light cuts against the side of the grinding wheel and will square up the end. Never grind off the valve stem beyond the chamfer.

Correct refacing of intake and exhaust valves and valve seats will provide a 1° interference angle. This angle is important since it aids in cutting carbon and helps seat the valves.




**Figure 20**

When the top edge of the contact area is too high or low on the valve face, the seat contact area must be moved. This is done by using the narrowing stones. Refer to Page 2010-19. The contact area width should never exceed the specified dimensions.

## GRINDING INTAKE AND EXHAUST VALVE SEATS


Always use a precision seat grinder. Take very light cuts with the grinding stones so just enough metal is removed to end up with a good smooth seat finish.

The proper angle of grind is a 45° angle, Figure 21, for intake and exhaust seats. The seat grinding angle of the stone should be dressed frequently on a stone dresser to maintain a clean accurate surface.




**Figure 21**

**IMPORTANT:** The valve seat runout should be checked after finish grinding with a dial indicator and seat grinding pilot, Figure 22. The runout of the valve seat must not exceed .002" (.051mm).




**Figure 22**

The valve seat contact area width and location can be checked by using the 30° and 60° narrowing stones, Figure 23.



**Figure 23**

**NOTE:** If the valve head has receded more than .060" (1.524mm) below the cylinder head surface, Figure 24, the valve and/or valve insert should be replaced to keep the compression ratio equal between cylinders for an efficient running engine.



**Figure 24**



**Suggest:**

**If the above button click is invalid.**

**Please download this document**

**first, and then click the above link**


**to download the complete manual.**

**Thank you so much for reading**

## LOCATING TOP DEAD-CENTER AND TAPPET ADJUSTMENTS

Firing Order ..... 1-5-3-6-2-4

The top dead center of No. 1 and No. 6 cylinders are found and indicated by aligning the TDC mark on the crankshaft pulley and the timing pointer on the timing gear cover, Figure 25.




**Figure 25**

The tappet adjustments can be done in two steps as described in the following manner.

### COLD SETTING

**STEP 1** - Remove the valve covers. Crank the engine until the timing pointer is aligned with the TDC timing mark on the crankshaft pulley, Figure 25. Check the push rods on No. 1 cylinder for looseness. If the push rods are loose, No. 1 cylinder is at TDC on the compression stroke. If the push rods are tight, crank the engine one complete revolution and align the pointer and the TDC mark.

Check and adjust the following valve clearances; intake valves at .015" (.381mm) clearance on cylinders 1, 2 and 4 and the exhaust valves on cylinders 1, 3 and 5 at .025" (.635mm) clearance, Figure 26.




NO. 1 TDC COMPRESSION STROKE

**Figure 26**

**STEP 2** - Crank the engine one complete revolution and align the timing pointer and the TDC mark. Cylinder No. 6 should be at TDC on the compression stroke. Check the push rods on No. 6 cylinder for looseness.

Check and adjust the following valve clearances; intake valves at .015" (.381mm) clearance on cylinders 3, 5 and 6 and the exhaust valves on cylinders 2, 4 and 6 at .025" (.635mm) clearance, Figure 27.



NO. 6 TDC COMPRESSION STROKE

**Figure 27**

### HOT SETTING

**STEP 3** - Follow steps 1 and 2 while the engine is hot. The tappet clearance for hot settings are .015" (.381mm) on the intake valves and .020" (.508mm) on the exhaust valves.

Install new cylinder head cover gaskets, the valve covers and breather tube. Torque the valve cover nuts 5 to 6 ft. lbs. (.691 to .830 m-kg.). Do not over torque.

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**