

# TABLE OF CONTENTS

## 3394 AND 3594 TRACTORS

SERIES	SECTION	DESCRIPTION	FORM NUMBER
10	<b>GENERAL</b>		
	1210	General Specifications .....	8-27430
	1212	Lubrication .....	8-27450
	1220	Engine Specifications - 504BDT Engine .....	8-20841
	1230	Fuel System Specifications .....	8-20851
	1250	Steering System Specifications .....	8-24920
	1260	Power Train Specifications .....	8-24930
	1270	Brake System Specifications .....	8-24880
	1280	Hydraulic System Specifications .....	8-24890
20	<b>ENGINES</b>		
	2201	Troubleshooting - Engine .....	8-20111
	2202	Engine Tune-Up .....	8-20120
	2210	Tractor Split (Between Engine and Torque Tube) .....	8-20900
	2215	Cylinder Head, Valve Train and Camshaft .....	8-20140
	2225	Cylinder Block, Sleeves, Pistons and Rods .....	8-20150
	2235	Crankshaft, Main Bearings, Flywheel and Oil Seals .....	8-20160
	2245	Lubrication System - Oil Pump, Oil Pan and Heat Exchanger .....	8-20910
	2255	Cooling System .....	8-20180
	2265	Turbocharger - T04B .....	8-20190
	2565	Turbocharger - Failure Analysis .....	9-78235
	2275	Air Induction System .....	8-20920
	2290	Reconditioning Engine Cylinder Block .....	8-21170
30	<b>FUEL SYSTEM</b>		
	3210	Fuel System and Filters .....	8-20220
	3212	Robert Bosch Fuel Injection Pumps .....	8-20230
	3213	American Bosch Fuel Injectors .....	8-20240
40	<b>ELECTRICAL</b>		
	4201	Electrical System Troubleshooting .....	8-26500
	4205	Instrument Cluster Troubleshooting .....	8-26470
	4210	Tractor Electrical Wiring Diagram .....	8-24360
	4215	Power Shift Electrical Wiring Diagram .....	8-24342
	4220	Cab Electrical Wiring Diagram .....	8-24371
	4230	Starting Motors .....	8-25980
	4235	Battery Servicing and Testing .....	8-20291
	4240	Delco-Remy Alternator System .....	8-25690
	4280	Neutral Start Switch Adjustment and Correct Starting Procedure Using Booster Batteries .....	8-20310
50	<b>STEERING</b>		
	5205	Testing Tractor Steering System .....	8-27360
	5210	Steering Column, Pump and Valve .....	8-20341
	5250	Flow Divider .....	8-27370

Reprinted

SERIES	SECTION	DESCRIPTION	FORM NUMBER
60		<b>POWER TRAIN</b>	
	6205	Troubleshooting - Power Shift Transmission .....	8-26780
	6210	Tractor Split (Between Torque Tube and Transmission) .....	8-27030
	6220	Torque Limiter Clutch .....	8-20980
	6325	Hydraulic Pump Drive .....	8-24140
	6230	Power Shift .....	8-27040
	6231	High/Low Range (24 Speed Transmission) .....	8-24030
	6235	Power Shift Control Valve and Linkage .....	8-24660
	6236	High/Low Range Solenoid (24 Speed Transmission) .....	8-24712
	6240	Four Speed Transmission .....	8-27050
	6241	Transfer Gear Box .....	8-27060
	6245	Hydraulic PTO .....	8-21030
	6251	Rear Axles and Planetaries .....	8-24390
	6255	Differential and Differential Lock .....	8-21050
	6260	Front Axle Differential and Steering Cylinder .....	8-26711
	6265	Front Axle and Planetary - 3394 Tractor .....	8-26720
	6365	Front Axle and Planetary - 3594 Tractor .....	8-27090
70		<b>BRAKES</b>	
	7210	Brake Pressure Regulator Valve .....	8-24670
	7215	Park Lock System .....	8-21070
	7220	Brake Cylinder .....	8-21080
	7240	Brake Valve .....	8-24470
80		<b>HYDRAULIC</b>	
	8202	Troubleshooting - Hitch System .....	8-21090
	8205	Testing Tractor Hydraulic System .....	8-26631
	8210	Hydraulic Oil Filter .....	8-27380
	8220	Hydraulic Charging Pump .....	8-21120
	8225	Hydraulic Pump .....	8-20601
	8250	Remote Hydraulic Valves .....	8-27320
	8255	Flow Divider and PTO Control Valve .....	8-21140
	8260	Differential Lock Solenoid .....	8-24690
	8280	Hitch System .....	8-21151
	8290	Break-Away Couplings and Portable Cylinder .....	8-20640
90		<b>ACCESSORIES</b>	
	9205	Troubleshooting - Air Conditioning System .....	8-20650
	9215	Gauging and Testing Air Conditioning System .....	8-20660
	9225	Compressor Isolation, Removal, Installation and Evacuation - Discharging, Evacuation and Charging the Air Conditioning System .....	8-20670
	9235	Servicing Air Conditioner Components .....	8-24770
	9245	Servicing the Cab Blower .....	8-25580
	9250	Operator Seat Adjustments - Non Air/Oil .....	8-24750
	9250	Operators Seat - Air/Oil .....	8-25511
	9260	Removal of Hood, Grill and Side Panels .....	8-20710
	9270	Cab Removal .....	8-24511
	9280	Pedal and Lever Adjustments .....	8-24680
100		<b>HOW IT WORKS</b>	
	14205	Digital Instrument Cluster .....	8-26550
	16430	Electrically Actuated and Hydraulic Operated 12 and 24 Speed Power Shift .....	8-24731
	18225	Case CON TROL Hydraulic .....	8-21350

# **Section 1210**

## **GENERAL SPECIFICATIONS**

**<https://www.ebooklibonline.com>**

Hello dear friend!


Thank you very much for reading.

Enter the link into your browser.


The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**


## SERIAL NUMBERS




**CAB SERIAL NUMBER PLATE**




**ENGINE SERIAL NUMBER PLATE**



**MODEL AND PRODUCT IDENTIFICATION  
NUMBER PLATE**



**TRANSMISSION SERIAL NUMBER PLATE**



**AXLE SERIAL NUMBER**

## DIESEL ENGINE SPECIFICATIONS

### General

Type .....	Six Cylinder, Four Stroke Cycle, Turbocharged, Valve In Cylinder Head
Firing Order .....	1-5-3-6-2-4
Bore .....	4-5/8 inch (117.5 mm)
Stroke .....	5 inch (127 mm)
Piston Displacement .....	504 Cubic inch (8 259 cm <sup>3</sup> )
Compression Ratio .....	15.8 to 1
Cylinder Sleeves .....	Wet Type, Can Be Removed
Governor Engine Speed Without Load .....	2280 to 2320 RPM
Rated Engine Speed .....	2100 RPM
Engine Idle Speed .....	725 to 775 RPM
Rocker Arm to Valve Clearance, Cold (Exhaust) .....	0.025 inch (0.635 mm)
(Intake) .....	0.015 inch (0.381 mm)

**IMPORTANT:** *Rocker arm to valve clearance adjustment must be made when the engine is not running.*

### Crankshaft

Main Bearing Journal Diameter .....	3.5 inch (88.9 mm)
Rod Bearing Journal Diameter .....	3.0 inch (76.2 mm)

### Piston And Rod

Rings Per Piston .....	3
Compression Rings Per Piston .....	2
Oil Rings Per Piston .....	1
Type of Piston Pin .....	Full Float
Type of Bearings .....	Replacement Bearings Available, Steel Back With Aluminum or Copper and Lead Liners

### Main Bearings

Quantity of Bearings .....	7
Type of Bearings .....	Replacement Bearings Available, Steel Back With Aluminum or Copper and Lead Liners

## Engine Lubrication System

Oil Pressure .....	45 to 60 PSI (310 to 414 kPa)(3.1 to 4.14 bar) With Engine Warm and Operating at Rated Speed With a Light Emitting Diode (LED) Service Monitor Located in the Digital Instrument Cluster.
Type System .....	Constant Pressure and Spray With Piston Oil Cooling
Oil Pump .....	Gear Type
Oil Filter (2) .....	Full Flow, Turn on Type, Bypass Valve in Filter Base
Oil Capacity .....	With Filters, 21 U.S. Quarts (20 Litres) Without Filters, 23 U.S. Quarts (22 Litres)
Oil Cooler .....	Cooled by Engine Coolant

## Fuel System

Fuel Injection Pump .....	Robert Bosch, Type PES
Pump Timing .....	25 Degrees (BTC) Before Top Center. <b>IMPORTANT: Do not increase past 25 degrees BTC at any time. The given 25 degrees gives minimum emissions in tractor operation.</b>
Fuel Injectors .....	American or Robert Bosch, 17 mm
Fuel Transport Pump .....	Plunger Type, a Part of the Fuel Injection Pump
Governor .....	Variable Speed, a Part of the Fuel Injection Pump
First Stage Fuel Filter .....	Full Flow, Turn On Type
Second Stage Fuel Filter .....	Full Flow, Turn On Type
Water Trap and Drain for Fuel Tank .....	Location is in Bottom of Fuel Tank
Fuel Tank Capacity .....	85 U.S. Gallons (322 Litres)
Fuel Level Indicator .....	Liquid Crystal Display (LCD) Bar Indicator Located in the Digital Instrument Cluster
Hand Primer Pump .....	Location is on Top of Fuel Transport Pump
Fuel Strainer .....	Location is at Bottom of Fuel Transport Pump

## GENERAL TRACTOR SPECIFICATIONS

### Air Intake System

Type ..... Dry Type Air Induction System, Two Stage, Aspirated System With Service Indicator on Digital Instrument Cluster

### Cooling System

Capacity ..... 44 U.S. Quarts (41.6 Litres)  
 Type ..... Pressure System, Thermostat Controlled, Bypass, Impeller Type Pump  
 Radiator ..... Heavy Duty Fin and Tube Type  
 Thermostats ..... Two, Starts to Open at Approximately 175°F (79°C), Fully Open at 202°F (94°C)  
 Pressure Cap ..... 10 PSI (69 kPa)(0.69 bar)  
 Water Level ..... Light Emitting Diode (LED) Service Monitor Located in the Digital Instrument Cluster  
 Coolant Temperature ..... Liquid Crystal Display (LCD) Bar Indicator Located in the Digital Instrument Cluster

### Electrical System

Type of System ..... 12 Volt, Negative Ground  
 Batteries ..... Two 12 Volt Batteries Connected in Parallel, AABM Group Size TFG10-600, Rated in 1.255 to 1.265 Specific Gravity. Discharge Rate 300 Amperes at 0°F.  
 Alternator ..... 12 Volt, 105 Ampere Output, Negative Ground With a Light Emitting Diode (LED) and a Liquid Crystal Display (LCD) Service Monitors Located in the Digital Instrument Cluster.  
 Voltage Regulator ..... 12 Volt, Solid State, Inside Component of Alternator  
 Starter Motor ..... 12 Volt With Solenoid Switch  
 Head Lamps (2) ..... 12 Volt, 40/60 Watt Sealed Beam High-Low  
 Front Flood Lamps (4 Max) ..... 12 Volt, 50 Watt, Sealed Beam  
 Rear Flood Lamps (4 Max) ..... 12 Volt, 50 Watt, Sealed Beam  
 Flasher Lamps (2) with Direction Turn Signals ..... 12 Volt, Amber Lens  
 Tail Lamps (2) ..... 12 Volt, Red Lens  
 Electrical System Circuit Breaker  
 Primary Circuit ..... 12 Volt, Three 50 Ampere Circuit Breakers Connected in Parallel, 150 Ampere Rating, 112.5 Ampere Minimum Continuing Capacity.  
 Auxiliary Circuit ..... 12 Volt, Four 50 Ampere Circuit Breakers

## Electrical System

### Bulb And Lamp Replacement:

Instrument Cluster Lamps .....	No. 73
Dome Lamp Bulb .....	No. 93
Console Lamp Bulb .....	No. 194
Flasher Lamp Bulb .....	No. 1156
Head Lamp .....	No. 4652
Front and Rear Flood Lamp .....	No. A48265
Tail Lamp Bulb .....	No. 168

### Fuse Replacement:

Instrument Cluster .....	3.0 Ampere
Automatic Shutoff Solenoid .....	7.5 Ampere
Tail Lamp .....	15 Ampere
Lamp Switch Feed .....	25 Ampere
Accessories .....	3.0 Ampere
Ether Switch and Cab Relay .....	20 Ampere
Head Lamp Low Beam .....	15 Ampere
Head Lamp High Beam .....	15 Ampere
Front Flood Lamps .....	25 Ampere
Radio and Night Lamp .....	10 Ampere
Ignition Switch .....	25 Ampere
Flasher and Dome Lamp .....	15 Ampere
Rear Flood lamps .....	25 Ampere
Wiper .....	7.5 Ampere
Blower .....	15 Ampere
Cigarette Lighter .....	15 Ampere
Instrument Reset .....	5.0 Ampere
Transmission Control Differential Lock .....	20 Ampere
Range Switch .....	1.0 Ampere
Rear Wiper and Washer (If equipped) .....	10 Ampere

## Tractor Brakes

Type ..... Hydraulic, Power Assistance, Self-Adjusting,  
Several Plate Wet Type Differential Brakes.

## Power Shift Transmission

Type ..... Three Speed, or Six Speed, Compound Planetary with  
Hydraulically Actuated Clutches and a Four Speed Gear Section

Gear Selection ..... 12 Speeds Forward and Three Speeds Reverse  
or 24 Speeds Forward and Three Speeds Reverse

Shift Control ..... Actuated by a Lever on the Console.

Oil Cooler ..... Transmission, Remote Hydraulics, Steering and Brake Oil

## Parking Lock System

Parking Lock ..... Actuated by Gear Shift Lever

## Differential Lock

Type ..... Electrically Controlled by Switch on Control Console  
and Hydraulically Actuated

## Hydrostatic Power Steering

Type ..... Gear Pump of Hydraulic Pump  
 Pump Capacity at 2100 RPM ..... 13 GPM (4.92 l/min)  
 Steering Pump ..... Hydrostatic Type, Actuated By the Steering Wheel  
 Steering Cylinder ..... Double Action Cylinder

## Hitch System

Type of Sensing ..... Lower Link  
 Type of Control ..... Hand Lever  
 Type of Valve ..... Three Position-Lift, Hold and Lower  
 Type of Draft Arms ..... Rigid, Swing Type or Extendable With Lower Float Adjuster  
 Type of Hitch ..... Three Point, Category III  
 Conversion Hitch Coupler (Available) ..... Category III To II  
 Lift Capacity at 24 inch (610 mm) Behind Lift Point ..... 7,750 lb (3 515 kg)

## Remote Hydraulic System

Pump ..... Axial Piston Pump, Pressure and Flow Compensated.  
 Type Remote Valve ..... Closed Center, Two to Four Sections,  
 Hand Lever Control, 1st Section Priority,  
 1st/2nd Section Load Check on "B" Port,  
 3rd Section Load Check Optional-Single or Dual,  
 Variable Flow Control for Each Section.  
 Pump Capacity at 2100 Engine RPM ..... 28 to 30 GPM (106 to 114 l/min)  
 Maximum System Pressure ..... 2250 PSI (15 503 kPa)(155.03 bar) With a Light  
 Emitting Diode (LED) Service Monitor for Both  
 Transmission Oil Pressure and Transmission  
 Filter Located in the Digital Instrument Cluster  
 Couplings ..... ASAE R366 Standard, Fast Removal, Break Away Type

## Power Takeoff

PTO Type ..... Independent of Transmission  
 Type of Clutch ..... Hydraulic Actuated  
 Rotation ..... Clockwise  
 Spline Size ..... 21 Splines, 1.375 inch (34.9 mm) Diameter  
 PTO Speed ..... 1000 RPM Shaft Speed at 2100 Engine RPM

## Drawbar

Standard or Yoke Type ..... Full Swing, Roller Mount, Takes a 1-1/2 inch  
 (38.1 mm) Diameter Pin.

## Mechanical Front Drive (MFD)


Front Axle ..... Spiral Bevel With Planetary Reduction in Hub  
 Interaxle Ratio - Front/Rear ..... 1.332  
 Differential Oil Capacity ..... 9 U.S. Quarts (8.5 litres)  
 Planetary Oil Capacity ..... 1.5 U.S. Quarts (1.4 litres) each planetary

# INSTALLATION INSTRUCTIONS FOR M20614 TEFLON VALVE SEAL KIT


## Special Tools Required



M20624 SEAL INSTALLATION TOOL




M20617 VALVE GUIDE CUTTING TOOL




VALVE SPRING COMPRESSOR

### STEP 1



Remove the cylinder heads. See Section 2215 of the Service Manual for removal of the cylinder heads.


### STEP 2



Use a valve spring compressor to push down the valve springs.


**IMPORTANT:** Make a mark on the valves, rotators, spring retainers and keepers. This will make sure that the parts are installed in the original location.

### STEP 3




Push down the valve springs and remove the valve keepers.

### STEP 4




Remove the valve rotators or the valve spring retainers.

**STEP 5**




Remove the valve springs.

**STEP 8**




Remove the valves.

**STEP 6**




Remove the spring seats.

**STEP 9**



Clean the cylinder head completely, removing all the carbon and other deposits. Check for cracks and for any sign of damage, existing in the area of the fire ring contact.

**STEP 7**





Remove the valve stem seals.

**STEP 10**




Clean the valves with a fine wire brush that is power driven. Remove all carbon and varnish deposits. Do not scratch the valve stems.

### STEP 11



Check the top surface of the valve guide. There must be a minimum of a 1/16" (0.0625 mm) wide flat around the complete top surface.


### STEP 12



Use the M20617 tool in an electric drill to give the necessary flat area on the valve guide.


**IMPORTANT:** Do not go over 450 RPM when drilling.

### STEP 13




Put clean engine oil on the valves before installing the valves in the cylinder head.

### STEP 14




Install the spring seats. Put the plastic installation cap on the end of the valve stem. The plastic cap prevents the sharp edges on the valve stem grooves from cutting the valve seal.


**NOTE:** One M20614 kit is required for one cylinder head.

**STEP 15**


Put the valve seal over the plastic cap. Hold your thumb against the white seal insert to keep the insert from coming out. Push the valve seal down so that the seal jacket is against the top of the valve guide. Remove the installation cap. Keep the cap since the cap will be used again.

**STEP 16**

Use the M20624 tool and push the seal down over the valve guide until the seal is level with the top of the guide.

**STEP 17**


Install the valve spring. Either end of the valve spring can be installed in the valve spring seat because both ends of the spring are closed.

**STEP 18**

Install the valve rotators or the valve spring retainers (flat side up).


**IMPORTANT:** *Install the valve rotators or the valve spring retainers with the original valves because these parts are worn as counterparts of each other.*

**STEP 19**




Push down the valve springs with a spring compressor.

**STEP 20**



Install a new valve seal in the lower valve stem groove.


**STEP 21**



Install the valve keepers in the upper valve stem groove.


Rac 8-20111

**STEP 22**




Remove the spring compressor. Hit the end of the valve stems with a soft hammer to seat the valve keepers.

**STEP 23**



Install teflon seals on all the intake and exhaust valves.

**STEP 24**




Install the cylinder heads. See Section 2215 of the Service Manual for installation of the cylinder heads.

Revised 7-83 Printed in U.S.A.

## ENGINE TUNE-UP PROCEDURE


### Checking The Crankshaft Damper Pulley (If Equipped)

#### STEP 1




The recommendation for the change interval for the crankshaft damper pulley is 2000 hours maximum. At any time over 1500 hours change the pulley at any engine overhaul or tune-up.

Every 500 hours and during the engine tune-up, visually check the rubber element for areas where the rubber is coming off or cracked. Check the alignment of the marks between the inner and outer units. If the marks move, the damper pulley must be replaced. Go to Step 2 for pulley removal.




#### STEP 2




Loosen the pulley to crankshaft bolt.

**NOTE:** See Section 9260 or 9360 of the Service Manual for hood removal and Section 2255 for radiator and alternator belts removal.

#### STEP 3




Remove the bolt, lockwasher and the retainer washer.


**STEP 4**

Remove the timing pointer.


**IMPORTANT:** Use a puller with bolts to remove the pulley. Do not pull or hit the pulley or the viscous damper. Serious damage to the pulley, damper and the rubber sleeve in the pulley can result.

**STEP 5**


Remove the pulley.

**STEP 6**


Do not lose the pulley retaining key.

**STEP 7**

Leave the puller on the pulley and put the puller in a vise. Loosen the bolts that hold the damper (if equipped) to the pulley.


**STEP 8**

Remove the bolts and the washers.

**STEP 9**


Remove the damper.

**STEP 10**




Fasten the puller to the front side of a new pulley and put the puller in a vise.

**STEP 13**




Tighten the bolts to a torque of 110 to 132 ft. lbs. (149 to 179 Nm)(14.9 to 17.9 kgm). Remove the puller.

**STEP 11**




Install the damper to the pulley. The flat side of the damper is against the pulley.

**STEP 14**




Replace the key if the key shows damage.

**STEP 12**



Install the bolts and new hardened washers.


**STEP 15**



Install the pulley to the crankshaft. Install the bolt, lockwasher and retaining washer.


**NOTE:** *The hub side of the pulley must be put against the engine. Align the crankshaft key with the slot in the pulley.*

**STEP 16**




Install the timing pointer.

**STEP 17**




Tighten the bolt to a torque of 100 to 110 ft. lbs. (136 to 149 Nm)(13.6 to 14.9 kgm).



## Checking Top Dead Center


**IMPORTANT:** Before checking top dead center, check the alignment marks on the pulley, see Step 1.

### STEP 18




Remove the breather tube.

### STEP 19




Remove the nuts, washers and rubber gaskets from the front valve cover.

### STEP 20



Remove the front valve cover.

### STEP 21



Turn the engine over until the Top Dead Center mark on the crankshaft pulley is aligned with the timing pointer.



**Suggest:**


**If the above button click is invalid.**

**Please download this document**


**first, and then click the above link**

**to download the complete manual.**


**Thank you so much for reading**

**STEP 22**

Remove the rocker arm retaining studs, nuts and washers.

**STEP 23**


Remove the rocker arm assembly.

**STEP 24**


Remove the leak off line from the Number One fuel injection nozzle to the fuel pump. Loosen the leak off line between the Number One and the Number Two fuel injection nozzles.

**NOTE:** Removal of fuel lines will prevent damage to the lines when removing the exhaust valve spring.


Rac 8-20120

**STEP 25**

Loosen the Number One nozzle fuel line.

**STEP 26**

Loosen the retaining nut of the Number One nozzle using a 7/8" crow's foot wrench (Snap-On Tool Part Number AN-8508-14, flared nut type or AN-8506-8, open end type) with an extension and ratchet wrench.

**STEP 27**

Remove the leak off line and turn the fuel injector nozzle towards the rear of the engine. Remove the Number One cylinder exhaust push rod.

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**