

7200 Pro and 8900 Series Tractor Service Manual No. 7-67882 Table of Contents

Description	Section No.	Form No.
General	Tab 1	
General Information	1001	7-85710
Fuel Systems	Tab 3	
Fuel System Specifications	3001	7-87430
Fuel Tank	3004	7-87440
Electrical	Tab 4	
Wiring Schematics		7-66740
Troubleshooting	4001	7-66720
Alternator	4004	7-86300
Neutral Start Switch	4005	7-85531
Battery Servicing and Testing	4235	7-67360
Steering	Tab 5	
Steering Hand Pump and Steering Column	5001	7-85410
Steering Cylinder-2WD and MFD Tractors	5002	7-85291
Steering Axle and Lines-2WD	5003	8-91841
Power Train	Tab 6	
Tractor Split for Speed Transmission Service	6001	7-67491
Tractor Split for Pinion Shaft or Range Transmission Service	6002	7-67501
MFD Front Axle Removal and Installation	6003	7-68701
Transmission Valve	6004	7-67510
Speed Transmission	6005	7-67521
Range Transmission	6006	7-67531
Hydraulic Pump Drive	6007	7-68711
Rear Frame	6008	7-85671
Rear Axle and Planetaries	6009	7-67541
Single and Dual Shaft PTO	6010	7-67551
MFD Clutch Removal Without Tractor Split	6011	7-67560
MFD Differential	6012	8-91962
MFD Axle and Planetaries	6013	7-67891
Brakes	Tab 7	
Brake Valve	7001	7-85551
Hydraulic Trailer Brake Valve	7002	
Brake Cylinders	7003	7-67571
Pneumatic Trailer Brake Valve	7004	

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

Reprinted

© 1998 Case Corporation
Printed in U.S.A.
April, 1998

Description	Section No.	Form No.
Hydraulics	Tab 8	
Hydraulic Schematics		7-66730
Hydraulic Troubleshooting	8001	7-66710
Manual Shuttle Shift Transmission Testing and Troubleshooting	8002	7-85921
Electrical PTO Valve	8003	7-65430
Priority and Remote Valves	8004	7-87450
Hydraulic Filters	8005	7-60782
MFD solenoid Valve	8006	7-87720
Charge/Lube Dual Gear Pump	8007	7-87460
Hydraulic Piston Pump	8008	7-87470
Electronic Hitch Calibration and Error Codes	8009	7-67870
Tractor Hitch	8010	7-85741
Hitch Valve	8011	7-68761
Hydraulic Couplers	8013	8-95332
Chassis	Tab 9	
Air Conditioning Troubleshooting and System Checks	9001	7-67231
Air Conditioner System Service	9002	7-67241
Air Conditioning System and Compressor	9003	7-67251
Air Conditioning Components	9004	7-67260
Cab Blower	9005	7-87480
Tractor Seat	9006	7-87730
Hood, Grill, Side Panels, Radiator and Support	9007	7-87740
8900 Decal Locations	9008	7-87750
Cab Removal	9009	7-87760
Pedal and Lever Adjustment	9010	7-87770

Section 1001

GENERAL INFORMATION 7200 Pro and 8900 Series Tractors

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
450 Sherman Avenue
Hamilton, ON L8N 4C4 CANADA

Rac 7-85710

© 1998 Case Corporation
Printed in U.S.A.
March, 1998

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

CONVERSION FACTORS








U.S. Customary to SI (Metric) Units

SI (Metric) Units to U.S. Customary

	Multiply	By	To Obtain:	Multiply By	To Obtain
Area:	square foot (ft ²)	0.092 903	square meter (m ²)	10.763 91	square foot (ft ²)
	acre	0.404 686	hectar (ha)	2.471 05	acre
Force:	ounce force (ozf)	0.278 014	newton (N)	3.598 942	ounce force (ozf)
	pound force (16f)	4.448 222	newton (N)	0.224 809	pound force (lbf)
Length:	inch (in)	25.4	millimetre (mm)	0.039 370	inch (in)
	foot (ft)	0.304 8	meter (m)	3.280 804	foot (ft)
	mile	1.609 344	kilometer (km)	0.621 371	mile
Mass:	pound (lb)	0.453 592	kilogram (kg)	2.204 622	pound (lb)
Mass/Area:	ton/acre	2241.702	kilogram per hectare (kg/ha)	0.000 446	ton/acre
Mass/Energy: (Fuel Consumption)	pound per brake horsepower-hour (lb/bhp-h)	608.277 4	gram per kilowatt hour (g/kwh)	0.001 644	pound per brake horsepower-hour (lb/bhp-h)
Mass/Volume: (Density)	pound per cubic yard (lb/yd ³) 0.593276	0.593 276	kilogram per cubic meter (kg/m ³)	1.685 555	pound per cubic yard (lb/yd ³)
Power	horsepower - U.S. customary (hp - U.S. customary)	0.745 700	kilowatt (kw)	1.341 02	horsepower - U.S. customary (hp - U.S. customary)
Pressure	pound per square inch (psi)	6.894 757	kilopascal (kPa)	0.145 038	pound per square inch (psi)
Temperature:	degrees Fahrenheit (°F)	TC=5/9 (TF-32)	degree celsius (°C)	TF=1.8 TC+32	degree Fahrenheit (°F)
Torque:	pound inch (lb in)	0.112 985	newton meter (Nm)	8.850 748	pound inch (lb in)
	pound foot (lb ft)	1.355 818	newton meter (Nm)	0.737 562	pound foot (lb ft)
Velocity (Speed):	miles per hour (mph)	1.609 344	kilometer per hour (km/h)	0.621 371	miles per hour (mph)
Volume:	cubic inch (in ³)	16.387 06	cubic centimeter (cm ³)	0.621 024	cubic inch (in ³)
	cubic foot (ft ³)	0.028 317	cubic meter (m ³)	35.314 66	cubic foot (ft ³)
	cubic yard (yd ³)	0.764 555	cubic meter (m ³)	1.307 950	cubic yard (yd ³)
	ounce-U.S. fluid (oz)	29.573 53	millimeter (ml)	0.033 814	ounce-U.S. fluid (oz)
	quart-U.S. liquid (qt)	.946 353	liter (l)	1.056 688	quart-U.S. liquid (qt)
	quart-Imperial (qt)	1.136 523	liter (l)	0.879 877	quart-Imperial (qt)
	gallon-U.S. liquid (gal)	3.785 412	liter (l)	0.264 172	gallon-U.S. liquid (gal)
	gallon-Imperial (gal)	4.546 092	liter (l)	0.219 969	gallon-Imperial (gal)
Volume/Area:	bushel (U.S.) per acre	0.087 078	cubic meter per hectare (m ³ /ha)	11 484 000	bushel (U.S.) per acre
Volume/Time: (Flow)	gallon per minute (U.S.) (gpm U.S.)	3.785 412	liter per minute (l/m)	0.264 172	gallon per minute (U.S.) (gpm U.S.)
	gallon per minute (Imperial)(gpm Imp.)	4.546 092	liter per minute (l/m)	0.219 969	gallon per minute (Imperial) (gpm Imp.)
Horsepower:	U.S. customary hp	1.014	metric horsepower	0.986.3	U.S. customary hp
	net engine hp	0.815*	P.T.O. observed hp		
	net engine hp	0.70*	max drawbar hp		

SAE FASTENER TORQUE CHART

NOTE: Use these torques, unless special torques are specified. Values are for UNC and UNF thread fasteners, plated or unplated, as received from supplier. Fasteners can be dry or lubricated with normal engine oil. Values do not apply if graphite, moly-disulphide or other extreme pressure lubricant is used.




SAE Grade No.	2				5				8*					
Bolt head identification (See Note 1)														
Bolt Size	LB FT		Nm		LB FT		Nm		LB FT		Nm			
	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.		
1/4	5	6	7	8	9	11	12	15	12	15	16	20		
5/16	10	12	14	16	17	20.5	23	28	24	29	33	39		
3/8	20	23	27	31	35	42	48	57	45	54	61	73		
7/16	30	35	41	47	54	64	73	87	70	84	95	114		
1/2	45	52	61	70	80	96	109	130	110	132	149	179		
9/16	65	75	88	102	110	132	149	179	160	192	217	260		
5/8	95	105	129	142	150	180	203	244	220	264	298	358		
3/4	150	185	203	251	270	324	366	439	380	456	515	618		
7/8	160	200	217	271	400	480	542	651	600	720	814	976		
1	250	300	339	406	580	696	787	944	900	1080	1220	1464		
1-1/8					800	880	1085	1193	1280	1440	1736	1953		
1-1/4					1120	1240	1519	1681	1820	2000	2468	2712		
1-3/8					1460	1680	1980	2278	2380	2720	3227	3688		
1-1/2					1940	2200	2631	2983	3160	3560	4285	4827		

NOTE 1: Bolt head identification marks as per grade. Manufacturing marks will vary.

*Thick nuts must be used with Grade 8 bolts

METRIC FASTENER (ISO) TORQUE CHART

NOTE: Use these torques, unless special torques are specified. Values are for coarse thread fasteners, plated or unplated, as received from supplier. Fasteners can be dry or lubricated with normal engine oil. Values do not apply if graphite, moly-disulphide or other extreme pressure lubricant is used.

ISO Class No.	8.8				10.9				12.9			
Bolt head identification (See Note 1)												
Bolt Size	Nm		LB FT		Nm		LB FT		Nm		LB FT	
	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
M4	3	4	2	3	4	5	3	4				
M5	6.5	8	5	6	9.5	11	7	8				
M6	10.5	12	8	9	15	17.5	11	13				
M8	26	31	19	23	37	43	27	32				
M10	52	61	38	45	73	87	54	64				
M12	90	107	66	79	125	150	93	112				
M14	144	172	106	127	200	245	149	179				
M16	217	271	160	200	310	380	230	280				
M20	434	515	320	380	610	730	450	540				
M24	675	815	500	600	1050	1275	780	940				
M30	1250	1500	920	1100	2000	2400	1470	1770				
M36	2175	2600	1600	1950	3500	4200	2580	3090				

Because of the low ductility of these fasteners, the torque range is to be determined individually for each application. As a general rule, the torque ranges specified for grade 10.9 fasteners can be used satisfactorily on 12.9 fasteners.

*M14 is not a preferred size

NOTE: Bolt head identification marks as per grade. Manufacturing marks will vary.

STANDARD TORQUE DATA FOR HYDRAULIC TUBES AND FITTINGS

TUBE NUTS FOR 37° FLARED FITTINGS							O-RING BOSS PLUGS, ADJUSTABLE FITTING LOCK NUTS, SWIVEL JIC - 37° SEATS				
SIZE	TUBING O.D.		THREAD SIZE	LB FT		Nm		LB FT		Nm	
	Inches	mm		Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
4	1/4	6.4	7/16-20	9	12	12	16	6	10	8	14
5	5/16	7.9	1/2-20	12	15	16	20	10	15	14	20
6	3/8	9.5	9/16-18	21	24	29	33	15	20	20	27
8	1/2	12.7	3/4-18	35	40	47	54	25	30	34	41
10	5/8	15.9	7/8-14	53	58	72	79	35	40	47	54
12	3/4	19.1	1-1/16-12	77	82	104	111	60	70	81	95
14	7/8	22.2	1-3/16-12	90	100	122	136	70	80	95	109
16	1	25.4	1-5/16-12	110	120	149	163	80	90	108	122
20	1-1/4	31.8	1-5/8-12	140	150	190	204	95	115	129	156
24	1-1/2	38.1	1-7/8-12	160	175	217	237	120	140	163	190
32	2	50.8	2-1/2-12	225	240	305	325	250	300	339	407

Above torque figures are recommended for plain, cadmium or zinc plated fittings, dry or wet installations and swivel nuts either swaged or brazed. These torques are not recommended for tubes 1/2 inch (12.7 mm) O.D. and larger with wall thickness of 0.035 inch (0.889 mm) or less. The torque is specified for 0.035 inch (0.889 mm) wall tubes on each application individually.

FLUID CAPACITIES AND TYPES

Engine Crankcase Capacity, without Filter Change	19 Litres (5 Gallons)
with Filter Change	21 Litres (5.5 Gallons)
Fluid Type	Case No. 1 Multi-Viscosity Engine Oil
Transmission/Hydraulic System Capacity	172 Litres (45.5 Gallons)
Fluid Type	Hy-Tran Plus® Fluid

Differential Housing Capacity - MFD	11 Litres (3 Gallons)
Planetary Housing Capacity - MFD (Each).....	0.9 Litres (1 Quart)
Fluid Type	Case 135H EP Gear Lubricant, SAE 85W-140
	Use one pint of Limited Slip additive in the differential

Cooling System Capacity - with Cab	
8910 and 8920 (7210 and 7220 Pro)	27.6 Litres (29 Quarts)
8930 (7230 Pro)	29.4 Litres (31 Quarts)
8940 and 8950 (7240 and 7250 Pro)	31.3 Litres (33 Quarts)
Fluid Type	50 Percent Ethylene Glycol Coolant

Engine Speeds

Governed Engine Speed without Load	2370 to 2530 RPM
Rated Engine Speed	2200 RPM
Engine Idle Speed	925 to 1025 RPM

Fuses

Dome Lamp and Radio Clock.....	5 Amp
Fuel Shut-off	5 Amp
Shut Down Override	15 Amp
Instrument Cluster - Run Position.....	7.5 Amp
Instrument Cluster - Accessory Position, PTO	10 Amp
Radio	5 Amp
Electronic Hitch System.....	7.5 Amp
Cigar Lighter	10 Amp
Ether Starting Aid	15 Amp
Differential Lock.....	10 Amp
Tail Lamps	10 Amp
Warning Lamps	15 Amp
Cab Roof Work Lamps	15 Amp
Air Seat.....	20 Amp
Mechanical Front Drive (If Equipped) (Less 3 Point Hitch).....	7.5 Amp
Mechanical Front Drive (If Equipped) (With 3 Point Hitch)	5 Amp
Creeper Drive (If Equipped).....	7.5 Amp

Bulb and Lamp Replacement

Dome Lamp Bulb.....	K913579
Console Lamp Bulb	No. 194
Flasher Lamp Bulb	No. 1156
Head Lamps	No. H4
Front and Rear Flood Lamps.....	No. H3
Tail Lamp Bulbs	No. 168
Rocker Switch Bulb	No. 3141107R1
Three Point Hitch Indicator Bulb.....	No. 182
Instrument Cluster Illuminating Bulb.....	No. 161

STEERING AND OSCILLATION STOPS


Mechanical Front Drive (MFD)

Tractors with mechanical front drive (MFD) are equipped with steering and oscillation stops. The steering and oscillation stops are used to give the required steering clearance between the front tires

and tractor frame. The front tire size and tread width being used, will determine the required steering and oscillation angles.


Steering Stop

Each adjustment hole in the steering stop (1) is identified with an arrow and a number. With the arrow pointing toward the wheel, the number indicates the turn angle when the mounting pin is installed in that hole. With the pin installed in the desired hole, the angle number will be visible outside the steering knuckle casting. The steering stop can be installed in either direction depending on the tire size and tread width being used.




RP96H043

Standard Steering Stop



RB96H024

Optional Steering Stop




755L93

An optional steering stop is available thru service. This stop allows the use of MFD fenders at a 64 inch tread and can be used to improve turning radius with some MFD tire options.

NOTE: If the steering angle recommended on the steering stop chart is not available on the stop rod that your tractor is equipped with, you should use the next smaller angle.


Oscillation Stop

Oscillation stops (2) are required for some tire size and tread width combinations. The oscillation stops are installed on the axle stop pad on each side of the tractor.



RP96H035

LIMITS OSCILLATION TO 6 DEGREES



RP96H036

ALLOWS 11 DEGREES OF OSCILLATION

Section 3004

FUEL TANK

3004

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
450 Sherman Avenue
Hamilton, ON L8N 4C4 CANADA

Rac 7-87440

© 1998 Case Corporation
Printed in U.S.A.
February, 1998

REPLACING THE MAIN FUEL TANK SENSOR


STEP 1



RD98A059

Remove the two screws and the tail lamp panel from the back of the cab.


STEP 2



RD98A062

Remove the wiring harness from the sensor.

STEP 3




RD98A063

Loosen the hose clamp(s) and remove the fuel tank vent hose(s) from the sensor.

Remove the sensor mounting screws and remove the sensor from the fuel tank.

NOTE: Tractors without auxiliary fuel tanks only have one vent hose attached to the sensor.


STEP 4



T97841

Remove the used sensor gasket from the fuel tank, and install a new sensor gasket.


STEP 5



RD98A063

Install the new sensor in the fuel tank and install the mounting screws through the sensor and gasket and into the fuel tank. Tighten the screws to a torque of 1.1 to 1.3 Nm (10 to 11.5 lb in).

STEP 6




RD98A061

Install the fuel tank vent hose(s) and the wiring harness on the sensor.

NOTE: *Tractors without auxiliary fuel tanks only have one vent hose attached to the sensor.*

STEP 7




RD98A058

Install the tail light panel on the tractor cab.

MAIN FUEL TANK REMOVAL

STEP 8



T97849

Before the main fuel tank can be removed from the tractor, all the fuel must be drained. If the tractor is equipped with an auxiliary fuel tank, drain the fuel from the main fuel tank through the auxiliary fuel tank.


STEP 9



RD98A059

Remove the two screws and the tail lamp panel from the back of the cab.

STEP 10




RD98A063

Remove the wiring harness and the fuel tank vent hose(s) from the sensor.

NOTE: *Tractors without auxiliary fuel tanks only have one vent hose attached to sensor.*


STEP 11



T97850

Loosen the hose clamp and remove the fuel inlet hose from the fuel tank.


STEP 12




T97852

Loosen the mounting screws for the fuel tank inlet. Twist the inlet in a counterclockwise direction and remove from the fuel tank.

STEP 13




RD98A064



RD98A067

Remove the rear assist handle and the right and left remote hitch switch housing (if equipped).


STEP 14



RD98A065


Remove the 7 pin electrical outlet from the fuel tank support.

STEP 15




T97855

Remove the four mounting nuts and bolts from the fuel tank support.

STEP 16

A10869

On single tank tractors, close the fuel shutoff valve under the main fuel tank and disconnect the fuel supply hose from the shutoff valve. On tractors with auxiliary fuel tanks, disconnect the auxiliary supply hose at the same location.


STEP 17

A10862

Use a sling and a hoist under the fuel tank support to lift the fuel tank out of position and over the transmission fill tube.


MAIN FUEL TANK INSTALLATION

STEP 18




Use a sling and a hoist to put the fuel tank into position on the tractor.

STEP 19




Install and tighten the fuel tank mounting bolts.

STEP 20



On single tank tractors, connect the fuel supply hose to the shutoff valve on the main fuel tank. Open the fuel shutoff valve. On tractors with a auxiliary fuel tank, connect the auxiliary supply hose at the same location.


STEP 21




Install the fuel tank vent hose(s) and the wiring harness on the fuel level sensor.

NOTE: Tractors without auxiliary fuel tanks only have one vent hose attached to sensor.

STEP 22




Install the tail lamp panel on the back of the cab.

STEP 23

RD98A065

Install the 7 pin electrical outlet on the fuel tank support.

STEP 24


RD98A064

Install the right and left remote hitch switch housing (if equipped) and install the rear assist handle.

STEP 25


T97962

Install a new o-ring on the fuel tank inlet.

STEP 26

T97852

Insert the fuel tank inlet into the fuel tank. Twist the inlet in a clockwise position. Tighten the mounting screws to a torque of 2.8 to 3.4 Nm (25 to 30 lb in). Tighten the mounting screws that are opposite of each other.

STEP 27


T97850

Install the fuel inlet hose on the fuel tank inlet. Tighten the hose clamps.

AUXILIARY FUEL TANK REMOVAL

NOTE: Two auxiliary tank sizes are available on the 8900 series tractor. The procedures are the same unless noted otherwise.

STEP 28




T94827

Remove the batteries from the tractor. Remove the battery box and cab steps as an assembly.

NOTE: The left hand rear wheel may be moved out on the axle instead of removing the batteries and steps. Refer to the Operators Manual for procedure.


STEP 29



T94453

Use the special tool clamp to close the fuel hose between the main fuel tank and the auxiliary fuel tank. If the auxiliary fuel tank is full, use the auxiliary fuel tank drain to remove some fuel. Loosen the fuel hose clamp on the auxiliary fuel tank.


STEP 30



RD98A068

Close the fuel shutoff valve and disconnect the fuel line, wiring harness, return line and vent line from the auxiliary fuel tank.


STEP 31



T94829

Put a floor jack under the auxiliary fuel tank support and remove the support mounting bolts.


STEP 32



RH98B034

If equipped with the extended auxiliary fuel tank, remove the rear mounting bracket bolts.


STEP 33



T94830

Remove the auxiliary fuel tank and support from the tractor.

REPLACING THE AUXILIARY FUEL TANK SENSOR



1. FUEL SHUTOFF VALVE
2. AUXILIARY FUEL TANK SENSOR

3. FUEL TANK SENSOR GASKET

RH98B002

1. Remove the fuel shutoff valve (1) from the auxiliary fuel tank sensor (2).
2. Remove the mounting screws and the auxiliary fuel tank sensor (2) from the tank.
3. Install new fuel tank sensor gasket (3).
4. Install new auxiliary fuel tank sensor (2) into tank and make sure that the float wire is not bent during installation. Secure with mounting bolts and tighten to a torque of 1.1 to 1.3 Nm (10 to 11.5 lb in).
5. Install fuel shutoff valve (1) on auxiliary fuel tank sensor (2).

AUXILIARY FUEL TANK INSTALLATION


STEP 34



T94830

Install the auxiliary fuel tank and support on the transmission housing.


STEP 35



T94829

Install and tighten the auxiliary fuel tank mounting bolts.


STEP 36



RH98B034


If equipped with the extended auxiliary fuel tank, install and tighten the rear mounting bracket bolts.

STEP 37




RD98A068

Connect the fuel line, return line and the vent line to the fuel level sensor. Connect the fuel sensor wiring harness to the main harness. Open the fuel shutoff valve and tighten all hose clamps on the sensor.

STEP 38

T94453

Install the fuel hose from the main fuel tank to the auxiliary fuel tank. Tighten the fuel hose clamp. Remove the special tool clamp.


STEP 39

T94827

Install the battery box and cab steps on the transmission housing. Tighten the mounting bolts to a torque of 54 to 61 Nm (40 to 45 lb ft) and the mounting nuts to a torque of 94 to 106 Nm (69 to 78 lb ft).

NOTE: *If the left hand rear wheel was moved out on the axle, slide the wheel to the original position and torque the wheel nuts according to the Operators Manual.*

SPECIAL TOOLS




Electrical Connector and Terminal Repair Kit AJ11400004.
See the Parts Merchandiser Catalog for ordering information
and identification of components.



Digital Multimeter CAS-1559.

NOTE: Case Corporation reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.


FRONT CONSOLE INSTRUMENTATION AND CONTROLS



- 1. Turn Signals
- 2. Lamp Switch
- 3. Ether Button
- 4. High/Low Lamp Switch
- 5. Instrument Cluster

- 6. Automatic Shutdown Override Switch (NAO)
- 7. Hazard Lamps Switch (EURO)
- 8. Horn Button
- 9. Key Switch
- 10. Tilt Control


OVERHEAD CONSOLE INSTRUMENTATION AND CONTROLS



- 11. Windshield Wiper Control
- 12. Heat Control
- 13. Blower Control


- 14. Air Conditioning Control
- 15. A.C. Pressure Indicator Lamp
- 16. Radio

SIDE CONSOLE INSTRUMENTATION AND CONTROLS




- | | |
|---------------------------------|-------------------------------|
| 1. Hitch Up/Down Switch | 9. MFD Switch (If Equipped) |
| 2. Hitch Indicator Lamp | 10. Cigarette Lighter |
| 3. Hitch Lever Mechanical Stop | 11. Slip Limit Control Switch |
| 4. Hitch Position Control Lever | 12. Hitch Diagnostic Monitor |
| 5. Remote Levers | 13. Drop Speed Control |
| 6. PTO Indicator Lamp | 14. Hitch Upper Limit Control |
| 7. PTO Switch | 15. Hitch Travel Control |
| 8. Differential Lock Switch | 16. Hitch Load Control |

SECONDARY ELECTRICAL PANEL - 7200 PRO MODELS ONLY



- | | |
|------------------------------------|--|
| 17. First Trailer Indicator Lamp | 21. Auto Hitch Indicator Lamp |
| 18. Second Trailer Indicator Lamp | 22. Work Lamps Indicator Lamp |
| 19. Park Brake Indicator Lamp | 23. Automatic Shutdown Override Switch |
| 20. Pneumatic Brake Indicator Lamp | 24. Rotating Beacon Switch |

(NAO) - FUSE, RELAY AND CIRCUIT BREAKER IDENTIFICATION



RB96K056

NOTE: To service fuses, relays and circuit breakers remove the cover panel at the front of the side console.

FUSES:


1. Radio/Dome Lamp (5 AMP)
2. Fuel Shutoff (5 AMP)
3. Shut-Down Override (15 AMP)
4. Instrument Cluster Keyed "B+" (7.5 AMP)
5. Instrument Cluster Acc. "B+" / PTO (10 AMP)
6. Radio Keyed Acc. "B+" (5 AMP)
7. Electronic Draft Control Acc. "B+" (7.5 AMP)
8. Cigar Lighter (10 AMP)
9. Ether Start (15 AMP)
10. GPS (10 AMP) w/3pt, Difflock (10 AMP) w/o
11. Tail Lamps (10 AMP)
12. Warning Lamps (15 AMP)
13. Cab Roof Lamps (15 AMP)
14. Seat (20 AMP)
15. MFD/Diff Lock (5 AMP) w/3pt, MFD (7.5A) w/o
16. Creep Drive (7.5 AMP) Optional

RELAYS:

1. Fuel Shutoff and Override
2. Front Field Lamps
3. Rear Field Lamps
4. Optional Field Lamps
5. Diff Lock (w/o 3pt hitch), MFD (w/ 3pt hitch)
6. MFD (w/o 3pt hitch), PTO (w/ 3pt hitch)
7. PTO (w/o 3pt hitch), Not Used (w/ 3pt hitch)

CIRCUIT BREAKERS:

1. Headlamps (20 AMP)
2. Work Lamps (30 AMP)
3. Work Lamps (20 AMP)
4. Implement "B+" (30 AMP)
5. Implement Keyed "B+" (30 AMP)
6. Blower Keyed "B+" (30 AMP)
7. Wipers (15 AMP)

(EURO) - FUSE, RELAY AND CIRCUIT BREAKER IDENTIFICATION

RB96K056

NOTE: To service fuses, relays and circuit breakers remove the cover panel at the front of the side console.

FUSES:

1. Radio/Dome Lamp (5 AMP)
2. Ether Start (15 AMP)
3. GPS (10 AMP)
4. Instrument Cluster Keyed "B+" (7.5 AMP)
5. Instrument Cluster Acc. "B+" / PTO (10 AMP)
6. Radio Keyed Acc. "B+" (5 AMP)
7. Electronic Draft Control Acc. "B+" (7.5 AMP)
8. Cigar Lighter (10 AMP)
9. RH Tail / Position Lamp (10 AMP)
10. LH Tail / Position Lamp (10 AMP)
11. Stop and Beacon Lamps (15 AMP)
12. Warning Lamps (15 AMP)
13. Cab Roof Lamps (15 AMP)
14. Cab Lower Work Lamps (15 AMP)
15. Seat / Air Brakes (20 AMP)
16. Creep Drive, 4WD and Diff Lock (5 AMP)


RELAYS:

1. Fuel Shutoff and Override
2. Front Field Lamps
3. Rear Field Lamps
4. Stop Lamps
5. 4WD
6. PTO

CIRCUIT BREAKERS:

1. Headlamps RH (10 AMP)
2. Headlamps LH (10 AMP)
3. Work Lamps (40 AMP)
4. Implement "B+" (30 AMP)
5. Implement Keyed "B+" (30 AMP)
6. Blower Keyed "B+" (30 AMP)
7. Wipers (15 AMP)

TRANSMISSION HARNESS Top View



RB96K008

- | | |
|--|---|
| 1. To RH Lower Light | 10. To LH Draft Pin Sensor |
| 2. Hydraulic Filter Restriction Switch | 11. MFD Solenoid Valve |
| 3. Hydraulic Fluid Temperature Sender | 12. Transmission Lube Pressure Switch |
| 4. To Cab - Connector No.4 | 13. Hitch Lower Solenoid |
| 5. PFC Pressure Switch | 14. Hitch Raise Solenoid |
| 6. Engine Speed Transducer (RPM) | 15. Ground Speed Transducer |
| 7. E.D.C Harness Connector No.86 | 16. Differential Lock Solenoid |
| 8. E.D.C Harness | 17. Transmission System Pressure Switch |
| 9. To E.D.C Rockshaft Arm Position Pot | 18. PTO Solenoid |



Suggest:

If the above button click is invalid.


Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading

TRANSMISSION HARNESS Side View



RB96N026

- | | |
|---------------------------------------|--|
| 1. Negative (-) Battery Cables | 6. To Cranking Motor Relay |
| 2. To Battery Clean Ground | 7. Ground |
| 3. To Left Hand Lower Lights | 8. Transmission System Pressure Switch |
| 4. Creep Solenoid Valve (If Equipped) | 9. Transmission Lube Pressure |
| 5. Neutral Start Switch | 10. MFD Solenoid Valve |

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>