

W11 ARTICULATED LOADER TABLE OF CONTENTS AND SERVICE MANUAL INTRODUCTION

Table of Contents

SERIES/SECTION	SECTION NO.	FORM NO.
10 SERIES - GENERAL		
General Engine Specifications	1010	9-46091
Decals and Repainting	1012	9-67531
Detailed Engine Specifications	1026	9-78685
Maintenance and Lubrication	1050	9-67531
Torque Charts	1051	9-67531
20 SERIES - ENGINE		
Engine Diagnosis	2001	9-78875
Engine Tune-up	2002	9-78825
Cylinder Head, Valve Train and Camshaft	2015	9-78836
Crankshaft, Bearings, Flywheel and Oil Seals	2035	9-78866
Oil Pump	2045	9-78885
Stall Tests, Engine Removal and Installation and Radiator	2050	9-67531
Air Cleaner and Mufflers	2051	9-67531
Ether Injection	2053	9-67531
Cooling System	2055	9-78816
Cylinder Block, Sleeves, Pistons and Rods	2125	9-78845
Engine Lubrication	2555	9-78985
30 SERIES - FUEL SYSTEM		
Fuel Filters	3010	9-78785
Fuel Injection Pump	3012	9-78795
Fuel Injectors	3013	9-78806
Engine Controls, Fuel Lines and Fuel Tank	3052	9-67531
Electric Fuel Pump	3053	9-67531
40 SERIES - ELECTRICAL SYSTEM		
Electrical System Specifications and Trouble Shooting	4002	9-67532
Wiring Diagrams	4003	9-67531
Indicators and Gauges	4004	9-67531
Battery	4005	9-67531
Starter	4006	9-67531
Alternator	4007	9-67531
Electrical Accessories	4015	9-67531
50 SERIES - STEERING SYSTEM		
Hydraulic Diagram, Pressure Check and Trouble Shooting	5002	9-67532
Steering Control Valve	5007	9-67531
Steering Cylinder	5010	9-67531
Center Pivot	5023	9-67531

60	SERIES - POWER TRAIN		
	Transmission Maintenance and Trouble Shooting	6102	9-67531
	Charging Pump	6105	9-67531
	Transmission Control Valve	6107	9-67531
	Torque Converter	6110	9-67531
	Transmission	6116	9-67531
	Transmission Controls	6118	9-67531
	Drive Shafts, Center Bearing and Universal Joints	6120	9-67531
	Rear Axle Trunnion	6125	9-67531
	Front and Rear Axle	6126	9-67532
	Wheels and Tires	6129	9-67532
70	SERIES - BRAKES		
	Brake System Operation, Brake Actuator and Brake Pedal Adjustment	7106	9-67532
	Brakes	7121	9-67532
	Parking Brake	7127	9-67531
80	SERIES - HYDRAULIC SYSTEM		
	Hydraulic Diagram, Maintenance, Trouble Shooting and Pressure Checks	8002	9-67532
	Hydraulic Pump	8005	9-67531
	Flow Control Valve	8006	9-67531
	Loader Control Valve	8007	9-67531
	Unloader Valve	8009	9-67531
	Cylinders	8090	9-67531
90	SERIES - MOUNTED EQUIPMENT		
	Loader	9010	9-67531
	ROPS Cab and ROPS Canopy	9061	9-67531

Service Manual Introduction



This Symbol Shows Important Information About Safety In This Manual. When You See This Symbol, Carefully Read The Information That Follows and Understand The Possible Causes of Injury Or Death. 1-1-A

Safety Rules

It is recommended that the warning tag shown in figure 1 be put on the key for the key switch when a person is working on the machine. A warning tag comes with the machine. Additional warning tags, part number 331-4614, are available from Service Parts Supply.




Figure 1



WARNING: Read operator's manual to familiarize yourself with control lever functions.

46-27



WARNING: Operate controls from the operator's seat only.

35-7



WARNING: When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.

35-4



WARNING: When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure. 47-44



WARNING: When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way. 47-45



WARNING: Whenever the bucket must be raised to aid in servicing, block the loader arms in place with lift cylinder safety strut or a suitable safety stand. 23-7-A



WARNING: This is a one man machine, no riders allowed. 35-8



CAUTION: When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer. 46-17



CAUTION: When using a hammer to remove and install pivot pins or separate parts, using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors). 46-13



CAUTION: When servicing or repairing the machine, keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc. Use an oil absorbing material and/or shop cloths as required. Use safe practices at all times. 40-8



CAUTION: Use suitable floor (service) jacks or chain hoists to raise wheels off the floor. Always block machine in place with suitable safety stands. 40-7

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>



CAUTION: *Pin sized and smaller streams of hydraulic oil under pressure can penetrate the skin and result in serious infection. If hydraulic oil under pressure does penetrate the skin, seek medical treatment immediately. Maintain all hoses and tubes in good condition. Make sure all connections are tight. Make a replacement of any tube or hose that is damaged or thought to be damaged. DO NOT use your hand to check for leaks; use a piece of cardboard or wood.* 40-6-A



CAUTION: *Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in this service manual.* 40-10

General Information

This service manual has been prepared with the latest service information available. Troubleshooting, removal, disassembly, inspection and installation procedures and complete specifications and tightening references can be found in most sections. Some sections will have drawings without a written procedure because the job is easily done. This service manual is one of the most important tools available to the service technician.

The terms right-hand and left-hand and front and rear as used in this manual indicate the right and left sides, and front and rear of the machine as seen from the operator's seat for correct operation of the machine or attachment.

Text

If the service manual is for more than one machine or different models of components (planetary axles, gear boxes, control valves, etc.) the procedures will have steps that are for a specific component.

Table of Contents

The first two pages of this section are a Table of Contents which show the series number and title, and the sections that are in each series. The individual sections, where necessary, will have a Table of Contents on the second page of that section.

Page Numbers

All page numbers are made of two sets of numbers separated by a dash, such as 4002-9. The numbers before the dash are the section numbers. The numbers following the dash are the page numbers in that section. Page numbers will be found at the up-

per right or left of each page.

Illustrations

Illustrations are put as near as possible to the test and are to be used as a part of the text.

Torque References

Most of the time two grades of fasteners (bolts, nuts and screws) are used on Case machines. The grades of the fasteners are grade 5 and grade 8. See Section 1051 for torque specifications and identification marks.

The specifications in Section 1051 are standard torque values and are to be used on all fasteners during assembly and installation unless special torque values are shown in a section.

Product Identification Number, Serial Number and Model Number

When replacement parts are needed, it can be necessary to give the parts department one or all of the numbers. The model number is normally found on the Product Identification Number plate or the Serial Number plate.

The Product Identification Number and Serial Numbers will be found in the following locations.

Machine - Product Identification Number plate fastened to the instrument panel.

Engine - Serial Number plate on the right-hand side of the engine above the starter.

Other component parts - Serial Number plate on the part or the serial number is stamped in the part.

NOTE: A Part Number plate will be found on some parts.

Classification of Lubricants

The Society of Automotive Engineers (SAE), the American Petroleum Institute (API), and the National Lubricating Grease Institute (NLGI) put oil and grease in classifications and grades according to temperature and use.

Engine Oil

The SAE number is the viscosity of engine oils, for example, SAE 30 is a single viscosity oil. SAE 10W30 is a variable viscosity oil.

The API classification (SD, CD, etc.) is the oil performance according to the application of the engine. Only oil specified in Section 1050 is to be used. These oils have the needed additives to give maximum engine protection. Both the SAE grade and API classification must be found on the container.

Gear Lubricant and Grease

Gear lubricant and grease for each application is specified in Section 1050.

Special Tools

There are some special tools that are needed to remove and install, disassemble and assemble,

check and adjust the component parts of this machine. Some special tools are easily made locally and the necessary information to make the tool is in this service manual. Other special tools are more difficult to make locally and available from Service Tools in the U.S. and from Jobborn Manufacturing in Canada. Use these tools according to the instructions in this service manual for your personal safety and to do the job correctly.

Special tools are no longer available from Case Service Parts Supply. Special tools are available from:

Service Tools
P.O. Box 314
Owatonna, Minnesota 55060

Jobborn Manufacturing Co.
97 Frid Street
Hamilton, Ontario L8P 4M3
Canada

Section 1010

GENERAL ENGINE SPECIFICATIONS

W11 Loader

Written In *Clear
And
Simple
English*

DIESEL ENGINES

General

Type	Case Open Chamber, 4 Cylinder, 4 Stroke Cycle, Valve-in-Head
Firing Order	1-3-4-2
Bore	4 Inches (101.6mm)
Stroke	4-1/8 Inches (104.8mm)
Piston Displacement	207 Cubic Inches (3 391.1 cm ³)
Compression Ratio	16.5 to 1
No Load Governed Speed	2285 to 2315 RPM
Rated Engine Speed	2100 RPM
Engine Idling Speed	700 to 750 RPM
Valve Tappet Clearance (Exhaust)	(Cold) .014 Inch (0.356mm)
(Intake)	(Cold) .012 Inch (0.305mm)

Piston and Connecting Rods

Rings per Piston	3
Number of Compression Rings	2
Number of Oil Rings	1
Type Pins	Full Floating Type
Type Bearing	Replaceable Precision, Steel Back, Copper-Lead or Aluminum Alloy Liners

Main Bearings

Number of Bearings	5
Type Bearings	Replaceable Precision Steel Back, Copper-Lead or Aluminum Alloy Liners

Engine Lubricating System

Crankcase Capacity (Without Filter)	5 US Quarts (4.7 litres)
(With Filter Change)	6 US Quarts (5.7 litres)
Oil Pressure	50 to 70 PSI (345 to 483 kPa) with Engine Warm and Operating at Rated Engine Speed
Type System	Pressure and Spray Circulation
Oil Pump	Gear Type
Oil Filter	Full Flow Spin on Type

Fuel System

Fuel Injection Pump	Roosa-Master
Pump Timing	0° Degrees Before Top Dead Center
Fuel Injectors	Pencil Type, Opening Pressure 2800 PSI (19 306 kPa)
Fuel Transfer Pump	Vane Type, Integral Part of Injection Pump
Governor	Variable Speed, Fly-Weight Centrifugal Type, Integral Part of Injection Pump
Fuel Filters	Full Flow Spin on Type

Section 1012

DECALS AND PAINTING

Written In *Clear
And
Simple
English*


GENERAL INFORMATION

1. All decals about operation of the machine and/or attachments must be in a condition so that you can read the decals easily. Replace any decal that has damage or can not be read.
2. All decals that start with the words WARNING, CAUTION, or DANGER must be in a condition so that you can read the decals easily. Replace any decal that has damage or cannot be read.
3. When you paint the machine or attachment, put covers over the good decals and remove the decals which have damage or can not be read easily. Use enamel thinner to make the decal easier to remove.
4. Remove the old decal before you install a new decal. Use enamel thinner to make the old decal easier to remove.
5. When you paint the machine or attachment, use standard procedure. Remove the grease, wash the area, use sandpaper to prepare the surface for paint, and put covers over all good decals and parts which you do not want to paint.
6. The following pages show decals installed on the machine or attachments. Part numbers of the decals are shown also. Check the parts catalog to make sure that the part number is correct before you make an order for the decals. Decals are available separately or in a kit for the machine.




1. 321-5031

Figure 1




1. 321-3919

Figure 4



1. 321-4228

Figure 2



1. 321-1980


2. 321-3205

Figure 5




1. 321-4228

Figure 3



1. 321-3205

Figure 6



1. 321-5033

Figure 7




1. 321-5032

Figure 8




1. 321-5031

Figure 9



1. 321-4126

Figure 10



1. 321-3596. See Figure 12 For Decal.

Figure 11



1. 321-3596. See Figure 11 For Location.

Figure 12



1. 321-3596


Figure 13



1. 321-3705
2. 321-3060


NOTE: These Decals Are Also Used On Machines With ROPS Canopy. For Machine With ROPS Canopy, Decals Are On Left Side Of Front Chassis.

Figure 16




1. 321-3061
2. 321-4380. See Figure 15 For Decal.

Figure 14




1. 321-4380. See Figure 14 For Location.

Figure 15




1. 321-3927

Figure 17




1. 321-3922

Figure 18




- 1. 321-3921
- 2. 321-4921
- 3. 321-4691
- 4. 321-3923

Figure 19



- 1. 321-4498. See Figure 23 For Decal.


Figure 22



780751


- 1. 321-4498. See Figure 22 For Location.

Figure 23



- 1. 321-4278
- 2. 321-4922

Figure 20



- 1. 321-4478
- 2. 321-4477
- 3. 321-4475
- 4. 321-4476
- 5. 321-2785

Figure 21



- 1. D82934

Figure 24

Section

1026

DETAILED SPECIFICATIONS

207 Diesel Engines

FRACTION to DECIMAL to MILLIMETER CONVERSION TABLE

Fraction	Decimal	MM	Fraction	Decimal	MM	Fraction	Decimal	MM
1/64	.0156	0.397	23/64	.3593	9.128	45/64	.7031	17.859
1/32	.0312	0.794	3/8	.3750	9.525	23/32	.7187	18.256
3/64	.0468	1.191	25/64	.3906	9.922	47/64	.7343	18.653
1/16	.0625	1.587	13/32	.4062	10.319	3/4	.7500	19.050
5/64	.0781	1.984	27/64	.4218	10.716	49/64	.7656	19.447
3/32	.0937	2.381	7/16	.4375	11.113	25/32	.7812	19.844
7/64	.1093	2.778	29/64	.4531	11.509	51/64	.7968	20.240
1/8	.1250	3.175	15/32	.4687	11.906	13/16	.8125	20.637
9/64	.1406	3.572	31/64	.4843	12.303	53/64	.8281	21.034
5/32	.1562	3.969	1/2	.5000	12.700	27/32	.8437	21.431
11/64	.1718	4.366	33/64	.5156	13.097	55/64	.8593	21.828
3/16	.1875	4.762	17/32	.5312	13.494	7/8	.8750	22.225
13/64	.2031	5.159	35/64	.5468	13.890	57/64	.8906	22.622
7/32	.2187	5.556	9/16	.5625	14.287	29/32	.9062	23.019
15/64	.2343	5.953	37/64	.5781	14.684	59/64	.9218	23.415
1/4	.2500	6.350	19/32	.5937	15.081	15/16	.9375	23.812
17/64	.2656	6.747	39/64	.6093	15.478	61/64	.9531	24.209
9/32	.2812	7.144	5/8	.6250	15.875	31/32	.9687	24.606
19/64	.2968	7.541	41/64	.6406	16.272	63/64	.9843	25.003
5/16	.3125	7.937	21/32	.6562	16.669	1	1.0000	25.400
21/64	.3281	8.334	43/64	.6718	17.065			
11/32	.3437	8.731	11/16	.6875	17.462			

INCH to MILLIMETER CONVERSION TABLE


Inch	MM	Inch	MM	Inch	MM	Inch	MM
1	25.400	6	152.000	10	254.000	60	1,524.000
2	50.800	7	177.800	20	508.000	70	1,778.000
3	76.200	8	203.200	30	762.000	80	2,032.000
4	101.600	9	228.600	40	1,016.000	90	2,286.000
5	127.000	10	254.000	50	1,270.000	100	2,540.000

TABLE OF CONTENTS


RUN-IN INSTRUCTIONS	3,4
DETAILED ENGINE SPECIFICATIONS	5-10
Cylinder Sleeves	5
Piston	5
Piston Rings	5,6
Piston Pin	6
Connecting Rod	6
Crankshaft	6,7
Camshaft	7
Valve Push Rod Lifters	7
Gear Train	8
Oil Pump	8
Cylinder Head	8
Intake Valve	8
Exhaust Valve	9
Intake and Exhaust Valve Guides	9
Valve Spring	9
Rocker Arm Assembly	10
SPECIAL TORQUES	10
GENERAL TORQUE SPECIFICATION TABLE	11

INSTALLATION INSTRUCTIONS FOR M20611 TEFLON VALVE SEAL KIT


Special Tools Required



M20624 SEAL INSTALLATION TOOL




M20615 VALVE GUIDE CUTTING TOOL




VALVE SPRING COMPRESSOR

STEP 1




Remove the cylinder head from the engine block. Refer to section 2015 for head removal. **NOTE:** This cylinder head requires two M20611 Kits.

STEP 2




Place cylinder head on work bench.

STEP 3




Install a valve spring compressor.

STEP 4




Compress valve spring and remove valve keepers. **IMPORTANT:** Valves and valve keepers should be marked when removed to insure that they will be reinstated in their original location.

STEP 5




Remove spring retainer.

STEP 8




Remove valve stem seal.

STEP 6




Remove spring.

STEP 9




Remove valve.

STEP 7




Remove spring seat.

STEP 10



Remove all the valve assemblies.

STEP 11





Wash, clean and inspect head. Use a rotary brush to clean around and down into valve ports. Refer to Section 2015 for complete head reconditioning.

STEP 12




Clean valves with a fine power drive wire brush, removing all carbon and varnish deposits. Be careful not to scratch valve stems. Refer to Section 2015 for valve inspection.

STEP 13




Check valve guide top surface. There must be a minimum of a 1/16" wide flat around entire top surface.

STEP 14




Use M20615 tool in a electric drill (if required) to provide necessary flat area on valve guide. **IMPORTANT:** Do not exceed 450 RPM drill speed when using valve guide cutting tool.

STEP 15




Dip valve stems into HDM #30 oil before assembly in cylinder head.

STEP 16




Install spring seat.

STEP 17




Place plastic installation cap, provided in kit, on the end of the valve stem. **NOTE:** Cap prevents sharp edges on valve stem grooves from cutting valve seal.

STEP 18




Carefully start valve seal on cap and hold thumb against white seal insert to avoid dislodging it. Push seal down until seal jacket touches top of valve guide.

STEP 19




Remove installation cap and save, since it must be reused.

STEP 20




Use M20624 tool and press seal down over valve guide until seal is flush with top of guide.

STEP 21





Valve seal installed.

STEP 23




Install valve spring compressor.

STEP 22




Install spring (damping coil end down) and spring retainer.

STEP 24



Install stem seal in lower valve stem groove.

STEP 25



Install valve keepers in outer valve stem groove.



Suggest:

If the above button click is invalid.


Please download this document

first, and then click the above link

to download the complete manual.


Thank you so much for reading

STEP 26




Remove spring compressor and tap valve stem end to seat keepers.

STEP 28



Install cylinder head on engine block following procedure outlined in Section 2015.

STEP 27



Install teflon seals on the other intake and exhaust valves, following the preceding procedure.

NOTE: The Case Corporation reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>