



# Service Repair Manual

## **Models**

311D LRR Excavator

---

Previous Screen

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

**Disassembly and Assembly  
C4.2 Engine for Caterpillar Built Machines**

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02767800

## Inlet and Exhaust Valves - Remove and Install

SMCS - 1105-010

### Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	8S-6691	Cylinder Head Repair Stand	1
B	9U-6195	Valve Spring Compressor Gp	1
C	5P-1720	Seal Pick	1

**Start By:**

- A. Remove the cylinder head. Refer to Disassembly and Assembly, "Cylinder Head - Remove".

---

**NOTICE**

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

**Note:** Note the location and orientation of all components for assembly purposes.

1. Clean the bottom face of the cylinder head. Check the depth of the valves below the face of the cylinder head before the valve springs are removed. Refer to Specifications, "Cylinder Head Valves" for the correct dimensions.

2. Place a temporary identification mark on the heads of the valves in order to identify the correct position.




Illustration 1

g01376164

Typical Example

3. Use a suitable lifting device in order to position cylinder head (1) onto Tooling (A) with the valve springs upward. The weight of cylinder head (1) is approximately 70 kg (155 lb).

**Note:** Ensure that cylinder head (1) is kept on a clean, soft surface in order to prevent damage to the machined face.




Illustration 2

g01376174

---

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**




Illustration 3

g01376184

## **WARNING**

**Personal injury can result from being struck by parts propelled by a released spring force.**

**Make sure to wear all necessary protective equipment.**

**Follow the recommended procedure and use all recommended tooling to release the spring force.**

- 
4. Install Tooling (B) on cylinder head (1) in order to compress valve spring (5) .

---

## **NOTICE**

**Ensure that the valve spring is compressed squarely or damage to the valve stem may occur.**

---

5. Apply sufficient pressure to Tooling (B) in order to remove valve keepers (3). Do not compress the spring so that valve spring retainer (4) touches valve stem seal (6) .
6. Slowly release the pressure on Tooling (B) .
7. Remove valve spring retainer (4). Remove valve spring (5). Remove valve (2) .
8. Use Tooling (C) in order to remove valve stem seal (6) .

9. Repeat Steps 4 through 7 for the remaining valves.

## Installation Procedure

Table 2

Required Tools			
Tool	Part Number	Part Description	Qty
A	8S-6691	Cylinder Head Repair Stand	1
B	9U-6195	Valve Spring Compressor Gp	1
D	312-8755	Valve Stem Seal Installer	1

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

1. Clean all components of the cylinder head assembly. Ensure that all ports, all coolant passages and all lubrication passages in the cylinder head are free from debris. Follow Steps 1.a through 1.d in order to inspect the components of the cylinder head assembly. Replace any components that are worn or damaged.
    - a. Inspect the cylinder head for wear and for damage. Refer to Testing and Adjusting, "Cylinder Head Inspect".
    - b. Inspect the valve seats for wear and for damage. Refer to Specifications, "Cylinder Head Valves" for further information.
    - c. Inspect the valve guides for wear and for damage. Refer to Specifications, "Cylinder Head Valves" and Testing and Adjusting, "Valve Guide - Inspect" for further information.
    - d. Inspect the valves for wear and for damage. Refer to Specifications, "Cylinder Head Valves".
    - e. Inspect valve springs (5) for damage and for the correct length. Refer to Specifications, "Cylinder Head Valves".
-




Illustration 4

g01376184




Illustration 5

g01376926

 **WARNING**

**Improper assembly of parts that are spring loaded can cause bodily injury.**

**To prevent possible injury, follow the established assembly procedure and wear protective equipment.**

2. Lubricate the stem of valve (2) with clean engine oil. Install valve (2) in the appropriate position in the cylinder head. Check the depth of valve (2) below the face of the cylinder head. Refer to Testing and Adjusting, "Valve Depth - Inspect" for more information.

3. The outer face of the valve guides must be clean and dry before installing the valve stem seal (6). Use Tooling (C) in order to install new valve stem seal (6) onto the valve guide.
4. Install valve spring (5) onto the cylinder head. Position valve spring retainer (4) on valve spring (5) .
5. Install Tooling (B) in the appropriate position on cylinder head (1) in order to compress valve spring (5) .



**Improper assembly of parts that are spring loaded can cause bodily injury.**

**To prevent possible injury, follow the established assembly procedure and wear protective equipment.**

- 
6. Apply sufficient pressure to Tooling (B) in order to install valve keepers (3). Do not compress spring (5) so that valve spring retainer (4) touches valve stem seal (6) .
  7. Carefully release the pressure on Tooling (B) .
  8. Repeat Steps 2 through 7 for the remaining valves.

**End By:** Install the cylinder head. Refer to Disassembly and Assembly, "Cylinder Head - Install".

Previous Screen

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

**Disassembly and Assembly  
C4.2 Engine for Caterpillar Built Machines**

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i04625005

## Inlet and Exhaust Valve Guides - Remove and Install

SMCS - 1104-010

### Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	384-8861	Valve Guide Remover	1
B	138-7573	Link Bracket	4
C	1U-9200	Lever Puller Hoist	1
D	8S-6691	Cylinder Head Repair Stand	1

**Start By:**

- A. Remove the inlet and exhaust valves. Refer to Disassembly and Assembly, "Inlet and Exhaust Valves - Remove and Install".
- B. Remove the electronic unit injectors. Refer to Disassembly and Assembly, "Electronic Unit Injector - Remove".

---

**NOTICE**

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---



---

## NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.

Dispose of all fluids according to local regulations and mandates.

---

**Note:** Refer to Special Instructions, SMHS7953-00, "Use of Valve Seat Insert Puller Group" to aid with the removal of the inlet and exhaust valve seats.




Illustration 1

g01377064

Typical Example

1. Attach Tooling (B) , Tooling (C) , and a suitable lifting device to cylinder head (1) . Use Tooling (B) , Tooling (C) , and the suitable lifting device in order to turn over cylinder head (1) by 180° onto Tooling (D) .
-




Illustration 2

g01377121

2. Use Tooling (A) in order to remove valve guides (2) (not shown).

## Installation Procedure

Table 2

Required Tools			
Tool	Part Number	Part Description	Qty
E	384-8862	Valve Guide Installer	1

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---




Illustration 3

g01377130

1. Lubricate the outside of valve guides (2) (not shown) with clean engine oil.
2. Use Tooling (E) in order to install new valve guides (2) . Install valve guide (2) so that valve guide (2) protrudes 16.000 mm (0.6299 inch) above Surface (X) of cylinder head (1) .

**End By:**

- a. Install the electronic unit injectors. Refer to Disassembly and Assembly, "Electronic Unit Injector - Install".
- b. Install the inlet and exhaust valves. Refer to Disassembly and Assembly, "Inlet and Exhaust Valves - Remove and Install".

[Previous Screen](#)

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

## Disassembly and Assembly

### C4.2 Engine for Caterpillar Built Machines

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02768108

## Engine Oil Cooler - Remove

SMCS - 1378-011

### Removal Procedure

#### Start By:

- A. Remove the fuel injection pump. Refer to Disassembly and Assembly, "Fuel Injection Pump - Remove".

---

#### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---

#### NOTICE

**Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.**

**Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.**

**Dispose of all fluids according to local regulations and mandates.**

---

1. Drain the coolant into a suitable container for storage or disposal. Refer to Operation and Maintenance Manual, "Cooling System Coolant (ELC) - Change".




Illustration 1

g01384719

2. Remove bolts (1) .
3. Remove bolts (2) and remove engine oil cooler (3). Remove gasket (4) (not shown) from the engine cylinder block.

[Previous Screen](#)

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

## Disassembly and Assembly C4.2 Engine for Caterpillar Built Machines

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02746254

## Engine Oil Cooler - Disassemble

SMCS - 1378-015

### Disassembly Procedure

#### Start By:

- a. Remove the engine oil cooler. Refer to Disassembly and Assembly, "Engine Oil Cooler - Remove".

---

#### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

---

#### NOTICE


**Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.**

**Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.**

**Dispose of all fluids according to local regulations and mandates.**

---

**Note:** Cleanliness is an important factor. Before you begin the disassembly procedure, the exterior of the components should be thoroughly cleaned. This will help to prevent dirt from entering the internal mechanism. Precision components can be damaged by contaminants or by dirt. Perform disassembly procedures on a clean work surface. Keep components covered and protected at all times.



---

Illustration 1

g01375411

1. Remove bolts (9) and the washers. Remove cover (8) and gasket (7).
2. Remove nuts (5) and the washers from engine oil cooler cover (4). Remove nuts (6) and the washers from engine oil cooler cover (4).
3. Remove engine oil cooler core (2) from engine oil cooler cover (4). Remove gaskets (1) and (3).

[Previous Screen](#)

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

## Disassembly and Assembly C4.2 Engine for Caterpillar Built Machines

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02746255

## Engine Oil Cooler - Assemble

SMCS - 1378-016

### Assembly Procedure

---

#### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

**Note:** Cleanliness is an important factor. Before assembly, thoroughly clean all parts in cleaning fluid. Allow the parts to air dry. Do not use wiping cloths or rags to dry parts. Lint may be deposited on the parts which may cause trouble. Inspect all parts. If any parts are worn or damaged, use new parts for replacement. Dirt and other contaminants can damage the precision component. Perform assembly procedures on a clean work surface. Keep components covered and protected at all times.

**Note:** Check the gaskets for damage. Replace the components, if necessary.

---




Illustration 1

g01375411

1. Install gaskets (3) and (1) to engine oil cooler core (2). Position engine oil cooler core (2) to engine oil cooler cover (4).
2. Install the washers and nuts (6). Install the washers and nuts (5).
3. Install gasket (7) and position cover (8). Install the washers and bolts (9).

**End By:**

- a. Install the engine oil cooler. Refer to Disassembly and Assembly, "Engine Oil Cooler - Install".

[Previous Screen](#)

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

## Disassembly and Assembly C4.2 Engine for Caterpillar Built Machines

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02768201

# Engine Oil Cooler - Install

SMCS - 1378-012

## Installation Procedure

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

**Note:** Check the gaskets for wear or for damage. Replace the components, if necessary.




Illustration 1

g01384719

1. Install gasket (4) (not shown). Position engine oil cooler (3) and install bolts (2). Tighten bolts (2) to a torque of  $17 \pm 2$  N·m ( $13 \pm 1$  lb ft).
2. Install bolts (1). Tighten bolts (1) to a torque of  $32 \pm 3$  N·m ( $24 \pm 2$  lb ft).
3. Fill the cooling system with coolant. Refer to Operation and Maintenance Manual, "Cooling System Coolant (ELC) - Change".

**End By:** Install the fuel injection pump. Refer to Disassembly and Assembly, "Fuel Injection Pump - Install".

[Previous Screen](#)

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

## Disassembly and Assembly

### C4.2 Engine for Caterpillar Built Machines

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02768236

## Engine Oil Relief Valve - Remove and Install

SMCS - 1315-010

### Removal Procedure

#### Start By:

- A. Remove the electronic control module. Refer to Disassembly and Assembly, "Electronic Control Module - Remove and Install".

---

#### NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

---



Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

---




Illustration 1

g01384786

1. Remove engine oil relief valve (1). Do not remove bolt (2) .

## Installation Procedure

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

**Note:** Check the O-ring seals, the gaskets, and the seals for wear or for damage. Replace the components, if necessary.




Illustration 2

g01384786

1. Install engine oil relief valve (1). Tighten engine oil relief valve (1) to a torque of  $49 \pm 5$  N·m ( $36 \pm 4$  lb ft). Do not remove bolt (2) .

**End By:** Install the electronic control module. Refer to Disassembly and Assembly, "Electronic Control Module - Remove and Install".

---

[Copyright 1993 - 2020 Caterpillar Inc.](#)

Mon Nov 30 22:13:02 UTC+0800 2020

[All Rights Reserved.](#)

[Private Network For SIS Licensees.](#)

[Previous Screen](#)

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

## Disassembly and Assembly C4.2 Engine for Caterpillar Built Machines

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02751881

# Engine Oil Bypass Valve - Remove and Install

SMCS - 1306-010-BV

## Removal Procedure

### Start By:

- a. Remove the oil pan. Refer to Disassembly and Assembly, "Engine Oil Pan - Remove".

---

### NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---




Illustration 1

g01377713

1. Remove engine oil bypass valve (1). Remove gasket (2) (not shown). Discard gasket (2).

# Installation Procedure

---

## NOTICE

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---




Illustration 2

g01377713

1. Install a new gasket (2) (not shown). Install engine oil bypass valve (1). Tighten engine oil bypass valve (1) to a torque of  $69 \pm 5$  N·m ( $51 \pm 4$  lb ft).

### End By:

- a. Install the oil pan. Refer to Disassembly and Assembly, "Engine Oil Pan - Install".

Previous Screen

Product: EXCAVATOR

Model: 311D LRR EXCAVATOR CLA

Configuration: 311D LRR Excavator CLA00001-UP (MACHINE) POWERED BY C4.2 Engine

**Disassembly and Assembly  
C4.2 Engine for Caterpillar Built Machines**

Media Number -KENR8105-04

Publication Date -01/06/2013

Date Updated -12/06/2013

i02741773

## Engine Oil Pump - Remove

SMCS - 1304-011

### Removal Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	1P-2320	Combination Puller	1
B	1P-0510	Driver Group	1

**Start By:**

- a. Remove the front housing. Refer to Disassembly and Assembly, "Housing (Front) - Remove".

---

**NOTICE**

**Keep all parts clean from contaminants.**

**Contaminants may cause rapid wear and shortened component life.**

---

**NOTICE**

**Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers**



**Suggest:**

**If the above button click is invalid.**

**Please download this document**

**first, and then click the above link**

**to download the complete manual.**

**Thank you so much for reading**

**before opening any compartment or disassembling any component containing fluids.**

**Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.**

**Dispose of all fluids according to local regulations and mandates.**

---




Illustration 1

g00607826

**Note:** Illustration 1 does not show that the front housing is removed from the cylinder block.

1. Remove bolts (1) from the cover (2).
2. Remove cover (2) for the engine oil pump from the front housing. Remove gasket (3) (not shown).




Illustration 2

g00607770

3. Remove driven gear (4) for the oil pump. Pull the gear straight out of the front housing (5) (slip fit).
-

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**