


**John Deere  
444D, 544D and 644D  
Loader  
Repair**



**TECHNICAL MANUAL**

**TM-1341 (Oct-87)**



LITHO IN U.S.A.

# 444D, 544D, AND 644D LOADERS TECHNICAL MANUAL TM-1341 (Oct-87)

## SECTION AND GROUP CONTENTS

### SECTION I—GENERAL INFORMATION

- Group I—Introduction and Safety Information
- Group II—General Specifications
- Group III—Torque Values
- Group IV—Fuels and Lubrication
- Group V—Inspection Procedures

### SECTION 01—WHEELS

- Group 0110—Powered Wheels and Fastenings

### SECTION 02—AXLES AND SUSPENSION SYSTEMS

- Group 0200—Removal and Installation
- Group 0210—Differential or Bevel Drive  
Differential and Differential Lock
- Group 0225—Input Drive Shafts and U-Joints
- Group 0250—Axle Shafts, Bearings and  
Reduction Gears
- Group 0260—Hydraulic System  
Unloading Valve and Differential  
Lock Valve

### SECTION 03—TRANSMISSION (IN-CLUDES TORQUE CONVERTER)

- Group 0300—Removal and Installation
- Group 0315—Controls Linkage
- Group 0325—Input Drive Shafts and U-Joints
- Group 0350—Gears, Shafts, Bearings and  
Power Shift Clutch  
Transmission and Torque Converter

### SECTION 03—TRANSMISSION (IN-CLUDES TORQUE CONVERTER—CONTINUED)

- Group 0360—Hydraulic System  
Oil Pump, Control Valve, Oil Cooler,  
Oil Cooler Thermal Bypass Valve,  
Clutch Cut-Off Solenoid Valve

### SECTION 04—ENGINE

- 5.4 L (329 Cu In.)—444D, 544D
- 5.9 L (359 Cu In.)—444D, 544D
- 6.8 L (414 Cu In.)—444D, 544D
- 7.6 L (466 Cu In.)—644D

*NOTE: For repair on 5.9 L (359 cu. in.) engines, see CTM-4; 7.6 L (466 Cu. in.) engines, see CTM-1.*

- Group 0400—Removal and Installation  
Oil Pan  
Fuel Injection Pump  
Fuel Injection Lines and Nozzles  
Turbocharger  
Water Pump  
Thermostats  
Fuel Transfer Pump  
Starting Motor

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

Copyright© 1987  
DEERE & COMPANY  
Moline, Illinois  
All Rights Reserved  
A JOHN DEERE ILLUSTRATION  
Previous Editions  
Copyright© 1986 Deere & Company  
Copyright© 1985 Deere & Company

T64;1341 J6 041187

## SECTION AND GROUP CONTENTS—Continued

### SECTION 05—ENGINE AUXILIARY SYSTEMS

- Group 0505—Cold Weather Starting Aids
- Group 0510—Cooling Systems
- Group 0515—Speed Controls And Fuel Shut-Off Linkage
- Group 0520—Intake System
- Group 0530—External Exhaust System
- Group 0560—External Fuel Supply Systems

### SECTION 06—TORQUE CONVERTER

- See Group 0350 For Torque Converter Repair

### SECTION 07—DAMPENER DRIVE

- Group 0752—Elements

### SECTION 09—STEERING SYSTEM

- Group 0930—Secondary Steering
- Group 0960—Hydraulic System
  - Steering Valve, Steering Column
  - Priority Valve, Steering Cylinder,
  - Crossover Relief Valve, Cushion Valve

### SECTION 10—SERVICE BRAKES

- Group 1011—Active Elements
- Group 1015—Controls Linkage
- Group 1060—Hydraulic System
  - Brake Valve, Brake Accumulator,
  - Brake Pump, Brake System Filter,
  - Unloading Valve and Differential Lock Valve

### SECTION 11—PARK BRAKE

- Group 1111—Active Elements
  - Brake Assembly
- Group 1115—Controls Linkage

### SECTION 16—ELECTRICAL SYSTEMS

- Group 1671—Batteries, Support and Cables
- Group 1672—Alternator, Regulator and Charging System Wiring
- Group 1673—Lighting System
- Group 1674—Wiring Harness and Switches
- Group 1675—System Controls
  - Transmission Clutch Cut-Off,
  - Differential Lock, Boom
  - Height Kickout and Return-To-Dig Components
- Group 1676—Instruments and Indicators

### SECTION 17—FRAME, CHASSIS, OR SUPPORTING STRUCTURE

- Group 1740—Frame Installation
- Group 1746—Frame Bottom Guards
- Group 1749—Chassis Weights
  - Side and Rear Weights

### SECTION 18—OPERATOR'S STATION

- Group 1800—Removal and Installation
- Group 1810—Operator Enclosure
- Group 1821—Seat and Seat Belt
- Group 1830—Heating and Air Conditioning

### SECTION 19—SHEET METAL AND STYLING

- Group 1921—Grille and Grille Housing

### SECTION 20—SAFETY, CONVENIENCE AND MISCELLANEOUS

- Group 2004—Horn and Warning Devices

### SECTION 31—LOADER

- Group 3102—Buckets
- Group 3115—Controls Linkage
- Group 3140—Frames
- Group 3160—Hydraulic System
  - Loader Control Valve, Hydraulic Pump, Boom, Bucket, Multi-Purpose Bucket, and Lumber Fork Cylinders,
  - Hydraulic Filter, Reservoir, Suction Screen, Pump Relief Valve

### SECTION 99—DEALER FABRICATED TOOLS

T64:1341 J8 021187

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

## INTRODUCTION

This manual is part of a total service support program.

### FOS Manuals—reference


### Technical Manuals—machine service

### Component Manuals—component service

*Fundamentals of Service (FOS) Manuals* cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

*Technical Manuals* are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.

*Component Technical Manuals* are concise service guides for specific components. Component technical manuals are written as stand alone manuals covering multiple machine applications.



AB6:RW5559 053;INTRO2 030785

## FEATURES OF THIS TECHNICAL MANUAL

John Deere ILLUSTRATION format emphasizing illustrations and concise instructions in easy-to-use modules.

Emphasis on diagnosis, analysis, and testing so you can understand the problem and correct it.

Diagnostic information presented with the most logical and easiest to isolate problems first to help you identify the majority of routine failures quickly.

Step-by-step instructions for teardown and assembly.

Summary listing at the beginning of each group of all applicable specifications, wear tolerances, torque values, essential tools, and materials needed to do the job.

An emphasis throughout on safety—so you do the job right without getting hurt.

This technical manual was planned and written for you—an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.




AB6:RW5560 053;INTRO3 071085

## USING TABS

To fully utilize this technical manual, you must understand how it is organized.

Only two tab colors are used—gray and yellow. Each color represents a different type of information.

Spend a minute reading this now and save many minutes of searching later.



018:T5933AB T82:FLPD I 260785


## GRAY TAB SECTIONS

The gray tab sections are repair sections that tell how to repair the components of the various systems.

Repair of a component includes:

- Removal from machine (when necessary)
- Disassembly
- Inspection
- Replacement of parts
- Assembly
- Adjustment
- Installation on machine (when necessary)

The numbers used for the repair (gray tab) sections are part of an overall service publication numbering system. The numbers identify the same sections in the parts catalog, flat rate manual, service information bulletins, and service training courses.




018:T5933AC T82:FLPD J 260785

## YELLOW TAB SECTIONS

Each yellow tab section contains information on:

Groups	
05	Theory of Operation
10	System Operational Checks
15	System Diagnostic Information
20	Adjustments
25	Tests



018:T5933AD T82:FLPD K 260785

### THREE-STEP PROCEDURE


Use the following three-step procedure to locate the desired information.

1. Determine the type of information you need. Is it repair, operation, or tests?

2. Go to the appropriate section tab:


Gray for Repair

Yellow for Operation or Tests



018:T5940AT T82;FLPD L 260785

3. Use the table of contents on the first page of the section to locate the information.



018:T5933AF T82;FLPD M 260785

### RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.



AB6;T81389 053;ALERT 071085

### UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



AB6;TS187 053;SIGNAL 071085


### FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Follow recommended precautions and safe operating practices.

Keep safety signs in good condition. Replace missing or damaged safety signs.



AB6;TS188 053;SIGNS 071085




*Above top step*

018;T6084BF T82;FLSA X 280685



Right front ROPS post, facing operator

018;T6001BE T82;FLSA R 290585



If equipped—Inside operator's station above left front ROPS post

018;T6084BE T82;FLSA Y 300585

## AVOID FIRE HAZARDS

Keep a fully charged fire extinguisher in a handy location.

Never use an open flame around the machine or to check fuel, battery electrolyte, or coolant levels.

Internal corrosion inhibitor is a volatile compound. All openings must be sealed and taped after preserving. Keep container closed when not in use.

Inspect and replace any damaged electrical wiring.



018;T6080AG T82;FLSA C 010485


## REFUEL SAFELY

Do not smoke while refueling or handling highly flammable material.

Shut off the engine when refueling.

Use care in refueling if the engine is hot.

Do not use open pans of gasoline or diesel fuel for cleaning parts. Use good commercial, nonflammable solvents.




018;T6130BP T82;FLSA F 010485

### CLEAN TRASH FROM MACHINE

Wait until engine has cooled before removing trash from areas such as engine, radiator, batteries, hydraulic lines, fuel tank, and operator's station.

Temperature in engine compartment may go up immediately after engine is stopped. **BE ON GUARD FOR FIRES DURING THIS PERIOD.**

Open side shields to cool the engine faster.



018;T86512 T82;FLSA D 010485

### PREVENT BATTERY EXPLOSIONS

Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (-) battery clamp first and replace it last.



AB6;TS181 053;EXPLO 180485

### AVOID ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10-15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.



AB6;TS182 053;ACID 180485

### HANDLE STARTING FLUID SAFELY

Starting fluid is highly flammable. DO NOT incinerate or puncture a starting fluid container. Store starting fluid containers away from high temperature areas.



018;T6089AU T82;FLSA G 010485

### WEAR PROTECTIVE CLOTHING

Wear fairly tight clothing . . . and safety equipment.



018;T85056 T82;FLSA AA 130685

### AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard to search for leaks.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result.




AB6;X9811 053;FLUID 010586

### PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs (A) or earplugs (B) to protect against objectionable uncomfortable loud noises.



AB6;X7662 053;NOISE 150584

### UNDERSTAND MACHINE OPERATION, SERVICE

Allow only qualified people to operate and service the machine.

Learn the location and purpose of all controls, instruments, indicators, and labels.

Be sure you understand a service procedure before you work on the machine.

Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

**ALWAYS USE TWO PEOPLE** when making checks with the engine running—the operator at the controls, able to see the person doing the checking.

Keep hands away from moving parts.



018;T6073A0 T82;FLSA H 010485

### PREVENT MACHINE RUNAWAY

Avoid possible injury or death from machine runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear and will move if normal circuitry is bypassed.


Never start engine while standing on ground. Start engine only from operator's seat, with gear shift lever in neutral, neutral lock latch in place, and park brake applied.



AB6;TS177 T82;FLSA I 010485

### PROTECT AGAINST FLYING DEBRIS

When you drive connecting pins in or out, guard against injury from flying pieces of metal or debris; wear goggles or safety glasses.



018;T6073AP T82;FLSA AB 130685

### SUPPORT RAISED EQUIPMENT


Raised equipment must be supported before working under it.

If a support is not available, lower equipment to the ground.

T82;FLSA O 010485

### AVOID POWER LINES

Keep away from power lines. Serious injury or death may result. Never move any part of the machine or load closer to power line than 10 ft (3 m) plus twice the line insulator length.



018;T6133AK T82;FLSA Q 100685

### OBSERVE SERVICE PRECAUTIONS

Keep ALL equipment free of dirt and oil.

Clean oil, grease, mud, ice or snow from the operator's station, steps and hand rails.


DO NOT remove the radiator cap unless the engine is cool. Then loosen the cap slowly to the stop. Release all pressure before you remove the cap.

Check the exhaust system regularly for leaks.

Release hydraulic pressure before you work on the hydraulic system.

Disconnect negative (—) battery cable.


When you check hydraulic pressure, be sure to use the correct test gauge.



018;T5813AM T82;FLPD P 130886

**Group II**  
**GENERAL SPECIFICATIONS**

**444D LOADER**



**Engine:**

John Deere 6-cylinder turbocharger diesel .....	90 SAE hp (67 kw)
<b>Bore and stroke</b>	
Pin ( —511476) .....	4.02 x 4.33 in. (102 x 110 mm)
Pin (511477— ) .....	4.19 x 4.33 in. (106 x 110 mm)
<b>Piston displacement</b>	
Pin ( —511476) .....	3.29 cu. in. (5.392 L)
Pin (511477— ) .....	3.59 cu. in. (5.833 L)
Lubrication .....	Pressure system with full-flow filter
Cooling .....	Pressurized with thermostat and controlled bypass
Fan .....	Blower
Dual-stage air cleaner with restriction indicator .....	Dry
Electrical system .....	12-volt with alternator
<b>Batteries (one 12-volt)</b>	
Cold cranking capacity at 0°F (−18°C) .....	625 amps
Reserve capacity .....	170 min. ea.
Alternator: standard .....	42 amps
optional with cab .....	90 amps

**Differentials:**

Front and rear .....	Standard
Front hydraulic differential lock with capture circuit .....	Optional
Front No Spin .....	Optional

**Drive Axles:**

- Inboard-mounted planetary gears to each wheel.
- Front axle fixed.
- Rear axle oscillates 22° total (15.6 in (396 mm) vertical travel at center of tire).

018;T6140AC 05T:115 C72 140886

*General Specifications*

Torque Converter ..... Twin-turbine

Transmission ..... Power shift planetary

Forward Speeds	mph	km/h
1 .....	0—2.9 .....	0—4.7
2 .....	2.9—6.5 .....	4.7—10.5
3 .....	0—11.0 .....	0—17.7
4 .....	11.0—24.6 .....	17.7—39.6
<b>Reverse Speeds</b>		
1 .....	0—3.9 .....	0—6.3
2 .....	3.9—8.8 .....	6.3—14.2

*NOTE: Shift from 1st to 2nd and 3rd to 4th is automatic.*

**Brakes:**

**Service:**

- Power-actuated, 4-wheel, inboard-mounted, wet-disk.
- Foot-operated by either pedal.
- Left pedal also disconnects transmission.
- External inspection.
- Low brake pressure warning light and buzzer.

**Park:**

- Expanding shoe on transmission output shaft, foot-operated.
- Transmission disconnects with park brake applied.
- Warning light on instrument panel.

**Steering:**

- Turning radius ..... 13 ft 10 in. (4.22 m) measure to center line of outside tire
- Secondary steering—if equipped: Meets the requirements of SAE J53.

**Main Hydraulic and Steering System @ fast idle:**

Hydraulic System Relief .....	2250—2450 psi (15 514—15 895 kPa) (155—159 bar)
Boom Raise Circuit Relief .....	2500—2625 psi (17 238—18 005 kPa) (173—180 bar)
Bucket Rollback Circuit Relief .....	2500—2625 psi (17 238—18 005 kPa) (173—180 bar)
Bucket Dump Circuit Relief .....	850—1050 psi (5 861—7 240 kPa) (59—72 bar)
Clam Open Circuit Relief .....	2500—2625 psi (17 238—18 005 kPa) (173—180 bar)
Clam Close Circuit Relief .....	2500—2625 psi (17 238—18 005 kPa) (173—180 bar)
Maximum Steering System Pressure .....	2400—2500 psi (16 550—17 240 kPa) (165—172 bar)
Steering Crossover Relief Valve Pressure .....	3000—3200 psi (20 685—22 060 kPa) (207—220 bar)

**Brake and Differential Lock Hydraulic System:**

Unloading Valve Pressure Setting (Closing) .....	1800 psi (12 411 kPa) (124 bar)
(Opening) .....	2300 psi (15 859 kPa) (159 bar)
Differential Lock Circuit Pressure .....	600 psi (4 137 kPa) (41 bar)
Transmission System Pressure .....	125—170 psi (862—1 172 kPa) (8.6—11.7 bar)

**Maximum lift capacity with standard equipment**

Maximum height .....	7,310 lb (3320 kg)
Ground level .....	18,790 lb (8525 kg)

05T;115 C73 140886

*General Specifications*

**Tires:**

- 13.0—24, 8 PR, G2
- 15.5—25, 8 PR, L2
- 15.5—25, 12 PR, L2
- 15.5—25, 1 STAR, XRAT
  
- 17.5—25, 12 PR, L2
- \*18.4—26, 10 PR, LS2
- \*23.1—26, 10 PR, LS2

**Cold Tire Inflation Pressure**

- 50 psi (345 kPa) (3.5 bar)
- 45 psi (310 kPa) (3.1 bar)
- 55 psi (380 kPa) (3.8 bar)
- front 50 psi (340 kPa) (3.4 bar)
- rear 30 psi (210 kPa) (2.1 bar)
- 50 psi (340 kPa) (3.4 bar)
- 30 psi (210 kPa) (2.1 bar)
- 25 psi (170 kPa) (1.7 bar)

*\*Use with log loader*

**Wheel Treads:**

Front and rear ..... 70.0 in. (1.78 m)

**Refill Capacities:**


	<b>U.S.</b>	<b>Metric</b>
Cooling System .....	24 qt. ....	23 L
Fuel tank .....	50 gal. ....	189 L
Engine crankcase and filter .....	12 qt. ....	11.4 L
Transmission case and filter .....	8.5 gal ....	32.2 L
Front and rear differential .....	17 qt. ....	16 L
Hydraulic reservoir .....	64 qt. ....	61 L
Weight: .....	19, 223 lb .....	8727 kg

*NOTE: Specifications and design subject to change without notice. Wherever applicable, specifications are in accordance with ICED and SAE standards. Except where otherwise noted, specifications are based on a machine equipped with all standard equipment, 15.5—25, 8 PR loader-tread tires with 940 lb (426 kg) CaC1<sub>2</sub> solution in rear tires, ROPS cab, full fuel tank, and 175 lb (79 kg) operator.*

T82;FLSP H 140685

General Specifications

**544D LOADER**



Engine:

John Deere 6-cylinder turbocharger diesel .....	115 SAE hp (86 kw)
Bore and stroke .....	4.19 x 5 in. (106.5 x 127 mm)
Piston displacement .....	414 cu. in. (6.785 L)
Lubrication .....	Pressure system with full-flow filter
Cooling .....	Pressurized with thermostat and controlled bypass
Fan .....	Blower
Aspirated dual-stage air cleaner with restriction indicator .....	Dry
Electrical system .....	12-volt with alternator
Batteries (one 12-volt)	
Cold cranking capacity at 0°F (-18°C) .....	625 amps
Reserve capacity .....	170 min. ea.
Alternator: standard .....	42 amps
optional with cab .....	90 amps

Torque Converter .....

Twin-turbine

Transmission .....

Power shift planetary

Forward Speeds

	mph	km/h
1 .....	0—3.1	0—5.0
2 .....	3.1—7.3	5.0—11.7
3 .....	0—11.7	0—18.8
4 .....	11.7—27.9	18.8—45.0

Reverse Speeds

1 .....	0—4.2	0—6.8
2 .....	4.2—9.9	6.8—16.0

NOTE: Shift from 1st to 2nd and 3rd to 4th is automatic.

25A/T6140AD T82/FLPD S 310785



## General Specifications

**Tires:**

14.0—24, 10 PR, G2  
 14.0—24, 12 PR, G2  
 17.5—25, 12 PR, L2  
 17.5—25, 12 PR, L3  
 17.5—25, 1 START, XRAT  
  
 20.5—25, 12 PR, L3  
 20.5—25, 12 PR, L3  
 \*23.1—26, 10 PR, LS2  
 \*28.1—26, 14 PR, LS2

**Cold Tire Inflation Pressure**

55 psi (380 kPa) (3.8 bar)  
 65 psi (410 kPa) (4.1 bar)  
 50 psi (345 kPa) (3.5 bar)  
 50 psi (345 kPa) (3.5 bar)  
 front 50 psi (345 kPa) (3.5 bar)  
 rear 30 psi (210 kPa) (2.1 bar)  
 50 psi (345 kPa) (3.5 bar)  
 50 psi (345 kPa) (3.5 bar)  
 25 psi (170 kPa) (1.7 bar)  
 30 psi (210 kPa) (2.1 bar)

*\*Use with feller buncher and log loader*

**Wheel Treads:**

Front and rear ..... 70.0 in. (1.78 m)  
 Front and rear w/20, 5—25 tires ..... 80.0 in. (2.03 m)

**Refill Capacities:**


	U.S.	Metric
Cooling System .....	24 qt. ....	23 L
Fuel tank .....	50 gal. ....	189 L
Engine crankcase and filter .....	20 qt. ....	19 L
Transmission case and filter .....	8.5 gal. ....	32 L
Front differential .....	24 qt. ....	23 L
Rear differential .....	24 qt. ....	23 L
Hydraulic reservoir .....	64 qt. ....	61 L
Weight: .....	22, 665 lb .....	10 290 kg

**NOTE:** Specifications and design subject to change without notice. Wherever applicable, specifications are in accordance with ICED and SAE standards. Except where otherwise noted, specifications are based on a machine equipped with all standard equipment, 17.5—25, 12 PR, L2 tires with 1180 lb (535 kg) CaC1<sub>2</sub> solution in rear tires, ROPS cab, full fuel tank, and 175 lb (79 kg) operator.

T82;FLSP I 111185

General Specifications

**644D LOADER**



Engine:

John Deere 6-cylinder turbocharger diesel ..... 155 SAE hp (116 kw)  
 Bore and stroke ..... 4.56 x 4.75 in. (116 x 121 mm)  
 Piston displacement ..... 466 cu. in. (7.636 L)  
 Lubrication ..... Pressure system with full-flow filter  
 Cooling ..... Pressurized with thermostat and controlled bypass  
 Fan ..... Blower  
 Dual-stage air cleaner with restriction indicator ..... Dry  
 Electrical system ..... 12-volt with alternator  
 Batteries (two 12-volt)  
     Cold cranking capacity at 0°F (-18°C) ..... 625 amps  
     Reserve capacity ..... 170 min. ea.  
 Alternator: standard ..... 42 amps  
     optional with cab ..... 90 amps

Torque Converter ..... Twin-turbine

Transmission ..... Power shift planetary

Forward Speeds	mph	km/h
1 .....	0—3.3 .....	0—5.3
2 .....	3.3—7.1 .....	5.3—11.4
3 .....	0—12.8 .....	0—20.6
4 .....	12.8—27.3 .....	20.6—43.9
Reverse Speeds		
1 .....	0—3.8 .....	0—6.1
2 .....	3.8—8.2 .....	6.1—13.2

NOTE: Shift from 1st to 2nd and 3rd to 4th is automatic.

018;T6140AE T82;FLPD T 310785

*General Specifications*

**Differentials:**

Front and rear .....	Standard
Front hydraulic differential lock with capture circuit .....	Optional
Front No Spin .....	Optional

**Drive Axles:**

- Inboard-mounted planetary gears to each wheel.
- Front axle fixed.
- Rear axle oscillates 22° total (15.6 in (396 mm) vertical travel at center of tire).

**Brakes:**

**Service:**

- Power-actuated, 4-wheel, inboard-mounted, wet-disk.
- Foot-operated by either pedal.
- Left pedal also disconnects transmission.
- External inspection.
- Low brake pressure warning light and buzzer.

**Park:**

- Expanding shoe on transmission output shaft, foot-operated.
- Transmission disconnects with park brake applied.
- Warning light on instrument panel.

**Steering:**

- Turning radius ..... 16 ft 6 in. (5.03 m) measure to center line of outside tire
- Secondary steering—if equipped: Meets the requirements of SAE J53.

**Main Hydraulic and Steering System:**

Hydraulic System Relief .....	2625—2750 psi (18 099—18 960 kPa) (181—190 bar)
Boom Raise Circuit Relief .....	2875—3000 psi (19 823—20 680 kPa) (198—207 bar)
Bucket Rollback Circuit Relief .....	2875—3000 psi (19 823—20 680 kPa) (198—207 bar)
Bucket Dump Circuit Relief .....	1750—1950 psi (12 066—13 445 kPa) (121—134 bar)
Clam Open Circuit Relief .....	2875—3000 psi (19 823—20 680 kPa) (198—207 bar)
Clam Close Circuit Relief .....	2875—3000 psi (19 823—20 680 kPa) (198—207 bar)
Maximum Steering System Pressure .....	2400—2500 psi (16 550—17 240 kPa) (166—172 bar)
Steering Crossover Relief Valve Pressure .....	3000—3200 psi (20 685—22 060 kPa) (207—220 bar)

**Brake and Differential Lock Hydraulic System:**

Unloading Valve Pressure Setting (Closing) .....	1800 psi (12 411 kPa) (124 bar)
(Opening) .....	2300 psi (15 859 kPa) (159 bar)
Differential Lock Circuit Pressure .....	600 psi (4 137 kPa) (41 bar)
Transmission System Pressure .....	125—170 psi (862—1 172 kPa) (8.6—11.7 bar)

**Maximum lift capacity with standard equipment**

Maximum height .....	14,682 lb (6 674 kg)
Ground level .....	31,325 lb (14 239 kg)

T82;FLSP G 081185

## General Specifications

**Tires:**

16.0—24, 12 PR, G2  
 17.5—25, 12 PR, L2  
 29.5—25, 12 PR, L2  
 20.5—25, 12 PR, L-3  
 20.5—25, 16 PR, L3  
 20.5—25, 1 STAR, XRAT  
  
 23.5—20, 12 PR, L3  
 \*28.1—26, 14 PR, LS2

**Cold Tire Inflation Pressure**

50 psi (345 kPa) (3.5 bar)  
 60 psi (410 kPa) (4.1 bar)  
 50 psi (345 kPa) (3.5 bar)  
 50 psi (345 kPa) (3.5 bar)  
 60 psi (410 kPa) (4.1 bar)  
 front 50 psi (345 kPa) (3.5 bar)  
 rear 30 psi (210 kPa) (2.1 bar)  
 45 psi (310 kPa) (3.1 bar)  
 30 psi (210 kPa) (2.1 bar)

*\*Use with log loader*

**Wheel Treads:**

Front and rear ..... 80.0 in. (2.03 m)  
 Front and rear w/23.5—25 tires ..... 84.8 in. (2.15 m)

**Refill Capacities:**

	U.S.	Metric
Cooling System .....	29 qt. ....	28 L
Fuel tank .....	67 gal. ....	254 L
Engine crankcase and filter .....	20 qt. ....	19 L
Transmission case and filter .....	8.5 gal ....	32 L
Front differential .....	24 qt. ....	23 L
Rear differential .....	24 qt. ....	23 L
Hydraulic reservoir .....	100 qt. ....	95 L
Weight: .....	29, 320 lb .....	13 311 kg

**NOTE:** Specifications and design subject to change without notice. Wherever applicable, specifications are in accordance with ICED and SAE standards. Except where otherwise noted, specifications are based on a machine equipped with all standard equipment, 20.5—25, 12 PR, L2 loader-tread tires w 1820 lb (826 kg) CaC1<sub>2</sub> solution in rear tires, ROPS cab, full fuel tank, and 175 lb (79 kg) operator.

T82/FLSP J 111185

## Group III TORQUE VALUES




### HARDWARE TORQUE SPECIFICATIONS

Check cap screws and nuts to be sure they are tight. If hardware is loose, tighten to torque shown on the following charts unless a special torque is specified.

T82;SKMA AT 270286

*NOTE: Torques shown are for dry (no lubrication on threads) hardware.*

*NOTE: Torque wrench tolerance is  $\pm 10$  per cent of specified torque.*

Cap Screw Size-Inches	Customary Hardware					
						
	Grade B		Grade D		Grade F	
	lb-ft. (N-m)		lb-ft. (N-m)		lb-ft. (N-m)	
1/4	----	----	10	(14)	14	(19)
5/16	----	----	20	(27)	30	(41)
3/8	----	----	35	(47)	50	(68)
7/16	35	(47)	55	(75)	80	(108)
1/2	55	(75)	85	(115)	120	(163)
9/16	75	(102)	130	(176)	175	(237)
5/8	105	(142)	170	(230)	240	(325)
3/4	185	(251)	300	(407)	425	(576)
7/8	160	(217)	445	(603)	685	(929)
1	250	(339)	670	(908)	1030	(1396)
1-1/8	330	(447)	910	(1234)	1460	(1979)
1-1/4	480	(651)	1250	(1695)	2060	(2793)

018;T88884 T82;FLMA AJ 140685

### WHEEL RETAINER CAP SCREWS

Tighten cap screws to  $410 \pm 40$  N-m ( $300 \pm 30$  lb-ft).

05T;115 C74 140886

*Torque Values*

**METRIC HARDWARE TORQUE CHART**

*NOTE: Torques shown are for hardware with SAE30W oil on threads.*

*NOTE: Torque wrench tolerance is  $\pm 10$  percent of specified torque.*

**Metric Standard Thread**

Thread	8.8		10.9		12.9	
	N·m	lb-ft	N·m	(lb-ft)	N·m	(lb-ft)
M5	5.9	( 4.4)	7.9	( 5.8)	9.8	( 7.2)
M6	9.8	( 7.2)	13.8	( 10.2)	16.7	( 12.3)
M8	24.6	( 18.1)	34.4	( 25.4)	40.2	( 29.6)
M10	48.1	( 35.5)	67.8	( 50.0)	81.5	( 60.1)
M12	84.4	( 62.2)	118.0	( 87.0)	142.0	(105.0)
M14	133.0	( 98.0)	187.0	(138.0)	226.0	(167.0)
M16	206.0	(152.0)	290.0	(214.0)	348.0	(257.0)
M18	285.0	(210.0)	398.0	(294.0)	476.0	(351.0)
M20	402.0	(296.0)	570.0	(420.0)	677.0	(499.0)
M22	540.0	(398.0)	765.0	(564.0)	914.0	(674.0)
M24	697.0	(514.0)	980.0	(723.0)	1180.0	(870.0)

**Metric Fine Thread**

Thread	8.8		10.9		12.9	
	N·m	(lb-ft)	N·m	(lb-ft)	(N·m)	lb-ft
M8 x 1	26.5	( 19.5)	37.3	( 27.5)	44.2	( 32.6)
M10 x 1	47.1	( 34.7)	68.8	( 50.7)	81.5	( 60.1)
M12 x 1.5	88.4	( 65.2)	123.0	( 91.0)	147.0	( 108.0)
M14 x 1.5	147.0	(108.0)	206.0	( 152.0)	246.0	( 181.0)
M16 x 1.5	221.0	(163.0)	309.0	( 228.0)	373.0	( 275.0)
M18 x 1.5	319.0	(235.0)	451.0	( 333.0)	540.0	( 398.0)
M20 x 1.5	451.0	(333.0)	628.0	( 463.0)	755.0	( 557.0)
M22 x 1.5	599.0	(442.0)	845.0	( 623.0)	1030.0	( 760.0)
M24 x 2	765.0	(564.0)	1080.0	( 796.0)	1275.0	( 940.0)
M26 x 2	1130.0	(833.0)	1570.0	(1158.0)	1915.0	(1412.0)

T82;EXMA T 290384

*Torque Values*

**SERVICE RECOMMENDATIONS FOR  
FLAT FACE O-RING SEAL FITTINGS**

- |  |  |
|--|--|
| <p>1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.</p> <p>2. Inspect the O-ring. It must be free of damage or defects.</p> <p>3. Lubricate O-rings and male threads with petroleum jelly.</p> | <p>4. Push O-ring into the groove.</p> <p>5. Index angle fittings and tighten by hand.</p> <p>6. Tighten fitting or nut to torque value shown on the chart per dash size shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist while tightening fittings.</p> |
|--|--|

**FLAT FACE O-RING SEAL FITTING TORQUE (1)**

Nominal		Dash	Thread	O-Ring Face Seal End		O-Ring Boss End	
				Swivel Nut Torque		Bulkhead Nut Torque	
Tube mm	O.D. in.	Size	Size in.	Nm	lb-ft	Nm	lb-ft
4.76	0.188	-3	-----	----	----	----	----
6.35	0.250	-4	9/16-18	16	12	5.0	3.5
7.94	0.312	-5	-----	----	----	----	----
9.52	0.375	-6	11/16-16	24	18	9.0	6.5
12.70	0.500	-8	13/16-16	50	37	17.0	12.5
15.88	0.625	-10	1-14	69	51	17.0	12.5
19.05	0.750	-12	1 3/16-12	102	75	17.0	12.5
22.22	0.875	-14	1 3/16-12	102	75	17.0	12.5
25.40	1.000	-16	1 7/16-12	142	105	17.0	12.5
31.75	1.250	-20	1 11/16-12	190	140	17.0	12.5
38.10	1.500	-24	2-12	217	160	17.0	12.5

1. Tolerance: +15 -20%

T82;FLSP A



**Suggest:**

**If the above button click is invalid.**

**Please download this document**

**first, and then click the above link**

**to download the complete manual.**

**Thank you so much for reading**

**O-RING BOSS FITTING SERVICE RECOMMENDATIONS**

1. Inspect boss O-ring seat. It must be free of dirt and defects. If repeated leaks occur, inspect for defects with a magnifying glass. Some raised defects can be removed with a slip stone.

Occasionally a lower durometer O-ring will seal against a rough seat. If neither of these solutions work, the component must be replaced.

2. Lubricate O-ring using petroleum jelly. Put a thimble over the threads to protect O-ring from nicks. Slide O-ring over the thimble and into the turned down section of fitting.

For angle fittings, loosen special nut and push special washer against threads so O-ring can be installed into the turned down section of fitting.

3. Turn fitting into the boss by hand until special washer or washer face (straight fitting) contacts boss face and O-ring is squeezed into its seat.

4. To position angle fittings, turn the fitting counterclockwise a maximum of one turn.

5. Tighten straight fittings to the torque value shown in chart. For angle fittings, tighten the special nut to value shown in the chart while holding body of fitting with a wrench.

**STRAIGHT FITTING OR SPECIAL NUT TORQUE (1)**

Thread Size	Torque <sup>1</sup>		Number Of Flats <sup>2</sup>
	N·m	(lb-ft)	
3/8-24 UNF	8	(6)	2
7/16-20 UNF	12	(9)	2
1/2-20 UNF	16	(12)	2
9/16-18 UNF	24	(18)	2
3/4-16 UNF	46	(34)	2
7/8-14 UNF	62	(46)	1-1/2
1-1/16-12 UN	102	(75)	1
1-3/16-12 UN	122	(90)	1
1-5/16-12 UN	142	(105)	3/4
1-5/8-12 UN	190	(140)	3/4
1-7/8-12 UN	217	(160)	1/2

1. Tolerance  $\pm$  10%.

2. To be used if a torque wrench cannot be used. After tightening fitting by hand, put a mark on nut and boss; then tighten special nut or straight fitting the number of flats shown.

T82:LP0 AA 040285

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**