

990 Excavator

John Deere Dubuque Works
TM-1230 (May-87)

LITHO IN U.S.A.

990 EXCAVATOR TECHNICAL MANUAL TM-1230 (MAY-87)

SECTION AND GROUP CONTENTS

SECTION I—GENERAL INFORMATION

- Group I —Introduction and Safety Information
- Group II —General Specifications
- Group III—Cap Screw Torque Values
- Group IV—Lubrication

SECTION 01—TRACKS

- Group 0130—Track Systems

SECTION 2—AXLES AND SUSPENSION SYSTEMS

- Group 0250—Axle Shaft, Bearings, Reduction Gears
- Group 0260—Hydraulic Systems

SECTION 4—ENGINE

- Group 0400—Removal and Installation
- Group 0401—Crankshaft and Main Bearings
- Group 0402—Camshaft and Valve Actuating Means
- Group 0403—Connecting Rods and Pistons
- Group 0404—Cylinder Block
- Group 0407—Oiling System
- Group 0408—Ventilating System
- Group 0409—Cylinder Head and Valves
- Group 0410—Exhaust Manifold

SECTION 4—ENGINE—Continued

- Group 0413—Fuel Injection System
- Group 0416—Turbocharger
- Group 0417—Water Pump
- Group 0418—Thermostats, Housings, and Water Piping
- Group 0419—Oil Cooler
- Group 0420—Fuel Filter
- Group 0421—Fuel Transfer Pump
- Group 0422—Starting Motor and Fastenings
- Group 0429—Fan Drive
- Group 0433—Flywheel, Housing and Fastenings

SECTION 5—ENGINE AUXILIARY SYSTEMS

- Group 0505—Cold Weather Starting Aids
- Group 0510—Cooling Systems
- Group 0515—Speed Controls
- Group 0520—Intake System
- Group 0560—External Fuels Supply Systems

SECTION 16—ELECTRICAL SYSTEMS

- Group 1671—Batteries, Support, and Cables
- Group 1672—Alternator, Regulator and Charging System Wiring
- Group 1674—Wiring Harness and Switches
- Group 1676—Instruments and Indicators

Continued on next page

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1987
DEERE & COMPANY
Moline, Illinois
All rights reserved
A JOHN DEERE ILLUSTRATION
Previous Editions
Copyright© 1986 DEERE & COMPANY
Copyright© 1983 DEERE & COMPANY
Copyright© 1981 DEERE & COMPANY

SECTION AND GROUP CONTENTS - CONTINUED

SECTION 17 - FRAME, CHASSIS, OR SUPPORTING STRUCTURE

- Group 1740 - Frame Installation
- Group 1749 - Chassis Weights

SECTION 18 - OPERATOR'S STATION

- Group 1810 - Operator Enclosure
- Group 1830 - Heating and Air Conditioning

SECTION 19 - SHEET METAL AND STYLING

- Group 1927 - Fenders

SECTION 33 - EXCAVATOR

- Group 3302 - Buckets
- Group 3340 - Frames
- Group 3360 - Hydraulic System

SECTION 43 - SWING, ROTATION OR PIVOTING SYSTEM

- Group 4311 - Brakes
- Group 4350 - Mechanical Drive Elements
- Group 4360 - Hydraulic System

SECTION 90 - SYSTEM TESTING

- Group 9005 - General Information - Seven Basic Steps of Diagnosis and Testing
- Group 9010 - Engine
- Group 9015 - Electrical System
- Group 9025 - Hydraulic System
- Group 9030 - Miscellaneous Components
- Group 9031 - Heating and Air Conditioning

SECTION 99 - SPECIAL TOOLS

INDEX

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

INTRODUCTION AND SAFETY INFORMATION

INTRODUCTION

This technical manual is part of a twin concept of service.

FOS Manuals - for reference

Technical Manuals - for actual service

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.



30A:T85958 T28:1 I101 130582

FEATURES OF THIS TECHNICAL MANUAL

- John Deere ILLUSTRATION format emphasizing detailed pictures and fewer words in easy-to-use modules.
- Removal and installation groups preceding some repair groups.
- A section of system diagnostic testing.
- Table of contents of all sections at the front of the manual and a listing of all groups and headings at the front of each section.
- Special tools and specifications listed at the front of each group they are used in.
- Special tools illustrated in numerical order at end of manual.
- Alphabetical listing of all major components, specifications, and special tools.
- Safety rules, general specifications, and lubrication specifications.

This technical manual was planned and written for you - an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.



30A:T85959 T28:1 I115 130582

SAFETY AND YOU




CAUTION: This safety symbol is used for important safety messages. When you see this symbol, follow the safety message to avoid personal injury.



30A:T61349 T28:1 I102 240881


Be prepared for an accident or fire.
Know where the first aid kit and fire extinguisher are.
Know how to use them.
Know where to get help.



T27504N

30A:T27504 N T28:1 I103 280581

Wear safety equipment.



T73432

30A:T73432 T28:1 I104 240881

Wear fairly tight clothing.




T45672

30A:T45672 T28:1 I105 280581

AVOID HIGH PRESSURE-FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. **DO NOT** use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result.



30A:K9811 T281 1106 161182

KEEP SHOP AND STORAGE AREA CLEAN

Maintenance area should be well-ventilated.

Keep maintenance area clean and dry.

Store flammable materials in a cool and well-ventilated area out of reach of unauthorized personnel.



30A:T27508 N T281 1107 260881

FOLLOW SAFE WORKING CONDITIONS

Do not work on the equipment unless you are approved to do so. Then be sure you know the correct procedure.

Do not work on equipment while it is being operated.

Keep hands away from moving parts.

When the engine is running, do not work on equipment unless the procedure is approved.

If you must work on the machine with the engine running, ALWAYS USE TWO service technicians. One must be at the controls. The other must be within sight of the operator.



Put a support under all raised equipment.

Park the machine across a slope, or use blocks to hold it in place.

Do not lift heavy parts by yourself. Use a hoist or jack.

TAKE CARE! WATCH OUT FOR OTHER PEOPLE IN THE AREA.

When you drill, grind or hammer metal, wear safety glasses.



OBSERVE SERVICE PRECAUTIONS

Keep ALL equipment free of dirt and oil.

Clean oil, grease, mud, ice or snow from the operator's station, steps and hand rails.


Do not remove the radiator cap unless the engine is cool. First, loosen the cap slowly to the stop. Then release all pressure in the cooling system before you remove the cap.

Check the exhaust system regularly for leaks.

Release hydraulic pressure before you work on the hydraulic system. See page I-I-06.


When you check hydraulic pressure, be sure to use the correct test gauge.

Before you work on the fuel system, close the fuel shutoff valve.



30A-T02345 T20:1 1109 091281

Do not work under a raised bucket. Lower the bucket to the ground, or put blocks under the bucket.



30A-T02345 T20:1 1110 240881


CHECK SAFETY EQUIPMENT ON MACHINE

All protective parts (shields, guards, ROPS, etc.) should be in good condition and fastened in place.

Check for leaks in all systems:

- Air intake system
- Engine oil system
- Hydraulic system
- Fuel system
- Cooling system


RIGHT



30A-T02325 T20:1 1111 240881

AVOID EXPLOSIONS OR FIRE


- Do not smoke while you fill the fuel tank.
- Do not smoke while you work with material that will start on fire easily.
- Stop the engine before you fill the fuel tank.
- Do not fill fuel tank if engine is hot.
- Do not use gasoline or diesel fuel for cleaning parts. Use solvents that will not start on fire.



30A:T62411 T2B:1 I112 260881

OBSERVE BATTERY PRECAUTIONS

- Do not put metal objects across terminals to check the battery charge.
- When you charge a battery, be sure there is enough ventilation.
- Keep sparks and flames away from batteries.
- Do not smoke near battery.
- Before you work on the electrical system, or make major repairs, turn off the battery disconnect switch.



30A:T27505 T2B:1 I113 260881

BEFORE YOU WORK ON THE HYDRAULIC SYSTEM


Follow these steps before you work on any part of the hydraulic system:

1. Park the excavator on level ground.
2. Lower hydraulic pressure:
 - Lower bucket to ground.
 - Stop engine.
 - Move control levers until boom and bucket do not move.
3. Push valve levers in all the way to stop oil flow.
4. Loosen the reservoir filler cap slowly to release pressure.
5. Open the diffuser vent. Turn it counterclockwise.

IMPORTANT: After you finish:

- Close diffuser vent.
- Pull levers out.

CAUTION: Do not walk or stand on sloping fenders or other sheet metal to service the excavator.



30A:T62348 T2B:1 I114 260881

General Specifications

Swing mechanism:

Swing 360-degree, internal drive, continuous Turntable bearing Single row, ball Case-hardened ring and pinion gears run in lubricant.

Undercarriage:

Propel motors (one for each track) . High-torque axial-piston hydraulic motors with planetary drive. Multiple-disk brakes automatically release while propelling, and apply when stationary. Independent drive to each track permits counterrotation.

Undercarriage, car body, and track frame Each track frame is a formed, reinforced U-channel. Track frames are joined by reinforced boxed car body with swing bearing mount.

Track Chain Sealed track chain

Track Adjustment Hydraulic

Buckets: High-strength steel, ribbed and plated bottom section.

Cab:

Steel, with urethane sound-proofing on ceiling and side walls, and cushioned neoprene floor mat. Safety glass on all sides and top. Front and rear windows open. Front window can be stored overhead.

Seat:

Fully adjustable heavy-duty cloth, foam-rubber cushioned seat.

Controls:

Pilot-operated two-lever for boom, arm, bucket, and swing. Pilot-operated right and left pedals control forward and rearward movement of right and left tracks respectively.

Nominal Width	Bite Width	Capacity		Weight
		SAE	Struck	
39 in. (991 mm)	42 in. (1067 mm)	1½ cu. yd. (1.15 m³)	1¼ cu. yd. (0.96 m³)	2550 lb. (1157 kg)
45 in. (1143 mm)	47 in. (1194 mm)	1⅞ cu. yd. (1.43 m³)	1½ cu. yd. (1.15 m³)	2670 lb. (1211 kg)
51 in. (1295 mm)	54 in. (1372 mm)	2⅞ cu. yd. (1.62 m³)	1¾ cu. yd. (1.34 m³)	2820 lb. (1279 kg)
Heavy-duty				
33 in. (838 mm)	37 in. (940 mm)	1½ cu. yd. (1.15 m³)	1¼ cu. yd. (0.96 m³)	3050 lb. (1383 kg)
39 in. (991 mm)	44 in. (1118 mm)	1⅞ cu. yd. (1.43 m³)	1½ cu. yd. (1.15 m³)	3575 lb. (1622 kg)
45 in. (1143 mm)	50 in. (1270 mm)	2 cu. yd. (1.53 m³)	1½ cu. yd. (1.15 m³)	3660 lb. (1660 kg)
Track Shoes:		Ground	Ground	
Width	Shoes	Contact	Pressure	
30 in. (750 mm)	Triple-bar semigrouser	9723 sq. in. (62 731 cm²)	9.18 psi (63.3 kPa) (0.65 kg/cm²)	
36 in. (900 mm) (optional)	Triple-bar semigrouser	11,668 sq. in. (75 278 cm²)	7.85 psi (54.1 kPa) (0.55 kg/cm²)	

T28J 1116 270881

General Specifications

Boom and Arm:

Internally reinforced tapered box construction with heat-treated steel bushings. Machined and bored after welding for accurate alignment. All pivot points are sealed to allow extended lubrication intervals.

Servicing and Vandal Protection:

Swingaway service doors expose built-in platforms for easy access to engine and hydraulic systems. Cab and access covers to fuel tank, radiator, and hydraulic lock with switch key.

Capacities:	U.S.	Imp.	Liters
Fuel tank	143 gal.	119.2 gal.	541.3
Cooling system	17 gal.	14.2 gal.	64.4
Engine lubrication, including filter	38 qt.	31.7 qt.	36.0
Hydraulic system	220 gal.	183.3 gal.	832.8
Planetary propel drive (each)	21 qt.	17.5 qt.	20.0
Swing drive (each)	8 qt.	6.7 qt.	7.5

Weights:	lb.	kg
Operating weight, excavator less bucket:		
30-in. (750 mm) track shoes	85,700	38 873
36-in. (900 mm) track shoes	89,700	40 688
Upper structure (without counterweight and boom)	22,600	10 251
Undercarriage:		
30-in. (750 mm) track shoes	34,270	15 549
36-in. (900 mm) track shoes	38,270	17 359
One piece mainboom (without hydraulic cylinders)	6,050	2744
Standard arm, 140 in. (3.56 m)	3,900	1769
Optional Arm, 108 in. (2.74 m)	3,600	1633
Main boom lift cylinders (2)	1,434	650
Arm cylinder	1,075	488
Bucket cylinder and bucket linkage	1,375	624
Main counterweight	15,000	6804
Auxiliary counterweight	4,500	2041

Additional Standard Equipment:


- Electric hour meter
- Alternator charge indicator light
- Hydraulic oil filter pressure warning light
- Engine overheating warning light
- Gauges (internal illuminated):
 - Engine coolant temperature
 - Hydraulic oil temperature
 - Engine oil pressure
- Fuel
- Key switch
- Cold weather starting aid
- Horn
- Positive-position hand throttle
- 15,000 lb. (6804 kg) counterweight
- Counterweight removal system
- Track guides
- Cab with heater
- Floor mat
- Lifting hook
- Tinted roof window

Special Equipment:

- 36-in. (900 mm) triple-bar semigrouser shoes
- Bucket side cutters
- Fire extinguisher
- Engine water heater
- Window protection group
- Air conditioner
- Auxiliary counterweight
- Two electric cab fans
- Vandal protection
- 108-in. (2.74 m) dipperstick


72801 1117 270801

General Specifications



Digging Depth and Lifting Height:

— 140 in. (3.56 m) dipperstick
 --- 108 in. (2.74 m) dipperstick
 40 ft. (12.19 m)



30A782378, 782437 T28, I 1118 280881

Group III CAP SCREW TORQUE VALUES

CUSTOMARY TORQUE SPECIFICATIONS

NOTE: Wrench torque tolerance is $\pm 10\%$.

Cap Screw In.	Plain Head*		Three Dashes*		Six Dashes*	
	(lb-ft.)	N-m	(lb-ft.)	N-m	(lb-ft.)	N-m
1/4	-----	-----	(10)	14	(14)	19
5/16	-----	-----	(20)	27	(30)	41
3/8	-----	-----	(35)	47	(50)	68
7/16	(35)	47	(55)	75	(80)	108
1/2	(55)	75	(85)	115	(120)	163
9/16	(75)	102	(130)	176	(175)	237
5/8	(105)	142	(170)	230	(240)	325
3/4	(185)	251	(300)	407	(425)	576
7/8	(160)	217	(445)	603	(685)	929
1	(250)	339	(670)	908	(1030)	1396
1-1/8	(330)	447	(910)	1234	(1460)	1979
1-1/4	(480)	651	(1250)	1695	(2060)	2793

All torques are dry torque unless noted.

*Dashes identify the grade of hardware.

T281 11109 170582

METRIC TORQUE SPECIFICATIONS

NOTE: Wrench torque tolerance is $\pm 10\%$.

Cap Screw Diameter	Property Class 8.8*		Property Class 10.9*	
	(lb-ft)	N-m	(lb-ft)	N-m
M5	(4.4)	6.0	(6.3)	8.5
M6	(7.4)	10.0	(10.7)	14.5
M8	(18.1)	24.5	(25.8)	35.0
M10	(36.1)	49.0	(51.6)	70.0
M12	(62.7)	85.0	(89.2)	121.0
M16	(154.9)	210.0	(221.2)	300.0
M20	(265.5)	360.0	(368.7)	500.0
M24	(457.2)	620.0	(634.2)	860.0
M30	(885.0)	1200.0	(1224.2)	1660.0
M36	(1541.3)	2090.0		

All torques are dry torque unless noted.

*Numbers identify the grade of hardware.

T281 11110 190582

GENERAL INFORMATION

When you service the excavator, check the periodic service chart inside the left, front fender. A copy of this chart is below. The 990 Operator's Manual has details for excavator service.

PERIODIC SERVICES
REFER TO OPERATOR'S MANUAL FOR MORE DETAILED INFORMATION

INTERVAL HOURS	ITEM NO.	COMPONENTS	SERVICE POINTS	DESCRIPTION OF SERVICE	CHECK/TY MEASUREMENT	APPROVED SERVICE MATERIAL
10 OR DAILY	1	RADIATOR	1	CHECK COOLANT LEVEL	BOTTOM OF TUBE IN NECK	ANTI-FREEZE OR SUMMER COOLANT
	2	HYDRAULIC RESERVOIR	1	CHECK OIL LEVEL	MIDDLE OF WINDOW WITH CYLINDERS HALF-WAY EXTENDED	JO-HO LINCOR OR EQUIVALENT
	3	ENGINE CRANKCASE	1	CHECK OIL LEVEL	TOP MARK ON DIPSTICK	SEE CHART BELOW
	4	AIR CLEANER	1	CHECK RESTRICTION	TOP MARK ON DIPSTICK	SEE CHART BELOW
	5	BUCKET CYLINDER HOOD	1	GREASE FITTING	2 SHOTS	SAE MFG
	6	BUCKET LINKAGE	2	GREASE FITTINGS	2 SHOTS	SAE MFG
50	7	BOOM TO MAIN FRAME PIN	4	GREASE FITTINGS	2 SHOTS	SAE MFG
	8	BOOM CYLINDER HEADS	2	GREASE FITTINGS	2 SHOTS	SAE MFG
	9	BOOM CYLINDER HOODS	2	GREASE FITTINGS	2 SHOTS	SAE MFG
	10	CROWD CYLINDER HEAD	1	GREASE FITTING	2 SHOTS	SAE MFG
	11	CROWD CYLINDER HOOD	1	GREASE FITTING	2 SHOTS	SAE MFG
	12	BUCKET CYLINDER HEAD	1	GREASE FITTING	2 SHOTS	SAE MFG
	13	BOOM TO DIPPERSTICK PIN	4	GREASE FITTINGS	2 SHOTS	SAE MFG
100	14	TRACKS****	2	CHECK SAG	3 IN. (76 MM) 127 MM; 30 LB. (136 KG) BELT TENSION	
	15	ENGINE BELTS*****	2	CHECK TENSION		
	16	HYDRAULIC RESERVOIR	1	CLEAN BREATHER VALVE		HEROSENE OR SOLVENT
	17	HOUSE BRAKES	1	CHECK OIL LEVEL	BOTTOM OF CHECK HOLE	JO-HO LINCOR OR EQUIVALENT
200	18	SWING GEARBOXES	2	CHECK OIL LEVEL	BOTTOM OF CHECK HOLE	JO DEAR GARD OR EQUIVALENT
	19	ENGINE CRANKCASE**	1	DRAIN AND REFILL	40 QT (3.8L)	SEE CHART BELOW
	20	CRANKCASE OIL FILTER**	1	REPLACE ELEMENT		JO FILTERS
	21	SWING GEARBOX AND BEARING OILS	2	GREASE FITTINGS	2 SHOTS	SAE MFG
	22	TRACK GEARBOXES	2	CHECK OIL LEVEL	BOTTOM OF CHECK HOLE	JO DEAR GARD OR EQUIVALENT
	23	HYDRAULIC OIL RETURN FILTERS****	4	REPLACE ELEMENT		JO FILTERS
	24	HYDRAULIC OIL HIGH PRESSURE FILTERS****	3	REPLACE ELEMENT		JO FILTERS
	25	HYDRAULIC OIL PILOT CONTROL FILTER	1	REPLACE ELEMENT		JO FILTER
	26	ENGINE COOLANT FILTER*****	1	REPLACE CONDITIONER/FILTER		JO CONDITIONER/FILTER
	27	FUEL TANK PUMP	1	DRAIN WATER AND SEDIMENT		
500	28	AIR CLEANER HOSE	1	CHECK HOSE AND CONNECTIONS		JO CONDITIONER/FILTER
	29	COOLING SYSTEM (SPRING & FALL)*****	1	DRAIN, FLUSH AND REFILL WITH ANTI-FREEZE OR WATER. REPLACE CONDITONER/COOLANT FILTER		
	30	FUEL FILTERS	2	REPLACE ELEMENTS		JO FILTERS
	31	SWING BEARING	4	GREASE FITTINGS ROTATE 90°; GREASE AGAIN. REPEAT FOR 360°	4 SHOTS EACH	JO FILTERS SHELL "ALYANSA EP" OR EQUIVALENT
	32	SWINGING GEAR**	1	ADD 1 LB (0.45 KG)	20 LB (9.08)	TERACO TRIGLAD 2 OR EQUIVALENT
1000	33	SWING GEARBOXES	2	DRAIN AND REFILL	8 QT (75.4L)	JO DEAR GARD OR EQUIVALENT
	34	TRACK ACCUMULATORS	2	CHECK PRESSURE	SEE CHART BELOW	JO-NITROGEN
	35	AIR CLEANER	2	REPLACE ELEMENTS		JO FILTERS
	36	TRACK GEARBOXES	4	DRAIN AND REFILL	31 QT (2.9L)	JO DEAR GARD OR EQUIVALENT
	37	HYDRAULIC RESERVOIR	1	DRAIN, FLUSH, CLEAN, SUCTION SCREENS AND REFILL	88 GAL (334 L) RESERVOIR (729 GAL (276 L) TOTAL)	JO-HO LINCOR OR EQUIVALENT
	38	ENGINE CRANKCASE VENT TUBE	1	REMOVE AND CLEAN		
	39	ENGINE VALVE LASH	16	CHECK AND ADJUST SEE JO DEALER		
	40	ENGINE SPEED	1	CHECK AND ADJUST SEE JO DEALER		
	41	CABLE PULLEY	2	GREASE FITTINGS	2 SHOTS	SAE MFG
	42	BATTERIES	4	ADD WATER AND CHECK TERMINALS		DISTILLED WATER
43	CAB AIR FILTERS	2	CLEAN OR REPLACE ELEMENTS		JO FILTERS	

TRACK ACCUMULATOR

AIR TEMP	DAY NITROGEN PRESSURE
ABOVE 60°F (15°C)	1750 PSI (120.7 MPa)
0° to 60°F (-18°C to 15°C)	1900 PSI (134.5 MPa)
BELOW 0°F (-18°C)	900 PSI (62.0 MPa)

ENGINE OIL

AIR TEMP	JOHN DEERE TORO GARD SUPPLIES OIL	SMOKE VISCOSITY OIL API SERVICE CLASS	MULTI-VISCOUS OIL API SERVICE CLASS	NOT RECOMMENDED
ABOVE 32°F (0°C)	SAE 30	SAE 30		
32°F TO 10°F (0°C TO 23°C)	SAE 30	SAE 30	SAE 15W-30	SAE 10W-30
BELOW 10°F (-12°C)	SAE 15W-30	SAE 15W-30	SAE 5W-30	SAE 1W-30

Engine Oils

Use John Deere TORQ-GARD SUPREME engine oil in the engine crankcase.

Use John Deere TORQ-GARD SUPREME SAE 10W-20 oil or equivalent during the first 100 hours of operation for break-in.

Oils other than John Deere TORQ-GARD SUPREME must have one of the following specifications:

Single Viscosity Oils

API Service CD/SC
MIL-L-2104C
Series 3

Multi-Viscosity Oils

API Service CC/SE
MIL-L-46152

Oils and Air Temperature

SAE ENGINE OILS			
Air Temperature	John Deere TORQ-GARD SUPREME Oil	Other Oils	
		Single Viscosity Oil	Multi-Viscosity Oil
Above 32°F (0°C)	30	30	Not recommended.
32° to -10°F (0° to -23°C)	10W-20	10W	10W-30
Below -10°F (-23°C)	5W-20	5W	5W-20

If you use SAE 5W-20 or SAE 5W oil, your engine may use more oil. Check the oil level often.

Storing and Handling Lubricants

Store lubricants in clean containers in an area protected from dust, moisture, and other contamination.

When you handle lubricants, use clean containers.

Hydraulic Oils

If you operate excavator at air temperatures above -13°F (25°C), use John Deere Hydraulic Oil (J14C) or equivalent.

For air temperatures between -31°F (-35°C) and 77°F (25°C), use SAE 5W-20 engine oil, CC/SE, MIL-L-46152.

NOTE: See your John Deere dealer for special arctic lubricants.

Track Rollers and Idlers, Swing and Track Gearboxes

Use a multi-purpose GL-5 gear oil, SAE 80W-90, MIL-L-2105C.

Greases

Use John Deere Multi-Purpose Grease or an equivalent for all grease fittings except where noted.

Swing Bearing

Use Shell Alvania EP-2 or one of the following or an equivalent:

- Sunoco 742 EP grease
- Esso Unirex EP2 grease
- American Amolith 2EP grease
- Conoco Super Stay Conolith EP2 grease
- Gulf Crown EP2 grease
- Mobil Mobilux EP2 grease
- Phillips Philube EP2 grease
- Texaco Multifax EP2 grease
- Standard Dura-Lith EP2 grease

Swinging Gear

Use Texaco Texclad 2 or equivalent.

Section 01 TRACKS

CONTENTS

	Page		Page
GROUP 0130 - TRACK SYSTEMS		GROUP 0130 - TRACK SYSTEMS—Continued	
Special Tools	0130-01	Sprocket	
Specifications		Remove and Install	0130-43
Guide	0130-01	Front Idler	
Guide and Slide	0130-02	Measure Front Idler Wear	0130-44
Roller	0130-02	Remove	0130-45
Track Shoe	0130-03	Disassemble	0130-46
Track Chain	0130-03	Inspect Metal Face Seals	0130-47
Sprocket	0130-05	Cross Section	0130-51
Idler	0130-05	Assemble	0130-52
Track Adjuster	0130-05	Test for Oil Leakage	0130-57
Accumulator	0130-06	Install	0130-57
Track Guides		Track Adjuster	
Remove and Install	0130-08	Remove	0130-59
Track Guides and Slides		Disassemble	0130-59
Remove and Install	0130-09	Cross Section	0130-62
Track Rollers		Assemble	0130-63
Measure Roller Wear	0130-11	Install	0130-65
Remove	0130-11	Adjust Relief Valve	0130-67
Disassemble	0130-12	Accumulator	
Inspect	0130-14	Remove	0130-71
Cross Section	0130-17	Disassemble	0130-73
Assemble	0130-18	Cross Section	0130-80
Test	0130-24	Assemble	0130-81
Install	0130-24	Charge	0130-86
Track Shoes		Leakage Test	0130-89
Measure Grouser Wear	0130-25	Install	0130-90
Remove and Install	0130-26		
Track Chain			
Measure Track Link for Wear	0130-27		
Measure Bushing for Wear	0130-28		
Measure Track Pitch	0130-28		
Remove	0130-29		
Disassemble	0130-32		
Assemble	0130-34		
Install	0130-38		
Adjust Tension	0130-42		

SPECIAL TOOLS


NOTE: Order tools from your SERVICE-GARD™ Catalog, unless otherwise indicated.

Number	Name	Use
D-01031AA	200-Ton Track Press	Disassemble and assemble track chain.
D-01043AA	Load Positioning Sling	Used With Master Pin Pusher to remove master pin.
D-01047AA	17½ and 30-Ton Puller Set	Remove and install bushings, seals and roller end brackets.
D-01063AA	100-Ton Master Pin Pusher	Remove and install master pin.
D-01065AA	Tooling Set for 200-Ton Track Press	Disassemble and assemble track chain.
D-01087AA	Master Accessory Kit for Hydraulic Analyzer	Fittings for adjusting track adjuster relief valve.
D-01168AA	Spring Compression Tester	Test track adjuster relief valve spring.
D-01182AA	20-Ton Floor Stands	Supports the unit.
D-05227ST	Undercarriage Inspection Service Tool	Measure wear on undercarriage components.
D-15028NU	Universal Pressure Test Kit	Test oil leakage of roller and idler.
D-15041NU	Nitrogen Accumulator Charging Kit	To charge accumulator.
JD-342	Idler Bushing Plate	Remove and install bushings in rollers and idlers.
JD-345	Zerk Adapter	To adjust track adjuster relief valve.
JDG-69	Nitrogen Accumulator Holding Tool	Remove and install accumulator.
JDG-127	O-Ring Seal Tool Set	To remove O-rings.
JDG-206	Seal Installation Tool	To install metal face seals.

T28:0130 86 090382


GUIDE SPECIFICATIONS

Cap screws torque(407 N·m) 300 lb-ft



314:782824 T28:0130 206 121081


2. Cap screws torque(908 N·m) 670 lb-ft



31A:T82825 T28:0130 207 121081

GUIDE AND SLIDE SPECIFICATION


Cap screws torque(325 N·m) 240 lb-ft



31A:T82829 T28:0130 208 121081


ROLLER SPECIFICATIONS

1. Outside contact surface of
new roller185 mm (7.28 in.)
Minimum roller outside surface175 mm (6.88 in.)



31A:T87973 T28:0130 209 171182


2. Cap screws torque(576 N·m) 425 lb-ft



31A:T82858 T28:0130 210 121081

Track Systems


3. Gap between roller bracket and inside of track frame (0.25 mm) 0.010 in.



31A:T82513 T28:0130 211 121081

TRACK SHOE SPECIFICATIONS

1. Grouser bar height of new shoe (26.5 mm) 1.04 in.
Minimum grouser bar height (12.5 mm) 0.49 in.



31A:T87971 T28:0130 212 171182


2. Track shoe cap screws torque (lubricated) (300 ± 30 N·m) 220 ± 22 lb-ft plus an additional 1/3 turn.
After 75 hours of operation (569 N·m) 420 lb-ft minimum



31A:T83549 T28:0130 213 121081

TRACK CHAIN SPECIFICATIONS

1. Track link height of new chain (125.5 mm) 4.94 in.
Minimum link height (114.3 mm) 4.50 in.



31A:T87970 T28:0130 214 171182


Track Systems

- 2. Track bushing outer surface (new bushing) (71.4 mm) 2.81 in.
- Minimum bushing outer surface before turning bushings (68.3 mm) 2.69 in.




31A:782855 T28:0130 215 121081

- 3. Track pitch of new chain (A) (864.8 mm) 34.05 in.
- Maximum track pitch before turning pins and bushings (877.5 mm) 34.55 in.



31A:782866 T28:0130 216 121081


- 4. Track tension sag (A) (76 to 127 mm) 3.00 to 5.00 in.



31A:782919 T28:0130 217 121081

SPROCKET SPECIFICATION


Cap screws torque (929 ± 93 N·m)
685 ± 68 lb-ft



31A:T82561 T28:0130 218 121061

IDLER SPECIFICATION


Flange height of new idler (23.0 mm)
0.91 in.
Maximum flange height (32.8 mm)
1.29 in.



31A:T87972 T28:0130 219 171182

TRACK ADJUSTER SPECIFICATIONS

1. Plug torque (81 ± 8 N·m)
60 ± 6 lb-ft




31A:T82955 T28:0130 220 090382

Track Systems

2. Track adjuster relief valve spring


free length (46.33 ± 0.25 mm)
1.824 ± 0.010 in.

Test length at (387 ± 20 N 38.56 mm)
87 ± 4.4 lb. force 1.518 in.



31A/T83550 T28:0130 221 131081


3. Cap screws torque(407 N·m)
300 lb-ft



31A/T83551 T28:0130 222 131081


ACCUMULATOR SPECIFICATIONS

1. Socket head cap screws torque (88 ± 7 N·m)
65 ± 5 lb-ft



31A/T82994 T28:0130 223 131081


2. Valve torque(68 N·m) 50 lb-ft



31A/T82006 T28:0130 224 131081

Track Systems

3. Cap screws torque(407 N·m) 300 lb-ft




31A:T83007 T28:0130 225 131081



CAUTION: When charging accumulator, use extreme handling care and proper equipment. Follow the steps for charging accumulator used in this group.

4. The accumulator is charged with dry nitrogen gas to $(8618 \pm 172 \text{ kPa})$ $(86 \pm 1.7 \text{ bar})$ $(1250 \pm 25 \text{ psi})$ at (20°C) 68°F .




31A:T83008 T28:0130 226 090382



CAUTION: Grease in track adjuster is under extreme pressure.


6. To loosen track chain, turn ball check valve (A) one to three turns counterclockwise. DO NOT turn grease fitting to release track tension. Tighten valve when tension is adjusted properly.



31A:T82685 T28:0130 227 220981


REMOVE AND INSTALL TRACK GUIDES

1. Lower bucket to the ground.
2. Stop the engine.
3. Remove four cap screws, two on each side of track frame.




31A:T82616 T28:0130 69 180981

4. Remove eight cap screws, four on each side of track frame.




31A:T82621 T28:0130 70 180981

5. Remove inner and outer guides.




31A:T82622 T28:0130 71 180981

6. Remove two spacers.
7. Inspect parts for wear or damage; replace if necessary.




31A:T82623 T28:013 72 180981

8. Install spacers, guides, cap screws, and lock washers. Tighten eight cap screws to (407 N·m) 300 lb-ft.



31A/T82824 T31:0130 73 180981

9. Install and tighten four cap screws and lock washers to (908 N·m) 670 lb-ft.




31A/T82825 T28:0130 74 180981

REMOVE AND INSTALL TRACK GUIDES AND SLIDES

1. Turn upper structure to obtain maximum clearance over the guide and slide to be removed.
2. Lower bucket to the ground.
3. Stop the engine.

⚠ CAUTION: Grease in track adjuster is under extreme pressure.


4. Turn ball check valve assembly (A) one to three turns counterclockwise to release track tension. DO NOT turn grease fitting to release track tension.



31A/T82665 T28:0130 75 180981


Track Systems

5. Lift track with chain and hoist.
6. Put blocks under track chain.




31A:T82826 T28:0130 76 180961

7. Remove two cap screws.




31A:T82827 T31:0130 77 180961

8. Remove middle block
9. Remove guide (A), two washers (B), and slide (C).
10. Inspect guide and slide for wear or damage; replace if necessary. Slide must be replaced when track chain bushings start to touch guide.



31A:T82828 T28:0130 78 180961

11. Install slide, washers, and guides.
12. Install cap screws and lock washers. Tighten cap screws to (325 N·m) 240 lb-ft.
13. Remove blocks.
14. Adjust track tension.



31A:T82829 T28:0130 79 180961



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading


MEASURE ROLLER WEAR

1. Use D-05229ST (3048 mm) 12 in. Spring Caliper from D-052275T Undercarriage Inspection Service Tool Kit to measure track roller tread diameter.

2. Put the caliper around each roller on the tread surface and record each measurement. Roller tread diameter of a new roller is 185 mm (7.28 in.). Minimum recommended roller diameter is 175 mm (6.88 in.).

3. Under some conditions, roller wear is uneven. If this condition exists, the rollers may be exchanged with other rollers providing the sequence of single and double flanges are not changed.

NOTE: For additional information on measuring track roller tread diameter, see the UNDERCARRIAGE APPRAISAL MANUAL SP-236.




31A:T67973 T28:0130 80 171182

REMOVE TRACK ROLLERS

1. Lower bucket to the ground.

2. Stop the engine.

3. Remove two cap screws to remove track adjuster cover on side of unit from which rollers are to be removed.




31A:T92831 T28:0130 81 180981



CAUTION: Grease in track adjuster is under extreme pressure.

4. Turn ball check valve assembly (A) one to three turns counterclockwise to release track tension. DO NOT turn grease fitting to release track tension.



31A:T82655 T28:0130 82 180981

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>