

**2440 AND 2640  
TRACTORS  
(S/N -340999)**




**TECHNICAL MANUAL  
2440 AND 2640 TRACTORS  
(S/N -340999)**

TM1142 (01MAR81) English

**JOHN DEERE TRACTOR WORKS  
TM1142 (01MAR81)**

LITHO IN THE U.S.A.  
ENGLISH



**2440 AND 2640  
TRACTORS**  
(Serial No. -340999)  
**TECHNICAL MANUAL**  
**TM-1142 (Sep-75)**

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

**GENERAL 10**

**ENGINE 20**

**FUEL SYSTEM 30**

**ELECTRICAL SYSTEM 40**

**POWER TRAIN 50**

**STEERING AND BRAKES 60**


**HYDRAULIC SYSTEM 70**

**MISCELLANEOUS 80**

Copyright© 1975  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved

*Litho in U.S.A.*

## INTRODUCTION



Use FOS Manuals for Reference

This technical manual is part of a twin concept of service:

- **FOS Manuals—for reference**
- **Technical Manuals—for actual service**


The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

*Fundamentals of Service (FOS) Manuals* cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

*Technical Manuals* are concise service guides for a specific machine. Technical Manuals are on-the-job guides containing only the vital information needed by an experienced technician.



When a service person should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.




Use Technical Manuals for Actual Service

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you—an experienced technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.

 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

# Section 10 GENERAL

## CONTENTS OF THIS SECTION

	Page		Page
GROUP 5 - GENERAL TRACTOR SPECIFICATIONS (2440)	5-1	GROUP 25 - SEPARATION (2440)	
GROUP 7 - GENERAL TRACTOR SPECIFICATIONS (2640)	7-1	Separating Tractor Front End	
GROUP 10 - PREDELIVERY, DELIVERY, AND AFTER-SALE SERVICES		From Engine	25-1
Predelivery Service	10-1	Removing Engine	25-2
Delivery Service	10-4	Separating Engine From Clutch	
After-Sale Inspection	10-4	Housing	25-3
GROUP 15 - TUNE-UP		Separating Clutch Housing From	
Preliminary Engine Testing	15-1	Transmission Case	25-5
Engine Tune-Up	15-1	Removing Final Drive Assembly	25-6
Tractor Tune-Up	15-3	GROUP 27 - SEPARATION (2640)	
GROUP 20 - LUBRICATION		Separating Tractor Front End	
Lubrication Chart	20-1	From Engine	27-1
Engine Lubricating Oils	20-2	Removing Engine	27-2
Transmission Hydraulic Oils	20-2	Separating Engine From Clutch	
Greases	20-2	Housing	27-3
Storing Lubricants	20-2	Separating Clutch Housing From	
		Transmission Case	27-5
		Removing Final Drive Assembly	27-6
		GROUP 30 - SPECIFICATIONS AND SPECIAL TOOLS	
		Specifications	30-1
		Special Tools	30-1
		Torque Chart	30-2

## Group 5 GENERAL TRACTOR SPECIFICATIONS (2440)

### ENGINE

Maximum PTO horsepower*	60.65 (45.23 kW)
Number of cylinders	4
Bore and stroke	4.02 in. (102 mm) x 4.33 in. (110 mm)
Displacement	219 in. <sup>3</sup> (3590 cm <sup>3</sup> )
Compression ratio	16.8 to 1
Firing Order	1-3-4-2
Intake valve clearance	0.014-in. (0.35 mm)
Exhaust valve clearance	0.018-in. (0.46 mm)
Slow idle	800 rpm
Fast idle	2650 rpm

\*Official test at 2500 engine rpm (650 or 1210 PTO rpm)

### ELECTRICAL SYSTEM

Battery dry voltage	12 volts
Battery specific gravity at full charge (corrected to 80°F [27°C])	1.260
Battery terminal grounded	negative

### CAPACITIES

Fuel tank	19-1/2 gals. (73.8 L)
Cooling system	12 qts. (11.4 L)
Crankcase (including filter)	6 qts. (5.7 L)
Transmission-hydraulic system	10 gals. (38 L)
Belt pulley	2-1/2 pts. (0.3 L)

CLUTCH ..... Single or dual stage,  
 spring-loaded, dry  
 disk, foot-operated.

**TRANSMISSION**

Type ..... Collar shift  
 Gear selections ..... 8 forward and 4 reverse  
 Shifting ..... 4 speeds each in high, low, and reverse ranges. Park lock included.

**HI-LO SHIFT**

Hydraulic wet clutches, no clutching required. Shifting from high to low decreases ground speed 21.4 percent and increases pull power up to 27 percent in any of the transmission speeds.

**REVERSER**

Hydraulic wet clutches, no clutching required. Provides reverse speeds for gear selections 1 through 4 which are 16% faster than corresponding forward speeds.

**BRAKES** ..... Hydraulically actuated, wet-disk type.

**DIFFERENTIAL AND FINAL DRIVES**

Type ..... Planetary reduction final drives with spiral bevel gear drive differential.  
 Differential lock .... Hand or foot-operated mechanical lock, spring-loaded out of engagement.

**POWER TAKE-OFF**

Type ..... Continuous-running or independent types available in 540 and/or 1000 rpm options.

**HYDRAULIC SYSTEM**

Type ..... Closed center, constant pressure. Actuates power steering and implement control. Standby oil pressure ..... 2250 psi (15.5 mPa)

**STEERING**

TYPE ..... Hydraulically actuated, with manual provision in case of hydraulic failure.

**FRONT TIRES (Standard Equipment)\*** ..... 6.00-16

**REAR TIRES (Standard Equipment)\*** ..... 16.9-28

**DIMENSIONS**

Over-all height to top of muffler . 81.2 in. (206 cm)  
 Over-all height to top of hood ... 55.7 in. (141 cm)  
 Over-all width, min. .... 69.5 in. (177 cm)  
 Over-all length  
 (with 3-point hitch) ..... 139.5 in. (354 cm)  
 Wheelbase (straight axle) ..... 87.8 (218 cm)  
 Shipping weight (approx.) .. 4800 lbs. (2 182 kg)

*\*Additional tire sizes available.*

**GROUND SPEEDS**  
 Given in MPH (km/h) with 16.9-28  
 Rear Tires and 2500 Engine RPM

Gear	Collar Shift Transmission	Hi-Lo Shift Transmission		Ground Speed at Rated PTO SPEED (2100 RPM)			
				"Lo"		"Hi"	
		"Lo"	"Hi"	"Lo"	"Hi"	"Lo"	"Hi"
1st	1.53 (2.46)	1.20 (1.93)	1.53 (2.46)	1.01 (1.62)	1.28 (2.06)	1.83 (2.95)	2.72 (4.38)
2nd	2.18 (3.51)	1.72 (2.77)	2.18 (3.51)	1.44 (2.32)	1.83 (2.95)	2.72 (4.38)	3.80 (6.12)
3rd	3.24 (5.21)	2.55 (4.10)	3.24 (5.21)	2.14 (3.44)	2.72 (4.38)	3.80 (6.12)	5.04 (8.10)
4th	4.53 (7.28)	3.56 (5.72)	4.53 (7.28)	2.99 (4.81)	3.80 (6.12)	5.04 (8.10)	7.20 (11.57)
5th	6.00 (9.65)	4.71 (7.57)	6.00 (9.65)	3.96 (6.37)	5.04 (8.10)	7.20 (11.57)	10.68 (17.17)
6th	8.57 (13.78)	6.73 (10.82)	8.57 (13.78)	5.66 (9.09)	7.20 (11.57)	10.68 (17.17)	14.93 (24.01)
7th	12.71 (20.44)	9.99 (16.06)	12.71 (20.44)	8.39 (13.50)	10.68 (17.17)	14.93 (24.01)	1.49 (2.40)
8th	17.78 (28.59)	13.97 (22.46)	17.78 (28.59)	11.73 (18.86)	14.93 (24.01)	1.49 (2.40)	2.13 (3.43)
R1	1.78 (2.86)	1.40 (2.25)	1.78 (2.86)	1.17 (1.88)	1.49 (2.40)	2.13 (3.43)	3.16 (5.09)
R2	2.54 (4.08)	1.99 (3.20)	2.54 (4.08)	1.67 (2.69)	2.13 (3.43)	3.16 (5.09)	4.42 (7.11)
R3	3.77 (6.06)	2.96 (4.76)	3.77 (6.06)	2.48 (4.00)	3.16 (5.09)	4.42 (7.11)	
R4	5.26 (8.46)	4.14 (6.66)	5.26 (8.46)	3.47 (5.59)	4.42 (7.11)		

# Group 7 GENERAL TRACTOR SPECIFICATIONS (2640)

## ENGINE

Maximum PTO HORSEPOWER\* 70.0 (52.2 kW)  
Nuner of cylinders ..... 4  
Bore and stroke, inches (cm) ..... 4.19 x 5.00  
(10.65 x 12.70)  
Displacement - cubic inches  
(cubic centimeters) ..... 276 (4416)  
Compression ratio ..... 16.2 to 1  
Firing order ..... 1-3-4-2  
Intake valve clearance ..... 0.014-in. (0.36 mm)  
Exhaust valve clearance .... 0.018-in. (0.46 mm)  
Slow idle ..... 800 rpm  
Fast idle ..... 2650 rpm  
Transport speed (foot throttle) ..... 2800 rpm

## ELECTRICAL SYSTEM

Battery dry voltage ..... 12 volts  
Battery specific gravity at full charge  
(corrected to 80°F [27°C]) ..... 1.260  
Battery terminal grounded ..... negative

## CAPACITIES (U.S. Standard Measures)

Fuel tank ..... 19-1/2 gals. (73.8 L)  
Cooling system ..... 12 qts. (11.4 L)  
Crankcase (including filter) ..... 9 qts. (8.5 L)  
Transmission-hydraulic system .... 10 gals. (38 L)  
Belt pulley ..... 2-1/2 pts. (0.3 L)

CLUTCH ..... Single or dual stage,  
spring-loaded, dry  
disk, foot-operated.

## TRANSMISSION

Type ..... Collar Shift  
Gear selections ..... 8 forward and 4 reverse  
Shifting ..... 4 speeds each in high, low,  
and reverse ranges. Park  
lock included.

## HI-LO SHIFT

Hydraulic wet clutches, no clutching required.  
Shifting from high to low decreases ground speed  
21.4 percent and increases pull power up to 27 per-  
cent in any of the transmission speeds.

\*Factory observed at 2500 engine rpm (650 or 1210  
PTO rpm).

## REVERSER

Hydraulic wet clutches, no clutching required.  
Provides reverse speeds for gear selections 1  
through 4 which are 16% faster than corresponding  
forward speeds.

BRAKES ..... Hydraulically actuated, wet-  
disk type.

## DIFFERENTIAL AND FINAL DRIVES

Type ..... Planetary reduction final  
drives with spiral bevel gear  
drive differential.  
Differential lock .... Hand or foot-operated me-  
chanical lock, spring-loaded  
out of engagement.

## POWER TAKE-OFF

Type ..... Continuous-running or inde-  
pendent types available in  
540 or 540/1000 rpm op-  
tions.

## HYDRAULIC SYSTEM

Type ..... Closed center, constant pressure.  
Actuates power steering and implement control.  
Standby oil pressure ..... 2250 psi (15.5 mPa)

## STEERING

TYPE ..... Hydraulically actuated, with  
manual provision in case of  
hydraulic failure.

FRONT TIRES (Standard Equipment)\* ..... 6.00-16

REAR TIRES (Standard Equipment)\* ..... 16.9-28

## DIMENSIONS

Over-all height to top of muffler . 81.2 in. (206 cm)  
Over-all height to top of hood . 55.7 in. (141.5 cm)  
Over-all width, min. .... 69.5 in. (176.5 cm)  
Over-all length  
(with 3-point hitch) ..... 139.5 in. (354 cm)  
Wheelbase (straight axle) ..... 87.8 in. (21.8 m)  
Shipping weight (approx.) ... 5100 lbs. (2313 kg)

\*Additional tire sizes available.

**GROUND SPEEDS**  
 Given in MPH (Km/h) With 16.9-28  
 Rear Tires and 2500 Engine RPM

Gear	Collar Shift Transmission		Hi-Lo Shift Transmission		Ground Speed at Rated PTO SPEED (2100 RPM)					
					"Lo"		"Hi"			
1st .....	1.56	(2.50)	1.23	(1.98)	1.56	(2.50)	1.03	(1.66)	1.31	(2.10)
2nd .....	2.23	(3.58)	1.75	(2.81)	2.23	(3.58)	1.47	(2.36)	1.87	(3.00)
3rd .....	3.30	(5.30)	2.60	(4.17)	3.30	(5.30)	2.18	(3.50)	2.78	(4.45)
4th .....	4.62	(7.41)	3.63	(5.83)	4.62	(7.41)	3.05	(4.89)	3.88	(6.23)
5th .....	5.49	(8.82)	4.32	(6.93)	5.49	(8.82)	3.63	(5.82)	4.61	(7.41)
6th .....	7.85	(12.61)	6.17	(9.91)	7.85	(12.61)	5.18	(8.32)	6.60	(10.59)
7th .....	11.64	(18.67)	9.16	(14.70)	11.64	(18.67)	7.69	(12.35)	9.77	(15.69)
8th .....	16.28	(26.14)	12.79	(20.52)	16.28	(26.14)	10.74	(17.24)	13.68	(21.96)
R1 .....	1.81	(2.91)	1.42	(2.28)	1.81	(2.91)				
R2 .....	2.59	(4.15)	2.03	(3.26)	2.59	(4.15)				
R3 .....	3.84	(6.16)	3.02	(4.84)	3.84	(6.16)				
R4 .....	5.37	(8.62)	4.22	(6.77)	5.37	(8.62)				

# Group 10

## PREDELIVERY, DELIVERY, AND AFTER-SALE SERVICES

### PREDELIVERY SERVICE

Because of the shipping factors involved, plus extra finishing touches that are necessary to promote customer satisfaction, proper predelivery service is of prime importance to the dealer.

A tag pointing out the factory-recommended procedure for predelivery service is attached to each new tractor before it leaves the factory.

After completing the factory-recommended dealer checks and services listed on the predelivery tag, remove the tag from the tractor and file it with the shop order for the job. The tag will certify that the tractor has received the proper predelivery service when that portion of the customer's John Deere Delivery Receipt is completed.

### Temporary Tractor Storage

Service	Specification	Reference
Check radiator for coolant loss and antifreeze protection .....	Midway between core and filler neck .....	
Remove and store batteries .....	Store at room temperature .....	
Reduce shipping pressure of tires .....		Operator's manual
Cover tractor and tires for protection and cleanliness .....		

### Before Delivering Tractor

#### Electrical System

Remove resistor and connect wiring lead (red) to alternator output terminal. Do not attempt to polarize alternator .....		Section 40, Group 10
Charge batteries. Check electrolyte level and specific gravity .....		FOS-20 Manual
Check battery terminal connections .....		Section 40, Group 5
Check alternator belt tension .....	3/4-inch (1.9 cm) deflection, 20 lb. (104 N) force .....	Operator's manual
Check light operation and adjustment. Remove flasher if required by local government regulations .....		Operator's manual

Service

Specification

Reference

**Before Delivering Tractor—Continued**

**Cooling System**

Inspect radiator for coolant loss .....	Midway between core and filler neck .....	
Check antifreeze protection .....		

**Tires and Wheels**

Adjust pressure of tires .....		Operator's manual
Check front wheel hub bolts, rear wheel rim clamp nuts, and rear wheel cap screws for tightness .....	Front hub bolts-100 ft-lbs (135 Nm) torque Rear hub bolts-300 ft-lbs (407 Nm) torque Rim clamp nuts-170 ft-lbs (230 Nm) torque Rear wheel-to-flanged axle— 130 ft-lbs (176 Nm) torque .....	Operator's manual

**Lubrication**

Check crankcase oil level .....	To upper marks on dipstick .....	Operator's manual
Check transmission-hydraulic system oil level .....	To top of "SAFE" range on dip- stick. Hy-GARD Oil .....	Operator's manual
Lubricate grease fittings .....	John Deere Multi-purpose Lubricant .....	Operator's manual
Check belt pulley oil level (if so equipped) .....		Operator's manual

**Engine**

Check air intake system—air cleaner and hose connections .....		Operator's manual
Drain sediment from fuel filter .....		Operator's manual
Fill fuel tank and start engine .....	19-1/2 U.S. gallons (73.8 liters) .....	Operator's manual
Check operation of starter, alternator, flashers, gauges, and indicator lights .....		Operator's manual
Check engine timing .....	TDC .....	Operator's manual
Check speed control and fuel shut-off linkages for free operation and adjustment .....		Section 30, Group 20

Service	Specification	Reference
<b>Before Delivering Tractor—Continued</b>		
Check engine speeds .....	Slow idle, 800 rpm High idle, 2650 rpm Foot throttle, 2800 rpm .....	Section 30, Group 20
<b>Operation</b>		
Check transmission clutch free travel (tractors without reverser) .....	Approximately 1-inch (2.54 cm) free pedal travel .....	Operator's manual
Check clutch wear adjustment (tractors with reverser) .....	5-1/4 in. (13.34 cm) from engine flange .....	Operator's manual
Shift transmission through all speeds .....		Operator's manual
Check power takeoff operation .....		Operator's manual
Check differential lock operation .....		Operator's manual
Check steering operation .....		Operator's manual
Check brakes .....	Bleed brakes if spongy, check for excessive pedal travel, and even position .....	Operator's manual
Check hydraulic system operation: Rockshaft, and remote cylinder .....		Operator's manual
Check 3-point hitch operation .....		Operator's manual
Check negative stop screw adjustment		
Tractors without independent PTO .....	1/4 turn .....	Section 70, Group 30
Tractors with Independent PTO .....	1/3 turn .....	Section 70, Group 30
Check operation of reverser, or Hi-Lo Shift .....		Operator's manual
Check seat operation .....		Operator's manual
<b>General</b>		
Check Roll-Gard Mounting bolts for correct torque .....	300 ft-lbs (407 Nm) .....	Section 10, Group 30
Check front axle-to-knee bolts for correct torque .....	300 ft-lbs (407 Nm) .....	Section 80, Group 5

**10 Before Delivering Tractor—Continued**

Service	Specifications	Source
Tighten accessible nuts and cap screws .....		
Clean tractor and touch up paint .....		
Remove covering from SCV emblem .....		

**DELIVERY SERVICE**

A thorough discussion of the operation and service of a new tractor at the time of delivery helps to assure complete customer satisfaction. Proper delivery should be an important phase of a dealer's program. A portion of the John Deere Delivery Receipt emphasizes the importance of proper delivery service.

It is a well-known fact that many complaints have arisen simply because the owner was not shown how to operate and service the new tractor properly. Enough time should be devoted, at the customer's convenience, to introducing the new tractor to the owner and explaining how to operate and service it.

The following procedure is recommended before the service technician and owner complete the delivery acknowledgments portion of the delivery receipt.

Using the tractor operator's manual as a guide, be sure that the owner understands these points thoroughly:

1. Controls and Instruments.
2. How to start and stop the engine.
3. The importance of the break-in period.
4. How to use liquid or cast-iron ballast.
5. all functions of the hydraulic system.
6. Using the power takeoff and belt pulley.
7. The importance of safety.
8. The importance of lubrication and periodic services

After explaining and demonstrating the above features, have the owner sign the delivery receipt and give the operator's manual to the owner.

**AFTER-SALE INSPECTION**

The purchaser of a new John Deere tractor is entitled to a free inspection within the warranty period after the equipment has been "run in." The terms of this after-sale inspection are outlined on the back of the John Deere Delivery Receipt.

The purpose of this inspection is to make sure that the customer is receiving satisfactory performance from the tractor. At the same time, the inspection should reveal whether or not the tractor is being operated, lubricated, and serviced properly.

If the recommended after-sale service inspection is followed, the dealer can eliminate a needless volume of service work by preventing minor irregularities from developing into serious problems later on. This will promote strong dealer-customer relations and present the dealer an opportunity to answer questions that may have arisen during the first few days of operation. During the inspection service, the dealer has the further opportunity of promoting the possible sale of other new equipment.

The following inspection program is recommended within the first 100 hours of tractor operation.

**Inspection Procedure**

Service	Specification	Reference
<b>Cooling System</b>		
Check radiator coolant level .....	Midway between core and filler neck .....	

**Inspection Procedure—Continued**

Service	Specification	Reference
Clean external surface of radiator core .....		
Check hoses and connections for leaks .....		
<b>Fuel System</b>		
Remove water and foreign matter from filter sediment bowl .....		Operator's manual
Bleed fuel system .....		Operator's manual
Tighten loose connections and check entire system for leaks. Correct if necessary .....		
Check air cleaner element and unloading valve. Clean element if necessary .....		Operator's manual
<b>Electrical System</b>		
Check specific gravity of battery(s) .....	Full charge - 1.260 at 80°F (27°C) ..	Operator's manual
Check level of battery electrolyte .....	To bottom of filler neck in each cell .....	Operator's manual
Check belt tension .....	3/4-inch (19.1 mm) deflection with a 20 lb. (104 N) force .....	Operator's manual
Start engine and check operation of starter, lights, and indicator lamps .....		Operator's manual
<b>Lubrication</b>		
Check crankcase oil level .....	To upper marks on dipstick .....	Operator's manual
Check transmission-hydraulic system oil level .....	In "SAFE" range on dipstick. Use John Deere Hy-GARD .....	Operator's manual
<b>Engine</b>		
Check valve clearance (static) .....	Intake: 0.014 in. (0.35 mm) Exhaust: 0.018 in. (0.46 mm) .....	Operator's manual

**10 Inspection Procedure—Continued**

Service	Specification	Reference
Check engine speed (under load), and horsepower .....	Specification .....	Group 15 of this Section.

**Operation**

Check transmission clutch free travel (tractors without reverser) .....	Approximately 1-inch (2.54 cm) free pedal travel .....	Operator's manual
Check clutch wear adjustment (tractors with reverser) .....	5-1/4 in. (13.34 cm) from pedal to rear of engine flange .....	Operator's manual
Shift transmission through all speeds .....		Operator's manual
Check Reverser, Hi-Lo operation .....		Operator's manual
Check Power Take-Off operation .....		Section 50, Groups 35, 40 and 42
Check differential lock operation .....		Operator's manual
Check rockshaft and remote cylinder operation .....		Section 70, Group 30
Check negative stop screw adjustment		
Tractors without Independent PTO .....	1/4 turn .....	Section 70, Group 30
Tractors with Independent PTO .....	1/3 turn .....	Section 70, Group 30
Check steering system operation .....	Smooth, without excessive freeplay .....	Section 70, Group 20
Check brakes .....	Bleed brakes if spongy, check for excessive pedal travel, and even position .....	Section 70, Group 25

**Nuts and Cap Screws**

Tighten accessible nuts and cap screws that require adjustment .....		
--	--	--

# Group 15 TUNE-UP

## GENERAL INFORMATION

Before tuning up a tractor, determine whether a tune-up will restore operating efficiency. When there is doubt, the following preliminary tests will help to determine if the engine can be tuned-up.

If the condition is satisfactory, proceed with the tune-up. Choose from the following procedures only those necessary to restore the unit.

### Preliminary Engine Testing

Operation	Specification	Section-Group Reference
Dynamometer Test (at 2500 engine rpm, full load—650 or 1210 PTO rpm)	Compare with previous recorded output; compare with output after tune-up	FOS 30 Manual, Chapter 12
Compression Test	300 psi (2067 kPa) at full cranking speed	FOS 30 Manual
Engine Coolant Check Test	No air bubbles or oil film in radiator	FOS 30 Manual, Chapter 12

### Engine Tune-Up

Operation	Specification	Section-Group Reference
<b>Air Intake System</b>		
Service air cleaner and check system for leaks		FOS 30 Manual, Chapter 12
Check system for restrictions using water manometer		
Normal reading with clean filter element (inches of water)	3-12 inches (8.89 cm)	FOS 30 Manual, Chapter 12
Maximum permitted reading	25 in. (63.5 cm) at 2500 rpm (full load)	FOS 30 Manual, Chapter 12
<b>Exhaust System</b>		
Check system for leaks		FOS 30 Manual, Chapter 12
Check muffler and exhaust pipe for restrictions		FOS 30 Manual, Chapter 12

10 Engine Tune-Up—Continued

Operation	Specification	Section-Group Reference	
		(2440)	(2640)
<b>Crankcase Ventilating System</b>			
Check system for restrictions .....		FOS 30 Manual, Chapter 12	
<b>Cooling System</b>			
Clean grille screen, radiator core, and oil cooler core .....		20-35	20-35
Clean and flush system; check thermostat opening temperature, if necessary .....		20-35	20-35
Check pressure cap .....	6.25 to 7.50 psi (43 to 52 kPa)		
	release pressure .....	20-35	20-35
<b>Cylinder Head and Valves</b>			
Torque cylinder head cap screws .....	110 ft-lbs (149 Nm) in sequence .....	20-10	20-12
Set valve clearance .....	Intake-0.014 inch (0.36 mm)		
	Exhaust-0.018 inch (0.46 mm) .....	20-10	20-12
<b>Fuel System</b>			
Check fuel tank for water or other foreign material .....			
Check fuel pump pressure .....	3-1/2 to 4-1/2 psi (24 to 31 kPa) ..	30-15	30-15
Change filter .....		30-15	30-15
Injection Pump:			
Service and check timing .....	TDC .....	30-15	30-15
	4° advance at 1100 rpm (2440) and 1200 rpm (2640) (no load) .....	30-15	30-15
Adjust speed control linkage .....	Foot throttle - 2800 rpm		
	Hand throttle		
	High idle - 2650 rpm		
	Slow idle - 800 rpm .....	30-20	30-20
<b>Lubrication System</b>			
Check engine oil pressure .....	45 to 65 psi (317 to 448 kPa)		
	at high idle .....	20-30	20-32
<b>Charging System</b>			
Check battery specific gravity .....	1.240 to 1.260 .....	40-10	40-10
Check battery water consumption and electrolyte level .....		40-10	40-10
Clean battery, cables, and box .....		40-10	40-10
Check alternator belt tension .....	20 lb. (104 N) with 3/4 in. (19.1 mm) belt deflection .....	40-10	40-10
Check alternator output .....	25 amps at 13 to 15 volts (2052 engine rpm, 3000 alternator rpm) ..	40-10	40-10
Check alternator regulated voltage .....	13.8 to 14.3 volts (operating) .....	40-10	40-10
<b>Starting System</b>			
Check neutral start switch operation .....			
Check battery voltage when starting .....	Min. 9 volts (cranking) .....	40-15	40-15
Check starter current draw .....	Approx. 400 amps .....	40-15	40-15
Check operation of alternator and oil pressure indicator lights .....		40-25	40-25

## Final Engine Test

Operation	Specification	Section-Group Reference
Dynamometer .....	Compare with previous recorded output. Record for future use.	FOS 30 Manual, Chapter 12

## Tractor Tune-Up

Operation	Specification	Section-Group Reference	
		(2440)	(2640)
Adjust transmission clutch pedal free travel			
Tractors without reverser .....	1 inch (2.54 cm) .....	50-5	50-5
Tractors with reverser .....	5-1/4 inches (13.34 cm) from rear of engine flange .....	50-5	50-5
Check transmission shifting .....		50-20	50-20
Check transmission for proper operation without excessive noise .....		50-20	50-20
Check Hi-Lo reverser operation .....		50-10&15	50-10&15
Check power take off for proper operation .....		50-35&40	50-35&42
Check differential lock operation .....		50-25	50-25
Check brake pedal travel and position .....	Bleed brakes if spongy .....	70-25	70-25
Check front wheel bearing adjustment and lubrication .....	35 ft-lbs (47 Nm) torque; back off to nearest hole .....		
Check front wheel toe-in .....	1/8 to 3/8 in. (3.2 to 9.5 mm) .....		
Check tire inflation .....	See operator's manual .....		
Transmission pump .....	6 gpm (0.38 l/s) at 2500 rpm .....	70-15	70-15
Main hydraulic pump .....	2200 to 2300 psi (15.2 to 15.8 mPa) standby; 13 gpm (0.82 l/s) or 23 gpm (1.45 l/s) .....	70-15	70-15
Pressure control valve .....	1700 to 1800 psi (11.7 to 12.4 mPa) at 1900 engine rpm .....	70-10	70-10
Rockshaft lift cycle time (60 degrees rotation) .....	1.5 to 1.6 seconds at 2100 rpm .....	70-30	70-30
Check selective control valve and remove cylinder cycle time .....	Remote cylinder (2.5 x 8 in. [6.35 x 14.35 cm] extends in 1.5 to 2.0 sec. ...	70-35	70-35

*Hydraulic system pressures and flow rates are for conditions specified in Section 70 (tractor at operating temperature, transmission-hydraulic oil at correct temperature, proper test equipment, correct test sequence, etc.)*

# Group 20 LUBRICATION

## GENERAL INFORMATION

Carefully written and illustrated lubrication instructions are included in the operator's manual furnished with your customer's machine. Remind the customer to follow these instructions.

For your convenience, the following chart shows capacities and types of lubricants for the tractor components and systems. Specifications for lubricants follow the chart.

Item	Capacity	Type of Lubricant	Interval of Service
Engine crankcase	6 U.S. quarts (5.7 l) (2440) 9 U.S. quarts (8.5 l) (2640) (in- cluding filter)	See page 20-2	10 Hours—Check 100 Hours—Drain and re- fill. 200 Hours—Change filter
Transmission and hy- draulic system	10 U.S. gals. (37.85 l)	Hy-GARD Oil (or its equivalent)	50 Hours—Check 50 Hours—Change filter (end of initial break-in) 500 Hours—Change filter 1000 Hours—Drain and re- fill. Clean screen.
Belt pulley	2-1/2 pts. (1.18 l)	Hy-GARD Oil (or its equivalent) or SAE 80 multipurpose lubricant	200 Hours—Check 500 Hours—Drain, flush and refill
Grease fittings	.....	John Deere Multi- Purpose Lubricant or its equivalent	See Operator's Manual
Starter	Saturate wicks	SAE 10W engine crankcase oil	1000 Hours
	Lubricate armature shaft splines during assembly	SAE 10W engine crankcase oil	.....

## LUBRICANTS

### Engine Lubricating Oils



X3377N

We recommend John Deere Torq-Gard Supreme Engine Oil for use in the engine crankcase. Torq-Gard Supreme is compounded specifically for use in John Deere engines and provides superior lubrication under all conditions. NEVER PUT ADDITIVES IN THE CRANKCASE. Torq-Gard Supreme Oil was formulated to provide all the protection your engine needs. Additives could reduce this protection rather than help it.

If Torq-Gard Supreme is not used, use an engine oil that conforms to one of the following specifications:

#### SINGLE VISCOSITY OILS

API Service CD/SD  
MIL-L-2104C  
Series 3\*

#### MULTI-VISCOSITY OILS

API Service CC/SE, CC/SD, or SD  
MIL-L-46152

*\*As further assurance of quality, the oil should also be identified as suitable for API service designation SD.*

Depending on the expected prevailing temperature for the fill period, use oil of viscosity as shown in the following chart.

Some increase in oil consumption may be expected when SAE 5W-20 or SAE 5W oils are used. Check oil level more frequently.

Air Temperature	John Deere Torq-Gard Oil	Other Oils	
		Single Viscosity Oil	Multi-Viscosity Oil
Above 32°F (0°C)	SAE 30	SAE 30	Not recommended
-10°F to 32°F (-19°C to 0°C)**	SAE 10W-20	SAE 10W	SAE 10W-30
Below -10°F (-19°C)	SAE 5W-20	SAE 5W	SAE 5W-20

*\*\*SAE 5W-20 oil may be used where required to insure optimum lubrication at starting, particularly for an engine subjected to -10°F (-19°C) or lower for several hours.*

### Transmission Hydraulic Oils

Use only John Deere Hy-GARD Transmission and Hydraulic Oil or its equivalent in the transmission hydraulic system. Other types of oil will not give satisfactory service and may result in eventual damage. This special oil, available from your John Deere dealer, may be used in all weather conditions.

*NOTE: John Deere Hy-GARD Transmission and Hydraulic Oil may be added to or mixed with John Deere Type 303 Special-Purpose Oil.*

### Greases

John Deere Multi-Purpose Lubricant or an equivalent SAE Multipurpose-type grease is recommended for grease fittings. Application of grease as instructed in the lubrication section of the Operator's Manual will provide proper lubrication and will keep contamination out of bearings.

### Storing Lubricants

A tractor can operate at top efficiency only if clean lubricants are used. Use clean containers to handle all lubricants. Store them in an area protected from dust, moisture, and other contamination.

## Group 25 SEPARATION (2440)

10

### SEPARATING TRACTOR FRONT END FROM ENGINE

Remove battery door from cowling. Remove right-hand or left-hand cowl. Disconnect negative battery cable from both batteries.

Remove side grille screen, muffler, hood, and front ballast (if so equipped).

Drain cooling system. Shut off fuel at fuel cock underneath fuel tank.

Wedge a block on each side between the front support and the axle.




Fig. 1-Left-Hand Removal Procedures

Refer to Fig. 1 for left-hand removal procedures.

1. Remove air intake hose from air intake pipe.
2. Remove upper and lower radiator hoses.
3. Disconnect the fuel leak-off pipe.
4. Disconnect front end of drag link from steering mechanism.




Fig. 2-Right-Hand Removal Procedure

Refer to Fig. 2 for right-hand removal procedures.

5. Remove tool box (if so equipped). Remove side frames from tractor.
6. Remove fuel inlet line from fuel pump.
7. Remove fuel pump from engine block.
8. Remove hydraulic oil pipe clamps from pipes.
9. Disconnect hydraulic oil lines underneath and directly behind the radiator. Disconnect hydraulic pump pressure pipe at connector.
10. Remove oil filler spout from front of engine block.
11. Disconnect and remove hydraulic pump drive coupling.
12. Disconnect fuel tank indicator wire.
13. Disconnect hydraulic reservoir vent hose and remove it from underneath the foam insulation piece.

Install JDG-9 in side frame holes of front support (Fig. 3). Adjust stand to be tight against floor.


## 10 SEPARATING TRACTOR FRONT END FROM ENGINE—Continued

*NOTE: A hydraulic pump check valve is located in clutch housing pump inlet pipe bore. Do not lose these parts.*

**CAUTION:** Place a hydraulic floor jack or floor support under clutch housing or transmission case. Be sure wooden blocks are positioned between front support and front axle before separation is made. Tractor will roll sideways without blocks.

Install JD-244 Lifting Eyes on engine. Using an overhead hoist, attach JDG-1 Engine Lift Sling to JD-244 Lifting Eyes to support engine (Fig. 12).

Remove the six engine-to-front support cap screws.



A—Block of Wood

Fig. 3-Front End Separated from Engine

Carefully separate tractor front end by rolling rear section away from front end (Fig. 3). Place a metal stand under clutch housing. Install caplugs.

### ASSEMBLY

**IMPORTANT:** Be sure hydraulic pump check valve (tractors without Hi-Lo or reverser) is installed in the pump inlet pipe before joining sections. Remove caplugs.

Join sections. Tighten bolts and cap screws to specified torque (Section 10, page 30-1). Remove JDG-1 Lift Sling, and JD-244 Lifting Eyes.


Reverse the numbered removal steps. Use new gaskets on oil filler spout (step 10) and fuel pump (step 7).

Install battery, side grille screens, hood, muffler, and front ballast (if used). Fill cooling system.

Start engine and check operation.

### REMOVING ENGINE

Remove the front end from tractor as explained in SEPARATING TRACTOR FRONT END FROM ENGINE.



A—Support Stand

Fig. 4-Left-Hand Removal Procedure

1. Disconnect temperature gauge sensing bulb from engine.
2. Disconnect speed control rod.
3. Disconnect and remove fuel shut-off rod.




Fig. 5-Right-Hand Removal Procedure

4. Disconnect wiring harness from oil pressure sensing unit, the fuel indicator connector, the two terminals on the starter solenoid, and three terminals on rear of alternator. Pull harness rearward until it is free from engine block and fuel filter.

5. Disconnect speed-hour meter drive from fly-wheel housing.

6. Remove hydraulic reservoir vent hose from support clamp and pull rearward until it is free from the engine.

7. Remove cowl-to-flywheel housing cap screws.

Place a hydraulic floor jack or a support stand under the clutch housing or transmission case. Remove the engine-to-clutch housing cap screws. Separate engine from clutch housing.

### ASSEMBLY

Join engine to clutch housing. Reverse removal procedure.

Tighten cap screws to specified torque (Section 10, page 30-1). To complete installation, refer to instructions for assembly given under SEPARATING TRACTOR FRONT END FROM ENGINE.

## SEPARATING ENGINE FROM CLUTCH HOUSING

Remove battery door on top of cowl. Disconnect battery ground cable(s) at terminals. Remove right-hand cowl from tractor. Remove muffler, hood, grille screens, and front ballast (if used). Remove both batteries. Drain cooling system.




Fig. 6-Left-Hand Removal Procedure

1. Remove tool box from right side frame (if so equipped) and remove both right-hand and left-hand side frames.

2. Disconnect drag link at front from steering mechanism.

3. Disconnect temperature gauge sensing bulb from engine.

4. Disconnect speed control rod at rear. Disconnect and remove fuel shut-off rod.




Fig. 7-Right-Hand Removal Procedure

5. Disconnect hydraulic oil reservoir vent hose from top of reservoir. Remove vent hose from support clamp and pull hose rearward until it can be positioned so it is free from engine.

6. Disconnect hydraulic pump pressure oil pipe at connector. Remove retaining clamp from pump inlet and reservoir return pipes. Disconnect power steering pressure line.

7. Disconnect wiring harness at oil pressure sensing switch, starter solenoid, rear of alternator, and fuel tank indicator wire. Pull the wiring harness rearward until it can be freed from engine and fuel filter housing.

8. Remove the two cowl-to-flywheel housing cap screws.

9. Disconnect tachometer at clutch housing and at tachometer and pull cable from clutch housing.


**CAUTION:** Install a wood block between front axle and engine front support on both sides of tractor to prevent assembly from tipping (A, Fig. 8).

If not already done so, install the JDG-9 Support Stand in rear engine flange side frame holes. Adjust wheel of support stand tightly against floor.

Place a container under the rear portion of clutch housing to catch the hydraulic oil from the pump inlet pipe and the cooler return pipe, when the tractor is separated.

**IMPORTANT:** Do not lose check valve assembly (tractors without Hi-Lo or reverser) in end of hydraulic pump inlet pipe when separation is made. Install caplugs on hydraulic pipes and fittings to prevent entry of foreign material.

10. Remove clutch housing-to-engine flange cap screws.



A—Block of Wood

Fig. 8-Front End After Separation  
(Tractor with Reverser)

Roll front section of tractor away from clutch housing (Fig. 8).

## ASSEMBLY

Remove caplugs and join engine and clutch housing. Reverse the numbered removal steps. Remove JDG-9 Support Stand and floor jack. Tighten cap screws to 170 ft-lbs (230 Nm) torque.

Install battery, side grille screens, hood, muffler, and cowl. Start engine, inspect for leaks, and check operation.

## SEPARATING CLUTCH HOUSING FROM TRANSMISSION CASE

Drain the transmission (remove both drain plugs). Remove the hydraulic oil filter cover and element.

Remove the drawbar from tractor.

Disconnect the clutch return spring. Remove the left-hand and right-hand footrests. Remove the transmission shield.




Fig. 9-Left-Hand Separation Procedures

1. Disconnect wiring harness from neutral start switch and light switch (Fig. 4).




Fig. 10-Right-Hand Separation Procedures

2. Disconnect hydraulic oil reservoir vent hose (Fig. 5). Disconnect mid couplers (if equipped).


3. Remove control valve cover, and remove shift cover cap screws (tractors with Hi-Lo shift). Remove shift cover from clutch housing. Inside the clutch housing, remove the two clutch housing-to-transmission case cap screws, and the gear shifter lever guide spring.

4. Disconnect brake pipes from brake valve housing, and disconnect pressure pipe at pressure control valve.

Install JDG-9 Support Stand on flywheel housing.

**CAUTION:** Install a wood block between front axle and front support on both sides of tractor to prevent assembly from tipping (A, Fig. 11).

Place floor jack under transmission case.



A—Block of Wood

Fig. 11-Front End After Separation

Remove the clutch housing-to-transmission case cap screws, and roll front end away from transmission case (Fig. 11). Install caplugs.

## ASSEMBLY

Install a new clutch housing-to-transmission case gasket and new rubber packings. Remove caplugs.

**IMPORTANT:** If tractor has a mid-PTO, be sure spring and ball are inserted in PTO drive shaft before joining units.

## ASSEMBLY—Continued

Join front and rear units. Reverse the numbered separation steps. Tighten cap screws to specified torque (Section 10, Group 30).

Install the transmission shield, footrests, clutch return spring, and drawbar.

Install hydraulic oil filter element and cover. Fill transmission to proper level.

Remove JDG-9 Support Stand, floor jack, and wood blocks.

## REMOVING FINAL DRIVE ASSEMBLY

Drain the transmission case at both plugs. Disconnect battery ground straps at negative terminals of the batteries.




Fig. 12-Final Drive Removal Procedure

When right-hand axle housing is to be removed, first remove the selective control valve.

1. Disconnect wiring harness from lights, fender, and axle housing. Pull harness free of axle housing.

2. Remove footrest and extension. Release tension on clutch pedal spring before removing footrest completely. Disconnect hydraulic brake line.

3. Remove outside long bolts so that fender may be removed. (It will be more convenient to remove tractor tire before removing fender, or position tire at widest position.)

4. Remove inside bolts attaching Roll-Gard to axle housing and remove Roll-Gard.

5. Place floor jack or support stand under transmission case. Remove tire (if not already done). Remove cap screws securing axle housing. Wrap chain around axle housing toward inner end. Remove axle housing from transmission case.




Fig. 13-Final Drive Housing Removed

## ASSEMBLY

Install a new gasket on transmission case. Be sure brake disk is properly positioned on final drive shaft.

Join axle housing to transmission case. Tighten cap screws to specified torque. Remove capplugs.

Reverse the removal steps. Fill transmission with oil to the proper level.

Start engine and check operation.

## Group 27 SEPARATION (2640)

10

### SEPARATING TRACTOR FRONT END FROM ENGINE

Remove battery door from cowling. Remove right-hand or left-hand cowl. Disconnect negative battery cable from both batteries.

Remove side grille screen, muffler, hood, and front ballast (if so equipped).

Drain cooling system. Shut off fuel at fuel cock underneath fuel tank.

Wedge a block on each side between the front support and the axle.




Fig. 1-Left-Hand Removal Procedures

Refer to Fig. 1 for left-hand removal procedure.

1. Remove air intake hose from air intake pipe.
2. Remove upper and lower radiator hoses.
3. Disconnect the fuel leak-off pipe.
4. Disconnect front end of drag link from steering mechanism.




Fig. 2-Right-Hand Removal Procedures

Refer to Fig. 2 for right-hand removal procedures.

5. Remove toolbox (if so equipped). Remove side frames from tractor.
6. Remove fuel inlet line from fuel pump.
7. Remove top engine oil cooler hose.
8. Remove hydraulic oil pipe clamps from pipes.
9. Disconnect hydraulic oil lines underneath and directly behind the radiator. Disconnect hydraulic pump pressure pipe at connector.
10. Remove oil filler spout from front of engine block.
11. Disconnect and remove hydraulic pump drive coupling.
12. Disconnect fuel tank indicator wire.
13. Disconnect hydraulic reservoir vent hose and remove it from underneath the foam insulation piece.

Install JDG-9 Support Stand in side frame holes of front support (Fig. 3). Adjust stand to be tight against floor.

## SEPARATING TRACTOR FRONT END FROM ENGINE—Continued

*NOTE: A hydraulic pump check valve is located in clutch housing pump inlet pipe bore on units without Hi-Lo. Do not lose these parts.*

**CAUTION:** Place a hydraulic floor jack or floor support under clutch housing or transmission case. Be sure wooden blocks are positioned between front support and front axle before separation is made. Tractor will roll sideways without blocks.

Install JD-244 Lifting Eyes on engine. Using an overhead hoist, attach JDG-1 Engine Lift Sling to JD-244 Lifting Eyes to support engine (Fig. 12).

Remove the six engine-to-front support cap screws.




Fig. 3—Tractor Front End Separated from Engine

Carefully separate the tractor front end from the engine by rolling the front end forward (Fig. 3).

## ASSEMBLY

**IMPORTANT:** Be sure hydraulic pump check valve (tractors without Hi-Lo or reverser) is installed in the pump inlet pipe before joining sections. Remove caplugs.


Join sections. Tighten bolts and cap screws to specified torque (Section 10, Group 30). Remove lift sling and lifting eyes. Remove support stands.

After reversing the removal steps, install muffler, hood, side grille screens, batteries, cowls, and front ballast (if used).

Fill the cooling system, start engine, and check operation.

## REMOVING ENGINE

Remove the front end from tractor as explained in SEPARATING TRACTOR FRONT END FROM ENGINE.



A—Support Stand

Fig. 4—Left-Hand Removal Procedure

1. Disconnect temperature gauge sensing bulb from engine.
2. Disconnect speed control rod.
3. Disconnect and remove fuel shut-off rod.




Fig. 5-Right-Hand Removal Procedure

4. Disconnect wiring harness from oil pressure sensing unit, the fuel indicator connector, the two terminals on the starter solenoid, and three terminals on rear of alternator. Pull harness rearward until it is free from engine block and fuel filter.

5. Disconnect speed-hour meter drive from fly-wheel housing.

6. Remove hydraulic reservoir vent hose from support clamp and pull rearward until it is free from the engine.

7. Remove cowl-to-flywheel housing cap screws.

Place a hydraulic floor jack or a support stand under the clutch housing or transmission case. Remove the engine-to-clutch housing cap screws. Separate engine from clutch housing.

### ASSEMBLY

Join engine to clutch housing. Reverse removal procedure.

Tighten cap screws to specified torque (Section 10, Group 30). To complete installation, refer to instructions for assembly given under SEPARATING TRACTOR FRONT END FROM ENGINE.

### SEPARATING ENGINE FROM CLUTCH HOUSING

Remove battery door on top of cowl. Disconnect battery ground cable(s) at terminals. Remove right-hand cowl from tractor. Remove muffler, hood, grille screens, and front ballast (if used). Remove both batteries. Drain cooling system.




Fig. 6-Left-Hand Separation Procedures

1. Remove toolbox from right side frame (if so equipped) and remove both right-hand and left-hand side frames.

2. Disconnect drag link at front from steering mechanism.

3. Disconnect temperature gauge sensing bulb from engine.

4. Disconnect speed control rod at rear. Disconnect and remove fuel shut-off rod.

## SEPARATING ENGINE FROM CLUTCH HOUSING—Continued




Fig. 7-Right-Hand Separation Procedures

5. Disconnect hydraulic oil reservoir vent hose from top of reservoir. Remove vent hose from support clamp and pull hose rearward until it can be positioned so it is free from engine.
6. Disconnect hydraulic pump pressure oil pipe at connector. Remove retaining clamp from pump inlet and reservoir return pipes. Disconnect power steering pressure line.
7. Disconnect wiring harness at oil pressure sensing switch, starter solenoid, rear of alternator, and fuel tank indicator wire. Pull the wiring harness rearward until it can be freed from engine and fuel filter housing.
8. Remove the two cowl-to-flywheel housing cap screws.
9. Disconnect tachometer at clutch housing and at tachometer and pull cable from clutch housing.

**CAUTION:** Install a wooden block between front axle and engine front support on both sides of tractor (Arrow, Fig. 8).

If not already done so, install the JDG-9 Support Stand in rear engine flange side frame holes. Adjust wheel of support stand tightly against floor.

Place a container under the rear portion of clutch housing to catch the hydraulic oil from the pump inlet pipe and the cooler return pipe, when the tractor is separated.

**IMPORTANT:** Do not lose check valve assembly (tractors without Hi-Lo or reverser) in end of hydraulic pump inlet pipe when separation is made. Install caplugs on hydraulic pipes and fittings to prevent entry of foreign material.

10. Remove clutch housing-to-engine flange cap screws.




Fig. 8-Engine Separated from Clutch Housing

Roll front section of tractor away from clutch housing (Fig. 8).

## ASSEMBLY

Remove caplugs and join engine and clutch housing. Reverse the numbered removal steps given under SEPARATION. Remove JDG-9 Support Stand and floor jack. Tighten cap screws to specified torque. (See Group 30 of this Section.)

Install battery, side grille screens, hood, muffler, and right-hand cowl. Start engine, inspect for leaks, and check operation.

## SEPARATING CLUTCH HOUSING FROM TRANSMISSION CASE

Drain the transmission (remove both drain plugs). Remove the hydraulic oil filter cover and element.

Disconnect the clutch return spring. Remove the left-hand and right-hand footrests. Remove the transmission shield.




Fig. 9-Left-Hand Separation Procedures

1. Disconnect wiring harness from neutral-start switch and light switch (Fig. 9).




Fig. 10-Right-Hand Separation Procedures

2. Disconnect hydraulic oil reservoir vent hose (Fig. 10). Disconnect mid couplers (if equipped).

3. Remove control valve cover, and remove shift cover cap screws (tractors with Hi-Lo shift). Remove shift cover from clutch housing. Inside the clutch housing, remove the two clutch housing-to-transmission case cap screws, and the gear shifter lever guide spring.

4. Disconnect brake pipes from brake valve housing, and disconnect pressure pipe at pressure control valve.

Install JDG-9 Support Stand on flywheel housing.

**CAUTION:** Install a wooden block between front axle and front support on both sides of tractor to prevent assembly from tipping (Arrow, Fig. 11).

Place floor jack under transmission case.




Fig. 11-Clutch Housing Separated from Transmission

Remove the clutch housing-to-transmission case cap screws, and separate units (Fig. 11). Install caplugs.

## ASSEMBLY

Install a new clutch housing-to-transmission case gasket and new rubber packings. Remove caplugs.

## 10 SEPARATING CLUTCH HOUSING FROM TRANSMISSION CASE—Continued

Join front and rear units. Reverse the numbered separation steps. Tighten cap screws to specified torque (Section 10, Group 30).

Install the transmission shield, footrests, clutch return spring, and drawbar.

Install hydraulic oil filter element and cover. Fill transmission to proper level.

Remove JDG-9 Support Stand, floor jack, and wooden blocks.

### REMOVING FINAL DRIVE ASSEMBLY

Drain the transmission case at both plugs. Disconnect battery ground straps at negative terminals of the batteries.




Fig. 12-Final Drive Assembly Removal Procedures

When right-hand axle housing is to be removed, first remove the selective control valve.


1. Disconnect wiring harness from lights, fender, and axle housing. Pull harness free of axle housing.

2. Remove footrest and extension. Release tension on clutch pedal spring before removing left-hand footrest completely. Disconnect hydraulic brake line.

3. Remove outside long bolts so that fender may be removed. (It will be more convenient to remove tractor tire before removing fender, or position tire at widest position.)

4. Remove inside bolts attaching Roll-Gard to axle housing and remove Roll-Gard.

5. Place floor jack or support stand (B, Fig. 13) under transmission case. Remove tire (if not already done). Remove cap screws securing axle housing. Wrap chain (A) around axle housing toward inner end. Remove axle housing from transmission case.



A—Chain on Housing

B—Support Stand

Fig. 13-Assembly Removed from Transmission Case

### ASSEMBLY

Install a new gasket on transmission case. Be sure brake disk is properly positioned on final drive shaft.

Join axle housing to transmission case. Tighten cap screws to specified torque (Section 10, Group 30). Remove capplugs.

Reverse the removal steps. Fill transmission with oil to the proper level.

Start engine and check operation.

# Group 30

## SPECIFICATIONS AND SPECIAL TOOLS

### SPECIFICATIONS

Item	Specification
Fan belt adjustment .....	3/4 inch (2.54 cm) deflection, 20 lb. (104 N) force

Item	Torque (ft-lbs [Nm])
Engine-to-clutch housing .....	170 (230)
Drag link nuts .....	55 (75)
Clutch housing-to-transmission case .....	85 (115)
Front end support-to-engine block	
5/8 inch .....	170 (230)
9/16 inch .....	130 (176)
Hydraulic pump drive coupling nuts .....	25 (34)
Axle housing-to-transmission case .....	85 (115)
Roll-Gard-to-axle housing .....	300 (407)
Rear wheel-to-hub bolts	
(rack and pinion axle) .....	300 (407)
Rim-to-wheel disk nuts .....	170 (230)
Rear wheel-to-flanged axle cap screws	
Cast wheel (regular and power adj.) .....	130 (176)
Steel wheel .....	100 (135)
Demountable rim wheel .....	100 (135)
Front wheel bearing .....	35 (47)
Front wheel hub bolts .....	100 (135)

### SPECIAL TOOLS

No.	Name	Use
JD-244*	Engine Lifting Eyes	Engine removal
JDG-1*	Engine Sling	Removing engine
JDG-9*	Support Stand	Tractor separation

\*Order from: Service Tools, P.O. Box 314, Owatonna, Minnesota 55060

TORQUE CHART



Bolt Diameter	Plain Head*	Three Radial Dashes*	Six Radial Dashes*
1/4 in. (6.35 mm)	6 ft-lbs (8 Nm)	10 ft-lbs (14 Nm)	14 ft-lbs (19 Nm)
5/16 in. (7.93 mm)	13 ft-lbs (18 Nm)	20 ft-lbs (27 Nm)	30 ft-lbs (41 Nm)
3/8 in. (9.53 mm)	23 ft-lbs (31 Nm)	35 ft-lbs (47 Nm)	50 ft-lbs (68 Nm)
7/16 in. (11.11 mm)	35 ft-lbs (47 Nm)	55 ft-lbs (75 Nm)	80 ft-lbs (108 Nm)
1/2 in. (12.70 mm)	55 ft-lbs (75 Nm)	85 ft-lbs (115 Nm)	120 ft-lbs (163 Nm)
9/16 in. (14.29 mm)	75 ft-lbs (102 Nm)	130 ft-lbs (176 Nm)	175 ft-lbs (237 Nm)
5/8 in. (15.88 mm)	105 ft-lbs (142 Nm)	170 ft-lbs (230 Nm)	240 ft-lbs (325 Nm)
3/4 in. (19.05 mm)	185 ft-lbs (251 Nm)	300 ft-lbs (407 Nm)	425 ft-lbs (576 Nm)
7/8 in. (22.23 mm)	160 ft-lbs (217 Nm)**	445 ft-lbs (603 Nm)	685 ft-lbs (929 Nm)
1 in. (25.40 mm)	250 ft-lbs (339 Nm)**	670 ft-lbs (908 Nm)	1030 ft-lbs (1396 Nm)

\*The types of bolts and cap screws are identified by head markings as follows:

Plain Head: regular machine bolts and cap screws.

3-Dash Head: tempered steel high-strength bolts and cap screws.

6-Dash Head: tempered steel extra high-strength bolts and cap screws.

\*\*Machine bolts and cap screws 7/8 inch and larger are sometimes formed hot rather than cold, which accounts for the lower torque.

# Section 20 ENGINE

## CONTENTS OF THIS SECTION

	Page		Page
<b>GROUP 5 - GENERAL INFORMATION AND DIAGNOSIS</b>		<b>GROUP 15 - CYLINDER BLOCK, LINERS, PISTONS AND RODS</b>	
General Information .....	5-2	General Information .....	15-1
Diagnosing Engine Malfunctions .....	5-2	Diagnosing Malfunctions .....	15-1
<b>GROUP 10 - CYLINDER HEAD, VALVES, CAMSHAFT, AND TIMING GEAR TRAIN - 2440 TRACTOR</b>		Removal .....	15-2
General Information .....	10-1	Repair	
Diagnosing Malfunctions .....	10-1	Pistons .....	15-2
Preliminary Valve Train Checks .....	10-2	Liners .....	15-3
Cylinder Head and Valves		Rods .....	15-4
Removal and Repair .....	10-2	Assembly .....	15-5
Assembly and Installation .....	10-4	Installation .....	15-5
Valve Clearance Adjustment .....	10-4	<b>GROUP 20 - CRANKSHAFT, MAIN BEARINGS, AND FLYWHEEL - 2440 TRACTOR</b>	
Camshaft		General Information .....	20-1
Removal .....	10-5	Diagnosing Malfunctions .....	20-1
Repair .....	10-5	Checking End Play .....	20-1
Installation .....	10-6	Removal .....	20-2
Timing Gear Train .....	10-7	Inspection and Repair	
Removal .....	10-7	Crankshaft and Flywheel .....	20-2
Inspection and Repair .....	10-7	Main Bearings and Journals .....	20-2
Assembly and Installation .....	10-9	Rear Crankshaft Oil Seal Housing, Flywheel and Wear Sleeve .....	20-3
<b>GROUP 12 - CYLINDER HEAD, VALVES, CAMSHAFT, AND TIMING GEAR TRAIN - 2640 TRACTOR</b>		Assembly .....	20-3
General Information .....	12-1	Front Oil Seal and Wear Sleeve .....	20-4
Diagnosing Malfunctions .....	12-1	<b>GROUP 22 - CRANKSHAFT, MAIN BEARINGS, AND FLYWHEEL - 2640 TRACTOR</b>	
Preliminary Valve Checks .....	12-2	General Information .....	22-1
Cylinder Head and Valves		Diagnosing Malfunctions .....	22-1
Removal and Repair .....	12-2	Checking End Play .....	22-1
Assembly and Installation .....	12-4	Removal .....	22-2
Valve Clearance Adjustment .....	12-5	Inspection and Repair	
Camshaft		Crankshaft and Flywheel .....	22-2
Removal .....	12-5	Main Bearings and Journals .....	22-2
Repair .....	12-6	Rear Crankshaft Oil Seal Housing, Flywheel and Wear Sleeve .....	22-3
Installation .....	12-6	Assembly .....	22-3
Timing Gear Train .....	12-7	Front Oil Seal and Wear Sleeve .....	22-4
Removal .....	12-7		
Inspection and Repair .....	12-7		
Assembly and Installation .....	12-9		

**CONTENTS OF THIS SECTION—Continued**

	Page		Page
<b>GROUP 25 - LUBRICATION SYSTEM - 2440 TRACTOR</b>		<b>GROUP 32 - COOLING SYSTEM - 2640 TRACTOR</b>	
General Information .....	25-1	General Information .....	32-1
Diagnosing Malfunctions .....	25-1	Diagnosing Malfunctions .....	32-1
Checking Oil Pressure .....	25-1	Radiator and Fan Belt .....	32-1
Oil Pump		Water Pump .....	32-1
Removal .....	25-1	Water Manifold and Thermostats .....	32-3
Inspection and Repair .....	25-1		
Assembly and Installation .....	25-2	<b>GROUP 35 - SPECIFICATIONS - 2440 TRACTOR</b>	
Oil Filter .....	25-3	Cylinder Head, Valves, and Camshafts ....	35-1
Oil Pressure Regulating Valve .....	25-3	Cylinder Block, Liners, Pistons, and Rods .....	35-2
		Crankshaft, Main Bearings and Flywheel .....	35-3
<b>GROUP 27 - LUBRICATION SYSTEM - 2640 TRACTOR</b>		Lubrication System .....	35-3
General Information .....	27-1	Cooling System .....	35-3
Diagnosing Malfunctions .....	27-1	Engine Break-In .....	35-4
Checking Oil Pressure .....	27-1	Special Tools .....	35-4
Oil Pump		Special Lubricants .....	35-4
Removal .....	27-1		
Inspection and Repair .....	27-1	<b>GROUP 37 - SPECIFICATIONS - 2640 TRACTOR</b>	
Assembly and Installation .....	27-2	Cylinder Head, Valves, and Camshafts ....	37-1
Oil Cooler - Filter Assembly .....	27-3	Cylinder Block, Liners, Pistons, and Rods .....	37-2
Oil Cooler Bypass Valve .....	27-3	Crankshaft, Main Bearings and Flywheel .....	37-3
Oil Pressure Regulating Valve .....	27-4	Lubrication System .....	37-3
Oil Filter .....	27-4	Cooling System .....	37-3
		Engine Break-In .....	37-4
<b>GROUP 30 - COOLING SYSTEM - 2440 TRACTOR</b>		Special Tools .....	37-4
General Information .....	30-1	Special Lubricants .....	37-4
Diagnosing Malfunctions .....	30-1		
Radiator and Fan Belt .....	30-1		
Water Pump .....	30-1		
Water Manifold and Thermostats .....	30-3		

20

## Group 5

# GENERAL INFORMATION AND DIAGNOSIS

### GENERAL INFORMATION

The engine is a 4-cylinder valve-in-head, vertical in-line four cycle engine.



For basic theory of engine operation see the FOS Manual 30—ENGINES.

### DIAGNOSING MALFUNCTIONS

#### Will not Start

Fuel System Malfunction—See Section 30

- Foreign matter in fuel
- Improper fuel
- Faulty fuel pump
- Fuel shut off at tank
- Restricted air intake system
- Faulty injection nozzles
- Plugged fuel filter

Electrical System Malfunction—See Section 40

- Corroded or loose battery connections
- Faulty or loose wiring
- Weak battery
- Faulty key switch
- Faulty neutral start switches

#### Uneven Running or Frequent Stalling

Basic Engine Problem—See This Section

- Improper valve clearance
- Cylinder head gasket leaking
- Valves sticking or burned
- Worn or broken compression rings
- Low compression
- Incorrect timing
- Coolant temperature below normal
- Engine overheating

Fuel System Malfunction—See Section 30

- Low fuel supply
- Restricted fuel lines or filters
- Faulty fuel pump
- Faulty injection pump
- Faulty injection nozzles
- Exhaust system restricted

#### Engine Misses

Basic Engine Problem—See This Section

- Worn camshaft lobes
- Weak valve springs
- Incorrect valve clearance
- Burned, warped, pitted or sticking valves
- Low compression
- Incorrect timing
- Engine overheating

Fuel System Malfunction—See Section 30

- Air in fuel
- Faulty injection nozzles
- Faulty injection pump
- Water in fuel
- Mixture of gasoline and diesel fuels
- Faulty fuel pump

#### Lack of Power

Basic Engine Problem—See This Section

- Blown cylinder head gasket
- Worn camshaft lobes
- Incorrect valve clearance
- Burned, warped, pitted or sticking valves
- Weak valve springs
- Incorrect timing
- Low compression
- Wrong oil viscosity
- Coolant temperature above or below normal
- Engine overheating

Fuel System Malfunction—See Section 30

- Plugged fuel filters
- Improper fuel
- Faulty injection pump
- Faulty injection nozzles
- Faulty fuel pump
- Restricted air cleaner
- Restricted exhaust system
- Low intake manifold pressure
- Obstructed fuel line

Power Train Malfunction—See Section 50

- Clutch slipping

### Engine Overheats

Basic Engine Problem—See This Section

- Defective head gasket
- Incorrect timing
- Crankcase oil level low
- Low coolant level
- Radiator or side grille screen dirty
- Loose or broken fan belt
- Faulty thermostat
- Cooling system limed up
- Defective radiator pressure cap
- Faulty water pump

Service Problem—See Section 10

- Engine overloaded
- Crankcase oil level low
- Improper fuel

Fuel System Malfunction—See Section 30

- Excessive fuel delivery

### Excessive Oil Consumption

Basic Engine Problem—See This Section

- Restricted oil passage from valve cover
- Worn valve guides or valve stems
- Oil control rings worn or broken
- Scored liners or pistons
- Excessive ring groove wear in piston
- Rings sticking in grooves of piston
- Oil return slots in piston clogged
- Insufficient piston ring tension
- Piston ring gaps not staggered
- Worn crankshaft thrust bearing  
(misaligned piston and rod)
- Excessive main or connecting rod  
bearing clearance
- Front or rear crankshaft oil seal faulty
- Crankcase oil too thin
- Oil pressure too high
- Oil level too high

Service Problem—See Section 10

- Crankcase oil too thin
- Oil level too high

Fuel System Malfunction—See Section 30

- Restricted air intake

### Excessive Fuel Consumption

Basic Engine Problem—See This Section

- Low compression
- Incorrect timing

Service Problem—See Section 10

- Engine overloaded

Fuel System Malfunction—See Section 30

- Leaks in fuel system
- Restricted air cleaner
- Faulty injection nozzles
- Faulty injection pump

### Black or Gray Exhaust Smoke

Basic Engine Malfunction—See This Section

- Incorrect engine timing

Service Problem—See Section 10

- Improper grade of fuel
- Engine overloaded

Fuel System Malfunction—See Section 30

- Excessive fuel delivery
- Restricted air cleaner
- Defective muffler
- Faulty injection nozzles

### White Exhaust Smoke

Basic Engine Problem—See This Section

- Low compression
- Incorrect timing

Fuel System Malfunction—See Section 30

- Faulty injection nozzles
- Improper fuel

### Slow Acceleration

Fuel System Malfunction—See Section 30

- Faulty injection pump
- Faulty injection nozzles

### Engine Noises—General

Regular Clicking Noise

- Incorrect valve clearance

Light Knock or Pound

- Worn bearings
- Misaligned connecting rod
- Lack of oil

Light Double Knock at Idle

- Worn or loose piston pin or bushing
- Lack of oil

## DIAGNOSING MALFUNCTIONS—Continued

### Chattering or Rattling during Acceleration

- Worn or broken piston rings
- Worn cylinder liners
- Low oil pressure
- Worn main bearings

### Hollow, Muffled Bell-Sound—Cold Engine

- Worn pistons
- Worn liners
- Lack of oil
- Misaligned connecting rods

### Dull, Heavy Knock Under Load

- Steady noise—worn main bearings
- Irregular noise—worn thrust bearing

### Miscellaneous Engine Noises

- Excessive valve clearance
- Worn cam followers
- Bent push rods
- Worn rocker arm shafts
- Worn main or connecting rod bearings
- Foreign material in combustion chamber
- Worn piston pins and pin bushings
- Scored piston
- Incorrect timing
- Excessive crankshaft end play
- Loose main bearing caps
- Worn gears
- Broken oil pump shaft
- Low engine oil level or pressure



## Group 10 CYLINDER HEAD, VALVES, CAMSHAFT AND TIMING GEAR TRAIN (2440)

### GENERAL INFORMATION

The cylinder head holds the rocker arm assembly, valve springs and valves. Valve guides and seats are integral with the head.

Valves are equipped with springs, spring retainers, retainer locks and replaceable wear caps.

The camshaft is driven at 1/2 engine speed by the crankshaft through the top idler gear. The camshaft has an eccentric lobe to actuate the fuel pump.

The timing gear train consists of upper and lower idler gear assemblies and balance shafts. The idler gears receive power from the crankshaft gear and, in turn, power the camshaft, injection pump, engine oil pump, and right-hand balancer shaft gears. The left-hand balancer shaft gear is driven by the engine oil pump gear.

### DIAGNOSING MALFUNCTIONS

#### Sticking Valves

- Carbon deposits on valve stems
- Worn valve guides
- Warped valve stem
- Cocked or broken valve springs
- Worn or distorted valve seats
- Insufficient lubrication

#### Burned, Pitted, Worn, or Broken Valves

- Worn or distorted valve seats
- Worn valve guides
- Insufficient cooling
- Insufficient lubrication
- Cocked or broken springs
- Pre-ignition
- Detonation
- Improper engine operation
- Improper valve clearance

- Improper valve gear train timing
- Warped or distorted valve stems
- "Stretched" valves due to excessive spring tension
- Distorted cylinder head
- Bent push rods
- Carbon build-up on valve seats
- Rocker arm failure

#### Worn, Warped, or Distorted Valve Guides

- Lack of lubrication
- Cylinder head distortion
- Excessive heat
- Unevenly tightened cylinder head bolts

#### Distorted Cylinder Head and Cylinder Head Gasket Leakage

- Improper cylinder head torque
- Improper gasket installation
- Excessive oil pressure
- Improper cylinder liner height above block

#### Worn or Broken Valve Seats

- Misaligned valves

#### Distorted Cylinder Head

#### Carbon Deposits on Seats Due to Incomplete Combustion

- Valve spring tension too weak
- Excessive heat
- Improper valve timing
- Improper valve clearance

#### Camshaft Failures

- Scored camshaft lobes due to inadequate lubrication
- Excessive end play due to thrust plate wear
- Broken or warped camshaft due to improper timing



**Suggest:**

**If the above button click is invalid.**

**Please download this document**

**first, and then click the above link**

**to download the complete manual.**

**Thank you so much for reading**

## PRELIMINARY VALVE TRAIN CHECKS

Check condition of visible valve train parts for indication of malfunctions.

Prior to cylinder head removal, inspect and check engine operation.

### Checking Valve Clearance

Intake valve clearance is 0.014 inch (0.35 mm).  
 Exhaust valve clearance is 0.018 inch (0.46 mm).

### Checking Valve Lift




Fig. 1-Checking Valve Lift

Before removing cylinder head, check valve lift. Measuring valve lift can give an indication of wear to cam lobes, cam followers, and push rods. Valves should be adjusted to proper clearance.

Place dial indicator on valve spring cap. Manually rotate engine in running direction with JD-281 Engine Rotation Tool. When rocker arm contacts valve stem, check dial indicator travel as rocker arm moves valve to full open. Indicator should read 0.460 to 0.480 inch (1.168 to 1.220 cm) on intake valves and 0.456 to 0.482 inch (1.158 to 1.224 cm) on exhaust valves. If lift is less than 0.430 inch (1.092 cm) on intake valves and 0.426 inch (1.082 cm) on exhaust valves, camshaft should be replaced.

## CYLINDER HEAD AND VALVES

### Removal

Remove battery ground cable.

The engine need not be removed to service the cylinder head and its related parts.

Drain cooling system and remove all parts that are connected to the cylinder head.

Disconnect fuel injection lines and identify. Remove injection nozzles as directed in Section 30. Plug all fuel lines to prevent fuel system contamination.

Identify all parts during removal for reassembly.

**NOTE:** Do not rotate crankshaft with cylinder head removed unless all cylinder liners are secured with cap screws and washers.


Remove spring washers (3, Fig. 2) and plugs (1) from rocker arm shaft. Slide parts from shaft and identify for reassembly.

Remove wear caps (9), spring retainers (10), retainer locks (11), springs (12), and valves (13 and 14). Identify each valve for reassembly.

## Repair

### Valve Springs

Inspect valve springs (12) for alignment, wear and damage. Place springs on a flat surface to see that they are square and parallel. Do not use springs that are cocked, crooked or contain broken or rusty coils.



R 23983N

- |                            |                            |
|----------------------------|----------------------------|
| 1—Plug (2 used)            | 9—Wear Cap (8 used)        |
| 2—Rocker Arm Shaft         | 10—Retainer Lock (16 used) |
| 3—Washer (2 used)          | 11—Retainer (8 used)       |
| 4—Spring (3 used)          | 12—Valve Spring (8 used)   |
| 5—Adjusting Screw (8 used) | 13—Intake Valve (4 used)   |
| 6—Rocker Arm (8 used)      | 14—Exhaust Valve (4 used)  |
| 7—Cap Screw (4 used)       |                            |
| 8—Clamp (4 used)           |                            |

Fig. 2-Valves and Rocker Arm Assembly

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**