

5400N and 5500N Narrow Tractors



JOHN DEERE

OPERATORS MANUAL

5400N and 5500N
Narrow Tractors

OMLV62124 H6 English

John Deere Augusta
OMLV62124 H6
(This manual replaces OMLV62124 H4)
European Edition

LITHO IN U.S.A.
ENGLISH



Introduction

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages (see your John Deere dealer to order).

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Specification or Identification Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

SETTING FUEL DELIVERY BEYOND PUBLISHED factory specifications or otherwise overpowering will result in loss of warranty protection for this machine.

BEFORE DELIVERING THIS MACHINE, your dealer performed a predelivery inspection. After operating for the first 100 hours, schedule an after-sale inspection with your dealer to ensure best performance.

THIS TRACTOR IS DESIGNED SOLELY for use in customary agricultural or similar operations ("INTENDED USE").

Use in any other way is considered as contrary to the intended use. The manufacturer accepts no liability for damage or injury resulting from this misuse, and these risks must be borne solely by the user.


Compliance with and strict adherence to the conditions of operation, service and repair as specified by the manufacturer also constitute essential elements for the intended use.

THIS TRACTOR SHOULD BE OPERATED, serviced and repaired only by persons familiar with all its particular characteristics and acquainted with the relevant safety rules (accident prevention).

The accident prevention regulations, all other generally recognized regulations on safety and occupational medicine and the road traffic regulations must be observed at all times.


Any arbitrary modifications carried out on this tractor will relieve the manufacturer of all liability for any resulting damage or injury.

IDENTIFICATION VIEWS



LV617
-UN-18JUN94

John Deere 5400N Tractor—Open Station



LV1648
-UN-05JUN96

John Deere 5500N Tractor—Cab

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

Contents

Page	Page		
Safety	05-1	Storage Compartment	30-4
Safety Signs	10-1	Using Horn	30-5
Controls and Instruments	15-1	Break-In Period	35-1
Lights		Prestarting Checks	40-1
Light Switch Positions	20-1	Operating the Engine	
Using Head Lamps	20-2	Before Starting the Engine	45-1
Full Beam Indicator	20-2	Starting the Engine	45-3
Using Front Position and Rear Tail Lamps	20-3	Check Instruments After Starting	45-4
Rear Flood Lamp—Open Station Using	20-4	Air Restriction Indicator	45-4
Adjusting	20-4	Watch Fuel Level	45-5
Using Flood Lamps—Cab	20-5	Changing Engine Speeds	45-5
Using Turn Signals	20-6	Warming Up the Engine	45-6
Using License Plate Light	20-7	Restart Stalled Engine	45-6
Attaching and Using Warning Lights Open Station	20-7	Avoid Idling the Engine	45-6
Cab	20-8	Observe Engine Work and Idle Speeds	45-7
Seven-Terminal Outlet	20-10	Working With Speed-Hour Meter	45-7
Operator's Platform (Open Station)		Stopping the Engine	45-8
Operating Foldable ROPS	25-1	Cold Weather Starting Procedure	45-8
Using Seat Belt	25-2	Using Booster Battery	45-9
Selecting Seat Position	25-2	Starting Engine With Slave Battery	45-9
Adjusting Ride Comfort	25-3	Driving the Tractor	
Using Horn	25-3	Avoid Contact With Pesticides	50-1
Operator's Station (Cab)		Observe Maximum Travel Speeds	50-2
Using Seat Belt	30-1	Reduce Fuel Consumption	50-2
Selecting Seat Position	30-1	Selecting a Gear	50-3
Adjusting Ride Comfort	30-2	Shifting Transmission	50-4
Adjusting Blower Speed	30-2	Using Brakes	50-5
Controlling Temperature	30-3	Using Differential Lock	50-5
Operating Wiper(s)	30-3	Operating Front-Wheel Drive	50-6
Accessory Electrical Outlet	30-3	Driving Tractor On Roads	50-7
Radio	30-4	Stopping the Tractor	50-11
Using Dome Lamp	30-4	Rockshaft and 3-Point Hitch	
		Match Tractor Power to Implement	55-1
		3-Point Hitch Components	55-1

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMLV62124 H6-19-22AUG96

COPYRIGHT© 1996
 DEERE & COMPANY
 Moline, Illinois
 All rights reserved
 A John Deere ILLUSTRATION Manual
 Previous Editions
 Copyright 1994 Deere & Company

Contents

	Page		Page
Rockshaft Control Levers	55-2	Installing Rear Cast Iron Weights	70-6
Using Rockshaft Position Control	55-2	Using Liquid Weight	70-7
Setting Position Control Lever Stop	55-4	Filling Tires with Liquid Ballast	70-8
Using Draft Control	55-5	Draining the Tires	70-8
Adjusting Rockshaft Speed-of-Drop	55-6		
Preparing Implement	55-6	Wheels, Tires and Treads	
Converting Hitch Category	55-7	Check Implement-to-Tire Clearance	75-1
Positioning Draft Link Ends	55-8	Tire Inflation Pressure	
Positioning Center Link	55-9	Check	75-2
Attaching Implements	55-10	Chart	75-3
Adjusting Sway Blocks	55-11	Tighten Bolts	
Leveling the Hitch	55-11	Correctly	75-3
Adjusting Rockshaft Control Lever Friction	55-13	Adjustable Front Axle	75-4
Warming Hydraulic System Oil	55-13	MFWD Axle	75-4
		Rear Axle	75-5
		Observe Rear Wheel Tread Width	
Remote Hydraulic Cylinders		Limitations	75-5
Use Correct Hose Tips	60-1	Tread Settings	
SCV Control Lever and Coupler		Two-Position Rear Wheels	75-6
Identification	60-1	Multi-Position Rear Wheels	75-6
Installing Remote Outlet Oil Manifolds		Two-Position MFWD Wheels	75-8
(Optional)	60-2	Adjustable Front Axle	75-9
Connecting Cylinder Hoses	60-3	Selecting Front Tire Rolling Direction	75-10
Operating SCV Controls	60-5	Adjusting Front Axle Tread Width	75-10
Adjusting Cylinder Stop	60-5	Toe-In	
Power Beyond Connections	60-6	Checking Two-Wheel Drive Tractor	75-11
Disconnecting Cylinder Hoses	60-8	Adjusting Two-Wheel Drive Tractor	75-11
		Checking MFWD Tractor	75-12
		Adjusting MFWD Tractor	75-12
Drawbar and PTO		Setting Steering Stops	
Drawbar Load Limitations	65-1	Adjustable Front Axle	75-13
Selecting Drawbar Position	65-1	MFWD Axle	75-14
Adjusting Drawbar	65-2	Use Correct Tire Combinations	75-14
Attaching PTO-Driven Implement	65-2	Tire Compatibility Chart	75-15
Selecting Correct PTO Speeds	65-4		
Operating Tractor PTO	65-4	Transporting	
Adjusting PTO Clutch Lever	65-5	Use Safety Lights and Devices	80-1
		Use a Safety Chain	80-1
Ballast		Observe Maximum Travel Speeds	80-2
Selecting Ballast	70-1	Transport on Carrier	80-2
Matching Ballast to Load Work	70-1	Towing Tractor	80-3
Checking for Correct Ballast	70-1		
Measuring Wheel Slip (Manually)	70-2	Fuels, Lubricants, and Coolant	
Ballast Limitations	70-3	Fuel	85-2
Ballasting		Handling and Storing Diesel Fuel	85-2
Front End for Transport	70-3	Fill Fuel Tank	85-3
Two-Wheel Drive Tractors Tractors	70-4	Alternative and Synthetic Lubricants	85-4
MFWD-Equipped Tractors	70-4	Lubricant Storage	85-4
Determining Maximum Ballast		Diesel Engine Oil	85-5
Rear	70-5	Oil Filters	85-5
Front	70-5		
Using Cast Iron Weights	70-6		

Continued on next page

Contents

	Page		Page
Engine Coolant	85-6	Service—600 Hours	
Transmission and Hydraulic Oil	85-7	Change Oil In MFWD Axle	120-1
MFWD Gear Oil	85-8	Clean Engine Crankcase Vent Tube	120-1
Grease	85-9	Pack Front Wheel Bearings (Adjustable Front Axle)	120-2
Mixing of Lubricants	85-9	Check Hoses and Hose Clamps	120-2
Lubrication and Maintenance		Lubricate Rear Axle Bearings	120-3
Clean Vehicle of Hazardous Pesticides	90-1	Check Engine Idle Speeds	120-3
Observe Service Intervals	90-2	Adjust Engine Valve Clearance	120-3
Use Correct Lubricant	90-2	Check Front Axle Pivot Pin	120-4
Break-In Service	90-3	Service—1200 Hours	
Service Intervals	90-4	Change Transmission-Hydraulic Oil and Filter	125-1
Service—10 Hours		Clean Transmission-Hydraulic Pickup Screen	125-2
Check Engine Oil Level	95-1	Service—Annually	
Check Coolant Level	95-2	Change Engine Oil and Filter	130-1
Drain Water and Sediment from Fuel Tank	95-3	Replace Air Cleaner Elements	130-1
Service—50 Hours		Service—2 Years/2000 Hours	
Check Transmission-Hydraulic Oil Level	100-1	Flush Cooling System and Replace Thermostat	135-1
Check MFWD Axle Oil Level	100-1	Service—As Required	
Clean and Check Battery	100-2	Service Air Cleaner	140-1
Inspect All Tires	100-2	Adjust Throttle Lever Friction	140-1
Lubricate		Adjust 540E PTO Throttle Limiter	140-1
Front Axle Pivot Pin	100-3	Service	
Steering Cylinder Ends and Spindles (Adjustable Front Axle)	100-3	Service Tractor Safely	145-1
Inspect For Loose Hardware	100-4	Additional Service Information	145-2
Service—First 100 Hours		Hood	
Change Engine Oil and Filter	105-1	Opening	145-3
Replace Transmission-Hydraulic Filter	105-1	Removing	145-3
Service—250 Hours		Removing Engine Side Shields	145-4
Service Air Cleaner	110-1	Removing Side Screens	145-5
Inspect and Adjust Belt(s)		Air Intake System Components	145-5
Alternator/Fan	110-1	Service Air Cleaner	145-6
A/C Compressor (Cab)	110-2	Checking Air Intake System	145-7
Lubricate Hitch Lift Links	110-2	Primary Air Cleaner Element	
Check Neutral Start System	110-3	Removing	145-8
Check and Adjust Clutch Pedal Free Play		Cleaning	145-8
Open Station	110-4	Washing	145-9
Cab	110-4	Inspecting	145-9
Clean Operator Enclosure (Cab) Air Filters	110-5	Storing	145-10
Service—500 Hours		Replace Alternator/Fan Belt	145-10
Replace Fuel Filter	115-1	Replace A/C Compressor Belt (Cab)	145-11
		Fuel System Components	145-12

Continued on next page

Contents

	Page		Page
Replace Fuel Filter	145-13	Electrical System	150-8
Bleeding Fuel System	145-14	Heater and A/C System (Cab)	150-9
Engine Cooling System Components	145-16	Wipers, Flood Lamps, Dome Lamp and Radio (Cab)	150-12
Cleaning Grille, Screens, Radiator and Oil Cooler	145-17	Storage	155-1
Flush Cooling System	145-18	Specifications	
Replacing Thermostat	145-19	Machine Specifications	160-1
Winterize Cooling System	145-20	Machine Dimensions	160-4
Prevent Battery Explosions	145-21	Sound Level	160-5
Battery		Ground Speeds	
Observe Electrical Service Precautions	145-21	Estimates	160-5
Access—Open Station	145-22	Chart	160-6
Access—Cab	145-22	Permissible Load Specifications	160-7
Removal	145-23	Bolt and Cap Screw Torque Value Charts	
Servicing	145-23	Metric	160-8
Replacement Specifications	145-25	Inch	160-9
Charging	145-25	Declaration of Conformity	160-10
Checking Condition	145-26	Identification Numbers	
Connect Starter Wiring	145-27	Identification Plates	165-1
Service Air Conditioner	145-28	Record Serial Numbers	
Connecting Alternator Wiring	145-29	Tractor	165-1
Locating Fuseable Link (Cab)	145-29	Adjustable Front Axle	165-1
Fuses		MFWD Axle	165-2
Locating	145-30	Engine	165-2
Size and Function—Tractor	145-31	Transmission	165-2
Size and Function—Cab	145-32	Lubrication Maintenance Record Charts	170-1
Head Lamps		Index	
Aiming	145-32		
Adjusting	145-33		
Replace Bulb	145-33		
Replace Warning Lamp Bulb	145-34		
Flood Lamp(s)			
Replace Bulb—Open Station	145-34		
Replace Bulb—Cab	145-35		
Replace Tail and Brake Lamp Bulb	145-35		
Replace Dome Lamp Bulbs (Cab)	145-35		
Checking and Adjusting Park Brake Lever	145-36		
Checking Tires	145-37		
Tubeless Tire Repair	145-37		
Keep ROPS Installed Properly (Open Station)	145-38		
Troubleshooting			
Engine	150-1		
Transmission	150-4		
Hydraulic System	150-5		
Brakes	150-5		
Rockshaft and Quick-Coupler 3-Point Hitch	150-6		
Remote Hydraulic Cylinders	150-7		

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

TS1389 -JUN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS167 -19-30SEP88


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-03MAR93

TS201 -JUN-23AUG88




PREVENT MACHINE RUNAWAY

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.



DX,BYPAS1

-19-03MAR93

TS177
-JUN-11-JAN83



OPERATE TRACTOR SAFELY



Features designed into your tractor make operation safer and let it perform a wide variety of jobs. Use your tractor only for specified jobs it was designed to perform: implement carrier, load mover, remote power source, or transport unit -- not a recreational vehicle.

Careless use or misuse can result in unnecessary accidents. Be alert to hazards of tractor operation. Understand causes of accidents and take every precaution to avoid them. Most common accidents are caused from:

- Tractor upsets
- Improper starting procedures
- Crushing and pinching during hitching
- Collisions with other motor vehicles
- Getting entangled in PTO shafts
- Falls from tractors

Avoid accidents by taking the following precautions:

- Put transmission levers in Neutral and engage park brake before dismounting. Leaving transmission in gear with engine stopped will NOT prevent the tractor from moving.
- Be sure everyone is clear of tractor and attached equipment before starting engine.
- Never try to get on or off a moving tractor.
- When tractor is left unattended, engage park brake, lower implements to the ground, stop the engine, and remove key.



-UN-07DEC88

RW13093

-UN-23AUG88

TS276

LV,5400N,SA,A1 -19-22JUL94



USE SEAT BELT AND FOLDABLE ROPS PROPERLY (IF EQUIPPED)

Open Station;


When the ROPS is in the "up" or extended position, ALWAYS use your seat belt to minimize chance of injury from an overturn accident.

DO NOT use seat belt when ROPS is folded down.

This tractor is equipped with a foldable Roll-Over Protective Structure (ROPS). The ROPS (A) should be kept in the "up" or extended position (as pictured) with pins (B) retained with quick-lock pins (C), except when necessary to fold it for low clearance operations.


Cab;

ALWAYS use your seat belt when operating tractor to minimize chance of injury from an accident, such as an overturn.




-UN-23AUG88

TS205



LV6'9
-UN-18JUN94



LV701
-UN-18JUN94

LV,5400N,SA,B2 -19-30MAY96



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading



USE CAUTION ON HILLSIDES

Open station; Always wear seat belt with ROPS in upper position.

Cab; Always wear a seat belt.

Avoid holes, ditches, and obstructions which cause the tractor to tip, especially on hillsides. Avoid sharp, uphill turns.


Never drive near the edge of a gully or steep embankment -- it might cave in.

Driving forward out of a ditch or mired condition or up a steep slope could cause tractor to tip over rearward. Back out of these situations if possible.

While front wheel drive greatly increases traction, it **DOES NOT** increase stability of the tractor. With front wheel drive engaged, the tractor can climb steeper slopes but it does not become more stable. When this option is used, extra caution is needed on slopes. Compared to a 2-wheel drive, a front-wheel drive tractor maintains traction on steeper slopes, increasing the possibility of a tip over.

Danger of overturn increases greatly with narrow tread setting, at high speed.

Hitch towed loads only to drawbar. When using a chain, take up the slack slowly.



-JUN-23AUG88

TS205

LV,5400N,SA,B3 -19-30MAY96

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>