

# 6600 AND 7700 COMBINES



JOHN DEERE

## OPERATORS MANUAL 6600 AND 7700 COMBINES

OMH84605 J2 English

JOHN DEERE HARVESTER WORKS  
OMH84605 J2

LITHO IN THE U.S.A.  
ENGLISH



D  
C  
Y




J  
2  
5  
0  
6  
4  
8  
H  
M  
O



## To the Purchaser

---

This new combine was carefully designed and manufactured to give years of dependable service. To keep it running efficiently, read the instructions in this operator's manual. Each section is clearly identified so you can easily find the information you need—whether it is operation, lubrication, or service. Read the Table of Contents to learn where each section is located. Use the alphabetical index for fast reference.

 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

This operator's manual covers the feeder house and separator areas of the combine. For platform and corn head information, see the separate operator's manuals furnished with that equipment.


In addition to the equipment furnished with your combine, attachments are available to help you do a

better job in special crop conditions. These are described in the attachments section of this manual and can be purchased from your John Deere dealer.

"Right-hand" and "left-hand" sides are determined by facing in the direction the combine will travel when in use. The radiator end of the engine is referred to as the "front," the flywheel end as the "rear."

Record your combine serial numbers in the space provided on page 161. Your dealer needs this information to give you prompt, efficient service when you order parts or attachments. If your combine requires replacement parts, go to your John Deere dealer where you can obtain Genuine John Deere parts—accept no substitutes.


The warranty on this combine appears on your copy of the purchase order which you should have received from your dealer when you purchased the combine.





# Contents

	Page
Controls and instruments .....	2-3
Operation .....	4-34
Safety suggestions .....	35
Fuels and lubricants .....	36-37
Lubrication and periodic service .....	38-51
Service .....	52-129
Trouble shooting .....	130-144
Storage .....	145-147
Attachments .....	148-155
Specifications .....	156-162
Index .....	163-166



H22678

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**



# Controls and Instruments

Before attempting to operate your new combine, become familiar with the location and purpose of its controls and instruments. Study these pages carefully, regardless of your previous combine experience.


The control levers and knobs have different colors and shapes to help you quickly locate the controls while operating the combine. Colors on controls indicate:

RED—Combine movement controls (Throttle, Gear-shift Lever, Selective Ground Speed Control)


YELLOW—Auxiliary Power Controls (Separator Control Lever, Cylinder Speed Control Ratchet, Platform or Corn Head Electromagnetic Clutch Switch)

BLACK—Miscellaneous Function Controls (Platform or Corn Head Height Control, Hydraulic Lift Reel Control, etc.)

## OPERATOR'S PLATFORM




**ENGINE - AIR INTAKE**




H21123

**SEPARATOR**




H21125

**FEEDER HOUSE**



H22877



H21126

	Page
A - Truck Signal Horns .....	27
B - Coolant Temperature Warning Horn or Straw Walker Warning Horn (Attachments) .....	7, 27
C - Headlight .....	27
D - Hydraulic Lift Reel Control (Optional) or Variable Speed Feeder House Control (Optional) .....	14, 151
E - Steering Wheel .....	24
F - Clutch Pedal (Belt Drive Combine) .....	25
G - Pivoting Ladder .....	11
H - Grain Tank Unloading Auger Lever .....	22
I - Unloading Auger Hydraulic Swing Control .....	22
J - Operator's Seat Control .....	10
K - Parking Brake Lever .....	24
L - Steering Column Control .....	11
M - Gearshift Lever .....	23
N - Concave Opening Control Wheel .....	17
O - Throttle .....	6
P - Ground Speed Indicator (Regular on 7700; Attachment on 6600) (Belt Drive Combine) .....	23
Q - Brake Pedals .....	25
R - Selective Ground Speed Control .....	23

	Page
S - Platform or Corn Head Height Control .....	13
T - Hydrostatic Drive Speed Range Control (Optional) .....	24
U - Separator Control Lever .....	16
V - Choke (Gasoline Engine only) .....	6
W - Fuel Gauge .....	7
X - Engine Tach-Hour Meter .....	7
Y - Platform or Corn Head Electromagnetic Clutch Switch (Optional) .....	13
Z - Parking Brake Indicator Light .....	25
AA - Alternator Indicator Light .....	6
BB - Light Switch .....	27
CC - Horn Button .....	27
DD - Key Switch .....	6
EE - Cigarette Lighter .....	27
FF - Ash Tray .....	27
GG - Cylinder Speed Control Ratchet .....	16
HH - Hydrostatic Drive Reel or Hydrostatic Drive Belt Pickup Control (Optional) .....	151
II - Cylinder Speed Tachometer .....	16
JJ - Coolant Temperature Gauge .....	7
KK - Engine Oil Pressure Gauge .....	7
LL - Air Restriction Indicator (Regular on 7700; Attachment on 6600) .....	7
MM - Platform Float Spring Indicator (Attachment) .....	150
NN - Fan Speed Control Wheel .....	20
OO - Chaffer Opening Control .....	20
PP - Sieve Opening Control .....	20
QQ - Powered Rear Wheel Drive Switch (Optional 7700 only) .....	
RR - Engine Fuel Shut Off (Diesel Engine only) .....	6



# Operation

---

## COMBINE AND ENGINE BREAK-IN

Follow the lubrication instructions closely. See pages 38 to 51.

Check coolant level in radiator and add coolant if necessary. Do not use water containing alkali. If combine is being operated in temperatures below 32°F., refer to "Cold Weather Operation," page 5.

To promote good ring seating and to prevent cylinder wall glazing, put the engine to work as soon as possible. Do not overload.

### AFTER 1 HOUR

Check torque on drive wheel bolts. Tighten bolts to 300 ft-lbs torque.

### AFTER 5 HOURS

Check all V-belts for initial stretch. Tighten if necessary. Continue to check V-belts every few hours for the first 50 hours.

### AFTER 20 HOURS

Drain oil from main hydraulic unit reservoir. Replace the oil filter and fill the reservoir with correct oil as specified on page 37. Thereafter, drain and replace oil and oil filter element every 500 hours of operation.

### AFTER 100 HOURS

During break-in, if oil consumption warrants, add oil as specified on page 37.

After the first 100 hours of operation, drain oil from crankcase, replace oil filter, and fill crankcase to proper level with John Deere Torq-Gard engine oil or its equivalent as specified in lubricants chart on page 37.

Thereafter change the oil and filter every 100 hours of operation or every season, whichever occurs first.

## COLD WEATHER OPERATION

### FUEL SYSTEM

Use winter-grade fuel. Fill the fuel tank at the end of the day's run to prevent moisture from condensing in the fuel tank.

### COOLING SYSTEM

Drain, flush, and fill cooling system with a recognized brand of radiator sealer and antifreeze solution. Use a permanent-type (ethylene glycol) antifreeze solution containing rust inhibitors and without stop-leak additive. This type of antifreeze is resistant to evaporation when heated.

Combine	Quarts of Ethylene Glycol Required at Lowest Expected Temperature					
	+20°F	+10°F	0°F	-10°F	-20°F	-34°F
6600	4	7	9	11	12-1/4	14
7700	5-1/4	8	10-1/2	12-1/2	14	16

After filling, check system for leaks.

### BATTERIES

When the temperature drops below freezing, be sure batteries are fully charged. A badly discharged battery freezes more quickly than one that is well charged. For example, a battery with a specific gravity reading of 1.175 (discharged) will freeze at 4°F., and a battery with specific gravity reading 1.300 (fully charged) will not freeze until the temperature reaches -65°F.


In freezing weather, do not add water to the batteries unless engine is going to be run. Water will freeze as it will not mix with the electrolyte until the alternator passes a charging current through the batteries.

**IMPORTANT:** If booster batteries are required, see instructions on page 106.

### COLD WEATHER STARTING AID

Diesel engines are equipped with an ether starting fluid adapter which injects atomized fluid into the engine air intake system. Normally ether is used for starting at temperatures below 32°F. Pressurized cans of starting fluid are available from your John Deere dealer.

To use the starting fluid, remove the safety cap and plastic spray button from the can. Remove the cap from the adapter and position the can under the adapter.



**IMPORTANT:** To avoid damage, turn engine with starter one or two revolutions before injecting starting fluid. Inject starting fluid only while the engine is turning.

To inject starting fluid, push up on the can.

Relax pressure on the can between "shots" of starting fluid. Stop injecting fluid after the engine starts. If the engine begins to die during the first few minutes of operation, inject another "shot" of fluid. When the engine is operating satisfactorily, remove the can from the adapter and replace the safety cap on the can.

Install the cap on the adapter when it is not in use to prevent dust from being drawn into the engine.

**CAUTION:** Ether starting fluid is highly flammable. Store starting fluid cans where they will not be subject to extreme cold or warm temperatures. For best results, store fluid at room temperature.

## HOT WEATHER OPERATION

Protect the combine engine cooling system against corrosive action by using Summer Engine Coolant Conditioner.

The Summer Engine Coolant Conditioner is available under Part No. T19566, and may be purchased from your John Deere dealer.

To install the Summer Engine Coolant Conditioner, perform the following:

Drain and flush cooling system and add two 32-oz. cans of Summer Engine Coolant Conditioner to the cooling system following directions on the container.

**IMPORTANT: Summer Engine Coolant Conditioner is NOT AN ANTIFREEZE or a cooling system sealer. Drain system and fill with recommended antifreeze solution as required for winter protection. When antifreeze solution is in system, it should not be necessary to use the Conditioner; however, should severely corrosive water conditions be present, the Conditioner is compatible with antifreeze solutions.**

## OPERATING THE ENGINE

### ENGINE INSTRUMENTS AND CONTROLS


#### Choke (Gasoline Engine Only)



X 2228

Pull choke control all the way out when starting engine. After engine is started, and for normal operation, push choke control all the way in.

#### Fuel Shutoff (Diesel Engines Only)



The fuel shutoff knob cuts off the fuel supply to the fuel injection pump. Push the knob all the way in before attempting to start engine.

To stop engine, pull fuel shutoff knob all the way out until engine stops running.

#### Throttle

Move throttle one quarter forward when starting engine. Move throttle all the way forward for normal operation; move throttle all the way rearward for slow idle.

#### Key Switch

Turn the key to "ON" to check the operation of the alternator indicator light. It should glow red.

Turn the key to "START" and hold until engine starts. Release the key when the engine starts. The alternator indicator light should go out.

If the lights do not go out after 10 seconds, shut off engine at once and determine the cause.

If the engine fails to start, refer to the trouble shooting charts on page 140.

If the parking brake is set when the key is turned "ON", the parking brake indicator light will flash off and on. When the parking brake is fully released the light will go out.

### Alternator Indicator Light




X 2229

This light glows red when the alternator is not charging. If the light goes on while the engine is running, stop engine and determine cause.

Check the operation of this light by turning the key to the "ON" position.

### Coolant Temperature Gauge



X2231

This gauge indicates the coolant temperature in the cooling system—not the quantity. The white zone on the dial indicates normal operating temperature; the red-orange zone indicates above normal operating temperature.

If the pointer on the gauge goes into the red-orange zone, stop the engine and determine the cause.

### Coolant Temperature Warning Horn

The low note horn sounds when the coolant temperature gauge registers "HOT." When the straw walker sensing unit (attachment) is activated, the horn will also sound.


If the horn sounds, stop engine and check the straw walkers for plugging and the engine for overheating.

If the straw walkers are not plugged, determine the cause of engine overheating.

### Air Restriction Indicator

The red signal in the restriction indicator is locked in view whenever the air cleaner element is dirty and needs servicing. Check the indicator every 10 hours and service the element (page 128) if necessary.


### Engine Oil Pressure Gauge



X 2232

This gauge indicates the pressure of the engine lubricating oil—not the amount of oil in the crankcase. Oil pressure will vary slightly with wear, but with recommended oil, it should read NORMAL at full governed speed (indicated by white zone on the dial). If oil pressure drops (indicated by red zone on the dial), stop immediately and determine the cause.

### Fuel Gauge



X 2233

The red-orange zone indicates that the tank is empty. A half-full mark and a full mark indicates the fuel level in the tank.

### Engine Tach-Hour Meter

The tach-hour meter shows the engine speed in hundreds of rpm and accumulated engine service in hours and tenths of hours (based on an average engine operating speed of 2500 rpm, 2200 rpm on turbocharged diesel). Use this hour meter to determine when lubrication and periodic services are needed.

## STARTING THE GASOLINE ENGINE

1. If starting in cold weather, see "Cold Weather Operation," page 5.
2. Disengage platform or corn head electromagnetic clutch switch, separator control lever, and grain tank unloading auger lever.
3. Place gearshift lever in neutral.
4. Depress clutch pedal fully or place the hydrostatic speed range lever in neutral.
5. Move throttle lever one-quarter open.
6. Pull the choke control out.
7. Turn key to "ON." Check the operation of the alternator indicator light. It should glow red.
8. Turn key to "START." After engine starts, release key and push the choke control in.

**IMPORTANT: When starting the engine, never hold the key in start position for more than 30 seconds at a time. If the engine does not start within 30 seconds, allow at least 2 minutes for proper cooling of the starter. Be sure to pause a few seconds after a false start to make certain that the starter has stopped completely before another start is attempted.**

If engine fails to start, see TROUBLE SHOOTING, page 140.

**IMPORTANT: Do NOT tow hydrostatic drive combines to start engine.**

9. Make certain the oil pressure gauge registers pressure and the alternator indicator light goes off. If not, stop engine and determine the cause.

10. Warm the engine and transmission for 5 minutes at fast idle—no load.

## STOPPING THE GASOLINE ENGINE

1. Set the throttle at medium idle speed and allow the engine to run at this speed for a few minutes before stopping. Turn key to "OFF."

2. After stopping the engine, remove the key from the switch to prevent tampering and unauthorized operation. Removing the key also prevents the switch from being accidentally left in the "on" or the "accessory" position and causing battery discharge.

## STARTING THE DIESEL ENGINE

1. If the engine has not been operated for a long period of time, or if the fuel tank has run dry, bleed the entire fuel system to remove air bubbles; see page 114.

**IMPORTANT: Never let the fuel tank run dry.**

2. If starting in cold weather, see "Cold Weather Operation," page 5.

3. Disengage platform or corn head electromagnetic clutch switch, separator control lever, and grain tank unloading auger lever.

4. Place gearshift lever in neutral.

5. Depress clutch pedal fully or place the hydrostatic speed range lever in neutral.

6. Move throttle lever to slow idle position and push in fuel shutoff.

7. Turn key to "ON." Check the operation of the alternator indicator light. It should glow red.

8. Turn key to "START." After engine starts, release key.

**IMPORTANT: When starting the engine, never hold the key in start position for more than 30 seconds at a time. If the engine does not start within 30 seconds, allow at least 2 minutes for proper cooling of the starter. Be sure to pause a few seconds after a false start to make certain that the starter has stopped completely before another start is attempted.**

If engine fails to start, see TROUBLE SHOOTING, page 140.

**IMPORTANT: Do NOT tow hydrostatic drive combines to start engine.**

9. Make certain the oil pressure gauge registers pressure and the alternator indicator light goes off. If not, stop engine and determine the cause.

10. Warm the engine and transmission for 5 minutes at fast idle—no load.

## STOPPING THE DIESEL ENGINE

1. Set the throttle at medium idle speed and allow the engine to run at this speed until the temperature gauge drops well into the white range on dial. Move the throttle to the rear pull out fuel shutoff and turn key to "OFF."

**IMPORTANT: Do not attempt to stop engine by turning off fuel supply at tank. Doing so will cause injection pump to run dry and damage internal parts.**

2. After stopping the engine, remove the key from the switch to prevent tampering and unauthorized operation. Removing the key also prevents the switch from being accidentally left in the "on" or the "accessory" position and causing battery discharge.

## STARTING THE TURBOCHARGED DIESEL ENGINE

1. If the engine has not been operated for a long period of time, or if the fuel tank has run dry, bleed the entire fuel system to remove air bubbles; see page 114.

**IMPORTANT: Never let the fuel tank run dry.**

*NOTE: If the prevailing temperature is 32°F. or lower, it may be necessary to use a cold weather starting aid to start the engine—see next page.*


3. Disengage platform or corn head electromagnetic clutch switch, separator control lever, and grain tank unloading auger lever.

4. Place gearshift lever in neutral.

5. Place the hydrostatic speed range lever in neutral.

6. Move throttle lever one-quarter open.

7. Make sure fuel shutoff is pushed all the way in.

 **CAUTION: Before starting the combine engine, be sure there is plenty of ventilation. Never operate the combine in a closed building.**

8. Turn key to "ON." Check the operation of the alternator indicator light. It should glow red.

9. Turn key to "START." After engine starts, release key.

**IMPORTANT: When starting the engine, never hold the key in start position for more than 30 seconds at a time. If the engine does not start within 30 seconds, allow at least 2 minutes for proper cooling of the starter. Be sure to pause a few seconds after a false start to make certain that the starter has stopped completely before another start is attempted.**

To obtain prompt engine starting after engine is killed (or starts and then stops), it may be necessary to pull the fuel shutoff out and push it all the way in.

If engine fails to start, see TROUBLE SHOOTING, page 140.

**IMPORTANT: Do NOT tow hydrostatic drive combines to start engine.**

10. Make certain the oil pressure gauge registers pressure and the alternator indicator light goes off. If not, stop engine and determine the cause.

11. Idle the engine for several minutes at speeds below 1200 rpm to insure turbocharger lubrication before accelerating or applying a load.

Should the engine be killed when operating under load, immediately restart the engine to prevent overheating of turbocharger parts, caused when the flow of oil for cooling and lubrication is stopped.

When starting the engine after the combine has been idle for an extended period or after the oil filter has been changed, pull the fuel shutoff all the way out, and crank the engine with the starter until the engine oil pressure indicator light goes out. Do not operate the starter more than 30 seconds at a time. After the indicator light goes out, move the throttle to the slow idle position, make sure fuel shutoff is all the way in, and start the engine.

## STOPPING THE TURBOCHARGED DIESEL ENGINE

1. Place the hydrostatic speed range lever in neutral.

2. Place gearshift lever in neutral.

3. Allow the engine to idle a few minutes to cool the engine and turbocharger. (Lubrication and cooling of the turbocharger and some engine parts is provided by the engine lubricating oil. Therefore, sudden stopping of a hot engine may allow some parts to overheat and cause possible damage.) Allow the temperature gauge to drop well into the white range on the dial.


4. Move the throttle lever to the rear, pull out the fuel shutoff, and then turn key to "OFF."

**IMPORTANT: Do not attempt to stop engine by turning off fuel supply at tank. Doing so will cause injection pump to run dry and damage internal parts.**

5. After stopping the engine, remove the key from the switch to prevent tampering and unauthorized operation. Removing the key also prevents the switch from being accidentally left in the "on" or the "accessory" position and causing battery discharge.

## OPERATOR'S PLATFORM COMPONENTS

### OPERATOR'S SEAT




*Seat in Sitting Position*

The operator's seat moves forward and rearward or up and down to accommodate individual height and allow greater accessibility to all controls. If the operator wishes to stand, the seat can be positioned out of the way to allow ample leg space.

Use only warm water and mild soap to clean the seat cushions. NEVER USE SOLVENTS.

#### **Positioning the Seat Forward or Rearward**

While sitting in the seat, push lever "A" forward as far as possible and by using your weight, adjust seat to desired position and then release lever "A."



*Seat in Standing Position*

#### **Positioning the Seat Up or Down**

Remove four spring locking pins "B." Raise or lower the seat to the desired height. Reinsert spring locking pins "B."


#### **Positioning the Seat for Standing**

To move the seat up and back, stand up and apply pressure to the front of the seat with the back of your legs. The seat will move to the up and back position to allow standing room.

To return the seat to the sitting position, move the seat forward by pulling on the front of the seat with your hand.

## STEERING COLUMN

The steering column is adjustable to one of four positions for individual arm lengths. This allows better visibility and greater accessibility to the steering wheel and controls on the steering column.




To adjust steering column, push pedal down, position column to desired setting, and release pedal.




## PIVOTING LADDER

Move the pivoting ladder up out of the way of uncut grain to avoid grain loss by ladder impact.



To move ladder, pull lever "A" up and to the right to release the lock.

Pull lever "B" forward until the ladder is parallel to the ground.




Push lever "A" to the left to lock ladder in place.

To lower the ladder, reverse above procedure.

## TRANSPORTING

The combine can be transported by driving it under its own power, carrying it on a truck, or by towing it. If combine is to be towed, place the gearshift lever in its "TOW" position and tow up to a maximum speed of 20 mph.

**CAUTION:** If towed at higher speeds, remove the drive shafts and lock the brake drums in place by applying the parking brake.



*Gearshift in Tow Position*

Couple the brake pedals together with the brake lock (page 25).

Reduce the width of the combine by folding the unloading auger back along the separator and removing the platform or corn head. Over-all dimensions are given on page 162.

When unloading auger is folded back along the separator the unloading auger spout must be raised so as not to block the left-hand warning light from view of vehicles approaching from the rear.

If the platform or corn head and feeder house are removed, the hydraulic cylinders must be wired or supported by chains no closer to separator support channel than 14 inches. Damage may result to hoses if carried too close.

If the platform or corn head is left on, raise it to a position allowing good visibility.

Reduce the spread of noxious weed seeds by thoroughly cleaning the combine before leaving one field and going to the next.

Sweep trash and straw from the outside of combine. Open doors at bottom of elevators, remove grain tank drain hole cover, and run combine until all straw, trash, and grain are removed from inside. Shut off combine engine. Clean out shoe grain supply augers (page 76).


The combine is equipped with a slow moving vehicle emblem on the rear hood, lights, and grain tank reflectors for transporting protection. Keep the emblem, reflectors, and lights clean.

**CAUTION:** When driving the combine on a road or highway at night or during the day, use accessory lights and devices provided for adequate warning to the operators of other vehicles. In this regard, check local governmental regulations.

## FIELD AND CROP OPERATING ADJUSTMENTS

This section explains adjustments which are made due to crop or field conditions. Adjustments which are made to compensate for wear or misalignment are explained in the SERVICE section, page 52. For illustrations of controls not shown in this section, see the CONTROLS AND INSTRUMENTS section, page 2.

### PLATFORM OR CORN HEAD



H21132

The cutting platform illustrated above is only one of the headers which can be attached to the front of the feeder house. For complete information on these headers (cutting platform, draper platform, pickup platform, belt pickup, and corn head) see the operator's manuals supplied with them.

The platform or corn head receives the crop and moves it to the front of the feeder house by means of an auger.

Height of the platform or corn head can be changed by moving the height control lever located on the steering column. As a safety measure, platform or corn head height cannot be changed unless the engine is running.


On combines so equipped, an electromagnetic clutch permits stopping the platform or corn head and feeder house while the separator continues to run. It is engaged or disengaged by operating a switch on the control panel.

While servicing the platform or corn head, always use the hydraulic cylinder safety stop (page 52).

#### Platform or Corn Head Electromagnetic Clutch Switch

Push switch in to disengage clutch. Pull switch out to engage clutch.


#### Platform or Corn Head Height Control Lever



To lower the platform or corn head, move the height control lever forward.

To raise the platform or corn head, move the lever rearward.

Regulate the speed of lowering by turning a cap screw on the control valve (page 100).



H22359

The feeder house receives the grain from the platform or corn head and force feeds it to the threshing cylinder.

The speed of the feeder house determines the speed of the platform or corn head.

When combining grain, the feeder house speeds must be as specified (page 30) to maintain correct platform speeds.

**IMPORTANT:** When attaching a platform to the corn feeder house, adjust the feeder house speeds as shown on page 56. Never alter speeds from these specifications.

When combining corn, change the feeder house speeds by moving the variable speed feeder house control lever. See the corn head operator's manual for correct speeds.

### Conveyor Chain


On left-hand side of feeder house, look down along rear edge of door opening and check clearance between bottom of conveyor chain and wear strip on feeder house torque frame. Clearance should be 1/16 to 1/8 inch on regular length feeder houses and 0 to 1/16 inch on long feeder houses (page 60).

### Conveyor Chain "Float"

Floating action of the conveyor accommodates varying volumes of material. Adjust the conveyor "float" for either grain or corn (page 61).

### Variable Speed Feeder House Control Lever (Optional)


HYDRAULIC LIFT CONTROL LEVER OR VARIABLE SPEED FEEDER HOUSE CONTROL LEVER



To increase the speed, push the variable speed feeder house lever forward.

To decrease the speed, pull the lever rearward.

## SEPARATOR



The separator receives the force-fed material from the feeder conveyor and separates the largest percentage of the grain from the straw at the cylinder and concave. This free grain falls immediately through the concave grate into the shoe grain supply augers.

The remaining straw and grain pass under the rotary deflector and curtains which regulate the flow of straw onto the straw walkers. The walkers lift and tumble the straw permitting the remaining grain to fall through the walkers into the shoe grain supply augers. The straw is carried over the walkers and out of the combine.

The shoe grain supply augers are positioned under the cylinder and concave and extend to the rear of the straw walkers. The front half of each auger conveys grain from the cylinder and concave rearward to the front of the cleaning shoe. Flights on the rear half of each auger are reversed to convey grain that falls through the straw walkers forward to the front of the cleaning shoe.

Regardless of the crop harvested, good separation is directly dependent on the speed of the separator. The separator speed is determined by the speed of the primary countershaft. Keep primary countershaft speed at 1500-1510 rpm with engine at full throttle-no load (page 74).

Reducing the primary countershaft speed reduces the speed of the platform or corn head, straw walkers, cleaning shoe, elevators, and augers. This sluggishness can result in clogging and grain loss.

Increasing the primary countershaft speed causes material to pass through the combine too rapidly, causing grain loss and strain and wear on all moving parts.

The separator is engaged or disengaged by moving the separator control lever on the operator's platform.



**CAUTION: Do not engage separator until everyone is standing away from moving parts or belts.**



**Suggest:**

**If the above button click is invalid.**


**Please download this document**

**first, and then click the above link**

**to download the complete manual.**

**Thank you so much for reading**

### Separator Control Lever



To engage the separator, push lever forward.

To disengage the separator, pull lever rearward.

### Cylinder (Rasp-Bar and Spike-Tooth)

Good threshing depends on proper relationship between the cylinder speed and the cylinder-concave spacing. A large seed requires low speed and a wide spacing to prevent cracking; a small seed requires high speed and a close spacing so the seed will be rubbed out.

Between these two extremes are the many crops a combine is expected to handle. Carefully select the best relationship for each crop (page 32). Neglect or carelessness can mean heavy crop losses.

These combines are equipped with a variable speed cylinder with a speed range from 407 to 1228 rpm. A special drive sheave may be purchased from your John Deere dealer to provide a slower speed range (280 to 845 rpm) for combining large seed (page 65).


Change cylinder speed by moving the cylinder speed control ratchet shown above at right. A tachometer in the instrument panel registers the cylinder rpm's by hundreds.

### Cylinder Speed Tachometer

The tachometer registers cylinder rpm's by hundreds. It aids in maintaining the correct cylinder speed for a particular crop.

To insure proper tachometer readings keep the drive belt tight at all times.

### Cylinder Speed Control Ratchet



Before increasing or decreasing cylinder speed, place ratchet pawl in the proper position.


To increase the cylinder speed, move the ratchet toward "FAST."

To decrease the cylinder speed, move the ratchet toward "SLOW."

**IMPORTANT: Adjust the cylinder speed only when the separator is running.**

See Suggested Settings Chart, page 32.

### Choked Cylinder



If the cylinder becomes choked, open concave and run separator to clean cylinder.

**IMPORTANT: Continued running of the separator with a choked cylinder will cause damage to sheaves and V-belts due to belt slippage.**

If cylinder remains choked, shut off engine, leave concave fully open and remove all straw and other material from front of concave through cylinder front door. Place a suitable breaker bar on cylinder sheave lugs. Rock cylinder back and forth until cylinder is clear.

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**