

JOHN DEERE 6601 COMBINE



OPERATORS MANUAL JOHN DEERE 6601 COMBINE

OMH88383 C5 English

OMH88383 C5


LITHO IN THE U.S.A.
ENGLISH





To the Purchaser

This new combine was carefully designed and manufactured to give years of dependable service. To keep it running efficiently, read the instructions in this operator's manual. Each section is clearly identified so you can easily find the information you need—whether it is operation, lubrication, or service. Read the Table of Contents to learn where each section is located. Use the alphabetical index for fast reference.


 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

In addition to the equipment furnished with your combine, attachments are available to help you do a better job in special crop conditions. These are described in the attachments section of this manual and can be purchased from your John Deere dealer.

"Right-hand" and "left-hand" sides are determined by facing in the direction the combine will travel when in use.

Record your combine serial numbers in the space provided on page 69. Your dealer needs this information to give you prompt, efficient service when you order parts or attachments. If your combine requires replacement parts, go to your John Deere dealer where you can obtain Genuine John Deere parts—accept no substitutes.


The warranty on this combine appears on your copy of the purchase order which you should have received from your dealer when you purchased the combine.





Contents

	Page
Safety suggestions	2
Controls and instruments	3,4
Operation	5-31
Lubrication and periodic service	32-37
Service	38-70
Trouble shooting	71-76
Storage	77
Attachments	78,79
Specifications	80,81
Index	82,83



- A. Field Lights
- B. Unloading Auger
- C. Feeder House

- D. Hitch Tube
- E. Turning Stop
- F. Support Stand

- G. Belt Pickup
- H. Clean Grain Elevator
- I. Straw Chopper
- J. Warning Light

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>



Safety Suggestions

⚠ This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

The safety of the operator was one of the prime considerations in the minds of John Deere engineers when this combine was designed. Shielding, simple adjustments, and other safety features were built into the combine wherever possible.

All machinery should be operated only by responsible persons who have been properly instructed and delegated to do so.

Only the operator should be allowed to ride on the tractor when combining.

Clothing worn by combine operator should be fairly tight and belted. Loose jackets, shirts, or sleeves should never be worn because of the danger of getting into moving parts.

Be certain shields and guards are in place and in good condition before starting in the field.

Escaping fluid under pressure can have sufficient force to penetrate the skin, causing serious personal injury. Before disconnecting lines be sure to relieve all pressure. Before applying pressure to system, be sure all connections are tight and that lines, pipes and hoses are not damaged. Fluid escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands, to search for suspected leaks.

If injured by escaping fluid, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.

Before applying cylinder breaker bar, always disengage separator and shut off tractor. After clearing cylinder, remove cylinder breaker bar before restarting tractor and engaging separator.

Make certain everyone is clear of the combine and tractor before starting so they cannot be struck by moving parts or caught in a drive belt or chain.

Never clean, lubricate, or adjust the combine when it is running.

Be especially careful when operating on hillsides because the combine or tractor may tip sideways if it strikes a hole, ditch, or other irregularity.

Always keep the tractor in gear when going down hills.

Lower safety stop when working on platform.

Before leaving the combine unattended, support the cutting platform with either the hydraulic cylinder safety stop or with blocks, or lower it to ground level.

Never attempt to clear obstructions off the platform unless the PTO is disengaged and the tractor engine is shut off.

Maintain a fire extinguisher in an easily accessible location and be familiar with its correct use.

Be certain the gearshift lever of your tractor is in neutral and the PTO lever is disengaged before starting the tractor engine.

Tractor brakes should be properly adjusted.

Always use platform safety stop when transporting the combine.

When transporting the combine on a road or highway at night or during the day, use the lights and devices provided for adequate warning to operators of other vehicles. In this regard, check your local governmental regulations.

Fold the unloading auger when transporting. When moving on a highway, keep as far to the right as possible.




Controls and Instruments

This section illustrates all controls and instruments necessary for successful field operation. For an explanation of each control and instrument, refer to the page reference given.


Before attempting to operate your new combine, become familiar with the location and purpose of its controls and instruments. Study these pages carefully, regardless of your previous combine experience.

SWITCH BOX



- Grain Tank Unloading Auger Switch - Page 27
- Grain Tank Unloading Auger Warning Light - Page 27
- Platform Switch - Page 14
- Platform Switch Warning Light - Page 14
- Straw Walker Plugging Warning Horn - Pages 62, 79
- Light Switch - Page 28


CONCAVE



A. Concave Spacing Control Ratchet C. Timed Sector
B. Pointer


Concave Spacing Control Ratchet - Page 20

CYLINDER



Cylinder Speed Control Crank - Page 19


CLEANING FAN



A. Pointer C. Fan Speed Control Wheel
B. RPM Indicator

Cleaning Fan Speed Control Wheel - Page 24

CHAFFER AND SIEVE



Chaffer Opening Control Levers - Page 25
Sieve Opening Control Lever - Page 25




Operation

TRACTOR HOOKUP

CAUTION: Operate the 6601 Combine at 1000 rpm PTO speed only. Operating the combine at any other PTO speed can result in machine damage or personal injury.

YOKE ASSEMBLY



Should it become necessary to disturb locking clamp on hitch tube powershaft, make certain bearing and yoke assemblies are assembled on the shaft, using dimensions given in the illustration above for proper position. Failure to do so will cause misalignment of hookup parts.

IMPORTANT: Under normal circumstances, locking clamp should not be moved unless it becomes necessary to replace parts.


SWITCH BOX

The switch box is wired at the factory for tractors with a 12-volt electrical system or a split electrical system (24-volt starting).

Instructions for hookup of switch box wires are on pages 9 and 10.

Diode Panel

The diode panel in the switch box is wired for tractors with a negative ground electrical system. This means that the double white wire in the six-pin connector is to the open side of the switch box as shown.




When using a tractor with a positive ground electrical system, rotate the six-pin connector 180 degrees.

ATTACHING SWITCH BOX AND WIRING TO ALL TRACTORS WITHOUT CABS AND TO TRACTORS WITH CABS PRIOR TO 1968

If switch box and wiring have not already been installed on tractor, proceed as follows:



Switch Box



1. Secure switch box support bracket to seat frame, using existing hardware.
2. Secure switch box to support bracket, using two 1/4 x 1/2-inch cap screws.




Harness Plate (Cabs Only)





1. Cut and drill holes, to dimensions shown, in right-hand rear of cab.
2. Attach harness plate to cab, using three 1/4 x 7/8-inch truss head machine screws. Install grommets in harness plate.
3. (Not Illustrated) Run wires from switch box through holes in harness plate.

SWITCH BOX—Continued

Attaching Switch Box To Tractors with Cabs 1968-1971




1. Secure switch box support bracket to cab, using existing hardware. On the 4520 Tractor the switch box support bracket will have to be mounted in the second and third hole from the front of the fender.



4. Cut and drill holes, to dimensions shown, in right-hand rear deck of cab.

5. Attach harness plate to rear deck, using three 1/4 x 7/8-inch truss head machine screws. Install grommets in harness plate.


6. (Not Illustrated) Run wires from switch box through holes in harness plate.



2. Secure switch box to bracket, using two 1/4 x 1/2-inch cap screws and two 9/32 x 5/8 x .060-inch flat washers.


3. Run wires from switch box through clip and attach clip to cab, using existing hardware.

Attaching Switch Box To 4230, 4430 And 4630 Tractors With Cabs (1972-)




1. Remove upper seat back support (not illustrated). Attach switch box support bracket to seat frame, as shown, using existing hardware.

2. Secure switch box to support bracket, using two 1/4 x 1/2-inch cap screws.




3. Pull cab foam away to expose the six 5/16 x 3/4-inch cap screws and remove cover. Route cable and wires through opening.

NOTE: Save cover removed in Step 3 for reuse when tractor is not used with combine.




4. Slip larger grommet around cable and push into the large hole in the harness plate provided. Slip the smaller grommet around the three wires and push into the small hole in the harness plate.

5. Attach harness plate, with new gasket, to rear of cab with hardware removed in Step 3. Replace cab foam.



6. Attach bracket with socket to transport arm, using existing hardware.

ATTACHING COMBINE TO TRACTOR




IMPORTANT: When attaching to a John Deere 6030 Tractor, it is necessary to change the tractor rear PTO shaft to 1-3/8-inch (35 mm) spline. See your John Deere dealer.

NOTE 1: To prevent accidental discharging of tractor batteries when tractor-combine hook-up is left unattended, disconnect six-pole plug from tractor.

NOTE 2: Adapt the tractor remote hydraulic cylinder valve housing for single-action cylinder operation. See tractor operator's manual. Couple hydraulic hose to tractor No. 1 hydraulic circuit breakaway coupler.


ATTACHING COMBINE TO TRACTOR—Continued

The following illustrations show wire connections between switch box and battery for various tractors.




H 19153

Gasoline and LP-Gas
4010 - 4020 - 4230




H 19156

Diesel
5010 - 5020



H 19155

Diesel
4010 - 4020 (-201000)




H 19154

Diesel
4000-4020 (201,001-) 4230-4320-
4430-4520-4620-4630-6030

Diode Panel


The diode panel in the switch box is wired for tractors with a negative ground electrical system. This means that the double white wire in the six-pin connector is to the open side of the switch box as shown.



When using a tractor with a positive ground electrical system, rotate the six-pin connector 180 degrees.

Hookup Adjustments

Adjust hitch plates, powershaft, tractor drawbar, and turning stops as shown below.



COMBINE BREAK-IN

Follow the lubrication instructions and periodic service information closely (page 32).


STARTING THE COMBINE

CAUTION: Make certain no one is standing near enough to the combine or tractor to touch any moving parts. Warn everyone to stand clear.

When tractor is properly warmed, idle engine and engage PTO slowly to engage the separator. Then run tractor at rated PTO speed.

Check the speed of the primary countershaft with a speed indicator (page 51). The countershaft should operate at 1500 rpm with separator empty and not under load. If the countershaft speed is incorrect, check tractor PTO speed. If PTO is not operating at proper rpm rated speed, see your John Deere dealer.

TRANSPORTING



Combine in Transport Position

This combine is designed for easy and safe transporting. The width of the combine can be reduced by: folding unloading auger back along separator, removing the platform, and moving the hitch.

To fold unloading auger back along separator, unfasten over-center lock and swing outer auger back. Secure outer end of auger against separator with transport lock (page 65).

IMPORTANT: Always fold unloading auger back along separator and disconnect powershaft when transporting the combine.

Three locking positions are provided for the swinging hitch. The inside locking position is for field operation. The center locking position is for loading and transporting the combine on a flat car. Under no circumstances will you need to use this center position once the combine has been removed from the flat car.

The outer position locks the hitch for highway or field transporting. To secure hitch tube in transporting position, raise platform to its highest position. Remove hitch pin from operating position and swing hitch tube inward as far as possible. Install hitch pin in transporting position.

CAUTION: Always use the hydraulic cylinder safety stop (page 15) when transporting the combine with the platform in raised position.

The combine is equipped with a slow moving vehicle emblem on the rear hood, lights, grain tank reflectors, and red reflective tape on the backside of the platform for transporting protection. Keep the emblem, reflectors, and lights clean.

CAUTION: When transporting the combine on a road or highway at night or during the day, use the lights and devices provided on the combine for adequate warning to the operators of other vehicles. In this regard, check your local governmental regulations.

FUNDAMENTALS OF COMBINE HARVESTING

This new combine can be quickly and easily adjusted to harvest almost any crop under any condition. Before attempting to operate your new combine, become familiar with the following fundamentals of combine harvesting.

1. The crop must be in condition to thresh. Moisture content must not be too high and straw must not be too green. Grain containing 14% moisture or less and corn containing 17% moisture or less is usually considered dry enough for safe storage.

2. Adjust the combine to suit the particular crop being harvested and the particular field condition.

3. Select a ground speed that will not overload the combine. The tractor engine should always be run at full throttle to keep the combine separator up to full speed. This will guard against slugging and clogging. Use the selective ground speed drive to obtain a slower travel speed or shift to a lower gear if necessary, but do not throttle down the tractor engine. Driving too fast or crowding the combine may result in crop loss or combine damage. Excessive ground speed travel is one of the greatest causes of trouble in combining.

4. Keep the cylinder speed as low as possible and the concave clearance as wide as possible to separate the maximum amount of grain from the heads without breaking up the straw excessively. Such crops as edible beans and peas are easily cracked and require the use of a special slower speed cylinder drive sheave. When combining edible beans and peas, keep the combine reasonably full at all times to provide sufficient straw and chaff to cushion the crop against cracking.

5. When using a cutting platform, cut the crop as high as possible without excessive loss of low heads. If the straw is down and tangled, it may be necessary to install lifting guards. A slower ground speed is important when combining under this condition. Adjust reel position and speed for even feeding. Keep the cutterbar in proper register and the guards in alignment to insure clean cutting.

6. When using a belt pickup attachment, keep the windrow to the left-hand side of the pickup so that the material is fed evenly into the feeder house. The heads of grain should be lying in one general direction; therefore, operate the combine so that the heads are picked up first. This insures better threshing and separation of the grain. Losses will increase if the windrows are picked up in the opposite direction.

7. Adjust chaffer openings to pass the grain or seed to the lower sieve, before it has passed over two-thirds the length of the chaffer, without admitting too much coarse material.


8. Use as much air as possible without blowing over clean grain and seed. Heavy crops, such as edible beans, require a large volume of air. Light seed crops, such as clover, require little air.

Combine harvesting can be profitable only if the operator knows how to adjust the combine properly and operate it efficiently with a minimum of losses.

FIELD AND CROP OPERATING ADJUSTMENTS

This section explains all field and crop operating adjustments. Adjustments which are required to compensate for wear and misalignment are explained in the SERVICE section, page 38. For illustrations of controls not shown in this section, see the CONTROLS AND INSTRUMENTS section, page 3.

PLATFORM



H20522

The platform receives the crop and moves it to the front of the feeder house by means of an auger. Retracting fingers on the auger feed the material to the feeder conveyor.

The operation and height of the platform is controlled by the operator from the tractor seat. By operating the platform switch, an electric clutch is either engaged or disengaged, allowing the platform to be started or stopped immediately. When the switch activates the electric clutch, a warning light on the switch box glows red.

The height of the platform is controlled by the tractor remote cylinder operating lever.

Platform performance depends largely on maintaining correct unit speeds (page 29) and keeping the platform as level as possible (page 39).

While servicing the platform, always use the hydraulic cylinder safety stop (page 15).


Platform Switch

Push switch (page 3) down to disengage clutch. Push switch down again to engage clutch.

Platform Switch Warning Light

The warning light (page 3) glows red when the platform switch is activated.


Platform Height Control



Remote Cylinder Operating Levers
on 4230, 4430, and 4630 Tractors

Raise and lower the platform with the remote cylinder operating lever on the tractor. To raise the platform, push the lever forward. To lower the platform, pull the lever rearward.


Hydraulic Cylinder Safety Stop



Safety Position

CAUTION: Always use the safety stop when working on the platform or when transporting the combine in the field or on the highway.

To place the stop in safety position, first extend hydraulic cylinder. Disconnect the support chain from the safety stop and position the safety stop on the piston rod.



Storage Position

After transporting or completing work on the platform, attach safety stop to support chain for storage.

Platform Auger

The platform auger is set at the factory with 1/8- to 5/8-inch (3 to 16 mm) clearance between the auger flights and platform bottom. This setting is required for most crops and conditions.

If the auger is too high or does not have the same relationship at both ends, material may not be fed properly to the feeder conveyor.

It may be necessary to raise the auger when combining coarse stemmed crops or heavy windrows.

When repositioning the auger, maintain the same measurement between the outer ends of the auger and the platform bottom.

Retracting fingers in the auger are adjustable to obtain the best delivery to the feeder conveyor.

Adjusting Auger Height

On right-hand side of platform, loosen two nuts "A." To raise the auger, loosen nut "B" and tighten nut "C." To lower the auger, loosen nut "C" and tighten nut "B."

On the left-hand side, loosen nuts "A" and nut "B." To raise the auger, tighten bolt "C." To lower the auger, loosen bolt "C." Tighten nut "B" and nuts "A."

IMPORTANT: Keep auger level; be certain there is ample clearance for the auger fingers and proper clearance between auger flights and stripper. Check drive chain tension (page 41).

Adjusting Auger Forward or Rearward

On right-hand side of platform, loosen the two bolts "D" in the adjusting bracket. Move auger to the necessary position, and tighten nuts.

NOTE: Do not disturb finger height setting.

On left-hand side, loosen nut "D" and tighten nut "E" to move the auger rearward. Loosen nut "E" and tighten nut "D" to move the auger forward.


Adjusting Finger Clearance

Maintain equal clearance between both the end finger bearings and the finger cranks, as illustrated. Loosen lock nut "F" on right-hand side of platform and move shaft in or out as necessary. Then secure shaft in position by tightening lock nut "F."


Adjusting Finger Height

On the right-hand side of the platform, loosen the two bolts "G" in the adjusting bracket and pivot the top of bracket forward to move the extended fingers down on the auger tube. Minimum clearance between fingers and platform bottom is 1/8 to 1/4 inch (3 to 6 mm). Tighten nuts. To move fingers up, reverse the procedure.


NOTE: Do not disturb the auger forward and rearward adjustment.




Right-Hand Side



Left-Hand Side



H25264



Conveyor Chain


Adjust the chain until the slats begin to rise off the rear of the feeder house bottom at the row of countersunk bolts (page 41). Too much slack allows the chain links to jump the sprocket teeth.

Do not overtighten the chain.

Conveyor Chain Float

Floating action of the conveyor accommodates varying volumes of material. Adjust the conveyor "float" so a 1/8-inch (3 mm) space exists between a slat and the feeder house bottom directly under the feeder drum (page 42).

SEPARATOR



H25456

The separator receives the force-fed material from the feeder conveyor and separates up to 90 percent of the grain from the straw at the cylinder and concave. This free grain falls immediately through the concave grate into the shoe grain supply augers.

The remaining straw and grain pass under the rotary deflector and curtains which regulate the flow of straw onto the straw walkers. The walkers lift and tumble the straw permitting the remaining grain to fall through the walkers into the shoe grain supply augers. The straw is carried over the walkers and out of the combine.

The shoe grain supply augers are positioned under the cylinder and concave and extend to the rear of the straw walkers. The front half of each auger conveys grain from the cylinder and concave rearward to the front of the shoe. Flights on the rear half of each auger are reversed to convey grain that falls through the straw walkers forward to the front of the shoe.

Regardless of the crop harvested, good separation is directly dependent on the speed of the separator. The separator speed is determined by the speed of the primary countershaft. Keep primary countershaft speed at 1500 rpm at all times (page 51).

Reducing the primary countershaft speed reduces the speed of the platform, straw walkers, cleaning shoe, elevators, and augers. This sluggishness can result in clogging and grain loss.


Increasing the primary countershaft speed causes material to pass through the combine too rapidly,

causing grain loss and strain and wear on all moving parts.

The separator is engaged or disengaged by moving the PTO clutch lever on the tractor.

CAUTION: Do not engage separator until everyone is standing away from moving parts or belts.

PTO Clutch Lever



4430 - 4630 Tractor PTO Lever Illustrated

To engage the separator, idle tractor engine and push lever forward slowly. After the separator is engaged, run tractor engine at rated PTO speed.

To disengage the separator, idle tractor engine and pull lever rearward.



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading

Cylinder


Good threshing depends on proper relationship between the cylinder speed and the cylinder-concave spacing. A large seed requires low speed and a wide spacing to prevent cracking; a small seed requires high speed and a close spacing so the seed will be rubbed out.

Between these two extremes are the many crops a combine is expected to handle. Carefully select the best relationship for each crop (page 30). Neglect or carelessness can mean heavy crop losses.

This combine is equipped with a variable speed cylinder with a speed range from 407 rpm to 1229 rpm. A special drive sheave may be purchased from your John Deere dealer to provide a slower speed range (280 rpm to 845 rpm) for combining large seed (page 49).

Change the cylinder speed by turning a control crank on the clean grain elevator. Check the tension on the control chain periodically (page 46).

Cylinder Speed Control Crank



Loosen locking knob.

To increase the cylinder speed, turn the crank toward "FAST."

To decrease the cylinder speed, turn the crank toward "SLOW."


Tighten locking knob.

IMPORTANT: Adjust the cylinder speed only when the separator is running.

A cylinder speed reference indicator is mounted on the back side of the clean grain elevator. The reference numbers are a guide to the operator so he can return to the cylinder speed setting that was previously found best for a particular crop or field condition.

See Suggested Settings Chart, page 30.

Choked Cylinder



If the cylinder becomes choked, open concave and run separator to clean cylinder.

If cylinder remains choked, shut off tractor. Leave concave fully open and remove all straw and other material from front of concave through the cylinder front door. Place the breaker bar on the sheave lugs on the right-hand end of the cylinder shaft. Rock the cylinder back and forth until the cylinder is clear.

CAUTION: Before applying cylinder rocker, disengage separator and shut off tractor. After clearing cylinder, remove cylinder rocker before re-starting tractor and engaging separator.

Be certain to adjust the concave to original position after the cylinder has been cleared.

Concave

The concave may be adjusted from almost no spacing to a front spacing of 1-1/2 inches (38 mm) measured at the fourth grate bar. It is designed so the rear spacing automatically increases or decreases to half the front spacing. Thus, the rear of the concave never needs adjusting unless the concave is replaced or the rear spacing is disturbed (page 50). Adjust the concave with the ratchet on the front right-hand side of the separator.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>