

Series 300 4039, 4045, and 6068 Marine Engines

**Deere Power Systems Group
OMRG20144 Issue B5
(This manual replaces OMRG20144 Issue D3)**

LITHO IN U.S.A.
ENGLISH

To The Operator

THIS OPERATING AND SERVICE MANUAL outlines the detailed service procedures and recommended service intervals for 4039, 4045, and 6068 Marine Engines to assure years of dependable and efficient performance. Each section is clearly identified so you can easily find the information you need—whether it is operation, lubrication, troubleshooting, or service.

SERVICE AND REPAIR/REPLACEMENT PROCEDURES outlined in this manual involve only the marine related components. For major internal engine repairs and externally accessible standard engine components (water pump, crankshaft oil seals, etc.), refer to CTM8—3029, 4039, 6059, 4045, and 6068 Engines Component Technical Manual. Have your authorized servicing dealer or marine engine distributor perform necessary repairs.

READ THIS MANUAL CAREFULLY to learn how to operate and service your engine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your boat and should remain with the boat when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and specified grade (or higher grade) of fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing the flywheel end (rear) of the engine and facing toward the front (water pump end) of engine.

WRITE PRODUCT IDENTIFICATION (SERIAL) NUMBERS and engine option codes in the spaces indicated in the Record Keeping Section of this manual. Accurately record all the numbers to help in tracing the boat should it be stolen. Your dealer also needs these numbers when parts are ordered for servicing. Since this manual is to remain on-board the boat at all times, also file the identification numbers in a secure place away from the boat.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

CERTAIN ENGINE ACCESSORIES such as air cleaner and instruments are optional equipment on John Deere Engines. These accessories may be provided by the equipment manufacturer instead of John Deere. This operator's manual applies only to the engine and those options provided through the John Deere parts distribution network.

• Engine Identification

MARINE ENGINES COVERED in this manual may be identified by the model number designation 4039D, 4045T, 6068D, or 6068T which are a portion of the serial number:

- The first digit shown indicates the number of cylinders.
- The second, third, and fourth digits indicate displacement in liters.
- The fifth digit (letter) indicates engine aspiration:
 - D—Naturally aspirated (non-turbocharged)
 - T—Turbocharged

For example: 4039D designates a 4-cylinder engine that has 3.9 L (239 cu. in.) displacement and the engine is naturally aspirated.

Engine Owner

JOHN DEERE ENGINE OWNER:

Don't wait until you need warranty or other service to meet your local John Deere Engine Distributor or Service Dealer.

Learn who he is and where he is. At your first convenience, go meet him. He'll want to get to know you and to learn what your needs might be.

UTILISATEURS DE MOTEURS JOHN DEERE:

N'attendez pas d'être obligé d'avoir recours à votre Concessionnaire ou Point de Service le plus proche pour vous adresser à lui.

Renseignez-vous dès que possible pour l'identifier et le localiser. À la première occasion, prenez contact avec lui et faites-vous connaître. Il sera lui aussi heureux de faire votre connaissance et de savoir que vous pourrez compter sur lui le moment venu.

AN DEN BESITZER DES JOHN DEERE MOTORS:

Warten Sie nicht auf einen evt. Reparaturfall um den nächstgelegenen John Deere Händler kennen zu lernen.

Machen Sie sich bei ihm bekannt und nutzen Sie sein "Service Angebot".

PROPRIETARIO DEL MOTORE JOHN DEERE:

Non aspetti fino a quando ha bisogno della garanzia o di un altro tipo di assistenza per incontrarsi con il Suo Concessionario che fornisce l'assistenza tecnica.

Impari a conoscere chi è e dove si trova. Alla Sua prima occasione cerchi d'incontrarlo. Egli desidera farsi conoscere e conoscere le Sue necessità.

PROPIETARIO DE EQUIPO JOHN DEERE:

No espere hasta necesitar servicio de garantía o de otro tipo para conocer a su Distribuidor de Motores John Deere o al Concesionario de Servicio.

Entérese de quién es, y dónde está situado. Cuando tenga un momento, vaya a visitarlo. A él le gustará conocerlo, y saber cuáles podrían ser sus necesidades.

JOHN DEERE MOTORÄGARE:

Vänta inte med att besöka Din John Deere återförsäljare till dess att Du behöver service eller garanti reparation.

Bekanta Dig med var han är och vem han är. Tag första tillfälle att besöka honom. Han vill också träffa Dig för att få veta vad Du behöver och hur han kan hjälpa Dig.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.


Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

Identification Views


4039DFM01 ENGINE WITH GEAR DRIVEN SEA WATER PUMP



RG6689 -UN-26MAR93




RG6688 -UN-26MAR93



RG6690 -UN-26MAR93




RG6691 -UN-26MAR93



RG6692 -UN-26MAR93

Identification Views

4045TFM01 ENGINE WITH BELT DRIVEN SEA WATER PUMP




RG6676

-UN-26MAR93




RG6677

-UN-26MAR93



RG6678

-UN-26MAR93



RG6679

-UN-26MAR93



RG6680

-UN-26MAR93




RG6681

-UN-26MAR93

Identification Views


6068DFM01 ENGINE (NO SEA WATER PUMP)




RG6693 -UN-26MAR93




RG6695 -UN-26MAR93



RG6700 -UN-26MAR93



RG6701 -UN-26MAR93



RG6696 -UN-26MAR93




RG6694 -UN-26MAR93

Identification Views

6068TFM01 ENGINE WITH GEAR DRIVEN SEA WATER PUMP



RG6683 -UN-26MAR93



RG6682 -UN-26MAR93



RG6685 -UN-26MAR93



RG6684 -UN-26MAR93



RG6687 -UN-26MAR93



RG6686 -UN-26MAR93

RG20144,11B -19-30MAR93

Contents

	Page		Page
Record Keeping			
Engine Serial Number Plate	1	Lubrication and Maintenance	
Record Engine Serial Number	1	Observe Service Intervals	41
Engine Option Codes	2	Use Correct Fuels, Lubricants, and	
Record Fuel Injection Pump Model		Coolant	41
Number	4	Lubrication & Maintenance Service	
Safety	5	Interval Chart	42
Fuels, Lubricants, and Coolant			
Diesel Fuel	12	Lubrication & Maintenance/250 Hour/3 Month	
Lubricity of Diesel Fuels	12	Change Engine Oil and Filter	43
Diesel Fuel Storage	13	Inspect and Replace Zinc Plugs	45
Filling Fuel Tank	13	Check and Adjust V-Belt Tension	46
Minimizing Effect of Cold Weather on		Service Fire Extinguisher	47
Diesel Engines	14	Check Engine Mounts	47
Engine Break-In Oil	15	Service Batteries	48
Diesel Engine Oil	16	Lubrication & Maintenance/400 Hour	
OILSCAN® and COOLSCAN™	17	Adjust Engine Valve Clearance (First	
Alternative and Synthetic Lubricants	17	400-Hour Interval)	50
Lubricant Storage	17	Adjust Engine Valve Clearance	50
Grease	18	Lubrication & Maintenance/600 Hour/6 Month	
Engine Coolant Requirements	19	Clean Crankcase Vent Tube	53
Recommended Engine Coolant	21	Check Air Intake Hoses	53
Engine Coolant Specifications	22	Replace Rectangular Fuel Filter Element	54
Replenishing Supplemental Coolant		Replace Round Fuel Filter Element	56
Additives (SCA'S) Between Changes	24	Replace Fuel/Water Separator Filter	
Operating in Tropical Conditions	25	Element	57
Disposing of Coolant	25	Replace Air Cleaner	58
Engine Operating Guidelines		Check Effectiveness of Coolant Solution	59
Break-In Service	26	Adding Supplemental Coolant Additives	60
Daily Prestarting Checks	28	Check Cooling System	60
Auxiliary Drive Gear Limitations	30	Remove, Inspect, and Clean Heat	
Standby Power Units	30	Exchanger Core	61
Engine Instrument (Gauge) Panel	32	Install Heat Exchanger Core	63
Engine Starting Instructions	34	Lubrication & Maintenance/1200 Hr/12 Month	
Stopping the Engine	37	Check and Adjust Engine Speeds	64
Using a Booster Battery or Charger	38	Adjust Variable Speed on Generator Set	
Normal Engine Operation	39	Engines	64
Engine Speeds	40	Adjust Engine Valve Clearance	65

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMRG20144 B5-19-23FEB95

COPYRIGHT©1993
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual

Contents


	Page		Page
Check Overall Fuel Injection System	65	General Engine Specifications—Continued.	103
Inspect Turbocharger—4045TFM01 Engines	66	Engine Crankcase Oil Fill Quantities	104
Check Crankshaft Vibration Damper (6 Cylinder Engines)	66	Unified Inch Bolt and Cap Screw Torque Values	105
Inspect and Repair Sea Water Pump	67	Metric Bolt and Cap Screw Torque Values	106
Lubrication & Maintenance/2000 Hr/24 Month		Lubrication and Maintenance Records	
Flush Cooling System and Replace Thermostats	70	Using Lubrication and Maintenance Records	107
Service As Required		250 Hour/3 Month Service	108
Additional Service Information	72	400 Hour Service	108
Checking Coolant Level	72	600 Hour/6 Month Service	109
Adding Coolant	73	1200 Hour/12 Month Service	109
Pressure Test Cooling System	74	2000 Hour/24 Month Service	109
Do Not Modify Fuel System	75	Service As Required Service	110
Drain Water From Fuel/Water Separator	75	Index	
Bleed Fuel/Water Separator	76		
Bleed Fuel System	77		
Replace V-Belts	79		
Remove and Install Auxiliary Gear Driven Sea Water Pump	81		
Remove and Install Belt Driven Sea Water Pump	82		
Troubleshooting			
General Troubleshooting Information	83		
Propulsion Engine Wiring Harness	84		
Wiring Diagram—Propulsion Engine Wiring Harness	86		
Wiring Diagram—Propulsion Engine Control Panel	87		
4039DFM01 and 6068DFM01 Engine Coolant and Sea Water Flow	88		
4045TFM01 and 6068TFM01 Engine Coolant and Sea Water Flow	90		
Engine Troubleshooting	92		
Electrical System Troubleshooting	96		
Seasonal Engine Storage			
Use AR41785 Engine Storage Kit	98		
Preparing Engine for Storage	98		
Removing Engine From Storage	100		
Specifications			
General Engine Description	101		
General Engine Specifications	102		

Record Keeping

ENGINE SERIAL NUMBER PLATE

Each engine has a 13-digit John Deere engine serial number.

Your engine's serial number plate (A) is located on right-hand side of cylinder block (viewed from flywheel end) between the oil filter housing and fuel filter.



RG20144,16 -19-31JAN95

RG66095 -UN-29JAN92

RECORD ENGINE SERIAL NUMBER


Your engine will have a serial number plate.

Record all of the numbers and letters found on your engine serial number plate in the spaces provided below.

This information is very important for repair parts or warranty information.

Engine Serial Number (A)

Application Data (B)



Embossed Serial Number Plate



Bar Coded Serial Number Plate

S55,OMSN,B1 -19-16FEB95

RG5609 -UN-09JAN90

RG6609

RG7301 -UN-17FEB95


ENGINE OPTION CODES

In addition to the serial number plate, OEM engines have an engine option code label affixed to the rocker arm cover. These codes indicate which of the engine options were installed on your engine at the factory. When in need of parts or service, furnish your authorized servicing dealer or engine distributor with these numbers.

The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as a 12-volt, 55-amp alternator.

If an engine is ordered without a particular component, the last two digits of that functional group option code will be nines (99). The following list shows only the first two digits of the code numbers. For future reference such as ordering repair parts, it is important to have these code numbers available. To ensure this availability, enter the third and fourth digits shown on your engine option code label in the spaces provided on the following pages.

NOTE: *Your engine option code label may not contain all option codes if an option has been added after the engine left the producing factory.*



RG4907 -JUN-15DEC88

RG,20144,18A -19-16FEB95

ENGINE OPTION CODES—CONTINUED

Option Codes	Description	Option Codes	Description
11 _____	Rocker Arm Cover	37 _____	Fuel Transfer Pump
12 _____	Oil Filler	39 _____	Thermostat Housing
13 _____	Crankshaft Pulley	40 _____	Dipstick
14 _____	Flywheel Housing	41 _____	Belt Driven Front Auxiliary Drive
15 _____	Flywheel	43 _____	Air Inlet Heater
16 _____	Injection Pump	44 _____	Timing Gear Cover With Gears
17 _____	Air Inlet	45 _____	Balancers For 4-Cylinder Engines
19 _____	Oil Pan	46 _____	Cylinder Block With Liners and Camshaft
20 _____	Water Pump	52 _____	Auxiliary Gear Drive
21 _____	Thermostat Cover	55 _____	Shipping Stand
22 _____	Thermostat	56 _____	Paint Option
23 _____	Fan Drive	59 _____	Oil Cooler and Filter
24 _____	Fan Belt	62 _____	Alternator Mounting
27 _____	Heat Exchanger	64 _____	Exhaust Elbow
28 _____	Exhaust Manifold	65 _____	Turbocharger
29 _____	Ventilator System	67 _____	Starter Relay
30 _____	Starting Motor	69 _____	Engine Serial Number Plate
31 _____	Alternator	80 _____	Sea Water Pump
35 _____	Fuel Filter	97 _____	Air Cleaner

RG20144,18 -19-02MAR92

RECORD FUEL INJECTION PUMP MODEL NUMBER

Record the fuel injection pump model and serial information found on the serial number plate (A).

Model No. _____ RPM _____

Manufacturer's No. _____

Serial No. _____



RG66096
-UN-23JAN92


RG20144,17 -19-23JAN92

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

T81389 -UN-07DEC68

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS187 -19-30SEP88


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your vessel safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer or authorized engine distributor.

Learn how to operate the vessel and how to use the controls properly. Do not let anyone operate without instruction.

Keep your vessel in proper working condition. Unauthorized modifications to the engine may impair the function, safety, and engine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer or authorized engine distributor.



RG20144,2 -19-03FEB92

TS201 -UN-23AUG88



PREVENT STARTING IN GEAR

Avoid possible injury from starting in gear.

Do not start engine by shorting across starter terminal. Engine can start with marine gear engaged if normal circuitry is bypassed.

Start engine only from operator's control station, with PTO or marine gear disengaged (neutral).



RG20144.8 -19-29JAN92


RG5419 -UN-28FEB89

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. When operating engine in an enclosed engine room, be sure ventilation system is operating properly.

If engine room ventilation system is not operating properly, open the access door or engine room hatches to get outside air into the enclosed area.

Keep all engine exhaust connections securely tightened. Repair any leaky joints in the exhaust system immediately.



RG20144.6 -19-29JAN92

TSS220 -UN-23AUG88

HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



DX,FIRE1 -19-03MAR93

TSS202 -UN-23AUG88




PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Always keep a first aid kit and fire extinguisher on hand and know how to use them. Inspect and service fire extinguisher as recommended by manufacturer.

Familiarize everyone aboard your vessel with emergency contact procedures. Keep a laminated copy of emergency contact information near your communication radio or telephone, if equipped.



-UN-23AUG88
TS291

RG20144,4 -19-12NOV91


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



-UN-23AUG88
TS206

DX,WEAR -19-10SEP90

PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs if working inside an enclosed engine room with engine running.



-UN-23AUG88
TS207

RG20144,5 -19-12NOV91




HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



DX.MSDS.NA -19-03MAR93

TS1132 -UN-26NOV90

STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Be sure protective guards and shields are securely installed over engine-driven drivelines at all times during engine operation.

Wear close fitting clothing. Stop the engine and be sure the propeller shaft and PTO driveline are stopped before making adjustments or performing any type service on the engine or PTO-driven equipment.



RG20144,7 -19-29JAN92

TS198 -UN-23AUG88



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading



PRACTICE SAFE MAINTENANCE

Understand service procedures before doing work. Do not attempt repairs that you do not understand. Do not use tools or equipment you do not know how to use.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris. Keep area clean and dry.

Do not touch any part of an operating engine. Allow the engine to cool before any repairs or adjustments are performed.

Disconnect battery ground (-) cable before making adjustments on electrical system or welding in engine room.



RG20144.9 -19-12NOV91

TS218 -UN-23AUG88

REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

TS220 -UN-23AUG88

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>