

**3200 X, 3300 X  
and 3400 X  
Tractors**

**DCEO-Mannheim  
RT6005012387 Issue B6**

Printed in France  
**ANGLAIS**

# Contents

	Page		Page
<b>Identification View</b> . . . . .	00-1	Cold-weather starting aids . . . . .	40-3
<b>Safety</b> . . . . .	05-1	Booster battery . . . . .	40-4
<b>Safety Decals</b> . . . . .	10-1	Engine warm-up period . . . . .	40-4
		Parking the tractor . . . . .	40-4
		Towing the tractor . . . . .	40-5
<b>Controls and Instruments</b>		<b>Operating the Tractor</b>	
Dash panel . . . . .	15-1	Reduce fuel consumption . . . . .	45-1
Operator's station . . . . .	15-2	Warning concerning steering . . . . .	45-3
Cab roof controls . . . . .	15-3	Transmission controls . . . . .	45-3
Display panel . . . . .	15-4	Transmission types . . . . .	45-4
Indicator lights . . . . .	15-5	Changing gears . . . . .	45-5
Instruments . . . . .	15-6	Changing ranges . . . . .	45-5
Numerical display . . . . .	15-7	Shifting gears from neutral . . . . .	45-5
<b>Lights</b> . . . . .	20-1	Reverse drive lever . . . . .	45-6
<b>Operator's Cab</b>		Splitter . . . . .	45-6
Roll-over protective structure . . . . .	25-1	Front-wheel drive axle . . . . .	45-7
Operator's seat . . . . .	25-4	Differential lock . . . . .	45-7
Passenger seat . . . . .	25-5	Brakes . . . . .	45-8
Opening the doors and windows . . . . .	25-6	Ground travel speed . . . . .	45-9
Windshield wiper . . . . .	25-9	3200 X . . . . .	45-10
Rear view mirrors . . . . .	25-9	3300 X and 3400 X . . . . .	45-14
Heating and ventilation . . . . .	25-10	<b>Rockshaft and Three-Point Hitch</b>	
Air conditioning system . . . . .	25-11	Rockshaft control . . . . .	50-1
Radio . . . . .	25-12	Remote control . . . . .	50-2
<b>Break-In Period</b>		Position control . . . . .	50-2
After the first 4 and 8 hours of operation . . . . .	30-1	Load control . . . . .	50-3
After the first 30 hours of operation . . . . .	30-2	Mixed control . . . . .	50-4
Within the first 100 hours of operation . . . . .	30-2	Float position . . . . .	50-4
After the first 100 hours of operation . . . . .	30-2	Three-point hitch . . . . .	50-5
After the first 250 hours of operation . . . . .	30-3	Center link adjustment . . . . .	50-6
<b>Prestarting Checks</b> . . . . .	35-1	Lift links . . . . .	50-7
<b>Operating the Engine</b>		Draft links . . . . .	50-8
Starting the engine . . . . .	40-2	Stabilizers . . . . .	50-9
		Hitch configuration . . . . .	50-11
		<b>Power Take-Off</b>	
		PTO guard . . . . .	55-1

Continued on next page

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

RT6005012387 B6-19-01APR96

COPYRIGHT© 1996  
 DEERE & COMPANY  
 European Office Mannheim  
 All rights reserved  
 A John Deere ILLUSTRATION® Manual  
 Previous Editions  
 Copyright 1995 Deere & Company

Contents

	<b>Page</b>		<b>Page</b>
Operating the rear PTO . . . . .	55-2	Access to battery . . . . .	85-1
Speed selector . . . . .	55-3	Access to fuses . . . . .	85-2
Attaching PTO-driven equipment . . . . .	55-4	Warning concerning the air conditioning system . . . . .	85-2
Operating from stationary position . . . . .	55-4	Alternator . . . . .	85-3
Front PTO . . . . .	55-5	Service during break-in period . . . . .	85-4
<b>Ballast</b>		Service intervals . . . . .	85-6
Selecting ballast . . . . .	60-1	<b>Service - Daily or Every 10 Hours</b>	
Measuring rear wheel slip . . . . .	60-2	Engine crankcase oil level . . . . .	90-1
Filling tires with liquid ballast . . . . .	60-3	Fuel filter . . . . .	90-1
Front weights . . . . .	60-4	Transmission/hydraulic oil level . . . . .	90-2
Rear wheel weights . . . . .	60-5	Coolant level . . . . .	90-3
<b>Wheel Tread, Tires</b>		Cleaning the dust unloading valve . . . . .	90-3
Tire maintenance . . . . .	65-1	Checking the lights . . . . .	90-3
Tire pressures . . . . .	65-2	<b>Service - Every 50 Hours</b>	
Tire combinations with front-wheel drive . . . . .	65-3	Lubricating the FWD axle . . . . .	95-1
Front wheel tread adjustment		Checking oil level in front PTO housing . . . . .	95-1
Without FWD axle . . . . .	65-4	Cleaning the condenser (air conditioning) . . . . .	95-1
With FWD axle . . . . .	65-5	Compressor (air conditioning) . . . . .	95-2
Steering stops . . . . .	65-8	<b>Service - Every 250 Hours</b>	
Adjusting rear wheel tread . . . . .	65-8	Changing engine oil . . . . .	100-1
Dual rear wheels . . . . .	65-10	Replacing engine oil filter . . . . .	100-2
<b>Additional Equipment</b>		Checking tension on the alternator belt . . . . .	100-3
Selective control valves . . . . .	70-1	Replacing the transmission oil filter element . . . . .	100-4
Couplers . . . . .	70-4	Bleeding the transmission/hydraulic circuit . . . . .	100-4
Maximum permissible oil withdrawal . . . . .	70-5	Vehicle clutch — free travel at pedal . . . . .	100-5
Hitches . . . . .	70-6	PTO clutch — free travel at slide control . . . . .	100-5
Power outlet socket for electrical equipment . . . . .	70-9	Lubricating the brakes . . . . .	100-5
<b>Transport</b>		Checking hardware at front of tractor . . . . .	100-6
Driving on public roads . . . . .	75-1	Lubricating the front axle (not FWD) . . . . .	100-7
Towing loads . . . . .	75-2	Checking oil level at FWD axle housing . . . . .	100-7
Towing the tractor . . . . .	75-3	Oil level in final drives (FWD axle) . . . . .	100-7
Trailer brakes . . . . .	75-3	Lubricating the three-point hitch . . . . .	100-8
<b>Fuel, Lubricants, Hydraulic Oil and Coolant</b>		Lubricating the pick-up hitch . . . . .	100-8
Fuel . . . . .	80-1	Changing oil in front PTO . . . . .	100-9
Engine oil . . . . .	80-2	<b>Service - Every 500 Hours</b>	
Transmission/hydraulic oil . . . . .	80-3	Replacing the fuel filter . . . . .	105-1
FWD axle oil . . . . .	80-3	Air intake hoses . . . . .	105-1
Brake fluid . . . . .	80-4	Replacing intake screen . . . . .	105-2
Grease . . . . .	80-4	Replacing the breather in the transmission/hydraulic circuit . . . . .	105-2
Engine coolant . . . . .	80-6	Check free travel at brake pedals . . . . .	105-3
<b>Lubrication and Periodic Service</b>		<b>Service - Every 750 Hours</b>	
Removing the side panels . . . . .	85-1	Checking engine speeds . . . . .	110-1

Continued on next page

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

Page	Page	
Changing the brake fluid . . . . .	110-1	<b>Lubrication and Maintenance Records . . . 150-1</b>
Important note on transmission/hydraulic oil . . . . .	110-1	
Changing the transmission/hydraulic oil . . . . .	110-2	<b>Index</b>
Replacing cab air filter . . . . .	110-3	
<b>Service - Every 1000 Hours</b>		
Changing oil in FWD axle housing . . . . .	115-1	
Changing oil in final drives of FWD axle . . . . .	115-1	
<b>Service - Every 1500 Hours or 2 Years</b>		
Replacing the coolant . . . . .	120-1	
<b>Service - As Required</b>		
Air cleaner (engine) . . . . .	125-1	
Cleaning cab air filter . . . . .	125-2	
Cleaning front and side grilles . . . . .	125-2	
Cleaning the radiator . . . . .	125-3	
Battery service . . . . .	125-3	
Bleeding the fuel circuit . . . . .	125-4	
Lubricating points . . . . .	125-4	
Starting motor . . . . .	125-4	
Fuses . . . . .	125-5	
Replacing bulbs . . . . .	125-7	
<b>Troubleshooting</b>		
Hitch . . . . .	130-1	
Engine . . . . .	130-2	
Electrical system . . . . .	130-3	
<b>Storage</b>		
Storage over lengthy period . . . . .	135-1	
Removing tractor from storage . . . . .	135-2	
<b>Specifications</b>		
Engine . . . . .	140-1	
PTO power output . . . . .	140-2	
Transmission . . . . .	140-2	
Hydraulic circuit . . . . .	140-2	
Electrical system . . . . .	140-3	
Capacities . . . . .	140-3	
Dimensions and weights		
Tractors without FWD axle . . . . .	140-4	
Tractors with FWD axle . . . . .	140-6	
Sound level . . . . .	140-8	
Weights . . . . .	140-8	
Load capacity of tires . . . . .	140-9	
<b>Serial Numbers</b> . . . . .	145-1	

# Identification View



*3200 X tractor with FWD axle*


FDX.IVIEW003200-19-02DEC94

# Safety

## RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

T81389 -UN-07DEC68

## UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS187 -19-30SEP88


## FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-03MAR93

TS201 -UN-23AUG88



## MOUNT AND DISMOUNT THE MACHINE SAFELY

Always use the access steps and handrails when mounting and dismounting the tractor.

Ensure that the access steps and operator's station are kept clean at all times. This will help prevent accidents.



FD,HANDLE -19-01APR94


TS279 -UN-23AUG88

## PREVENT MACHINE RUNAWAY

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.




DX,BYPAS1 -19-03MAR93

TS177 -UN-11JAN89

## WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.




DX,AIR -19-04JUN90


TS220 -UN-23AUG88



## OPERATING THE TRACTOR SAFELY



TS276 -UN-23AUG88



FD000286

FD000286 -UN-24JAN95

Careless use of the tractor can result in unnecessary accidents. Be alert to the hazards of tractor operation. Understand the causes of accidents and take every precaution to avoid them. Most common accidents are caused by:

- Tractor roll-over
- Improper starting procedures
- Crushing and pinching during hitching
- Collisions with other motor vehicles
- Entanglement in PTO shafts
- Falling from tractor

To avoid such accidents, it is vital to comply with the safety regulations described in this publication.

### Keep riders off the machine


Only allow the operator on the machine. Keep riders off. On machines equipped with a passenger seat, one rider is permitted.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.


FD,HAZARD -19-02JUN94



## DRIVING THE TRACTOR SAFELY



TS216 -JUN-23AUG88



RW13093 -JUN-07DEC88

Always check the road and general operating safety of the machine before using.

Operate tractor only when all guards are fitted and in their correct position.

Before moving away, always check immediate vicinity of machine (e.g. for children). Ensure adequate visibility.

To limit the risks of overturning, set the tread width to the maximum suitable for the task. Comply with regulations restricting maximum width.

Make sure the tractor is ballasted properly for its intended task.

Always adapt your ground speed to meet the ground conditions. Avoid making sharp turns when driving up or down slopes or when driving across the slope. Do not attempt to turn the machine with the differential lock engaged. Reduce your ground speed when driving the tractor on slopes or over uneven ground and before making sharp turns. Before descending a steep hill, shift to a lower gear. When driving down slopes, never depress the clutch and change gear; use the same gear you would use to drive up the slope. Never coast downhill.

When making turns with towed or mounted implements, always take into consideration the width and inertia of the implement.

Avoid holes, ditches and obstructions which may cause the tractor to tip, particularly on hillsides. Never drive near the edge of a gully or steep embankment — it might cave in!

Front-wheel drive greatly increases traction. This means that the tractor can be driven on steeper slopes, increasing the possibility of a tip over. Driving forward out of a ditch or up a steep slope could cause tractor to tip over to the rear. Therefore reverse out of these situations whenever possible.

### Driving on public roads

It is vital to comply with road traffic regulations.

Before driving the tractor on a public road, make sure that the lights, turn signals and brake lights are functioning correctly. Never switch on the work lights while driving on public roads.

The brake pedals must be coupled together. Never apply the differential lock when driving on a road.

When transporting mounted implement(s), raise the rockshaft. If the implement is equipped with road wheels, use them.

### Towing implements or trailers

Attach implements and trailers to the tractor only using the prescribed drawbars or hitches. Attach trailers and implements correctly. Always ensure that trailers and implements cannot roll away. If trailer brakes are equipped, use them!

Braking to stop towed loads from transport speeds can cause the towed load to swerve and upset. Reduce speed if towed load weighs more than the tractor and is not equipped with brakes.



## PARKING AND LEAVING THE TRACTOR

Lower mounted implement(s) or equipment to the ground before leaving the tractor.

When leaving the tractor and/or implements, shut off engine, engage range and gear shift levers AS WELL AS the handbrake (the tractor is NOT necessarily immobilized when the transmission is in gear and the engine is switched off), remove main switch key and lock the operator's cab. Position chock blocks.

Never leave tractor unattended while the engine is still running.

Never leave the operator's seat when driving.



LX002510

FD,PARK -19-01JUN94

LX002510 -UN-17JAN95

## HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



DX,FIRE1 -19-03MAR93


TS202 -UN-23AUG88

## PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

TS291 -UN-23AUG88




## WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



DX,WEAR -19-10SEP90


TS206 -UN-23AUG88

## AVOID CONTACT WITH PESTICIDES

This enclosed cab does not protect against inhaling harmful pesticides. If pesticide use instructions require respiratory protection, wear an appropriate respirator inside the cab.

Before leaving the cab, wear personal protective equipment as required by the pesticide use instructions. When re-entering the cab, remove protective equipment and store either outside the cab in a closed box or some other type of sealable container or inside the cab in a pesticide resistant container, such as a plastic bag.

Clean your shoes or boots to remove soil or other contaminated particles prior to entering the cab.



DX,CABS -19-03MAR93

TS220 -UN-23AUG88

TS272 -UN-23AUG88



## STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.




DX,PTO -19-12SEP95

TS1644 -UN-22AUG95

## USE SAFETY LIGHTS AND DEVICES

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use hand signals or turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible and in good working order. Replace or repair lighting and marking that has been damaged or lost. An implement safety lighting kit is available from your John Deere dealer.




DX,FLASH -19-12SEP95

TS951 -UN-12APR90

## SAFELY TRANSPORTING THE TRACTOR

A disabled tractor is best transported on a flatbed carrier. Use chains to secure the tractor to the carrier.

Never tow a tractor at a speed greater than 16 km/h (10 mph). An operator must steer and brake the tractor under tow.



LX,OTRANS003525-19-01SEP92


RW13090 -UN-07DEC88



## KEEP ROPS OF CAB INSTALLED PROPERLY

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) on the cab is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling or cutting. A damaged ROPS should be replaced, not re-used.



FD,CAB -19-01JUN94

-UN-23AUG88  
TS212

## PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



DX,SERV -19-03MAR93

-UN-23AUG88  
TS218



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**



## REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

TS220 -UN-23AUG68

## AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



DX,TORCH -19-03MAR93

TS953 -UN-15MAY90




## AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID -19-03MAR93

X9811 -UN-23AUG88

## STORE ATTACHMENTS SAFELY

Stored attachments such as dual wheels, cage wheels, and loaders can fall and cause serious injury or death.

Securely store attachments and implements to prevent falling. Keep playing children and bystanders away from storage area.



DX,STORE -19-03MAR93

TS219 -UN-23AUG88

## SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to relieve pressure before removing completely.

Add coolant only when the engine is shut off.



LX,RCAP -19-01SEP95

TS281 -UN-23AUG88

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**