

TABLE OF CONTENTS

85 and 95 Series Tractors

SERIES	SECTION	DESCRIPTION	PUBLICATION
10		GENERAL	
	1000	General Specifications	8-57670
	1005	Special Tools	8-59410
	1230	Fuel System Specifications	8-57721
	1250	Steering System Specifications	8-57570
	1280	Hydraulic System Specifications	8-56930
20		ENGINES	
	2115	Engine Removal - Tractor with L Cab	8-57150
	2120	Engine Removal - Tractor with XL Cab	8-57160
	2201	Engine Troubleshooting	8-56590
	2215	3 Cylinder Engine Head, Valves and Rockers	8-57110
	2225	3 Cylinder Engine Cylinder Block, Pistons and Conrods	8-57120
	2235	3 Cylinder Engine Crankshaft and Bearings	8-57130
	2240	3 Cylinder Engine Camshaft and Idler Gear	8-57140
	2245	3 Cylinder Engine Lubrication System	8-57170
	2310	Separating the Tractor - Tractor without Cab	8-56660
	2315	4 Cylinder Engine Cylinder Head, Valves and Rockers	8-56600
	2325	4 Cylinder Engine Cylinder Block, Pistons and Conrods	8-56610
	2330	4 Cylinder Engine Camshaft and Idler Gear - Tractor without Air Conditioning	8-57100
	2331	4 Cylinder Engine Camshaft and Idler Gear - Tractor with Air Conditioning	8-57190
	2335	4 Cylinder Engine Crankshaft, Bearings and Balancer	8-56620
	2345	4 Cylinder Engine Lubrication System	8-56630
	2355	Engine Cooling System	8-56640
	2410	Engine Removal - Tractor without Cab	8-56670
30		FUEL SYSTEM	
	3310	Fuel System	8-56650
	3311	Fuel Injection Pump VE	8-59020
	3312	Fuel Injection Pump VA	8-57630
	3313	Fuel Injectors	8-57640
	3315	Fuel Tanks - Tractor with XL Cab	8-57180
40		ELECTRICAL	
	4001*	Electrical Troubleshooting and Schematics	7-35871
	4235	Battery Servicing and Testing	8-56980
	4240	Lucas A115 and A127 45 Ampere Alternator and Regulators	8-57030
	4241	Lucas A133 65 Ampere Alternator and Regulator	8-57230
	4330	Starter Motors	8-57020

SERIES	SECTION	DESCRIPTION	PUBLICATION
50	STEERING		
	5015	Steering Pump Removal	8-57600
	5020	Steering Hand Pump	8-56470
	5025	Steering System Tests and Troubleshooting	8-57540
	5330	Front Axles 2WD Tractor	8-56700
	5340	Front Axle - Cast Heavy Duty Fixed	8-58940
	5420	Steering Cylinder, 2WD	8-57410
	5425	Steering Cylinder, MFD	8-56460
	5430	Steering Cylinder - Cast Axle	8-58930
60	POWER TRAIN		
	6001	Clutch Controls, Linkage and Thrust Bearing	8-56520
	6030	Rear Axles	8-56480
	6241	Clutch (Rockford Type)	8-56681
	6305	Steering Support Removal - Tractor with XL Cab	8-57210
	6306	Steering Support Removal - Tractor without Cab	8-57240
	6307	Steering Support Removal - Tractor with L Cab	8-57610
	6310	Transmission Speedbox	8-56950
	6315	Transmission Rangebox with Light Duty Park Brake	8-56960
	6320	Power Shift Transmission	8-56970
	6325	Forward/Reverse Transmission - Tractor with L Cab	8-56980
	6325	Forward/Reverse Transmission - Tractor with XL Cab	7-35910
	6326	Forward/Reverse Testing and Troubleshooting	8-59380
	6330	Differential - Transmission with Light Duty Park Brake	8-57290
	6331	Differential - Transmission with Heavy Duty Park Brake	8-57650
	6335	Transmission Rangebox - with Heavy Duty Park Brake	8-56990
	6340	Power Take Off (PTO) Clutch and Lower Shaft - 2WD	8-56540
	6341	Clutch (Laycock Type)	8-56690
	6342	PTO Testing and Troubleshooting	8-58220
	6343	PTO Clutch and Lower Shaft - MFD Tractor	8-59360
	6410	Speedbox Removal - Tractor without Cab	8-56830
	6411	Rangebox Removal - Tractor without Cab	8-57370
	6415	Rangebox Removal - Tractor with L Cab	8-56840
	6416	Speedbox Removal - Tractor with L Cab	8-57380
	6420	Speedbox Removal - Tractor with XL Cab	8-56850
	6421	Rangebox Removal - Tractor with XL Cab	8-57360
	6430	Creeper Speed Transmission - Tractor with XL Cab	7-35880
	6430	Creeper Speed Transmission - Tractor without Cab and L Cab	7-36620
	6465	Center Drive MFD Front Axles - (ZF Types APL 325 and APL 330)	8-56530
	6470	Center Drive MFD Front Axle - (ZF Type APL 335)	8-58230
	6471	Axle Hubs and Planetaries (Carraro Type 707-164 and 707 STD-164).....	7-36731
	6472	Axle Removal and Differential (Carraro Type 707-164 and 707 STD-164).....	7-36741
	6473	Carraro Drop Box	7-37740
	6475	Center Drive MFD Transfer Gearbox, with Dog Clutch	8-57401
	6480	Center Drive MFD Transfer Gearbox, with Multi Plate Clutch	8-57220
	6485	MFD Drive Shaft	8-57390
70	BRAKES		
	7105	Disc Brakes	8-57480
	7110	Brake Master Cylinders and Controls	8-57660
	7115	Park Brake - 385, 395 and 485, 495 2WD Tractors	8-58250
	7120	Park Brake	8-58260

SERIES	SECTION	DESCRIPTION	PUBLICATION
80		HYDRAULIC SYSTEM	
	8001*	Hydraulic Schematics and Troubleshooting	7-36030
	8005	Hitch Adjustments	8-56920
	8010	Multiple Control Valve (MCV)	8-56870
	8015	Unloading and Flow Control Valve	8-56880
	8020	Filter and Pump	8-56860
	8025	Bosch Remote Valves	8-56890
	8030	Draft Cylinder and Rockshaft	8-56900
	8035	Control Levers and Raise Rate Valve	8-56910
	8040	Hydraulic Housing Removal	8-57250
90		CHASSIS AND ACCESSORIES	
	9001*	Pedal and Lever Adjustment	7-35900
	9205	Air Conditioning System Troubleshooting	8-58290
	9215	Testing Air Conditioning System	8-58300
	9225	Servicing Air Conditioning System	8-58900
	9235	Servicing Air Conditioning System Components	8-58310
	9240	Hood and Panels	7-35940
	9440	Cab Removal - Tractor with XL Cab	8-56750
	9441	Servicing XL Cab	8-58270
	9540	Cab and Safety Frame Removal - Tractor with L Cab	7-35920
	9541	Servicing L Cab	7-35930

* Schematic Set Sections

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

Section 1000

GENERAL SPECIFICATIONS 85 Series Tractors

SERIAL NUMBERS

Compiled in this manual are the operating and maintenance instructions for the 85 Series Agricultural Tractors

When in need of service parts always quote the tractor, transmission unit, and engine serial numbers, including prefix and suffix letters.

If information is required that is not available in this manual see the nearest authorized Case Dealer.

Transmission Serial Number

EXAMPLE: 293805 BTY

The suffix letters, BTY denote the build of the unit.

The first letter denotes the type of drive train, B = fast speed transmission, A or D = slow speed transmission.

The second letter denotes the bevel gear ratio,
T = 11:52, S = 14:51 and R = 12:53.

The third letter denotes the operating speeds for the PTO and the number of splines on the upper and lower shafts as shown below.

U	=	555 r/min	6 splines upper shaft
V	=	1000 r/min	6 splines lower shaft
W	=	580 r/min	6 splines upper shaft
X	=	606 r/min	6 splines upper shaft
Y	=	611 r/min	6 splines upper shaft
Z	=	614 r/min	6 splines upper shaft

V denotes that only the lower PTO shaft is fitted, as for compressor drive. When applicable, dual speed installations are indicated by a fourth suffix letter D.

GENERAL SPECIFICATIONS

Specifications for each machine are under individual headings which follow these GENERAL SPECIFICATIONS.

Capacities

	UK Value	U.S. Value	Metric Value
Fuel Tanks			
XL Tractors	24.6 gal	29.6 gal	112 litres
Non XL Tractors	17 gal	20.3 gal	77 litre
2WD Transmission	7.5 gal	8.9 gal	34 litre
MFD Transmissions	8 gal	9.6 gal	36.5 litre

NOTE: These capacities are only a guide to the quantities. Always use the dipstick or level plug to make sure that units are filled to the correct level.

Electrical System

Type of System	12 Volt, Negative ground
Battery (Rating IEC/BS)	
Standard	Reserve Capacity 170 minute
Cold Cranking Amperes 420 ampere
Heavy Duty	Reserve Capacity 170 minute
Cold Cranking Amperes 510 ampere
Heavy Duty Plus	Reserve Capacity 220 minute
Cold Cranking Amperes 510 ampere
Alternators	
XL Tractors 65 amp
Non XL Tractors 45 amp
North America with Simms Cab 75 amp

XL Tractors

Head Lamps (2)	12 Volt, 37.5/60 watt sealed beam or 40/45 watt British prefocus cap (export)
Side Lamps (2)	12 Volt, 10 watt small bayonet cap
Stop Lamps (2)	12 Volt, 21 watt small bayonet cap
Tail Lamps (2)	12 Volt, 10 watt small bayonet cap
Work Lamps	12 Volt, 55 watt Halogen
Registration Number Plate Lamp	12 Volt, 10 watt small bayonet cap
Direction Indicator Lamps (2)	12 Volt, 21 watt small bayonet cap
Instrument Warning Lamps	12 Volt, 1.2 watt capless wedge
Tachometer Lamp	12 Volt, 3 watt capless wedge
Speedometer Lamp	12 Volt, 3 watt capless wedge
Speed Decal Lamp	12 Volt, 1.5 watt capless wedge

Non XL Tractors

Head Lamps	12 Volt, 37.5/60 watt sealed beam 40/45 watt British prefocus cap (export)
Side Lamps (2)	12 Volt, 5 watt festoon
Stop/Tail Lamps (2)	12 Volt, 21/5 watt small bayonet cap
Work Lamp	12 Volt, 35 watt sealed beam
Direction Indicator Lamps (2)	12 Volt, 21 watt small bayonet cap
Registration Number Plate Lamp	12 Volt, 5 watt miniature center contact
Instrument Warning Lamps	12 Volt, 3 watt capless wedge
Tachometer Lamp	12 Volt, 3 watt capless wedge
Speedometer Lamp	12 Volt, 3 watt capless wedge
Panel Lamp	12 Volt, 5 watt festoon

Transmissions

BASIC

Type 4 Speed Synchronesh with High/Low Ranges and Reverse
 Number of Gears 8 Forward, 4 Reverse
 Controls 2 Levers

OPTIONAL (Not 885/885XL)

Type Forward/Reverse
 Same as Synchronesh, plus a Hydraulically Operated Forward
 and an Increased Speed Reverse

Number of Gears 8 Forward, 8 Reverse
 Controls 3 Levers

OPTIONAL

Type 2 Speed Power Shift
 Same as Synchronesh, Plus Hydraulically
 Operated Speed Decrease in all Gears

Number of Gears 16 Forward, 8 Reverse
 Controls 2 Levers and an Electrical Switch

Foot Brakes

Type Hydraulic, Self Adjusting, Oil Cooled Discs

	U.S Value	Metric Value
Disc Diameter	10 in	254 mm

Hydraulic System

Type Independent, with Fully Live
 Hydraulic Pump in the Transmission

Operating Pressure 175 kg/cm² (2500 lb/in²)

Steering

Type Hydrostatic

Turning Radius with Brake Assistance: 2WD 132 in 3352 mm
 (with MFD engaged) MFD 146 in 3708 mm

Turning Radius without Brake Assistance: 2WD 151 in 3835 mm
 (with MFD engaged) MFD 171 in 343 mm

Differential Lock

Type Mechanical Actuated by the Operators Right Foot

Hitch system

Type of Sensing Upper Link

Type of Control Hand Lever

Type of Valve Four-Position, Hold, Lift, Lower, and Float

Type of Draft Arms Rigid, Swing Type, Manual Float Adjuster

Type of Hitch 385 and 485 Three Point, Category one and Two

585, 685 and 885 Three Point, Category Two

Quick Hitch Coupler (Available)

Section 2115

**ENGINE REMOVAL
85 Series Tractors with L Cab**

TABLE OF CONTENTS

STANDARD TORQUES	2
ENGINE	
Removal	3
Installation	12



WARNING: *This safety symbol is used in this manual to indicate important safety messages.*

When you see this symbol, read the message carefully. It is shown when possible injury or death can be caused.

STANDARD TORQUES


STANDARD TORQUE DATA FOR NUTS AND BOLTS

Where no special torque data is specified, the following torque figures should be applied. Threads should be lubricated with engine oil or chassis grease. Apply the minimum figure to bolts that have previously been used.

BOLT		TYPE 5				TYPE 8			
		MIN		MAX		MIN		MAX	
SIZE									
inch	(mm)	Nm	lb ft	Nm	lb ft	Nm	lb ft	Nm	lb ft
1/4	6	12	9	14	10	22	12	19	14
5/16	8	26	19	28	21	36	27	41	30
3/8	9	45	33	50	37	61	45	68	50
7/16	11	72	53	81	60	102	75	115	85
1/2	13	108	80	122	90	156	115	176	130
9/16	15	156	115	176	130	224	165	251	185
5/8	16	217	160	244	180	298	220	329	250
3/4	19	393	290	434	320	542	400	610	450
7/8	22	569	420	637	470	881	650	990	730
1	25	854	630	963	710	1311	970	1478	1090
1-1/8	28	1152	850	1288	950	1871	1380	2102	1550
1-1/4	31	1627	1200	1830	1350	2631	1940	2956	2180


Removal

STEP 1




Apply the parking brake.

STEP 2




Put blocks in front of and behind the rear wheels.

STEP 3



Remove the battery access panel.

STEP 4



Disconnect the battery terminals.


NOTE: *Negative (-) terminal first.*

STEP 5



Remove the hoodsheet. See section 9240.

STEP 6




Remove the radiator drain plug and drain the coolant. After draining install and tighten the drain plug.

STEP 7




Loosen the battery clamp nuts and remove the clamp.

STEP 8




Remove the battery.

STEP 9



Loosen the clip and disconnect the top radiator hose from the water pump.

STEP 10




Loosen the clip and disconnect the bottom radiator hose from the engine.

STEP 11




Loosen the clips and disconnect the oil cooler pipes.


STEP 12




Install caps to prevent foreign material entering the system.

STEP 13


Remove the wiring harness from the radiator shroud.

STEP 14


Remove the radiator side plate bolt, (both sides) and the hoodsheet side straps.

STEP 15


Remove the radiator baffle plate bolt.

STEP 16

Remove the radiator baffle plate.


STEP 17

Remove the oil cooler pipe bracket.

STEP 18


Remove the radiator mountings.

STEP 19




Remove the radiator and oil cooler from the tractor.

STEP 20



Remove the radiator mounting pads and side cover brackets.

STEP 21




Loosen the front weight securing bolts, (if fitted).

STEP 22




Remove the weights, (if fitted).

STEP 23



Remove the weight bracket, (if fitted).


STEP 24



Remove the front axle. See section 5330 for 2WD tractors or section 6465 for MFD tractors.

STEP 25


If tractor is fitted with MFD, remove the drive shaft.
See section 6485.

STEP 26


Mark the hydraulic steering pipes for correct installation and disconnect and cap the steering pipes.

STEP 27


Install two 5/8 x 2-1/2 inch UNC bolts into each side of the front bolster.

STEP 28

Fasten the bolster to a hoist as shown.

STEP 29

Remove the oil pan shield and bolster mounting bolts.

STEP 30

Remove the bolster from the tractor.



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.


Thank you so much for reading

STEP 31




Loosen the heater hose clips, (both sides).

STEP 32




Disconnect and cap the hose, (both sides).
Remove the hoses from the cab.

STEP 33




Remove the ground cable nut.

STEP 34




Remove the ground cable and battery lead.

STEP 35



Remove the side panel bolts, (both sides).

STEP 36



Remove the side panel, (both sides).

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>