

AXIAL-FLOW® 5140
AXIAL-FLOW® 6140
AXIAL-FLOW® 7140
Tier 4B (final)
Combine

SERVICE MANUAL

Part number 47795174

2nd edition English

November 2014

Replaces part number 47677209





SERVICE MANUAL

AXIAL-FLOW® 5140 [YDG012001 - YEG012700] , AXIAL-FLOW® 5140 [YEG012701 -] , AXIAL-FLOW® 6140 [YDG012001 - YEG012700] , AXIAL-FLOW® 6140 [YEG012701 -] , AXIAL-FLOW® 7140 [YDG012001 - YEG012700] , AXIAL-FLOW® 7140 [YEG012701 -]

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.216] Fuel tanks	10.3
[10.254] Intake and exhaust manifolds and muffler	10.4
[10.310] Aftercooler.....	10.5
[10.400] Engine cooling system	10.6
[10.408] Oil cooler and lines.....	10.7
[10.414] Fan and drive	10.8
[10.419] Stationary air screen	10.9
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.10
Main gearbox and drive	14
[14.100] Main gearbox and drive	14.1
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.145] Gearbox internal components.....	21.2
[21.182] Differential.....	21.3
Front axle system	25
[25.310] Final drives	25.1
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.124] Final drive hub, steering knuckles, and shafts	27.2
Hydrostatic drive.....	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.134] Two-speed assembly.....	29.2

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

[29.202] Hydrostatic transmission	29.3
[29.204] Reservoir, cooler, and lines	29.4
[29.218] Pump and motor components	29.5
[29.300] Rear hydrostatic transmission	29.6
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump	35.3
[35.220] Auxiliary hydraulic pump and lines	35.4
[35.300] Reservoir, cooler, and filters.....	35.5
[35.359] Main control valve	35.6
[35.410] Header or attachment height system	35.7
[35.536] Crop processor system	35.8
Steering.....	41
[41.101] Steering control	41.1
[41.106] Tie rods.....	41.2
[41.200] Hydraulic control components.....	41.3
[41.206] Pump	41.4
Wheels	44
[44.511] Front wheels.....	44.1
Cab climate control	50
[50.100] Heating	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning.....	50.3
Electrical systems	55

[55.000] Electrical system	55.1
[55.014] Engine intake and exhaust system.....	55.2
[55.100] Harnesses and connectors.....	55.3
[55.201] Engine starting system.....	55.4
[55.202] Cold start aid	55.5
[55.301] Alternator.....	55.6
[55.302] Battery.....	55.7
[55.408] Warning indicators, alarms, and instruments	55.8
[55.421] Feeding control system	55.9
[55.512] Cab controls.....	55.10
[55.610] Ground speed control	55.11
[55.640] Electronic modules.....	55.12
[55.785] Precision farming system	55.13
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.14
[55.DTC] FAULT CODES.....	55.15
Attachments/Headers.....	58
[58.105] Attachment/Header reel control system.....	58.1
Product feeding	60
[60.105] Floating roll, feed chain, and drive	60.1
[60.110] Feeder housing.....	60.2
[60.150] Feeder drive system	60.3
[60.500] Gearbox housing.....	60.4
Threshing	66
[66.105] Concave.....	66.1
[66.110] Concave control system.....	66.2
[66.260] Threshing mechanism drive system	66.3
[66.331] Rotor	66.4
Separation	72

[72.410] Rotary separator drive system	72.1
[72.420] Rotary separator	72.2
Residue handling	73
[73.210] Straw chopper drive system.....	73.1
[73.230] Straw chopper.....	73.2
[73.335] Chaff spreader	73.3
Cleaning	74
[74.000] Cleaning.....	74.1
[74.101] Cleaning drive systems	74.2
[74.114] Upper shaker shoe	74.3
[74.118] Lower shaker shoe	74.4
[74.130] Fan housing	74.5
[74.140] Tailings return system	74.6
Crop storage / Unloading	80
[80.101] Clean grain elevator.....	80.1
[80.150] Grain tank	80.2
[80.175] Grain tank unload drive system	80.3
[80.180] Grain tank unload	80.4
Platform, cab, bodywork, and decals.....	90
[90.100] Engine hood and panels	90.1
[90.105] Machine shields and guards	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.150] Cab.....	90.4
[90.151] Cab interior.....	90.5



INTRODUCTION

Basic instructions - Important notice regarding equipment servicing

AXIAL-FLOW® 5140	NA
AXIAL-FLOW® 6140	NA
AXIAL-FLOW® 7140	NA

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The information in this manual is up-to-date at the date of the publication. It is the policy of the manufacturer for continuous improvement. Some information could not be updated due to modifications of a technical or commercial type, or changes to the laws and regulations of different countries.

In case of questions, refer to your CASE IH Sales and Service Networks.

Safety rules - Ecology and the environment

AXIAL-FLOW® 5140	NA
AXIAL-FLOW® 6140	NA
AXIAL-FLOW® 7140	NA

Soil, air, and water quality is important for all industries and life in general. When legislation does not yet rule the treatment of some of the substances that advanced technology requires, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

Familiarize yourself with the relative legislation applicable to your country, and make sure that you understand this legislation. Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, anti-freeze, cleaning agents, etc., with regard to the effect of these substances on man and nature and how to safely store, use, and dispose of these substances.

Helpful hints

- Avoid the use of cans or other inappropriate pressurized fuel delivery systems to fill tanks. Such delivery systems may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of these products contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when you drain fluids such as used engine coolant mixtures, engine oil, hydraulic fluid, brake fluid, etc. Do not mix drained brake fluids or fuels with lubricants. Store all drained fluids safely until you can dispose of the fluids in a proper way that complies with all local legislation and available resources.
- Do not allow coolant mixtures to get into the soil. Collect and dispose of coolant mixtures properly.
- The air-conditioning system contains gases that should not be released into the atmosphere. Consult an air-conditioning specialist or use a special extractor to recharge the system properly.
- Repair any leaks or defects in the engine cooling system or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding. Penetrating weld splatter may burn a hole or weaken hoses, allowing the loss of oils, coolant, etc.

Battery recycling

Batteries and electric accumulators contain several substances that can have a harmful effect on the environment if the batteries are not properly recycled after use. Improper disposal of batteries can contaminate the soil, groundwater, and waterways. CASE IH strongly recommends that you return all used batteries to a CASE IH dealer, who will dispose of the used batteries or recycle the used batteries properly. In some countries, this is a legal requirement.



Mandatory battery recycling

NOTE: The following requirements are mandatory in Brazil.

Batteries are made of lead plates and a sulfuric acid solution. Because batteries contain heavy metals such as lead, CONAMA Resolution 401/2008 requires you to return all used batteries to the battery dealer when you replace any batteries. Do not dispose of batteries in your household garbage.

Points of sale are obliged to:

- Accept the return of your used batteries
- Store the returned batteries in a suitable location
- Send the returned batteries to the battery manufacturer for recycling

Safety rules - Personal safety

AXIAL-FLOW® 5140	NA
AXIAL-FLOW® 6140	NA
AXIAL-FLOW® 7140	NA

Carefully study these precautions, and those included in the external attachment operators manual, and insist that they be followed by those working with and for you.

1. Thoroughly read and understand this manual and the attachment Operator's Manual before operating this or any other equipment.
2. Be sure all people and pets are clear of the machine before starting. Sound the horn, if equipped, three times before starting engine.
3. Only the operator should be on the machine when in operation. Never allow anyone to climb on to the machine while it is in motion. If the machine is equipped with an Instructors Seat, this must only be used for training purposes. Passengers must not be allowed to use the Instructors Seat.
4. Keep all shields in place. Never work around the machine or any of the attachments while wearing loose clothing that might catch on moving parts.
5. Observe the following precautions whenever lubricating the machine or making adjustments.
 - Disengage all clutching levers or switches.
 - Lower the attachment, if equipped, to the ground or raise the attachment completely and engage the cylinder safety locks. Completing these actions will prevent the attachment from lowering unexpectedly.
 - Engage the parking brake.
 - Shut off the engine and remove the key.
 - Wait for all machine movement to stop before leaving the operators platform.
6. Always keep the machine in gear while travelling downhill.
7. The machine should always be equipped with sufficient front or rear axle weight for safe operation.
8. Under some field conditions, more weight may be required at the front or rear axle for adequate stability. This is especially important when operating in hilly conditions or/when using heavy attachments.
9. Always lower the attachment, shut off the engine, set the parking brake, engage the transmission gears, remove the key and wait for all machine movement to stop before leaving the operators platform.
10. If the attachment or machine should become obstructed or plugged; set the parking brake, shut off the engine and remove the key, engage the transmission gears, wait for all machine or attachment motion to come to a stop, before leaving the operators platform to removing the obstruction or plug.
11. Never disconnect or make any adjustments to the hydraulic system unless the machine and/or the attachment is lowered to the ground or the safety lock(s) is in the engaged position.
12. Use of the flashing lights is highly recommended when operating on a public road.
13. When transporting on a road or highway, use accessory lights and devices for adequate warning to the operators of other vehicles. In this regard, check local government regulations. Various safety lights and devices are available from your CASE IH dealer.
14. Practice safety 365 days a year.
15. Keep all your equipment in safe operating condition.
16. Keep all guards and safety devices in place.
17. Always set the parking brake, shut off the engine and remove the key, engage the transmission gears, wait for all machine or attachment motion to come to a stop, before leaving the operators platform to service the machine and attachment.
18. Remember: A careful operator is the best insurance against an accident.
19. Extreme care should be taken in keeping hands and clothing away from moving parts.



SERVICE MANUAL

Engine


AXIAL-FLOW® 5140 [YDG012001 - YEG012700] , AXIAL-FLOW® 5140 [YEG012701 -] , AXIAL-FLOW® 6140 [YDG012001 - YEG012700] , AXIAL-FLOW® 6140 [YEG012701 -] , AXIAL-FLOW® 7140 [YDG012001 - YEG012700] , AXIAL-FLOW® 7140 [YEG012701 -]

Engine - Install

AXIAL-FLOW® 5140


NA

1. Attach suitable lifting chains (**1**) to the engine lift brackets (**2**) and attach to a suitable lifting device. Lift engine into position at the gearbox.




NH12AF001337A 1

2. Guide engine into the PTO gearbox and install twelve gearbox to engine mount bolts.




NH12AF001336A 2


3. Install flange bolts (1) to the engine mounts (2). Hand tighten at this time.




NHIL14AF00229AA 3



NHIL14AF00230AA 4




NHIL14AF00231AA 5




NHIL14AF00232AA 6

4. Connect the fuel supply line (1).




NH12AF001323A 7




NH12AF001322A 8

5. Connect the fuel return line (1).




NH14AF00228AA 9

6. Connect the engine pre-heater connector (1) to the engine pre-heater (2) .




NH12AF001319A 10



NH12AF001320A 11

7. Connect the electrical connections (1) and (2) to the Engine Control Unit (ECU) (3).



NH14AF00227AA 12

8. Install cable ties to retain the harness to the engine.

Next Operations

Engine starter - Install (55.201)

Alternator - Install (55.301)

Diesel Oxidation Catalyst (DOC) - Install (10.500)

Exhaust pipes - Install exhaust tube from turbo charger to Diesel Oxidation Catalyst (DOC) (10.254)

Selective Catalytic Reduction (SCR) muffler and catalyst - Install (10.500)

Exhaust pipes - Install mixer tube (10.254)

Fan and drive - Install (10.414)

Aftercooler air supply and return lines - Install return air tube from cooler to intake manifold (10.310)

Aftercooler air supply and return lines - Install air supply tube from turbocharger to lower cooler box (10.310)

Selective Catalytic Reduction (SCR) muffler and catalyst - Install (10.500)

Air intake system - Install (10.202)

Radiator coolant tubes - Install (10.400)

Deaeration tank - Install (10.400)

Engine - Install engine oil drain line and drain valve (10.001)


Engine hood and panels - Install (90.100)

Engine cooling system - Filling (10.400)

Engine - Filling engine oil (10.001)

Battery - Install (55.302)

9. Disconnect the fuel pump wire connector (1) to disable the fuel pump (2).
10. Check the engine oil level and top off if necessary.
11. Crank the engine over for three ten second intervals. This will distribute lubricating oil to the engine operating systems and will allow oil pressure to be built before starting the engine.




NHIL14AF00437AA 13

12. Connect the fuel pump wire connector (1) to the fuel pump (2) and bleed the air from fuel injection system, as described in the Operators manual.
13. Start the engine and check all hoses, fittings and clamps for leaks.

NOTICE: Monitor the instrument warning light bar at all times during initial engine start up to ensure the engine has proper oil pressure. Shut down the engine immediately if oil pressure is not adequate.

14. Ensure all electrical components are working properly.



NHIL14AF00437AA 14



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading

Engine - Remove

AXIAL-FLOW® 6140	NA
AXIAL-FLOW® 7140	NA

⚠ CAUTION

Unexpected machine movement!

1. Disengage all drives.
2. Engage parking brake.
3. Lower all attachments to the ground, or raise and engage all safety locks.
4. Shut off engine.
5. Remove key from key switch.
6. Switch off battery key, if installed.
7. Wait for all machine movement to stop.

Failure to comply could result in minor or moderate injury.

C0038A

Prior operation:

Battery - Remove (55.302)

Prior operation:

Engine hood and panels - Remove (90.100)

Prior operation:

Engine - Drain fluid (10.001)

Prior operation:

Engine - Remove engine oil drain line and drain valve (10.001)

Prior operation:

Engine cooling system - Drain fluid (10.400).

Prior operation:

Deaeration tank - Remove (10.400) .

Prior operation:

Radiator coolant tubes - Remove (10.400)

Prior operation:

Air intake system - Remove (10.202)

Prior operation:

Aftercooler air supply and return lines - Remove air supply tube from turbocharger to upper cooler box (10.310)

Prior operation:

Aftercooler air supply and return lines - Remove return air tube from cooler to intake manifold (10.310)

Prior operation:

Fan and drive - Remove (10.414)

Prior operation:

Exhaust pipes - Remove mixer tube (10.254)

Prior operation:

Exhaust pipes - Remove exhaust tube from turbo charger to Diesel Oxidation Catalyst (DOC) (10.254)

Prior operation:

Selective Catalytic Reduction (SCR) muffler and catalyst - Remove (10.500)

Prior operation:

Diesel Oxidation Catalyst (DOC) - Remove (10.500)

Prior operation:

Air-conditioning compressor lines - Remove (50.200)

Prior operation:

Engine starter - Remove (55.201)

Prior operation:

Alternator - Remove (55.301)

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>