

SERVICE MANUAL

CX7.80 / CX7.90 / CX8.70 / CX8.80
CX8.85 / CX8.90 / CR7.90 / CR8.80
CR8.90 / CR9.80 / CR9.90 / CR10.90
Combine

Part number 47956056

English
March 2016





SERVICE MANUAL

**CR10.90, CR7.90, CR8.80, CR8.90, CR9.80, CR9.90, CX7.80, CX7.90, CX8.70,
CX8.80, CX8.85, CX8.90**

Link Product / Engine

Product	Market Product	Engine
CX7.80 TIER 4B [1957 -]	Europe	F2CFE613F*B041
CX7.90 TIER 4B Tracks [1957 -]	Europe	F2CFE613E*B043
CX7.90 TIER 4B Tires [1957 -]	Europe	F2CFE613E*B043
CX8.70 TIER 4B Tires [1957 -]	Europe	F2CFE613E*B043
CX8.80 TIER 4B Tires [1957 -]	Europe	F2CFE613E*B043
CX8.80 Tracks TIER 4B [1957 -]	Europe	F2CFE613E*B043
CX8.85 TIER 4B Tracks [1962 -]	Europe	F2CFE613A*B041
CX8.85 TIER 4B Tires [1962 -]	Europe	F2CFE613A*B041
CX8.90 TIER 4A tracks [1962 -]	Europe	F3AFE613A*A
CX8.90 TIER 4A [1962 -]	Europe	F3AFE613A*A
CR10.90 TIER 4B tracks [1947 -]	Europe	F3JFE613A*B004
CR7.90 TIER 4B	Europe	F2CFE613A*B
CR7.90 TIER 4A [1946 -]	Europe	F2CFE613A*A
CR8.80 TIER 4A [1946 -]	Europe	F3AFE613A*A
CR8.80 TIER 4B TRACK	Europe	F3HFE613A*B009
CR8.80 TIER 4A tracks [1946 -]	Europe	F3AFE613A*A
CR8.80 TIER 4B	Europe	F3HFE613A*B009
CR8.90 TIER 4B TRACK	Europe	F3GFE613B*B003
CR8.90 TIER 4A [1946 -]	Europe	F3AFE613A*A
CR8.90 TIER 4A tracks [1946 -]	Europe	F3AFE613A*A
CR8.90 CR8.90 TIER 4B third axle [1961 -]	Europe	F3GFE613B*B003
CR8.90 TIER 4B	Europe	F3GFE613B*B003
CR9.80 TIER 4A 3 axle [1946 -]	Europe	F3BFE613E*A
CR9.80 TIER 4A tracks [1946 -]	Europe	F3BFE613E*A
CR9.80 TIER 4B 12.5 3 AXLE	Europe	F3HFE613A*B009
CR9.80 TIER 4B [1961 -]	Europe	F3HFE613A*B009
CR9.80 TIER 4A [1946 -]	Europe	F3BFE613E*A
CR9.80 TIER 4B [1961 -]	Europe	F3HFE613A*B009
CR9.90 TIER 4B TRACK	Europe	F3HFE613A*B009
CR9.90 TIER 4A 3 axle [1947 -]	Europe	F3BFE613D*A
CR9.90 TIER 4B	Europe	F3HFE613A*B009
CR9.90 TIER 4A [1954 -]	Europe	F3BFE613D*A
CR9.90 TIER4A [1954 -]	Europe	F3BFE613D*A
CR9.90 TIER 4A [1947 -]	Europe	F3BFE613D*A
CR9.90 TIER 4A tracks [1947 -]	Europe	F3BFE613D*A

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.254] Intake and exhaust manifolds and muffler	10.3
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment	10.4
[10.400] Engine cooling system	10.5
[10.418] Rotary screen	10.6
[10.450] Engine air compressor	10.7
Main gearbox and drive	14
[14.100] Main gearbox and drive	14.1
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.130] Mechanical transmission external controls	21.2
[21.145] Gearbox internal components	21.3
[21.182] Differential	21.4
Front axle system	25
[25.108] Final drive hub, steering knuckles, and shafts	25.1
[25.310] Final drives	25.2
Rear axle system	27
[27.124] Final drive hub, steering knuckles, and shafts	27.1
Hydrostatic drive	29
[29.100] Transmission and steering hydrostatic control	29.1
[29.204] Reservoir, cooler, and lines	29.2
[29.218] Pump and motor components	29.3
[29.202] Hydrostatic transmission	29.4

[29.300] Rear hydrostatic transmission.....	29.5
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.106] Variable displacement pump	35.3
[35.102] Pump control valves.....	35.4
[35.359] Main control valve	35.5
[35.322] Regulated/Low pressure system	35.6
[35.220] Auxiliary hydraulic pump	35.7
[35.410] Header or attachment height system	35.8
[35.602] Header or attachment leveling system	35.9
[35.760] Header reverser drive	35.10
[35.992] Stone trapping system	35.11
[35.994] Positive Straw Discharge (PSD)	35.12
[35.796] Chaff spreader control	35.13
[35.440] Grain tank unload system	35.14
[35.450] Traction variator system.....	35.15
Steering.....	41
[41.101] Steering control	41.1
[41.200] Hydraulic control components.....	41.2
[41.432] Autoguidance steering	41.3
Tracks and track suspension	48
[48.138] Track rollers	48.1
[48.130] Track frame and driving wheels	48.2
[48.134] Track tension units	48.3

[48.100] Tracks	48.4
Cab climate control	50
[50.100] Heating	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning	50.3
Electrical systems	55
[55.000] Electrical system	55.1
[55.100] Harnesses and connectors	55.2
[55.201] Engine starting system	55.3
[55.301] Alternator	55.4
[55.988] Selective Catalytic Reduction (SCR) electrical system	55.5
[55.640] Electronic modules	55.6
[55.029] Gearbox electric system	55.7
[55.019] Hydrostatic drive control system	55.8
[55.512] Cab controls	55.9
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls	55.10
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system	55.11
[55.662] Header height control	55.12
[55.628] Threshing electrical control	55.13
[55.426] Harvest material flow control system	55.14
[55.624] Residue handling control	55.15
[55.785] Precision farming system	55.16
[55.911] Global Positioning System (GPS)	55.17
[55.680] Autopilot/Autoguidance	55.18
[55.518] Wiper and washer system	55.19
[55.404] External lighting	55.20
[55.405] External lighting switches and relays	55.21
[55.514] Cab lighting	55.22

[55.408] Warning indicators, alarms, and instruments	55.23
[55.DTC] FAULT CODES.....	55.24
Attachments/Headers.....	58
[58.900] Belt feeding	58.1
Product feeding	60
[60.105] Floating roll, feed chain, and drive	60.1
[60.110] Feeder housing	60.2
[60.150] Feeder drive system	60.3
[60.165] Feeder reverse system.....	60.4
[60.112] Stone trapping system	60.5
[60.260] Rotor	60.6
Threshing	66
[66.000] Threshing	66.1
[66.260] Threshing mechanism drive system	66.2
[66.331] Rotor	66.3
[66.330] Drum	66.4
[66.360] Drum/Rotor housing.....	66.5
[66.321] Drum/Rotor variator with electrical control	66.6
[66.105] Concave.....	66.7
[66.101] Concave conveyor plate	66.8
[66.110] Concave control system.....	66.9
Separation	72
[72.220] Discharge beater.....	72.1
[72.350] Beater	72.2
[72.420] Rotary separator	72.3
[72.440] Straw-flow beater	72.4
[72.110] Straw walker drive system	72.5
[72.101] Straw walkers and shafts	72.6

Residue handling	73
[73.300] Positive Straw Discharge (PSD)	73.1
[73.230] Straw chopper	73.2
[73.210] Straw chopper drive system	73.3
[73.220] Straw chopper frame	73.4
[73.335] Chaff spreader	73.5
[73.410] Opti-Spread™ system	73.6
Cleaning	74
[74.000] Cleaning	74.1
[74.101] Cleaning drive systems	74.2
[74.110] Grain pan	74.3
[74.114] Upper shaker shoe	74.4
[74.118] Lower shaker shoe	74.5
[74.125] Clean grain and return cross auger housing	74.6
[74.130] Fan housing	74.7
[74.136] Fan drive system	74.8
[74.140] Tailings return system	74.9
Crop storage / Unloading	80
[80.101] Clean grain elevator	80.1
[80.150] Grain tank	80.2
[80.175] Grain tank unload drive system	80.3
[80.180] Grain tank unload	80.4
Platform, cab, bodywork, and decals	90
[90.154] Cab doors and hatches	90.1
[90.110] Operator platform less cab	90.2
[90.118] Protections and footboards	90.3
[90.124] Pneumatically-adjusted operator seat	90.4
[90.105] Machine shields and guards	90.5



INTRODUCTION

Safety rules

LEGAL OBLIGATIONS

This machine may be equipped with special guarding or other devices in compliance with local legislation. Some of these require active use by the operator. Therefore, check local legislations on the usage of this machine.

ACCIDENT PREVENTION

Most accidents or injuries that occur in workshops are the result of non compliance to simple and fundamental safety principles. For this reason, IN MOST CASES THESE ACCIDENTS CAN BE AVOIDED by applying the fundamental safety principles, acting with the necessary caution and care.

Accidents may occur with all types of machine, regardless of how well the machine in question was designed and built.

CAUTION

Unexpected machine movement!

- 1. Disengage all drives.**
 - 2. Engage parking brake.**
 - 3. Lower all attachments to the ground, or raise and engage all safety locks.**
 - 4. Shut off engine.**
 - 5. Remove key from key switch.**
 - 6. Switch off battery key, if installed.**
 - 7. Wait for all machine movement to stop.**
- Failure to comply could result in minor or moderate injury.**

C0038A

SAFETY REQUIREMENTS FOR FLUID POWER SYSTEMS AND COMPONENTS - HYDRAULICS (EUROPEAN STANDARD EN982)

- Flexible hose assemblies must not be constructed from hoses which have been previously used as part of a hose assembly.
- Do not weld hydraulic pipes: when flexible hoses or piping are damaged, replace them immediately.
- It is forbidden to modify a hydraulic accumulator by machining, welding or any other way.
- Before removing hydraulic accumulators for servicing, the liquid pressure in the accumulators must be reduced to zero.
- Pressure check on hydraulic accumulators must be carried out by a method recommended by the accumulator manufacturer.
- Take care not to exceed the maximum allowed pressure of the accumulator. After any check or adjustment, check for leakages or gas in the hoses or tubes.


SAFETY RULES

General guidelines

- Carefully follow specified repair and maintenance procedures.
- When appropriate, use P.P.E (Personal Protective Equipment)
- Do not wear rings, wristwatches, jewellery, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips that may remain entangled in moving parts. It is advised to wear approved safety clothing, e.g.: non-slip footwear, gloves, safety goggles, helmets, etc.
- Do not carry out repair operations with someone sitting in the driver's seat, unless the person is a trained technician who is assisting with the operation in question.
- Do not operate the machine or use any of the implements from different positions, other than the driver's seat.
- Do not carry out operations on the machine with the engine running, unless specifically indicated.

INTRODUCTION

- Bring all hydraulic cylinders to the home positions (down, retracted, etc.) before engine shut down.
- Stop the engine and check that the hydraulic circuits are pressure-free before removing caps, covers, valves, etc.
- All repair and maintenance operations must be carried out using extreme care and attention.
- Service steps and platforms used in the workshop or elsewhere should be built according to the applicable standards and legislation.
- Disconnect the Power Take-Off (PTO) and label the controls to indicate that the machine is being serviced.
- Brakes are inoperative when manually released for repair or maintenance purposes. Use blocks or similar devices to secure the machine in these conditions.
- Only use specified towing points for towing the machine. Connect parts carefully. Make sure that all pins and/or locks are secured in position before applying traction. Never remain near the towing bars, cables or chains that are operating under load.
- When loading or unloading the machine from the trailer (or other means of transport), select a flat area capable of sustaining the trailer or truck wheels. Firmly secure the machine to the truck or trailer and lock the wheels in the position used by the carrier.
- Electric heaters, battery-chargers and similar equipment must only be powered by auxiliary power supplies with efficient ground insulation to avoid electrical shock hazards.
- Always use suitable hoisting or lifting devices when raising or moving heavy parts.
- Keep bystanders away.
- Never use gasoline, diesel oil or other inflammable liquids as cleaning agents. Use non-inflammable, non toxic commercially available solvents.
- Wear safety goggles with side guards when cleaning parts with compressed air.
- Never use open flames for lighting when working on the machine or checking for leaks.
- When carrying out checks with the engine running, request the assistance of an operator in the driver's seat. The operator must maintain visual contact with the service technician at all times.
- If operating outside the workshop, position the machine on a flat surface and lock in position. If working on a slope, lock the machine in position. Move to a flat area as soon as is safely possible.
- Maintenance and repair operations must be carried out in a clean and dry area. Clean up any water or oil spillage immediately.
- Do not create piles of oil or grease-soaked rags as they represent a serious fire hazard. Always store rags in a closed metal container.
- Before engaging the machine, make sure that there are no persons within the machine or implement range of action.
- Empty your pockets of all objects that may fall accidentally unobserved into the machine inner compartments.
- When metal parts are sticking out, use protective goggles or goggles with side guards, helmets, special footwear and gloves.
- When welding, use protective safety devices: tinted safety goggles, helmets, special overalls, gloves and footwear. All persons present in the area where welding is taking place must wear tinted goggles. **NEVER LOOK DIRECTLY AT THE WELDING ARC WITHOUT SUITABLE EYE PROTECTION.**



SERVICE MANUAL

Engine


**CR10.90, CR7.90, CR8.80, CR8.90, CR9.80, CR9.90, CX7.80, CX7.90, CX8.70,
CX8.80, CX8.85, CX8.90**

Engine - Remove

NOTE: The engine and cooling system used in the combine is designed to be removed as a modular unit. The following engine removal procedure demonstrates the removal of the engine only from the module. This procedure takes into consideration the possible unavailability of proper, or sufficient lifting equipment for complete module removal. When possible, remove the engine and cooling system module as designed.

1. Remove the gearbox and hydraulic pumps from the engine. (Refer to **Main gearbox and drive - Remove (14.100)**)
Place a suitable container (1) below the coolant drain hose (2).

NOTE: Depending on model, the cooling system has a coolant capacity between **50 - 60 l (13.2 - 15.9 US gal)**. Be sure to use clean containers with adequate capacity when draining the cooling system.




10013105_780 1

2. Refer to **Expansion tank - Remove (10.400)** for the coolant fluid drain and removal of the engine coolant reservoir.


NOTE: Depending on the model, the combine engine has an oil capacity between **29 - 35 l (7.7 - 9.2 US gal)**. Be sure to use clean containers with adequate capacity when draining the engine oil.

3. Remove the cap (1) and turn the engine oil drain valve (2), to the open position. Drain all of the engine oil into suitable containers.




10013107 2

4. Loosen and remove the mounting hardware from the protection cover (1).
Remove the cover (1) from the engine compartment.




ZEIL09CR0245A0B 3

5. Secure the engine cover with an adequate rope. Attach the rope to a lifting device, able to carry the engine cover and stair assembly. Disconnect the shock absorber (1) from the engine cover (2).




ZEIL09CR0246A0B 4

6. Remove the two retaining rings (1), washers (2) and hinge pins (3) from the engine cover. Remove the engine cover from the combine.



ZEIL09CR0247A0B 5


7. Refer to **Exhaust muffler - Remove (10.254)** for removal of the exhaust pipe.
8. Loosen the hardware (1) and remove the support (2).
9. Loosen the clamps (3) from the air inlet pipe (4). Remove the air inlet pipe (4).



ZEIL09CR0248A0B 6


10. Remove the air cleaner assembly, if necessary, refer to **Air cleaner - Remove (10.202)**.

11. Loosen the clamps (1) and remove the air lines (2).
Loosen the clamps (3).
Loosen and remove the hardware (4) and remove the air duct (5) from the combine.




ZEIL09CR0249A0B 7

Depending on model/options, an additional air tube (7) needs to be removed/disconnected, loosen the coupler (6) from the air compressor.




ZEIL09CR0250A0B 8

12. Loosen the coupler (1) and disconnect the fuel line (2) from the ECU cooler.
Loosen the coupler (4) and disconnect the fuel hose towards the injection pump from the fuel line (5).
Loosen and remove the clamp (3).
13. Loosen and disconnect the compressed air tube (7) at the connector (6).
Loosen and remove the clamp (8).




ZEIL09CR0251A0B 9

14. Loosen the hose clamps (1) and remove the top coolant pipe (2) from the engine and radiator neck.



10013111 10

15. Loosen the clamps (1) and remove the air pipe (2).
16. Loosen the clamp (3) and disconnect the water hose from the cooling system.




ZEIL09CR0252A0B 11

17. Remove the main drive belt (1) from the engine.
18. Disconnect the electrical connectors (1).


ATTENTION: Do not disconnect any of the air conditioning lines or hoses during compressor removal, as serious injury could result.

19. Remove the mounting bolts and nuts (2) from the air conditioning compressor (3). Remove the compressor from the engine and tie the assembly out of the way.



10013117 12

20. From inside the grain tank, loosen the mounting nuts on the carriage bolts (1) and turn the rotary screen drive pulley adjusting bolt (2) counter clockwise, to release the tension on the drive belt (3). Remove the drive belt.



10013118 13




Suggest:

If the above button click is invalid.

**Please download this document
first, and then click the above link
to download the complete manual.**


Thank you so much for reading

21. From inside the grain tank, loosen the hose clamp (1) and disconnect the lower coolant hose (2) from the engine.




10013123 14

22. Disconnect the main engine electrical harness connector (1).



10004682 15


23. If installed, open the rotary screen door and disconnect the rotary screen brush electrical connector (1).



10013132 16

24. Feed the connector and wire loom (1) and grommet (2) through the hole in the radiator frame. Secure the wire loom and connector to the engine to prevent damage during removal.

NOTE: Removal of the rubber grommet in the radiator frame hole may be necessary to remove the radiator screen brush electrical connector.



10013133 17

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>