
TC35A, TC35DA, TC40A, TC40DA, TC45A, TC45DA REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCH	10
SECTION 21 - TRANSMISSION	12
SECTION 23 - DRIVELINE	14
SECTION 25 - FWD FRONT AXLE	15
SECTION 27 - DIFFERENTIAL, REAR AXLE	18
SECTION 29 - HYDROSTATIC TRANSMISSION	19
SECTION 31 - POWER TAKE-OFF (PTO) SYSTEMS	22
SECTION 33 - BRAKES	25
SECTION 35 - HYDRAULIC SYSTEM	25
SECTION 41 - STEERING	29
SECTION 44 - 2WD FRONT AXLE	31
SECTION 50 - CLIMATE CONTROL	31
SECTION 55 - ELECTRICAL	35
SECTION 90 - PLATFORM	53

The following pages are the collation of the contents pages from each section and chapter of the TC35A - TC45DA Repair manual. Complete Repair part # 87618714.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TC35A - TC45DA Tractors.

SECTION 00 - GENERAL INFORMATION

Chapter 1 - General Information

CONTENTS

Section	Description	Page
00 000	Introduction	2
	Safety	3
	Technical Information	4
	Safety Precautions	5
	Safety Decals - TC35A, TC40A, TC45A	8
	Instruction Decals - TC35A, TC40A, TC45A	9
	Safety Decals - TC35DA, TC40DA, TC45DA	12
	Instruction Decals - TC35DA, TC40DA, TC45DA	13
	International Symbols	17
	Specifications - TC35A, TC40A, TC45A	18
	General Dimensions - TC35A, TC40A, TC45A	25
	Specifications - TC35DA, TC40DA, TC45DA	31
	General Dimensions - TC35DA, TC40DA, TC45DA	37
	Minimum Hardware Tightening Torques	41
	Special Tools	43
	Lubricants	44
00 400	Recommended Lubricants	44
	Adjustments	45
	Tire Inflation Pressure - Adjustments	45
00 100	Pre-Season and Pre-Delivery Checklist	46

INTRODUCTION

This repair manual provides the technical information needed to properly service the New Holland TC35A, TC35DA, TC40A, TC40DA, TC45A and TC45DA tractors. Use this manual in conjunction with the operator's manual for complete operation, adjustment, and maintenance information.

On New Holland equipment, left and right are determined by standing behind the unit, looking in the direction of travel.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

PRECAUTIONARY STATEMENTS

PERSONAL SAFETY

Throughout this manual and on machine decals, you will find precautionary statements (“**CAUTION**”, “**WARNING**”, and “**DANGER**”) followed by specific instructions. These precautions are intended for the personal safety of you and those working with you. Please take the time to read them.



CAUTION



The word “**CAUTION**” is used where a safe behavioral practice according to operating and maintenance instructions and common safety practices will protect the operator and others from accident involvement.



DANGER



The word “**DANGER**” denotes a forbidden practice in connection with a serious hazard.



WARNING



The word “**WARNING**” denotes a potential or hidden hazard which has a potential for serious injury. It is used to warn operators and others to exercise every appropriate means to avoid a surprise involvement with machinery.

FAILURE TO FOLLOW THE “CAUTION”, “WARNING”, AND “DANGER” INSTRUCTIONS MAY RESULT IN SERIOUS BODILY INJURY OR DEATH.

MACHINE SAFETY

The precautionary statement (“**IMPORTANT**”) is followed by specific instructions. This statement is intended for machine safety.

IMPORTANT: The word “**IMPORTANT**” is used to inform the reader of something he needs to know to prevent minor machine damage if a certain procedure is not followed.

TECHNICAL INFORMATION

HARDWARE

GENERAL

The TC35A, TC35DA, TC40A, TC40DA, TC45A and TC45DA tractors have been built using metric hardware.

NOTE: *Be sure to use the hardware specified when using tapped holes, as trying to install a metric bolt in an inch thread, or an inch bolt in a metric thread, will damage the thread.*

Certain hardware must be tightened to specific torque specifications. If specific torque specifications are not noted, tighten the hardware to the standard torque chart specification listed in this manual.

PLATING

Hardware used on New Holland balers is plated with zinc chromate (gold color). Gold colored hardware has different torquing requirements from unplated or zinc plated (silver color) hardware because of the difference in the coefficient of friction of the plating material. The torque charts in this manual list the correct specifications for gold, silver, and unplated bolts.

NUT TIGHTENING

Whenever possible, the nut should be tightened, not the head of the bolt. When tightening using the bolt head, the clamp load can be lost because some of the torque applied twists the bolt instead of tensioning (stretching) it. The tension on the bolt is what holds the joint together.

Approximately 90% of the torque applied during assembly goes to overcoming friction between the parts. The other 10% is used to tension (stretch) the bolt. After assembly, the frictional forces disappear, which is the basis for the saying "If it does not fail during assembly, it will not fail in service." The bolt may later fail due to other factors, but not from being over tightened.

LOCKNUTS

Most locknuts are coated with a special lubricant that is dry to the touch. Anytime a locknut is used, a lower than normal torque is required. Refer to the torque charts in this manual for specific values.

JAM NUTS

When using a jam nut to lock a regular nut, the jam nut should be installed first and tightened to one half the recommended torque, then held in place while installing a regular nut to the recommended torque.

THREAD LUBRICATION

The addition of antiseize compound, Molykote, oil, graphite, or any other lubricant to a bolt decreases the friction between it and a nut. This makes it necessary to reduce the recommended torque to prevent over tensioning of the bolt. When using the torque charts in this manual, decrease the value by 20% whenever a lubricant is used.



SAFETY PRECAUTIONS

A careful operator is the best operator. Most accidents can be avoided by observing certain precautions. To help prevent accidents, read and take the following precautions before operating this tractor. Equipment should be operated only by those who are responsible and instructed to do so.

THE TRACTOR

1. Read the Operator's Manual carefully before using the tractor. Lack of operating knowledge can lead to accidents.
2. Use an approved roll bar and seat belt for safe operation. Overturning a tractor without a roll bar can result in death or injury. If your tractor is not equipped with a roll bar and seat belt, see your New Holland Dealer.
3. Always use the seat belt. The only instance when the seat belt should not be used is if the roll bar has been removed from the tractor or folding ROPS is in down position.
4. If a front end loader is to be installed, always use a FOPS (Falling Object Protective Structure) canopy to avoid injury from falling objects.
5. Use the handholds and step plates when getting on and off the tractor to prevent falls. Keep steps and platform cleared of mud and debris.
6. Do not permit anyone but the operator to ride on the tractor. There is no safe place for extra riders.
7. Keep all safety decals clean of dirt and grime, and replace all missing, illegible, or damaged safety decals. See the list of decals in the Decal section of this manual.

SERVICING THE TRACTOR

1. The cooling system operates under pressure which is controlled by the radiator cap. It is dangerous to remove the cap while the system is hot. Always turn the cap slowly to the first stop and allow pressure to escape before removing the cap entirely.
2. Keep any type of open flame away from the tractor and do not smoke while refueling. Wait for the engine to cool before refueling.
3. Keep the tractor and equipment, particularly brakes and steering, maintained in a reliable and

satisfactory condition to ensure your safety and comply with legal requirements.

4. Keep open flame or cold weather starting aids away from the battery to prevent fires or explosions. Use jumper cables according to instructions to prevent sparks which could cause explosion.
5. Stop the engine before performing any service on the tractor.
6. Escaping hydraulic/diesel fluid under pressure can penetrate the skin causing serious injury. If fluid is injected into the skin, obtain medical attention immediately or gangrene may result.
 - DO NOT use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks.
 - Stop the engine and relieve pressure before connecting or disconnecting lines.
 - Tighten all connections before starting the engine or pressurizing lines.
7. Do not modify or permit anyone else to modify or alter this tractor or any of its components or functions without first consulting a New Holland Dealer.
8. The fuel oil in the injection system is under high pressure and can penetrate the skin. Unqualified persons should not remove or attempt to adjust a pump, injector, nozzle, or any other part of the fuel injection system. Failure to follow these instructions can result in serious injury.
9. Continuous long-term contact with used engine oil may cause skin cancer. Avoid prolonged contact with used engine oil. Wash skin promptly with soap and water.
10. Some components of your tractor, such as gaskets and friction surfaces (brake linings, clutch linings, etc.) may contain asbestos. Breathing asbestos dust is dangerous to your health. You are advised to have any maintenance or repair on such components carried out by an authorized New Holland Dealer. However, if service operations are to be undertaken on parts that contain asbestos, the essential precautions listed below must be observed:

- Work out of doors or in a well ventilated area.
- Dust found on the tractor or produced during work on the tractor should be removed by extraction, not by blowing.
- Dust waste should be dampened, placed in a sealed container, and marked to ensure safe disposal.
- If any cutting, drilling, etc. is attempted on materials containing asbestos, the item should be dampened and only hand tools or low speed power tools used.

OPERATING THE TRACTOR

1. Before starting the tractor, apply the parking brake, place the PTO lever in the "OFF" position, the lift control lever in the down position, the remote control valve levers in the neutral position, and the transmission in neutral.
2. Always sit in the tractor seat when starting the engine or operating controls. Do not start the engine or operate controls while standing beside the tractor.
3. Do not bypass the neutral start switches. Consult your New Holland Dealer if your neutral start controls malfunction. Use jumper cables only in the recommended manner. Improper use can result in tractor runaway.
4. Avoid accidental contact with the gear shift lever while the engine is running, as this can cause unexpected tractor movement.
5. Before getting off the tractor, disengage the PTO, turn the engine off, and apply the parking brake. Never get off the tractor while it is in motion.
6. Do not park the tractor on a steep incline.
7. Do not operate the tractor engine in an enclosed building without adequate ventilation. Exhaust fumes can cause death or illness.
8. If the power steering or engine ceases operating, stop the tractor immediately.
9. Pull only from the drawbar or the lower link drawbar in the down position. Use only a drawbar pin that locks in place. Pulling from the tractor rear axle or any point above the axle may cause the tractor to upset.
10. If the front end of the tractor tends to rise when heavy implements are attached to the three-point hitch, install front end or front wheel weights. Do not operate the tractor with a light front end.

11. Always set the hydraulic selector lever in position control when attaching or transporting equipment. Ensure hydraulic couplers are properly mounted and will disconnect safely in case of accidental detachment of implement.
12. Do not leave equipment in the raised position.
13. Use the flasher/turn signal lights and SMV signs when traveling on public roads both day and night (unless prohibited by law).
14. When operating at night, adjust lights to prevent blinding oncoming drivers.

DRIVING THE TRACTOR

1. Watch where you are going, especially at row ends, on roads, around trees and low hanging obstacles.
2. To avoid upsets, drive the tractor with care and at a safe speed. Use extra caution when operating over rough ground, when crossing ditches or slopes, and when turning corners.
3. To provide two-wheel braking, lock tractor brake pedals together when transporting on roads.
4. Do not coast or free wheel down hills. Use the same gear when going downhill as is used when going uphill.
5. Any towed vehicle with a total weight exceeding that of the towing tractor should be equipped with brakes for safe operation.
6. If the tractor becomes stuck or the tires become frozen to the ground, back up the tractor to prevent upset.
7. Always check overhead clearance, especially when transporting the tractor.
8. When operating at night, adjust lights to prevent blinding oncoming drivers.

OPERATING THE PTO

1. When operating PTO driven equipment, shut off the engine and wait until the PTO stops before getting off the tractor and disconnecting the equipment.
2. Do not wear loose clothing when operating the power take-off or when near rotating equipment.
3. When operating stationary PTO driven equipment, always place all gear shift levers in neutral position.

Apply the tractor parking brake, and block the rear wheels front and back.

4. To avoid injury, do not clean, adjust, unclog, or service PTO driven equipment when the tractor engine is running.
5. Ensure the PTO master shield is installed at all times. Always replace the PTO shield cap when the PTO is not in use.

DIESEL FUEL

1. UNDER NO CIRCUMSTANCES should gasoline, alcohol, or blended fuels be added to diesel fuel. These combinations can create an increased fire or explosive hazard. Such blends are more explosive than pure gasoline in a closed container such as a fuel tank. **DO NOT USE THESE BLENDS.**
2. Never remove the fuel cap or refuel with the engine running or hot.
3. Do not smoke while refueling or when standing near fuel.
4. Maintain control of the fuel filler pipe nozzle when filling the tank.
5. Do not fill the fuel tank to capacity. Allow room for expansion.
6. Wipe up spilled fuel immediately.
7. Always tighten the fuel tank cap securely.
8. If the original fuel tank cap is lost, replace it with a New Holland approved cap. A non-approved, proprietary cap may not be safe.

9. Keep equipment clean and properly maintained.
10. Do not drive equipment near open fires.
11. Never use fuel for cleaning purposes.
12. Arrange fuel purchases so that winter grade fuels are not held over and used in the spring.

SAFETY FRAME (ROPS)

Your New Holland tractor is equipped with a safety frame. It must be maintained in a serviceable condition. Be careful when driving through doorways or working in confined spaces with low headroom.

UNDER NO CIRCUMSTANCES should you:

- modify, drill, or alter the safety frame in any way. Doing so may render you liable to legal prosecution.
- attempt to straighten or weld any part of the main frame or retaining brackets which have suffered damage. Doing so may weaken the structure and endanger your safety.
- secure any parts on the main frame or attach your safety frame with anything other than the special high tensile bolts and nuts specified.
- attach chains or ropes to the main frame for pulling purposes.
- take unnecessary risks even though your safety frame affords you the maximum protection possible.



WHEN YOU SEE THIS SYMBOL

IT MEANS:

ATTENTION!

BECOME ALERT!

YOUR SAFETY IS INVOLVED!

SECTION 10 - ENGINE

Chapter 1 - Engine

CONTENTS

Section	Description	Page
	Specifications	6
	Metric Bolt Torque Specifications	15
	Special Tools	16
	Compression Test and Tools	17
	Description of Operation	18
	Troubleshooting	19
	Cylinder Head and Valve Train Components	23
	Cylinder Block Assembly	23
	Separating the Tractor at the Clutch Housing/Engine - 12x12 Transmission	25
	Removal	25
	Separating the Tractor at the HST Housing/Engine - HST Transmission	29
	Removal	29
	Separating the Tractor at the HST Engine Frame	33
	Installation	35
	Attaching the 12x12 Transmission to the Engine	42
	Attaching the HST to the Engine	46
	Overhaul	54
	Engine	54
	Fuel Injector and Glow Plug	54
	Removal	54
	Oil Pressure Switch	54
	Temperature Sending Switch and Alternator	54
	Removal	54
	Fan, Water Pump and External Oil Tube	55
	Removal	55
	Air Inlet Manifold	55
	Removal	55
	Rocker Arm Shaft and Support Bracket	56
	Removal	56
10 101	Cylinder Head	56
	Removal	56

SECTION 10 - ENGINE - CHAPTER 1

Section	Description	Page
	Valve Tappet	57
	Removal	57
	Fuel Shutoff Solenoid	57
	Removal	57
10 106	Engine Timing Gear Cover, Timing Gears, and Cam Shaft	57
	Timing Gear Cover Removal	57
10 106	Timing Gears and Cam Shaft	60
	Removal	60
10 102	Oil Sump	61
	Removal	61
	Oil Suction Pipe and Strainer	61
	Removal	61
10 110	Balancer Assembly	62
	Removal	62
10 105	Connecting Rods, Bearings, and Pistons, Rings	62
	Removal	62
10 103	Flywheel	63
	Removal	63
10 103	Backplate and Oil Seal	63
	Removal	63
	Crankshaft - Main Bearings	63
	Removal	63
10 101	Cylinder Head	64
	Disassembly	64
	Inspection and Repair	64
	Valve Seats	65
	Valves	66
	Valve Guides	67
	Valve Springs	68
	Rocker Arms	68
	Push Rods	69
	Cylinder Head	69
	Assembly	69
	Cylinder Block	70
	Pistons	70
	Disassembly and Inspection	70
	Piston Rings	73
	Connecting Rods	73

SECTION 10 - ENGINE - CHAPTER 1

Section	Description	Page
	Connecting Rod Bearing	75
	Clearance Check	75
	Connecting Rod Bearing	75
	Clearance Check	75
	Pistons, Rings, and Connecting Rod	76
	Assembly	76
10 103	Crankshaft - Main Bearing and Thrust Washer	77
	Removal and Inspection	77
	Crankshaft	78
	Bearing (Bushing)	79
	Replacement	79
	Main Bearing	80
	Assembly	80
	Port Block	81
	Removal	81
	Installation	81
10 106	Timing Gear	82
	Camshaft	82
	Disassembly	82
	Inspection	82
	Assembly	83
10 103	Flywheel	83
10 102	Timing Gear Housing	84
10 102	Front Oil Seal and Steering Pump Seal	84
	Replacement	84
10 103	Crankshaft and Bearing Holder	85
	Installation	85
	Rear Oil Seal and Backplate	85
	Installation	85
	Flywheel	86
	Installation	86
10 105	Pistons and Connecting Rods	86
	Installation	86
10 110	Balancer Assembly	87
	Installation	87
	Balancer Shims	87
	Oil Suction Pipe and Suction Strainer	88
	Installation	88

SECTION 10 - ENGINE - CHAPTER 1

Section	Description	Page
	Oil Sump	84
	Installation	88
10 106	Camshaft and Camshaft Gear	88
	Installation	88
10 106	Idler Gear, Oil Pump, and Injection Timing	89
	Installation	89
	Timing Gear Cover	89
	Installation	89
	Crankshaft Pulley	90
	Installation	90
	Fuel Injection Pump	90
	Installation	90
	Hydraulic Oil Pump	91
	Installation	91
	Power Steering Pump	91
	Installation	91
10 101	Head Gasket Selection	92
	Selection Chart	92
	Cylinder Head	92
	Installation	92
10 106	Valve Clearance	93
	Adjustment	93
	Valve Cover	94
	Installation	94
	Water Pump and Cooling Fan	94
	Installation	94
	External Oil Tube	94
	Assembly	94
	Glow Plug and Connector	95
	Installation	95
	Fuel Injector	95
	Installation	95
10 218	Fuel Piping	95
	Installation	95
	Alternator and Temperature Sender Switch	96
	Installation	96
	Exhaust Manifold	96
	Installation	96

SECTION 10 - ENGINE - CHAPTER 1

Section	Description	Page
10 304	Description of Operation - Engine Lubrication System	97
10 206	Oil Filter	101
	Construction and Function	101
	Maintenance	101
10 304	Oil Pump	101
	Removal	102
	Inspection	102
	Installation and Adjustment	102
	Engine Oil Pressure	103
	Check	103
	Oil Pressure Relief Valve	104
	Removal	104
	Installation	104
	Oil Consumption	104
10 400	Description of Operation - Cooling System	105
	Maintenance	107
	Coolant	107
	Radiator Cap	107
10 402	Thermostat	108
10 402	Water Pump	108
10 414	Cooling Fan	108
	Overhaul - Cooling System	109
10 406	Radiator	109
	Removal	109
	Inspection and Repair	110
	Installation	110
10 402	Water Pump	111
	Removal	111
	Inspection and Repair	113
	Installation	113
10 402	Thermostat	114
	Removal	114
	Inspection and Repair	114
	Installation	115
	Cab Heater	115
	Installation	115


SPECIFICATIONS

GENERAL	TC35A, TC35DA	TC40A, TC40DA	TC45A, TC45DA
Engine Model	N843L	N844	N844L
Number of Cylinders	3	4	4
Bore x Stroke	3.31 x 3.94 in. (84 x 100 mm)	3.31 x 3.54 in. (84 x 90 mm)	3.31 x 3.94 in. (84 x 100 mm)
Displacement	101.4 cu. in. (1622 cc)	121.7 cu. in. (1995 cc)	135.2 cu. in. (2216 cc)
Compression Ratio	22.5:1	22.5:1	22.5:1
Rated Speed (rpm)	2600	2600	2600
Muffler	Horizontal		
Firing Order	1-2-3	1-3-4-2	1-3-4-2
Low Idle Speed	1050 rpm	1050 rpm	1050 rpm
Maximum No-Load Speed	2840 rpm	2840 rpm	2840 rpm
Cylinder Arrangement	In-Line Vertical	In-Line Vertical	In-Line Vertical
Valve Arrangement	Overhead	Overhead	Overhead
Compression Pressure at 200 rpm (cylinder speed)	427 ± 50 psi (29.4 ± 1.8 bar)	427 ± 50 psi (29.4 ± 1.8 bar)	427 ± 50 psi (29.4 ± 1.8 bar)
Variation between cylinders			
CYLINDER BLOCK	N843L	N844	N844L
Bore			
Standard	3.3071-3.3078 in. (84.0 mm)	3.3071-3.3078 in. (84.0 mm)	3.3071-3.3078 in. (84.0 mm)
Maximum	3.3543 in. (85.2 mm)	3.3543 in. (85.2 mm)	3.3543 in. (85.2 mm)
Head Surface Warp			
Standard	.002 in. (.05 mm)	.002 in. (.05 mm)	.002 in. (.05 mm)
Maximum	.005 in. (.12 mm)	.005 in. (.12 mm)	.005 in. (.12 mm)


* If bore size exceeds 3.3543 in. (85.2 mm) replace with long block.

SECTION 10 - ENGINE - CHAPTER 1

CYLINDER HEAD	N843L	N844	N844L
Head Warp			
Standard	0.002 in. less than (0.05 mm)	0.002 in. (0.05 mm)	0.002 in. (0.05 mm)
Maximum	0.005 in. (0.12 mm)	0.005 in. (0.12 mm)	0.005 in. (0.12 mm)
Valve Seat Width			
Standard	0.067-0.082 in. (1.7-2.1 mm)	0.067-0.082 in. (1.7-2.1 mm)	0.067-0.082 in. (1.7-2.1 mm)
Maximum	0.098 in. (2.5 mm)	0.098 in. (2.5 mm)	0.098 in. (2.5 mm)
Valve Seat Sink			
Standard (Recess)	0.0334-0.0453 in. (0.85-1.15 mm)	0.0334-0.0453 in. (0.85-1.15 mm)	0.0334-0.0453 in. (0.85-1.15 mm)
Maximum	0.071 in. (1.8 mm)	0.071 in. (1.8 mm)	0.071 in. (1.8 mm)
Valve Angle	45°	45°	45°
PISTON	N843L	N844	N844L
Diameter			
Standard	3.30503-3.30562 in. (83.948-83.963 mm)	3.30503-3.30562 in. (83.948-83.963 mm)	3.30503-3.30562 in. (83.948-83.963 mm)
Minimum	3.2953 in. (83.7 mm)	3.2953 in. (83.7 mm)	3.2953 in. (83.7 mm)
Bore Clearance			
Standard	0.0014-0.0028 in. (0.038-0.072 mm)	0.0014-0.0028 in. (0.038-0.072 mm)	0.0014-0.0028 in. (0.038-0.072 mm)
Maximum	0.010 in. (0.25 mm)	0.010 in. (0.25 mm)	0.010 in. (0.25 mm)
Piston Pin Bore			
Standard	1.102-1.1023 in. (27.996-28.000 mm)	1.102-1.1023 in. (27.996-28.000 mm)	1.102-1.1023 in. (27.996-28.000 mm)
Maximum	1.102 in. (27.98 mm)	1.102 in. (27.98 mm)	1.102 in. (27.98 mm)
Piston Pin Clearance			
Standard	-0.000393 +0 .0002 in. (-0.001 + 0.007 mm)	-0.000393 +0 .0002 in. (-0.001 + 0.007 mm)	-0.000393 +0 .0002 in. (-0.001 + 0.007 mm)
Maximum	0.0008 in. (0.02 mm)	0.0008 in. (0.02 mm)	0.0008 in. (0.02 mm)



4



5



Suggest:

If the above button click is invalid.


Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading


SEPARATING THE TRACTOR AT THE CLUTCH HOUSING/ENGINE - 12X12 TRANSMISSION

Removal

1. Remove the negative (-) battery cable, 1, and the positive (+) battery cable, 2, from the battery.
2. Drain all of the hydraulic fluid from the transmission and the differential into a suitable container.
3. Disconnect the headlight wire harness plug and remove the hood from the tractor.
4. Remove the seat, and the seat base assembly from the tractor.
5. Remove the light bars from the fenders and the ROPS.
6. If equipped, remove the remote loader control valve, 1, and the connecting hydraulic tubes from the right fender.
7. Remove the left and right fenders from the tractor.




6



7

8. Remove the left, 1, and right, 2, rear hood side panels.
9. Disconnect and remove the throttle cable from the foot throttle control pedal, located on the right deck.
10. Remove the left and the right deck from the tractor.
11. Disconnect the throttle cable from the dash mounted throttle control lever.



8

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>