

---

# TN60VA, TN75VA, TN95VA REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL .....	2
SECTION 10 - ENGINE .....	2
SECTION 18 - CLUTCH .....	7
SECTION 21 - TRANSMISSIONS .....	11
SECTION 23 - FWD TRANSFER BOX AND AUTO FWD .....	13
SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION .....	15
SECTION 27 - REAR AXLE MECHANICAL TRANSMISSION .....	19
SECTION 31 - MECHANICAL POWER TAKE-OFF .....	20
SECTION 33 - BRAKES .....	21
SECTION 35 - HYDRAULIC SYSTEMS .....	22
SECTION 41 - STEERING .....	25
SECTION 44 - AXLES AND WHEELS .....	27
SECTION 50 - CAB CLIMATE CONTROL .....	28
SECTION 55 - ELECTRICAL SYSTEM .....	30
SECTION 90 - PLATFORM, CAB, BODYWORK .....	38

The following pages are the collation of the contents pages from each section and chapter of the TNVA Series Repair manual. Complete Repair part # 87352279.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TNVA Series Tractors.

**SECTION 00 - GENERAL**

**Chapter 1 - General**

**CONTENTS**

<b>Section</b>	<b>Description</b>	<b>Page</b>
	General Instructions .....	3
	Health and Safety .....	5
	Precautionary Statements .....	15
	Safety .....	16
	Ecology and the Environment .....	19
	Minimum Hardware Tightening Torques .....	20
	Federal Emissions Warranty .....	22
	Consumables .....	25

# SAFETY

## PRECAUTIONARY STATEMENTS

A careful operator is the best operator. Most accidents can be avoided by observing certain precautions. To help prevent accidents, read the following precautions before operating this equipment. Equipment should be operated only by those who are responsible and instructed to do so.

Carefully review the procedures given in this manual with all operators. It is important that all operators be familiar with and follow safety precautions.

### THE TRACTOR

1. Read the Operator's Manual carefully before using the tractor. Lack of operating knowledge can lead to accidents.
2. Only allow properly trained and qualified persons to operate the tractor.
3. To prevent falls, use the handrails and step plates when getting on and off the tractor. Keep steps and platform clear of mud and debris.
4. Do not permit anyone but the operator to ride on the tractor unless a passenger seat is fitted. There is no safe place for extra riders otherwise.
5. Replace all missing, illegible or damaged safety decals.
6. Keep safety decals free of dirt or grime.
7. Do not modify or alter or permit anyone else to modify or alter the tractor or any of its components or any tractor function without first consulting your dealer.
8. Tractor wheels are very heavy. Handle with care and ensure, when stored, that they cannot fall.
5. Use extreme caution and avoid hard application of the tractor brakes when towing heavy loads at road speeds.
6. Any towed vehicle whose total weight exceeds that of the towing tractor must be equipped with brakes for safe operation.
7. Never apply the differential lock when turning. When engaged, the differential lock will prevent the tractor from turning.
8. Always check overhead clearance, specifically when transporting the tractor. Watch where you are going, especially at low overhanging obstacles.
9. Use extreme caution when operating on steep slopes.
10. To avoid overturns, drive the tractor with care and at speeds compatible with safety, especially when operating over rough ground, when crossing ditches or slopes and when turning overturning.
11. If the tractor becomes stuck or the tires are frozen to the ground, reverse the tractor out to prevent corners.

### DRIVING THE TRACTOR

1. Always sit in the drivers seat while starting or driving the tractor.
2. When driving on public roads, have consideration for other road users. Pull in to the side of the road occasionally to allow any following traffic to pass. Do not exceed the legal speed limit set in your area.
3. Use low beam lights when meeting a vehicle at night. Make sure the lights are adjusted to prevent blinding the drive of an oncoming vehicle
4. Reduce speed before turning or applying the brakes. Ensure that both brake pedals are locked together when traveling at road speeds or when on public roads. Brake both wheels simultaneously when making an emergency stop.

12. Keep the tractor in the same gear when going downhill as would be used when going uphill. Do not coast or freewheel down hills.

### OPERATING THE TRACTOR

1. Apply the parking brake, place the PTO control in the 'OFF' position, the lift control lever in the down position, the remote control valve levers in the neutral position and the transmission lever in neutral before starting the tractor.
2. Do not start the engine or operate controls while standing beside the tractor. Always sit in the tractor seat when starting the engine or operating the controls.

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

3. Do not bypass the neutral start switches. Consult your authorized dealer if your neutral start controls malfunction. Use jump cables only in the recommended manner. Improper use can result in a tractor runaway.
4. Avoid accidental contact with the gear shift levers while the engine is running. Unexpected tractor movement can result from such contact.
5. Do not get off the tractor while it is in motion.
6. Shut off the engine and PTO and apply the parking brake before getting off the tractor.
7. Do not park the tractor on a steep incline.
8. Do not run the tractor engine in an enclosed building without adequate ventilation. Exhaust fumes are toxic and can cause death.
9. Always wear a protective mask when working with toxic spray chemicals. Follow the directions on the chemical container.
10. If the power steering or engine ceases operating, stop the tractor immediately as the tractor will be more difficult to control.
11. Stop the engine and relieve pressure before connecting or disconnecting hydraulic, steering or fuel lines.
12. Tighten all connections before starting the engine or pressurizing lines.
13. Pull only from the swinging drawbar or the lower link drawbar in the lowered position. Use only a drawbar pin that locks in place. Pulling from the tractor rear axle or any point above the axle may cause the tractor to overturn.
14. If the front end of the tractor tends to rise when heavy implements are attached to the three-point hitch, install front end or front wheel weights. Do not operate the tractor with a light front end.
15. Always select Position Control when attaching implements and when transporting equipment. Be sure hydraulic couplers are properly installed and will disconnect safely in case of accidental detachment of the implement.
16. Do not leave equipment in the raised position when the vehicle is stopped or unattended.
17. Ensure any attached equipment or accessories are correctly installed, are approved for use with the tractor, do not overload the tractor and are operated and maintained in accordance with the instructions issued by the equipment or accessory manufacturer.
18. Remember that your tractor, if abused or incorrectly used, can be dangerous and become

a hazard both to the operator and to bystanders. Do not overload or operate with attached equipment which is unsafe, not designed for the particular task or is poorly maintained.

19. The tractor is designed to provide the minimum noise level at the operator's ears and meets or exceeds applicable standards in this respect. However, noise (sound pressure level) in the workplace can exceed 86 dB(A) when working between buildings or in confined spaces. Therefore, it is recommended that operators wear suitable ear protectors during vehicle operation.

### **OPERATING THE PTO**

1. When operating PTO driven equipment, shut off the engine and wait until the PTO stops before getting off the tractor and disconnecting the equipment.
2. Do not wear loose clothing when operating the power take-off or especially when near rotating equipment.
3. When operating stationary PTO driven equipment, always apply the tractor parking brake and block the rear wheels front and back.
4. To avoid injury, do not clean, adjust, unclog or service PTO driven equipment when the tractor engine is running.
5. Make sure the PTO guard is in position at all times and always replace the PTO cap when the PTO is not in use.

### **SERVICING THE TRACTOR**

1. The cooling system operates under pressure which is controlled by the radiator cap. It is dangerous to remove the cap while the system is hot. Always turn the cap slowly to the first stop and allow the pressure to escape before removing the cap entirely.
2. Do not smoke while refueling the tractor. Keep any type of open flame away. Wait for the engine to cool before refueling.
3. Keep the tractor and equipment, particularly brakes and steering, maintained in a reliable and satisfactory condition to ensure your safety and comply with legal requirements.
4. To prevent fire or explosion, keep open flames away from battery or cold weather starting aids. To prevent sparks which could cause explosion, use jumper cables according to instructions.
5. Stop the engine before performing any service on the tractor.

## SECTION 00 - GENERAL - CHAPTER 1

---

6. Escaping diesel/hydraulic fluid under pressure can penetrate the skin causing serious injury.
    - **Do not** use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks.
    - Stop the engine and relieve pressure before connecting or disconnecting lines.
    - Tighten all connections before starting the engine.
    - If fluid is injected into the skin obtain medical attention immediately.
  7. Do not modify or alter or permit anyone else to modify or alter the tractor or any of its components or any tractor function without first consulting an authorized dealer.
  8. The fuel oil in the injection system is under high pressure and can penetrate the skin. Unqualified persons should not remove or attempt to adjust a pump, injector, nozzle or any other part of the injection system. Failure to follow these instructions can result in serious injury.
  9. Continuous long term contact with used engine oil may cause skin cancer. Avoid prolonged contact with used engine oil. Wash skin promptly with soap and water.
5. Do not fill the fuel tank to capacity. Allow room for expansion.
  6. Wipe up spilled fuel immediately.
  7. Always tighten the fuel tank cap securely.
  8. If the original fuel tank cap is lost, replace it with an approved cap. A non-approved cap may not be safe.
  9. Keep equipment clean and properly maintained.
  10. Do not drive equipment near open fires.
  11. Never use fuel for cleaning purposes.
  12. Arrange fuel purchases so that summer grade fuels are not used in the winter.

### ROPS

The tractor may be equipped with a safety frame (ROPS) which must be maintained in a serviceable condition. Be careful when driving through doorways or working in confined spaces with low headroom.

### DIESEL FUEL

1. Under no circumstances should gasoline, alcohol or blended fuels be added to diesel fuel. These combinations can create an increased fire or explosive hazard. In a closed container such as a fuel tank these blends are more explosive than pure gasoline. Do not use these blends.
  2. Never remove the fuel cap or refuel with the engine running or hot.
  3. Do not smoke while refueling the tractor or when standing near fuel. Keep any type of open flame away. Wait for the engine to cool before refueling.
  4. Maintain control of the fuel filter pipe nozzle when filling the tank.
1. Do not modify, drill, weld or alter the ROPS in any way.
  2. Never attempt to straighten or weld the ROPS or retaining brackets, which have suffered damage. By doing so you may weaken the structure and endanger your safety.
  3. Do not secure any parts on the ROPS or attach it with other than the special high tensile bolts and nuts specified.
  4. Never attach chains or ropes to the safety frame or roll bar for pulling purposes.
  5. Never take unnecessary risks even though your safety frame or roll bar affords you the maximum protection possible.
  6. Whenever possible, operate with the ROPS in its fully upright and locked position.

## SECTION 10 - ENGINE

### Chapter 1 - Engine

#### CONTENTS

Section	Description	Page
	Specifications .....	3
	Engine Type .....	3
	Timing System .....	4
	Valve Timing Gears .....	4
	Crankcase and Cylinder Block .....	5
	Crankshaft and Bearings .....	6
	Connecting Rod .....	7
	Piston .....	8
	Tappet .....	8
	Rocker Arm and Valve .....	9
	Rotating Counterweight Dynamic Balancer .....	9
	Cylinder Head .....	10
	Tightening Torques .....	11
	Special Tools .....	12
	Description and Operation .....	14
	Sectional Views .....	14
	Troubleshooting .....	18
	Overhaul .....	22
	Engine .....	22
10 001 10	Removal .....	22
	Installation .....	28
10 001 30	Compression Test .....	29
10 001 54	Disassembly .....	30
	Assembly .....	46
	Crank, Main Bearings and Thrust Rings .....	46
	Rear Cover with Seal and Engine Flywheel .....	48
	Synchronizing the Timing Gears .....	49
	Bosch Injection Pump .....	50
	Cylinder Head .....	50
	Valve and Rocker Arm .....	51
	Fuel Injectors .....	52
	Cooling System Belt .....	53

Section	Description	Page
	Cylinder Block .....	54
	Inspection .....	54
	Crankshaft and Main Bearings .....	56
	Crankshaft Inspection .....	56
	Main Bearing Inspection .....	58
	Main Bearing Cap Bolt Inspection .....	58
10 102 70	Crankshaft Front Oil Seal .....	59
	Removal .....	59
	Installation .....	60
	Engine Flywheel .....	61
	Refacing .....	61
	Flywheel Bolts .....	61
	Inspection .....	61
	Connecting Rods .....	62
	Inspection .....	62
	Pistons with Rings, Pins, Connecting Rods, Big End Caps and Bearings .....	63
	Inspection .....	63
	Assembly .....	64
	Installation .....	65
	Valves, Tappets and Camshaft .....	67
	Valves, Grinding .....	67
	Dimensions (mm) of Valves and Valve Guides .....	67
	Valve Timing Check .....	68
	Tappets Inspection .....	68
	Camshaft Inspection .....	69
	Cylinder Head .....	70
	Inspection .....	70
	Valve Seats, Grinding .....	71
10 101 53	Valve Guides, Replacement .....	72
	Rotating Counterweight Dynamic Balancer .....	75
	Assembly .....	76
	Installation .....	76
10 254 44	Exhaust Pipe .....	77
	Removal .....	77
	Installation .....	77

## OVERHAUL

## ENGINE

## Op. 10 001 10

## Removal

————— **!** **DANGER** **!** —————

Lift and handle all heavy parts using suitable lifting equipment.

Make sure that assemblies or parts are supported by means of suitable slings and hooks. Check that no one is in the vicinity of the load to be lifted.

————— **!** **WARNING** **!** —————


Always use appropriate tools to align fixing holes. NEVER USE FINGERS OR HANDS.

Proceed as follows.


1. Carry out operation **90 150 10** Cab with platform unit removal (see Sect. 90) (models with cab).

*Ensure that the bracket **380001613** locking the front axle in relation to the engine is positioned and secured between the above.*

2. Carry out operation **90 110 36** Platform assembly removal (see Sect. 90) (models with platform).
3. Carry out operation **90 114 20** Front roll bar, removal (see Sect. 90) (models with platform).
4. Unscrew the plug and drain the oil from the rear transmission casing (the prescribed quantity is 11.09 US gal. (42 liters)).
5. Disconnect the electrical connections (2) and remove the front guard (1) by sliding forwards.




6




7

6. If the tractor is not fitted with an extra fuel tank, disconnect the piping (1) and drain the fuel from the main tank.
7. If the tractor is fitted with a platform the coolant must be drained.




8

8. Disconnect the fuel return piping (1).




9

9. Remove the clamp (1) and detach the radiator sleeve (2), unscrew the radiator retaining bracket (3).




10

10. Disconnect the connecting pipe (1) between the main fuel tank and the extra fuel tank.




11

11. Unscrew the brake control piping (1) on the front axle (if fitted).




12

12. Disconnect the hydrostatic steering piping (1).




13

13. Disconnect the steering sensor wire, loosen the hose and wire retaining clamps (1) on the radiator.




14

14. Loosen the clamp and disconnect the fuel injection pump hose (1).




15

15. Unscrew the clamp (3) to release the sleeve (2) from the turbocharger (if fitted).
16. Disconnect the electrical connections (1) on the clogged air filter sensor.




16

17. Unscrew the clamp and remove the sleeve (1) on the relative rigid pipe (2).




17

18. Loosen the hydraulic pump line piping bolts (1).




18

19. Loosen the clamps (1, 3 and 4), unscrew the bracket retaining bolts (2) and remove the hydraulic pump line piping (5).




19

20. Unscrew the filter piping (1 and 2).
21. Unscrew the services distributor piping (3, 4 and 5).




20

22. Disconnect and remove piping (1, 2, 3, 4, 5 and 6).
23. Carry out operation **10 254 44** Exhaust pipe removal (see Sect. 10).




21

24. Disconnect the piping (2), unscrew the clamp (1), the piping/clutch housing retaining bolt, and remove piping (1 and 3).



22


25. Remove the guard (2) and disconnect the starter motor wires (1), disconnect the pipe (4).
26. Remove the retaining clamp and disconnect the engine electrical wires, place the wires (2 and 3) on the clutch casing.



23

27. Disconnect the brake piping (1) from the block.


28. Carry out operation **23 101 26** Drive shafts and guard, removal (see Sect. 23).



24


29. Position an hydraulic jack under the rear axle, attach the motor to a hoist, using a chain, and place a stand under the clutch casing.

30. Unscrew the front axle - engine retaining bolts (1).



25


31. Remove the front axle, complete with support, tanks, radiator and air filter.



26

32. Unscrew the bolt (2) accessing the Allen screw (1) (on both sides).

33. Unscrew all of the clutch casing - engine bolts and detach the engine.



27

## Installation




### WARNING

Always use appropriate tools to align fixing holes. NEVER USE FINGERS OR HANDS.

Apply the prescribed tightening torques. See table of contents.

1. Before refitting the engine to the clutch box carefully clean the mating surfaces and apply sealing compound (0.0787 in. (2 mm) diameter), according to the diagram shown Section 21.
2. Install the engine on the clutch casing.
3. Install the front axle support assembly on the engine.
4. Carry out operation **23 101 26** Drive shafts and guard, installation (see Sect. 23).
5. Connect the brake piping.
6. Connect the wires to the starter motor and position the other wires on the engine.
7. Assemble all hydraulic pipes and hoses.
8. Carry out operation **10 254 44** Exhaust pipe installation (see Sect. 10).
9. Assemble the hydraulic pump feed piping, complete with the relative support bracket.
10. Connect the lower radiator sleeve to the rigid pipe.
11. Place the inlet sleeve on the turbocharger and secure in position (if fitted).
12. Connect the electrical connections to the clogged air filter sensor.
13. Connect the injection pump fuel supply piping.
14. Connect the steering sensor wire.
15. Install the hydrostatic steering piping to the radiator.
16. Connect the hydrostatic steering piping.
17. Connect the brake piping on the front axle.
18. Connect and secure the main fuel tank/extra fuel tank piping.
19. Connect the upper radiator sleeve.
20. Attach the radiator bracket.
21. Connect the fuel return piping to the fuel tank.
22. Position the front guard and connect the headlamps and direction indicator electrical connections.
23. Screw the plug on the rear transmission casing and fill up with oil (see Sect. 00 for prescribed products and quantities).
24. Carry out operation **90 114 20** Removable front roll bar re-assembly (see sect. 90) (models with platform).



28

25. Carry out operation **90 110 36** Platform assembly installation (see Sect. 90) (models with platform).
26. Carry out operation **90 150 10** Cab with platform unit installation (see Sect. 90) (models with cab).
27. Fill up the engine cooling system (see Sect. 00 for prescribed products and quantities).
28. Fill up the fuel tank (see Sect. 00 for prescribed products and quantities).
29. Bleed the brakes (see Sect. 33).

**Op. 10 001 30****Compression Test**

In case of poor engine performance, in addition to checking the fuel injection system (injection nozzles and injection pump), also test the compression on each cylinder.



**Do not use matches, lighters, blowtorches or any form of naked flame as a source of light when inspecting the engine due to the presence of flammable fluids and vapor.**

**Compression ratio**

The compression ratio is a measure of the quantity of air drawn into the cylinder, and provides an indication of the efficiency of the sealing elements in the cylinder (piston rings and valves).

Uniform compression in all the cylinders ensures that they all perform an equal amount of work, provided that each cylinder is injected with the same quantity of fuel at the right time.

Low compression not only reduces engine performance, it also causes incomplete fuel combustion due to the lack of available combustion air.

The engine therefore gives poor performance with excessive fuel consumption and, consequently, exhaust smoke and restriction of the exhaust passages.

As the compression ratio **also varies with the temperature of the engine** (cold engines produce lower compression values than hot engines), the compression should only be tested when the engine is at normal operating temperature.

Compression should be tested using the compression test kit **380000303**, as follows:

- 1) run the engine until it reaches normal operating temperature;
- 2) switch off the engine;
- 3) disconnect the lead from the engine stop electromagnet on the injection pump in order to close the valve and block the flow of fuel to the injectors;
- 4) remove the injector from the cylinder to be tested;
- 5) turn the engine over a few times with the starter motor in order to expel any carbon residue;

6) install the dummy injector **380000617** in place of the injector removed previously, inserting the copper sealing washer;

7) connect the compression test instrument **380000303** and take readings while turning the engine over with the starter motor.

On engines in perfect working order, with the sump oil at approx. 104 °F (40 °C) at sea level (29.9212 in. (760 mm) mercury) and at an engine speed of 200 to 280 rpm, the compression should be 369.75 to 398.75 psi (25.5 to 27.5 bar).

8) Test the compression on the other cylinders, repeating steps 4-5-6-7, bearing in mind that:

The minimum permissible compression on a used engine is 313.2 psi (21.6 bar).

The maximum permissible compression difference between cylinders is 43.5 psi (3 bar).

Every 328 ft. (100 meters) above sea level corresponds to a reduction in compression by approx. 1%.

**CONSIDERATIONS:****Uniform compression**

Although high compression is important, it is more important for smooth engine running that compression is uniform in all cylinders.

Low compression readings.

If extremely low pressure readings are obtained on one cylinder it is advisable to repeat the test.

Before testing this time, pour about a spoonful of engine oil into the cylinder through the injector bore.

Turn over the engine a few times to distribute the oil evenly over the cylinder walls, and then repeat the test.

If the second test readings are significantly higher, suspect worn piston rings, out-of-round or damaged pistons or cylinders.

If the second test readings are not higher, the problem will be the valves.

On the other hand, if the second test reading shows only a slight improvement, the problem will be due to both the valves and the rings.


Op. 10 001 54  
Disassembly

**WARNING**


Handle all parts carefully. Do not put your hands or fingers between parts. Wear the prescribed safety clothing, including goggles, gloves and safety footwear.

Proceed as follows.


1. Carry out operation **10 001 10** Engine, removal.
2. Remove the alternator and air conditioning compressor belts (1).
3. Unscrew the retaining bolts and remove the exhaust muffler (1).
4. Unscrew the retaining bolt (2) and move the alternator (1) outwards.
5. Loosen the clamp and remove the turbocharger sleeve (1) (if fitted).




29



30



31



32



**Suggest:**

**If the above button click is invalid.**


**Please download this document**

**first, and then click the above link**

**to download the complete manual.**


**Thank you so much for reading**

6. Disconnect the turbocharger lubrication piping (1) (if fitted).
7. Unscrew the retaining bolts and remove the exhaust manifold (2) complete with the turbocharger (1) (if fitted).




33

8. Unscrew the retaining bolt and remove the alternator.
9. Disconnect and remove the turbocharger (2) lubrication piping (if fitted).




34

10. Unscrew the retaining bolts and remove the lift pump (1).
11. Unscrew: the hydraulic oil filter (2), the relative retaining bolts and remove the filter support (3).



35

12. Unscrew the retaining bolts and remove the services pump (1).



36

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**