

Vibratory Rollers DV201 - DV202 - DV204

Service Manual

Cre 9-54980

CASE

DV201 - DV202 - DV204

Vibratory Rollers

CONTENT

1	GENERAL INSTRUCTIONS	3
	INTRODUCTION	3
	SAFETY INSTRUCTIONS	4
	ENVIRONMENTAL MEASURES AND HEALTH PRECAUTIONS	7
	PRODUCT IDENTIFICATION	9
	TORQUES SPECIFICATIONS	12
	SERVICING INSTRUCTIONS	15
	HOURMETER	15
	SERVICING INTERVAL	16
	FLUIDS AND LUBRICANTS	18
	FLUIDS AND LUBRICANT CAPACITIES AND SPECIFICATIONS	21
2	DESCRIPTION OF THE MACHINE	23
3	THE ENGINE	37
	REMOVAL OF THE ENGINE FROM THE MACHINE WITH THE TRAVEL PUMP	39
4	DRUM	69
	REMOVAL OF THE HYDRAULIC MOTOR OF VIBRATION	69
	REMOVAL OF THE HYDRAULIC MOTOR OF TRAVEL	81
	REPLACEMENT OF RUBBERIZED METAL PIECES ON THE DRUM	107
	REPLACEMENT OF THE SEAL ON THE DAMPING PLATE ON THE MACHINE	139
	REMOVAL OF DRUMS FROM THE FRAME OF THE MACHINE	153
	REMOVAL OF THE ECCENTRIC FROM THE DRUM	195
	INSTALLATION OF THE DRUM ON THE FRAME OF THE MACHINE	207
5	STEERING JOINT	217
	REMOVAL OF THE STEERING JOINT FROM THE MACHINE	217
	REMOVAL OF THE STEERING JOINT	231
	INSTALLATION OF THE STEERING JOINT	241
6	HYDRAULICS	253
	REMOVAL OF THE TRAVEL PUMP AND THE CLUTCH	253
	REMOVAL OF THE PUMPS OF VIBRATION AND OF STEERING	271
	REMOVAL OF THE OIL COOLER	281
	REMOVAL OF STEERING HYDRAULIC MOTOR FROM THE MACHINE	295
	REMOVAL OF THE STEERING HYDRAULIC MOTOR	303
	INSTALLATION OF THE STEERING HYDRAULIC MOTOR	309
	REMOVAL OF THE SERVOSTEERING	313
	REMOVAL OF THE HYDRAULIC TANK	319
	REPLACEMENT OF THE ELECTROMAGNET VALVE OF VIBRATION ON THE MACHINE	331
	REMOVAL OF THE HYDRAULIC LOOP FILTER	335
	REPLACEMENT OF FILTER CARTRIDGE AND OIL	339
	DISASSEMBLY OF SUCTION STRAINER	345
	SCHEMATICS OF THE HYDRAULIC LOOP	349
	HYDRAULIC OF DRIVE	352
	LINEAR VALVES	354
	HYDRAULIC OF VIBRATION	355
	HYDRAULIC OF STEERING	358
	FLUSHING AND DRAIN	360
7	CONTROL OF GAS	361
	REMOVAL OF BOWDEN CABLE OF GAS CONTROL	361
	REMOVAL OF TRAVEL LEVER ON THE CONTROL PANEL	365
	REMOVAL OF TRAVEL PULL ROD	373
8	PLATFORM	383
	REMOVAL OF THE PLATFORM	383
	REMOVAL OF RUBBERIZED METAL PIECES OF THE PLATFORM	389

DV201 - DV202 - DV204

Vibratory Rollers

CONTENT

9 THE SEAT	397
REMOVAL OF THE SWITCH ON THE SEAT	397
10 THE WATER TANK	405
REMOVAL OF THE FRONT TANK FROM THE FRAME OF THE MACHINE	405
REMOVAL OF THE REAR TANK FROM THE FRAME OF THE MACHINE	409
11 SPRINKLING	415
REMOVAL OF THE SPRINKLING PUMP	415
12 ROPS FRAME	419
REMOVAL OF THE PROTECTIVE ROPS FRAME	419
13 ELECTRICAL WIRING	423
FUSE BOX	425
BATTERIES	427
EXCHANGE BULB	429
ALTERNATOR	435
STARTER	439
SCHEME OF THE ELECTRICAL INSTALLATION	443
FUNCTIONAL DESCRIPTION	448
14 APPENDICES	453
TEST POSTS	453
TOWING THE MACHINE	455
TROUBLESHOOTING	463
LIST FIXTURES	483

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

INTRODUCTION

This series of Vibratory Rollers is suitable for compaction of all kinds of ground and for large and average-scale site preparation in highway construction (construction of highways, railways, airports), in hydro-engineering (construction of dams), in building construction (industrial areas, ports), and the like.

These machines are manufactured in compliance with the latest developments and standards, which ensure their safe function.

If the machine is used incorrectly, by untrained operators or for other purposes than those stipulated within, there is a danger of an accident or damage to the equipment or injury to personnel.

The main purpose of this manual is to give the information necessary for carrying out assembly and disassembly of the machine as well as service repairs of main assemblies of the equipment. It contains technical and installation data, instructions on how to adjust the machine and how to use special tools, fixtures and aids.

The manufacturer continuously seeks to make product improvements on the basis of experience and latest developments in the field.

For this reason, the manufacturer may make some changes in drawings, descriptions and designs in this manual.

SAFETY INSTRUCTIONS

GENERAL SAFETY INSTRUCTIONS

The following safety instructions must be observed by ALL personnel repairing the machine.

1. Repairs may be carried out by skilled, trained and experienced personnel only.
2. When performing repairs, always use our service manual. Special instructions for the assembly work are given in individual chapters of this manual.
3. Before putting the machine into operation familiarize yourselves with the machine controls as explained in the "Operator's Manual" and make sure that you are completely familiar with the machine.
4. Do not use the machine if you do not fully understand all controls and until this know how the machine works.
5. Familiarize yourself with the area where you will work.
6. Do not carry out any redesign work or modifications on the machine because you could compromise the safety of the equipment.
7. Original parts and accessories have been designed especially for this machine.
8. Installation and use of spare parts not supplied by the manufacturer of the machine or not authorized by them can have negative effects on operational characteristics and safe operation of the machine.
7. Attach a "Do not operate" warning note to the steering wheel and leave it there for the duration of the service work.
8. Wash the equipment thoroughly. If you use steam, do not expose electrical components and insulation directly to the steam, otherwise cover them beforehand.
9. Keep all parts absolutely clean when dismantling, mounting, and servicing each assembly. Protect removed parts from getting soiled.
10. Clean the surface of dismantled parts and do the necessary to ensure adequately dust-free working conditions and a suitable storage area.
11. Be careful when handling cleaning agents. Do not use fuel or other easy inflammable materials for cleaning.
12. Dry the cleaned parts and immediately cover with anti-corrosive protective oil, never install corroded parts.
13. Tools, hoists, safety equipment on chains, and other additional items must be serviceable and in good condition.
14. Use hoists and fasteners (ropes, chains) that have sufficient lifting capacity and are in good condition.
15. Make sure that there is enough fresh air supply when starting up the equipment in an enclosed area.

REPAIRING AND INSPECTING THE MACHINE

1. Wear working clothes and boots.
2. Use gloves when handling oils, fuel or coolant.
3. Protect your eyes with a full face shield when handling the battery.
4. Place the equipment on a flat and firm surface before starting repair. Secure the machine to prevent spontaneous movement.
5. Secure the frame of the machine and the drum to prevent rotation using a locking pin and a draw bar.
6. Before starting work remove the starter switch key, disconnect the batteries and let hot parts cool down.

16. Before operating the equipment make sure there is nobody on the machine or close by. Starting up of the machine must always be announced with an audible alarm, also after any pause in operation before the equipment is restarted. Those present on the machine and dangerously close by must leave the machine after the alarm has been sounded.
17. Do not adjust moving equipment.
18. When working (adjusting) on a running engine, avoid touching hot and rotating parts. During work on a running engine, another person must be present that can easily access the emergency switch and must be in contact at all times with the person performing the adjustment, to be able to switch off the engine immediately when necessary.
19. Use only approved makes of motor, gear and hydraulic oil and coolant.

WORKING ON HYDRAULIC CIRCUITS

1. Make sure that no hydraulic circuit is under pressure before opening it. Hydraulic oil leaks under pressure may penetrate your skin and cause serious injury.
2. Mark all parts, hoses and pipes before removing them.
3. Do not operate hydraulic pumps and hydraulic motors without oil.
4. There is danger of being scalded when handling hot oil.
5. Do not warm oil to temperatures above 160°C (320°F), oil or its fumes may ignite.
6. For cleaning and wiping hydraulic parts use lint free material.
7. When reassembling parts use hydraulic oil, not grease, as a lubricant.
8. Clean screws and bolts carefully before installation, wash hoses and pipes and blow through them using compressed air.
9. Always use new seals and packing in sealing areas during re-installation.

10. Fill new components with hydraulic oil before installation.
11. Rinse the hydraulic circuit after replacing a hydraulic component; clean the hydraulic reservoir as well.
12. Replace the oil filter cartridge.
13. Fill the hydraulic circuit with clean oil of the recommended viscosity, but only when the engine has been stopped.
14. Wipe off excess oil.
15. Check connections for tightness and any oil leaks, before applying pressure to the system.
16. Do not adjust safety valves.
17. After all work has been finished, recheck all connections and replace all safety items.
18. After finishing the work put all protective devices back in place.
19. After putting the machine into operation.
 - Check the level in the hydraulic reservoir.
 - Check the output pressure of hydraulic pumps if they have been replaced as well as safety valve pressure. Carry out the measurements at a temperature of 40°C (104°F).

WORKING ON THE FUEL SYSTEM

Mixtures of gasoline and diesel (winter fuel) are as inflammable as gasoline.

1. Do not refuel in closed areas.
2. Wipe off excess fuel.
3. Do not smoke when working on the fuel system and do not use open flames. There is a danger of fire.

WORKING ON ELECTRICAL WIRING

1. Disconnect the battery when carrying out any repairs on the charging circuit to avoid accidental short-circuits.
2. When dismantling, first disconnect the cable from the negative pole (-), then the cable from the positive one (+).
3. Do not disconnect batteries when the engine is running.
4. Connect the "minus" pole of the battery to the chassis and the "plus" pole to terminal "B+" from the alternator. Opposite connection will cause the whole semi-conductor device to be destroyed.
5. When starting with an auxiliary external supply, do not disconnect the supply before is the battery the machine is charging. Make sure of the starting voltage of the auxiliary external supply, (for 24 V).
6. Do not put the alternator into no-load operation, i.e. with the wire disconnected from the "+" terminal and connected to the "D+" terminal.
7. Do not check the presence of voltage in the wire by sparking it on the chassis of the equipment.
8. Do not do anything that produces sparks.
9. When handling batteries, use protective rubber gloves and full face protection.
10. Protect your skin and clothes from stains caused by electrolyte or lead particles.
11. If electrolyte gets into your eyes, rinse them with running water for 15 minutes. Then see a doctor as soon as possible.
12. When electrolyte stains your skin or clothes, take off your clothes, wash the stained area with soapy water or with a solution of baking soda and water and see a doctor.
13. In the event of accidentally swallowing electrolyte, drink as much milk or water as possible or a solution of milk of magnesia and immediately see a doctor.
14. Never pour distilled water into the cells unless the operation of the machine or charging outside the machine follows. In this case, the battery would discharge rapidly.

15. Never add sulfuric acid (H_2SO_4).
16. Do not overturn the batteries because electrolyte could run out of the air vents in the battery.
17. If acid (electrolyte) is spilled, rinse the area with water and neutralize it with lime.
18. When the batteries are being charged, hydrogen is released and, mixed with air, makes an explosive, easily combustible mixture. Do not use open flames and do not smoke.

WELDING ON THE MACHINE

Before starting arc welding, disconnect all parts with semi-conductors from electrical wiring, i.e.:

- engine alternator,
- hourmeter,
- control unit under the instrument panel,
- ground both the supply and the machine that is being repaired,
- protect the supply point against moisture,
- place the ground terminal close to the welded joint,
- when parts are welded or when the machine is in the suspended position, insulate the point of current transfer to avoid current entering the hoist, or use a non-conducting rope.

SEALS

1. Always use new seals.
2. You can obtain seals kits in spare part form.

HARDWARE TORQUE

1. Use a torque wrench to obtain correct hardware torque.
2. Fastening screw and nut are tightened according to the table.
3. Screw grades are shown normally on the screw head.
4. Hardware torque is given in the tables.
5. Threaded connections for hydraulics are tightened as specified in the tables.
6. The given hardware torque specifications are valid for dry screw threads.
7. Use new self-locking nuts only.

2 - DESCRIPTION OF THE MACHINE

DESCRIPTION

Front frame (1)

The front frame is a weldment, and it contains a fuel tank. A plastic water tank (14) is placed in the front part of the frame along with a hydraulic oil tank (13) and a storage battery (20) with a master switch. The driving unit is flexibly mounted in the rear part of the frame. The whole space of the front frame is covered with a hinged laminated cowl.

Rear frame (2)

The rear frame is a weldment too. The platform (15) and plastic water tank (14) are flexibly mounted on the frame. The protective frame (21) is fixed to the rear part of the frame.

Articulated joint (3)

The hinge joins the front and rear frames. It has a horizontal pin (1) and a vertical pin (2). Both are mounted in bearings that make it possible for both parts to turn horizontally as well as vertically.

Front and rear forks (4)


The forks attach the drums flexibly to the rear and front frames. The travel hydraulic motor is fixed to the left fork; the absorber plate with two rubberized metal pieces is also flexibly attached to the right fork.

Front and rear drums (5)

The drum is welded of steel plates. In the lids there are roller bearings with the shaft of the vibrator with two eccenters. The shaft is driven through a clutch by the vibration hydraulic motor. The bearings are lubricated by a grease fill. The drum rotates in the bearing in the right lid and the bearing of the hydraulic motor.


Driving unit

This unit is flexibly mounted in the front frame. It consists of a combustion engine with air cooling (6) which is driven by the travel hydraulic generator via the clutch. Two gear hydraulic generators – vibration and servosteering (8) – are mounted on the engine side.



3435R062

2 - DESCRIPTION OF THE MACHINE




34880001

2 - DESCRIPTION OF THE MACHINE


- 1 - Front frame
- 2 - Rearframe
- 3 - Articulated joint
- 4 - Front and rear forks
- 5 - Front and rear drum
- 6 - Engine
- 7 - Hydraulic generator of travel
- 8 - Tandem hydraulic generator of vibration and power steering
- 9 - Hydraulic oil cooler
- 10 - Motor air filter
- 11 - Exhaust
- 12 - Fuel tank
- 13 - Hydraulic oil tank
- 14 - Sprinkling water tank front and rear
- 15 - Platform
- 16 - Hood
- 17 - Sprinkling pump
- 18 - Sprinkling of the drums
- 19 - Scrapers of the drums
- 20 - Battery
- 21 - Protective frame ROPS
- 22 - Travel hydraulic motor
- 23 - Vibration hydraulic motor

REMOVAL OF THE ENGINE FROM THE MACHINE WITH THE TRAVEL PUMP




348D0100

DV 201 - DV 202




348D0001

103




348D0002

DV 204



348D0003

103



348D0004

3 - THE ENGINE

Lift the hood, remove the mounting of the gas-operated support on the hood and tilt the hood.



34804786




34804788




34804789

3 - THE ENGINE

Remove cover on the front frame of the machine on the left side.




34804719




34804720

3 - THE ENGINE

Remove cover on the front frame of the machine on the right side.




34804784



34804785

3 - THE ENGINE

Remove cover on the front frame above the steering joint of the machine.





Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading

3 - THE ENGINE


Release the lid on the filling hole of the oil tank for the engine.



Remove drain plug of oil fill of the engine and drain oil.



Remove the hose in the frame of the machine on the „L“ joint of the drain plug.



<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>