

# 1825 Uni-Loader

## Table of Contents

DIVISION/SECTION	SECTION NO.	FORM NO.
<b>1 GENERAL</b>		
Safety Rules, Service Manual Introduction, and Torque Specifications .....	1001	8-68110
Fluids and Lubricants .....	1002	8-17680
Gasoline Engine Specifications .....	1010	8-58790
Diesel Engine Specifications.....	1024	8-58760
General Machine Specifications .....	1210	8-68140
<b>2 ENGINES</b>		
Engine Removal and Installation and Radiator Removal and Installation .....	2000	8-68480
Engine Accessories.....	2001	8-68490
Cylinder Head and Valve Train - Gasoline Engine .....	2015	8-58040
Cylinder Head and Valve Train - Diesel Engine .....	2015	8-58120
Camshafts - Diesel Engine .....	2020	8-58820
Cylinder Block, Pistons, Rods, Camshaft, Main Bearings, Oil Seals, and Flywheel - Gasoline Engine.....	2025	8-58050
Cylinder Block, Pistons, Rods, Main Bearings, Oil Seals, and Flywheel - Diesel Engine.....	2025	8-58130
Crankshaft - Gasoline Engine .....	2035	8-58060
Crankshaft - Diesel Engine .....	2035	8-58140
Lubrication System - Gasoline Engine .....	2045	8-58070
Lubrication System - Diesel Engine.....	2045	8-58150
Cooling System - Gasoline Engine.....	2055	8-58080
Cooling System - Diesel Engine .....	2055	8-58160
Ignition System.....	2065	8-58720
Engine Lubrication System - Gasoline Engine .....	2555	8-58090
Engine Lubrication System - Diesel Engine .....	2555	8-58170
<b>3 FUEL SYSTEM</b>		
Carburetor .....	3002	8-58730
Fuel Injection Pump .....	3312	8-58840
Fuel Injectors and Glow Plugs.....	3313	8-58830
<b>4 ELECTRICAL</b>		
Removal and Installation of Electrical Components.....	4000	8-68690
Electrical Specifications, Troubleshooting, and Schematics.....	4002	8-17690
Instruments and Gauges .....	4004	8-68720
Battery .....	4005	8-44360
Starter - Gasoline Engine.....	4006	8-58100
Starter - Diesel Engine.....	4006	8-58180
Alternator - Gasoline Engine.....	4007	8-58110
Alternator - Diesel Engine .....	4007	8-58190

**Reprinted**

DIVISION/SECTION	SECTION NO.	FORM NO.
<b>6 POWER TRAIN</b>		
Removal and Installation of Power Train Components .....	6000	8-70080
Maintenance .....	6001	8-70090
Hydrostatic System Troubleshooting .....	6002	8-17700
Piston Pump .....	6004	8-70110
Motor .....	6005	8-70120
Sprockets, Chains and Axles .....	6007	8-70140
Wheels and Tires .....	6011	8-68310
<b>8 HYDRAULICS</b>		
Removal and Installation of Hydraulic Components .....	8000	8-70180
Maintenance .....	8001	8-70190
Hydraulic Schematics, Specifications, and Troubleshooting .....	8002	8-17710
Cleaning the Hydraulic System and Hydrostatic System .....	8003	8-68360
Hydraulic Pump .....	8004	8-70210
Loader Control Valve .....	8005	8-68380
Auxiliary Control Valve .....	8006	8-68390
Cylinders .....	8090	8-68400
<b>9 MOUNTED EQUIPMENT</b>		
Pedals and Levers .....	9000	8-17720
Loader .....	9001	8-70230
ROPS Canopy, Seat, Seat Belts, and Operators Compartment .....	9003	8-70240
Auxiliary Hydraulic Installation .....	9004	8-70250

# 1001

## SAFETY RULES SERVICE MANUAL INTRODUCTION AND TORQUE SPECIFICATIONS

### TABLE OF CONTENTS

<b>Safety Rules</b> .....	1001-2	Grade 8.8 Bolts, Nuts, and Studs .....	1001-7
<b>Service Manual Introduction</b> .....	1001-5	Grade 10.9 Bolts, Nuts, and Studs .....	1001-7
<b>Torque Specifications</b> .....	1001-6	Grade 12.9 Bolts, Nuts, and Studs .....	1001-7
Grade 5 Bolts, Nuts, and Studs .....	1001-6	Steel Hydraulic Fittings .....	1001-8
Grade 8 Bolts, Nuts, and Studs .....	1001-6	Split Flange Mounting Bolts .....	1001-8

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**




## SAFETY RULES



Most accidents involving machine operation and maintenance can be avoided by following basic safety rules and precautions. Read and understand all the safety messages in this manual, the safety manual, and the safety signs on the machine before you operate or service the machine.

Read the operators manual and make sure you understand the operation of the machine.



Operators Manual Storage

876245

The safety information given in this manual does not replace safety codes, insurance needs, federal, state, and local laws.

**IMPORTANT:** *Safety messages in this section point out situations which can be encountered during the normal operation and maintenance of your machine. These safety messages also give possible ways of dealing with these conditions.*

Additional safety messages are used in the text of the manual to show specific safety hazards.




## BEFORE OPERATION



Do not wear loose clothing or jewelry that can catch on controls, etc. Safety shoes, heavy gloves, ear protection, etc., can also be required for your protection.

Foreign material or grease on the steps and hand rails can cause an accident. Keep the steps and hand rails clean.



Remove all loose objects from the operators area and from the machine. Loose objects can jam controls and cause accidents.

Engine exhaust fumes can cause death. If you operate this machine in an enclosed area, use good ventilation to replace the exhaust fumes with fresh air.

Make sure all persons are away from the machine before you start the engine.

Before you start the engine, always fasten the seat belt and pull down the operators protection bars.

Use hand rails and step provided. Do not rush.



## MACHINE OPERATION



Check all controls in a clear area and make sure the machine is operating correctly.

Be alert, always know the location of all workers in your area. Keep all other persons completely away from your machine. Injury or death can result if you do not follow these instructions.

Do not allow another person to ride on the machine. This other person can fall or can cause an accident.



## PARKING THE MACHINE



When you park the machine and before you leave the operators area, lower the loader bucket to the ground or support the loader lift arms with the support strut and stop the engine.



## MAINTENANCE



When you service the machine, put a Do Not Operate tag on the instrument panel. A Do Not Operate tag (Case part number 321-4614) is included with each new machine. Extra tags are available from your Case dealer.



If you must service this machine with the engine running, have another person help you. Follow the instructions in this manual. Do not leave the operators seat with the engine running.

Metal chips or debris can cause eye injury. Always wear eye or face protection when you use a hammer on this machine. Use a hammer with a soft face, such as brass, to drive hardened pins.

When adding air to a tire, always stand behind the tread of the tire and use a self-adjusting chuck. Explosive separation of the tire can result if you overinflate. When tire service is necessary, have a qualified tire mechanic service the tire.

Improper service or repair can cause injury or death. If you do not understand a service or adjustment procedure, see the correct section in this manual.

Hydraulic fluid or grease injected into your skin can cause severe injury or death. Keep your hands and body away from any pressurized leak. If fluid is injected into your skin, see a doctor immediately and have the fluid removed.

Unauthorized modifications to this machine can cause injury or death. Do not make unauthorized modifications to this machine.



## FIRE OR EXPLOSION PREVENTION



Engine fuel can cause an explosion or fire. Do not fill the fuel tank with the engine running, if you are near an open fire, or if you are welding, smoking, etc.

Use nonflammable cleaning solvent to clean parts.

Sparks or flame can cause the hydrogen gas in a battery to explode. To prevent an explosion, do the following:

1. When disconnecting the battery cables, disconnect the negative (-) cable first; when connecting the battery cables, connect the negative (-) cable last.
2. When connecting jumper cables to start the engine, use the procedure shown in this manual.
3. Do not short circuit the battery posts with metal items.

4. Do not weld, grind, or smoke near a battery.

Sparks from the electrical system or engine exhaust can cause a fire or an explosion. Before you operate this machine in an area with flammable dust or vapors, use good ventilation to remove all flammable dust or vapors.

A fire can cause injury or death. Always have a fire extinguisher near the machine. Make sure the fire extinguisher is serviced according to the manufacturer's instructions.

Remove all trash or debris from the machine. Make sure that oily rags or other flammable materials are not stored on the machine.

Check for fuel, oil, and hydraulic fluid leaks. Replace worn or damaged hoses/lines. After repairs are made, clean the machine before you operate.



## BURN PREVENTION



Battery acid causes severe burns. Batteries contain sulfuric acid. Avoid contact with skin, eyes, or clothing. Antidote - EXTERNAL: flush with water. INTERNAL: drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call a doctor immediately. EYES: flush with water for 15 minutes and get prompt medical attention.

When the battery electrolyte is frozen, the battery can explode if, (1) you try to charge the bat-

tery, (2) you try to jump start and run the engine. To prevent the battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured.


Hot coolant can spray out if the radiator cap is removed. To remove the radiator cap, let the cooling system cool, turn to the first notch, then wait until the pressure is released.

## SERVICE MANUAL INTRODUCTION

This service manual has been prepared with the latest service information available. Troubleshooting, removal, disassembly, inspection and installation procedures, and complete specifications and tightening references can be found in most sections. Some sections have drawings but no written procedure because the job is so easily done. This service manual is one of the most important tools available to the service technician.

### Right, Left, Front, and Rear

The terms right-hand and left-hand and front and rear as used in this manual indicate the right and left sides, and front and rear of the machine as seen from the operator's seat for correct operation of the machine or attachment.



### Text

If the service manual is for more than one machine or different models of components (planetary axles, gear boxes, control valves, etc.) the procedures have the steps necessary to service each model.

### Table of Contents

A Table of Contents is in the front of this manual. The Table of Contents shows the main divisions and the sections that are in each division. The individual sections, where necessary, have a Table of Contents on the cover or second page of that section.

### Page Numbers

All page numbers are made of two numbers the separated by a dash, such as 4002-9. The number dash before the dash is the section number. The number following is the page number in that section. Page numbers will be found at the upper right or left of each page.

### Illustrations

Illustrations are put as near as possible to the text and are to be used as part of the text.

### Special Tools

Special tools are needed to remove and install, disassemble and assemble, check, and adjust some components parts of this machine. Some special tools can be easily made locally and the necessary information to make the tool is in this service manual. Other special tools are more difficult to make locally and are available from Service Tools in the U.S. and from Jobborn Manufacturing in Canada. Use these tools according to the instructions in this service manual for your personal safety and to do the job correctly.


Order special tools from either of the following companies:


Service Tools  
P.O. Box 314  
Owatonna, Minnesota 55060

Jobborn Manufacturing Co.  
97 Frid Street  
Hamilton, Ontario L8P 4M3  
Canada

## TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers, dry, or when lubricated with engine oil. Not applicable if special graphites, molydisulfide greases, or other extreme pressure lubricants are used.

<b>Grade 5 Bolts, Nuts, and Studs</b>		
		
Size	Pound-Feet	Newton metres
1/4 in	9-11	12-15
5/16 in	17-21	23-28
3/8 in	35-42	48-57
7/16 in	54-64	73-87
1/2 in	80-96	109-130
9/16 in	110-132	149-179
5/8 in	150-180	203-244
3/4 in	270-324	366-439
7/8 in	400-480	542-651
1.0 in	580-696	787-944
1-1/8 in	800-880	1085-1193
1-1/4 in	1120-1240	1519-1681
1-3/8 in	1460-1680	1980-2278
1-1/2 in	1940-2200	2631-2983


<b>Grade 8 Bolts, Nuts, and Studs</b>		
		
Size	Pound-Feet	Newton metres
1/4 in	12-15	16-20
5/16 in	24-29	33-39
3/8 in	45-54	61-73
7/16 in	70-84	95-114
1/2 in	110-132	149-179
9/16 in	160-192	217-260
5/8 in	220-264	298-358
3/4 in	380-456	515-618
7/8 in	600-720	814-976
1.0 in	900-1080	1220-1465
1-1/8 in	1280-1440	1736-1953
1-1/4 in	1820-2000	2468-2712
1-3/8 in	2380-2720	3227-3688
1-1/2 in	3160-3560	4285-4827


**NOTE:** Use thick nuts with Grade 8 bolts.

## TORQUE SPECIFICATIONS - METRIC HARDWARE

Use the following torques when special torques are not given

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or molydisulfide grease or oil is used.

Grade 8.8 Bolts, Nuts, and Studs		
		
Size	Pound-Feet	Newton metres
<b>M4</b>	2-3	3-4
<b>M5</b>	5-6	6.5-8
<b>M6</b>	8-9	10.5-12
<b>M8</b>	19-23	26-31
<b>M10</b>	38-45	52-61
<b>M12</b>	66-79	90-107
<b>M14</b>	106-127	144-172
<b>M16</b>	160-200	217-271
<b>M20</b>	320-380	434-515
<b>M24</b>	500-600	675-815
<b>M30</b>	920-1100	1250-1500
<b>M36</b>	1600-1950	2175-2600

Grade 10.9 Bolts, Nuts, and Studs		
		
Size	Pound-Feet	Newton metres
<b>M4</b>	3-4	4-5
<b>M5</b>	7-8	9.5-11
<b>M6</b>	11-13	15-17.5
<b>M8</b>	27-32	37-43
<b>M10</b>	54-64	73-87
<b>M12</b>	93-112	125-150
<b>M14</b>	149-179	200-245
<b>M16</b>	230-280	310-380
<b>M20</b>	450-540	610-730
<b>M24</b>	780-940	1050-1275
<b>M30</b>	1470-1770	2000-2400
<b>M36</b>	2580-3090	3500-4200

### Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

## TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
<b>37 Degree Flare Fittings</b>			
<b>1/4 in</b> 6.4 mm	7/16-20	6-12	8-16
<b>5/16 in</b> 7.9 mm	1/2-20	8-16	11-21
<b>3/8 in</b> 9.5 mm	9/16-18	10-25	14-33
<b>1/2 in</b> 12.7 mm	3/4-16	15-42	20-56
<b>5/8 in</b> 15.9 mm	7/8-14	25-58	34-78
<b>3/4 in</b> 19.0 mm	1-1/16-12	40-80	54-108
<b>7/8 in</b> 22.2 mm	1-3/16-12	60-100	81-135
<b>1.0 in</b> 25.4 mm	1-5/16-12	75-117	102-158
<b>1-1/4 in</b> 31.8 mm	1-5/8-12	125-165	169-223
<b>1-1/2 in</b> 38.1 mm	1-7/8-12	210-250	285-338

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
<b>Straight Threads with O-ring</b>			
<b>1/4 in</b> 6.4 mm	7/16-20	12-19	16-25
<b>5/16 in</b> 7.9 mm	1/2-20	16-25	22-23
<b>3/8 in</b> 9.5 mm	9/16-18	25-40	34-54
<b>1/2 in</b> 12.7 mm	3/4-16	42-67	57-90
<b>5/8 in</b> 15.9 mm	7/8-14	58-92	79-124
<b>3/4 in</b> 19.0 mm	1-1/16-12	80-128	108-174
<b>7/8 in</b> 22.2 mm	1-3/16-12	100-160	136-216
<b>1.0 in</b> 25.4 mm	1-5/16-12	117-187	159-253
<b>1-1/4 in</b> 31.8 mm	1-5/8-12	165-264	224-357
<b>1-1/2 in</b> 38.1 mm	1-7/8-12	250-400	339-542

<b>Split Flange Mounting Bolts</b>		
Size	Pound- Feet	Newton metres
5/16-18	15-20	20-27
3/8-16	20-25	26-33
7/16-14	35-45	47-61
1/2-13	55-65	74-88
5/8-11	140-150	190-203

# Section 1002

FLUIDS AND LUBRICANTS

## CAPACITIES AND LUBRICANTS

### Fuel Tank

Capacity..... 8.5 U.S. gallons (32.2 litres)

### Diesel Engine Crankcase

Capacity - with filter change ..... 6 U.S. quarts (5.7 litres)

Type of oil..... See Engine Oil Recommendations on page 3

### Gasoline Engine Crankcase

Capacity - with filter change ..... 3.5 U.S. quarts (3.3 litres)

Type of oil..... See Engine Oil Recommendations on page 3

### Gasoline Engine Governor

Capacity..... 1.2 U.S. fluid ounces (35.5 mL)

Type of oil..... SAE 10W30 engine oil

### Hydraulic Reservoir

Capacity - with filter change ..... 5.75 U.S. gallons (21.8 litres)

Capacity - without filter change ..... 5.5 U.S. gallons (20.8 litres)

Capacity - total system ..... 7.5 U.S. gallons (28.4 litres)

Type of oil..... SAE 10W30 engine oil with additive, see below

When you change the hydraulic oil, add one U.S. quart of Case HTO (Hydrostatic Transmission Oil Additive) Case part number B17508.

When you add oil to the hydraulic reservoir between oil changes, use a mixture of SAE 10W30 engine oil and HTO additive. Mix one U.S. quart of HTO additive with five U.S. gallons (19 litres) of 10W30 engine oil. (20 to 1 ratio).

### Drive Chain Compartments

Capacity - each side ..... 3 U.S. quarts (2.8 litres)

Type of oil..... SAE 10W30 engine oil

### Engine Cooling System

Capacity..... 7 U.S. quarts (6.6 litres)

Type of coolant..... Ethylene glycol type antifreeze and water that is mixed for lowest ambient temperature at least 50/50 mix

### Grease Fittings


Type of lubricant..... Case IH molydisulfide grease

### Hydrostatic Motor Shaft Spline

Type of lubricant..... Molykote, Type G grease

## GASOLINE ENGINE OIL RECOMMENDATIONS

Use Case IH Engine Oil of the correct viscosity. See the chart for the temperatures and the recommended viscosity. API classification of SD, SE or SF must be used.



B902073J

## DIESEL ENGINE OIL RECOMMENDATIONS

Use Case IH Engine Oil of the correct viscosity. See the chart for the temperatures and the recommended viscosity. API classification of CD, SE/CD, or SF/CD must be used.

Above 77°F (25°C) ..... SAE 30  
 32 to 77°F (0 to 25°C) ..... SAE 20W or SAE 10W30  
 Below 32°F (0°C) ..... SAE 10W or SAE 10W30

## FUEL

### Gasoline Engines

Use clean, unleaded regular grade gasoline. Do not use leaded gasoline in the engine.

### Diesel Engines

Use the diesel fuel recommended for the temperatures in your area. If the ambient temperature lowers to the "cloud point" of the fuel, wax particles will form in the fuel. The wax particles can cause a restriction in the fuel filters decreasing engine power. See your fuel dealer.

# **Section 1010**

## **ENGINE SPECIFICATIONS Nissan A12 Gasoline Engine**

## TABLE OF CONTENTS

GENERAL SPECIFICATIONS .....	3
DETAILED SPECIFICATIONS .....	4
Cylinder Head .....	4
Valves .....	4
Valve Springs .....	4
Valve Guides .....	5
Valve Seats .....	5
Camshaft .....	6
Cylinder Block .....	7
Pistons .....	7
Piston Pins .....	7
Piston Rings .....	7
Connecting Rods .....	8
Cylinder Liners .....	8
Crankshaft .....	8
Flywheel .....	8
Oil Pump .....	8
Cooling System .....	9
Distributor .....	9
Ignition Coil .....	9
Spark Plugs .....	9
Carburetor .....	9
Fuel Pump .....	9
Governor .....	10
Starter Motor .....	10
Alternator .....	10
SPECIAL TORQUES .....	11
STANDARD TORQUES .....	12

## GENERAL SPECIFICATIONS


Type .....	Gasoline	
Stroke .....	4	
No. Of Cylinders .....	4	
Valve Arrangement .....	OHV (Over Head Valve)	
Bore x Stroke .....	2.87 x 2.76 inch	73.0 x 70.0 mm
Displacement .....	71.45 inch	1.171 cm <sup>3</sup>
Compression Ratio .....	9:0	
Number Of Piston Rings		
Compression .....	2	
Oil .....	1	
Number Of Main Bearings .....	5	
Valve Clearance (Hot)		
Intake And Exhaust .....	0.014 inch	0.35 mm
Engine Idle Speed .....	650 rpm	
Ignition Timing At Idle Speed		
BTDC .....	12° at 650 rpm	
Engine Oil Capacity		
With Oil Filter .....	3.37 US Quarts      2.87 UK Quarts	3.2 L
Without Oil Filter .....	2.87 US Quarts      2.37 UK Quarts	2.7 L
Oil Pump Type .....	Trochoid Gear	
Oil Filter Type .....	Paper Element (Cartridge)	
Water Pump Type .....	Centrifugal	
Thermostat Operating Temperature		
Tropical Area .....	170°F	76°C
Cold Area .....	180 to 190°F	82 to 88°C
Carburetor Type .....	Downdraft	
Air Cleaner Type .....	Dry Paper	
Alternator Model .....	Mitsubishi A1T24371	
Capacity .....	12 Volt 35 Amp	
Voltage Regulator Model .....	Mitsubishi RQB220B5	
Starter Motor Model .....	Mitsubishi M2T20181	
Capacity .....	0.8 kW	
Ignition System		
Firing Order .....	1 - 3 - 4 - 2	
Ignition Coil Model .....	Mitsubishi HP-BE10	
Distributor .....	Mitsubishi T3T03571	
Spark Plug Type .....	NGK B4ES	

## DETAILED SPECIFICATIONS

### Cylinder Head

Maximum Warpage .....	0.0020 inch	0.05 mm
Limit .....	0.004 inch	0.1 mm

### Valves



<b>Valve Head Diameter (D)</b>		
Intake .....	1.378 inch	35.0 mm
Exhaust .....	1.142 inch	29.0 mm
<b>Valve Stem Diameter (d)</b>		
Intake .....	0.3134 to 0.3140 inch	7.960 to 7.975 mm
Exhaust .....	0.3128 to 0.3134 inch	7.945 to 7.960 mm
Valve Length (L) .....	4.0748 to 4.0945 inch	103.5 to 104.0 mm
Valve Seat Angle (a) .....	45° 30'	45° 30'
<b>Valve Margin (T)</b>		
Standard .....	0.051 inch	1.3 mm
Limit .....	0.020 inch	0.5 mm
Valve Stem End Surface Grinding Limit .....	0.020 inch	0.5 mm
<b>Valve Clearance (In. &amp; Ex)</b>		
Hot .....	0.014 inch	0.35 mm
Cold .....	0.010 inch	0.25 mm

### Valve Spring


Free Height .....	1.831 inch	46.5 mm
Pressure Height .....	1.189 inch	30.2 mm
Pressure .....	120 to 138 lb	54.4 to 62.6 mm
Out Of Square Limit .....	0.063 inch	1.6 mm

**Valve Guide**

Outside Diameter		
Standard	0.4737 mm to 0.4742 inch	12.033 to 12.044 mm
Oversize	0.4816 mm to 0.4820 inch	12.233 to 12.244 mm
Inside Diameter		
	0.3150 to 0.3157 inch	8.000 to 8.020 mm
Cylinder Head Valve Guide Hole Diameter		
Standard	0.4724 to 0.4729 inch	12.000 to 12.011 mm
Oversize	0.4803 to 0.4807 inch	12.200 to 12.211 mm
Interference Fit Of Valve Guide		
	0.0009 to 0.0017 inch	0.022 to 0.044 mm
Valve Stem Clearance (Standard)		
Intake	0.0010 to 0.0024 inch	0.025 to 0.060 mm
Exhaust	0.0016 to 0.0030 inch	0.040 to 0.075 mm
Limit	0.0039 inch	0.10 mm
Valve Deflection Limit		
	0.008 inch	0.2 mm


**Valve Seat**

Intake Valve Seat  
(Standard)



Diameter	(a)	1.46 inch	37 mm
Diameter	(b)	1.36 inch	34.6 mm
	(c)	0.047 inch	1.2 mm
Diameter	(d)	1.18 inch	30 mm
	(e)	45°	45°

Intake Valve Seat  
(Oversize)



Diameter	(a)	1.36 inch	34.6 mm
	(b)	0.047 inch	1.2 mm
Radius	(c)	0.020 inch	0.5 mm
Diameter	(d)	1.4764 to 1.4770 inch	37.500 to 37.516 mm
	(e)	45°	45°



**Suggest:**

**If the above button click is invalid.**

**Please download this document**

**first, and then click the above link**


**to download the complete manual.**

**Thank you so much for reading**

## SPECIFICATIONS


### Valve Seat (Con't)

Exhaust Valve Seat  
Standard



Diameter	(a)	.....	1.30 inch	33 mm
Diameter	(b)	.....	1.126 inch	328.6 mm
	(c)	.....	0.075 inch	1.9 mm
Diameter	(d)	.....	1.02 inch	26 mm
	(e)	.....	45°	45°

Intake Valve Seat  
Oversize



Diameter	(a)	.....	1.126 inch	28.6 mm
	(b)	.....	0.075 inch	1.9 mm
Radius	(c)	.....	0.020 inch	0.5 mm
Diameter	(d)	.....	1.3189 to 1.3195 inch	33.500 to 33.516 mm
	(e)	.....	45°	45°

### Camshaft

Journal Diameter	No 1	.....	1.7237 to 1.7242 inch	43.783 to 43.796 mm
	No 2	.....	1.7041 to 1.7046 inch	43.283 to 43.296 mm
	No 3	.....	1.6844 to 1.6849 inch	42.783 to 42.796 mm
	No 4	.....	1.6647 to 1.6652 inch	42.283 to 42.296 mm
	No 5	.....	1.6224 to 1.6229 inch	41.208 to 41.221 mm

Finished Bearing Inside Diameter  
(After Line Boring)

No 1	.....	1.7257 to 1.7261 inch	43.833 to 43.843 mm
No 2	.....	1.7056 to 1.7060 inch	43.323 to 43.333 mm
No 3	.....	1.6865 to 1.6868 inch	42.836 to 42.846 mm
No 4	.....	1.6663 to 1.6667 inch	42.323 to 42.333 mm
No 5	.....	1.6243 to 1.6247 inch	41.258 to 41.268 mm

Camshafts and camshaft bearings are available in the following undersizes:

1st Undersize	.....	0.0098 inch	0.25 mm
2nd Undersize	.....	0.0197 inch	0.50 mm
3rd Undersize	.....	0.0295 inch	0.75 mm

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**