

CX800 Tier 3 Crawler Excavators

Table of Contents

DIVISION/SECTION	SECTION N°	REFERENCE N°
1 GENERAL INFORMATION		
Safety, general information and standard torque data	1001	7-27691EN
General specifications and special torque setting.....	1002	9-94710EN
2 ENGINE		
Radiator and engine, removal and installation	2001	9-94910EN
Engine specifications	*	
Disassembly and assembly of the engine.....	*	
3 FUEL SYSTEM		
Fuel tank	3001	9-36821EN
Fuel engine system.....	*	
4 ELECTRICAL SYSTEM		
Electrical system, electrical and electronic troubleshooting.....	4001	9-94700EN
Inspection and maintenance of batteries and connecting a booster battery....	4002	9-36830EN
Main and engine electronic control boxes.....	4003	9-94510EN
5 UNDERCARRIAGE		
Removal and installation of tracks	5001	9-36860EN
Rollers.....	5003	9-36881EN
Sprocket.....	5004	9-36890EN
Idler wheel and tension shock absorber	5005	9-94350EN
6 DRIVE TRAIN		
Drive motor and final drive transmission removal and installation	6001	9-36980EN
Drive motor and final drive transmission disassembly and assembly	6002	9-40351EN
Swing reduction gear, removal and installation.....	6003	9-36991EN
Swing reduction gear, disassembly and assembly.....	6004	9-42631EN
7 UNDERCARRIAGE HYDRAULICS		
8 UPPERSTRUCTURE HYDRAULICS		
Depressurising and decontaminating the hydraulic system, use of the vacuum pump and bleeding the components	8000	9-94430EN
Specifications, troubleshooting, checks and hydraulic pressure settings.....	8001	9-94740EN
Hydraulic reservoir removal and installation	8002	9-94490EN
Main and pilot pumps, removal and installation	8003	9-40771EN
Main hydraulic control valve, removal and installation	8004	9-94501EN
Attachment cylinders, removal and installation	8005	7-27792EN
Hydraulic swivel, removal and installation.....	8006	9-94600EN
Pilot blocs, removal and installation	8007	9-94520EN
Swing motor, removal and installation.....	8008	9-94420EN
Main hydraulic pump, disassembly and assembly	8010	9-94590EN
Main hydraulic control valve, disassembly and assembly	8011	9-94781EN
Attachment cylinders, disassembly and assembly.....	8012	9-40941EN
Hand control levers, disassembly and assembly	8013	9-94630EN
Foot control levers, disassembly and assembly.....	8014	9-40992EN
Six-solenoid valves, disassembly and assembly.....	8015	9-42521EN
Caution valve, disassembly and assembly.....	8016	9-94531EN
Safety valve.....	8017	9-42770EN
Hydraulic swivel, disassembly and assembly.....	8018	9-42511EN
Swing motor, disassembly and assembly	8019	9-42530EN
Hydraulic functions.....	8020	9-94720EN

DIVISION/SECTION	SECTION N°	REFERENCE N°
Fan motor, removal and installation	8022	9-94660EN
Fan motor, disassembly and assembly	8023	9-94670EN
Fan pump, removal, disassembly, assembly and installation	8024	9-94680EN
Hydraulic component functions	8030	9-94130EN
9 UPPERSTRUCTURE		
Upperstructure, turntable and counterweight	9002	9-42551EN
Boom, dipper and bucket	9003	9-42621EN
Seat and seat belt	9004	9-40960EN
Cab and cab equipment	9005	9-94650EN
Air conditioning troubleshooting	9006	██████████
Air conditioning unit disassembly and assembly	9007	9-94640EN
Air conditioning servicing	9008	██████████
Air conditioning components	9009	██████████
Removal and installation attachment, counterweight and side fram	9010	9-94730EN
Large format hydraulic schematic	Pocket	87520431
Large format electrical schematic	Pocket	9-93930

* *Consult the Engine Service Manual*

██████████ *Sections to be distributed at a later date*

NOTE: CNH Company reserves the right to make changes in the specification and design of the machine without prior notice and without incurring any obligation to modify units previously sold.

The description of the models shown in this manual has been made in accordance with the technical specifications known as of the date of design of this document.

Section

1001

SAFETY, GENERAL INFORMATION AND TORQUE SPECIFICATIONS

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

GENERAL INFORMATION

Cleaning

Clean all metal parts except bearings, in a suitable cleaning solvent or by steam cleaning. Do not use caustic soda for steam cleaning. After cleaning, dry and put oil on all parts. Clean oil passages with compressed air. Clean bearings in a suitable cleaning solvent, dry the bearings completely and put oil on the bearings.

Inspection

Check all parts when the parts are disassembled. Replace all parts that have wear or damage. Small scoring or grooves can be removed with a hone or crocus cloth. Complete a visual inspection for indications of wear, pitting and the replacement of parts necessary to prevent early failures.

Bearings

Check bearings for easy action. If bearings have a loose fit or rough action replace the bearing. Wash bearings with a suitable cleaning solvent and permit to air dry. **DO NOT DRY BEARINGS WITH COMPRESSED AIR.**

Needle bearings

Before you press needle bearings in a bore always remove any metal protrusions in the bore or edge of the bore. Before you press bearings into position put petroleum jelly on the inside and outside diameter of the bearings.

Gears

Check all gears for wear and damage. Replace gears that have wear or damage.

Oil seals, O-rings and gaskets

Always install new oil seals, O-rings and gaskets. Put petroleum jelly on seals and O-rings.

Shafts

Check all shafts that have wear or damage. Check the bearing and oil seal surfaces of the shafts for damage.

Service parts

Always install genuine Case service parts. When ordering refer to the Parts Catalog for the correct part number of the genuine Case replacement items. Failures due to the use of other than genuine Case replacement parts are not covered by warranty.

Lubrication

Only use the oils and lubricants specified in the Operator's or Service Manuals. Failures due to the use of non-specified oils and lubricants are not covered by warranty.

SAFETY



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

To prevent injury always follow the Warning, Caution and Danger notes in this section and throughout the manual.

Put the warning tag shown below on the key for the keyswitch when servicing or repairing the machine. One warning tag is supplied with each machine. Additional tags Part Number 331-4614 are available from your service parts supplier



WARNING: *Read the operator's manual to familiarize yourself with the correct control functions.*



WARNING: *Operate the machine and equipment controls from the seat position only. Any other method could result in serious injury.*



WARNING: *This is a one man machine, no riders allowed.*



WARNING: *Before starting engine, study Operator's Manual safety messages. Read all safety signs on machine. Clear the area of other persons. Learn and practice safe use of controls before operating.*

It is your responsibility to understand and follow manufacturers instructions on machine operation, service and to observe pertinent laws and regulations. Operator's and Service Manuals may be obtained from your Case dealer.



WARNING: *If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing.*



WARNING: *When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.*



WARNING: *When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure.*



WARNING: *When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way.*



WARNING: Use insulated gloves or mittens when working with hot parts.



WARNING: Lower all attachments to the ground or use stands to safely support the attachments before you do any maintenance or service.



WARNING: Pin sized and smaller streams of hydraulic oil under pressure can penetrate the skin and result in serious infection. If hydraulic oil under pressure does penetrate the skin, seek medical treatment immediately. Maintain all hoses and tubes in good condition. Make sure all connections are tight. Make a replacement of any tube or hose that is damaged or thought to be damaged. **DO NOT** use your hand to check for leaks, use a piece of cardboard or wood.



WARNING: When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer.



WARNING: When using a hammer to remove and install pivot pins or separate parts using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors).



WARNING: Use suitable floor (service) jacks or chain hoist to raise wheels or tracks off the floor. Always block machine in place with suitable safety stands.



WARNING: When servicing or repairing the machine, keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc. Use an oil absorbing material and/or shop cloths as required. Use safe practices at all times.




WARNING: Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in this Service Manual.




WARNING: Engine exhaust fumes can cause death. If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension. Open the doors and get outside air into the area.



WARNING: When the battery electrolyte is frozen, the battery can explode if (1), you try to charge the battery, or (2), you try to jump start and run the engine. To prevent the battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured.



700-2-01-00-15A



700-2-01-01-44AA

Section

2001

**RADIATOR, OIL-COOLER, INTER COOLER, FUEL
COOLER AND ENGINE**

REMOVAL AND INSTALLATION

RADIATOR, OIL-COOLER, INTER COOLER AND FUEL COOLER

Before carrying out any operation on the machine, perform the following operations in the order shown:

- Park the machine on hard, flat ground.
- Lower the attachment to the ground.
- Shut down the engine.
- Remove the starter switch key.
- Make sure that pressure in the hydraulic system has been completely released (see Operator's Manual).



WARNING: *When the machine is working, the engine components and the hydraulic pump reach a high temperature. To avoid being burnt by hot metal or scalded by high temperature water or oil, allow the machine to cool down before starting any servicing operation.*

NOTE: *For the removal and the installation of the radiator, oil cooler, inter cooler and fuel cooler refer to the figure 1, page 10.*

Removal

STEP 1

Drain the cooling system (see Operator's Manual).

STEP 2

Release pressure in the hydraulic reservoir to allow the vacuum pump to be mounted (see Section 8000).

Installation


When installing, proceed in the reverse order from that of removal.

Before operating the machine:

- Check the oil level in the hydraulic reservoir. Top up if necessary.
- Check the hydraulic fluid cooling circuit for leaks.
- Fill and bleed the engine cooling system (see Operator's Manual).
- Check the engine cooling system for leaks.

ENGINE

Description




PAW5Z0LF000901

- | | |
|---|--|
| B1 Coolant temperature sensor | B50 Camshaft position sensor (or G sensor: cylinder recognition sensor (detects rotation of cam shaft)) |
| B3 Fuel temperature sensor | B51 Boost temperature sensor |
| B21 Engine oil pressure switch | B52 Common rail pressure sensor |
| B47 Boost pressure sensor | |
| B49 Crankshaft position sensor (or engine speed sensor (flywheel mounted)) | |

Removal and installation

NOTE: For the removal and the installation of the engine refer to the figure 1, page 10.

STEP 1




Park the machine on hard, flat ground. Lower the attachment to the ground. JS00163A

STEP 2


Release pressure in the hydraulic system and in the hydraulic reservoir (see Section 8000).

STEP 3




Disconnect the earth cable (-) (1) from the battery. CT05L063

STEP 4




Remove the screws (1) from the compressor and put it away from the engine. CD01D131

STEP 5




Disconnect the exhaust gas recirculation valve position sensor (B53) from the exhaust gas recirculation motor (M15). CRPH06A031A

STEP 6



Label and disconnect the boost temperature sensor (B51) and the boost pressure sensor (B47). CRPH06A033A


STEP 7



CRPH06A034A

Label and disconnect the electrical connections from the injectors.


STEP 8



CRPH06A035A

Label and disconnect the electrical supply to the glow plug (R1).


STEP 9



CRPH06A037A

Label and disconnect the connections from the common rail pressure sensor (B52).


STEP 10



CRPH06A038A

Label and disconnect the coolant temperature switch (B1).


STEP 11



CD00J031


Label and disconnect the electrical connections to the starter motor (M1). Remove the earth cable at the engine end.

STEP 12




CRPH06A039A

Label and disconnect the electrical connections of the fuel temperature sensor (B3).

STEP 13


CRPH06A040A

Label and disconnect the supply pump valve PCV1 (Y33) and the supply pump valve PCV2 (Y34).

STEP 14


CRPH06A041A

Label and disconnect the electrical connections to the alternator (G2).

STEP 15


CRPH06A042A

Label and disconnect the engine oil pressure sensor (B21).



CRPH06A043A

Label and disconnect the camshaft position sensor (B50).

STEP 16

CRPH06A044A

Label and disconnect the crankshaft position sensor (B49).

STEP 17

Remove all the clips, etc. which attach the electrical harnesses to the engine and move out of the way.

STEP 18

Install a suitable lifting device on the engine lifting rings (for the weight of the engine, see Section 1002).

STEP 19

Remove the engine retaining hardware.

NOTE: When installing, make a visual inspection of the condition of the rubber flexible mountings and change them if necessary. Tighten the engine retaining screws to the torque specified in Section 1002.

STEP 20

When there is nothing interfering with the removal of the engine, raise the engine carefully and install it on a suitable repair bench.

2001-8

STEP 21

Refer to Section 8003 and remove the hydraulic pump.

STEP 22

Remove the silencer assembly with his bracket from the engine.

NOTE: *When installing, tighten the screws to a torque of 109 to 127 Nm.*

NOTE: *When installing the engine in the machine, proceed in the reverse order from removal.*


Before operating the machine, carry out the following operations:

- Bleed and prime the fuel system (see Operator's Manual).
- Fill and bleed the engine cooling system (see Operator's Manual).
- Check the hydraulic, fuel and cooling systems for leaks.
- Check the oil level in the hydraulic reservoir. Top up if necessary.

FUEL TANK

Removal

STEP 1



JS00163A

Park the machine on hard, flat ground. Lower the attachment to the ground.

STEP 2

Reduce the engine speed to idle for 30 seconds, then shut down the engine.

STEP 3

Turn the ignition key to «ON» without starting the engine.

STEP 4

Attach a «DO NOT OPERATE» tag to the ignition key in the cab.

STEP 5

NOTE: *The numbers within brackets refer to the figures on pages 5 and 6.*

Remove the access panel (A) under the fuel tank (1).

STEP 6

Open the filling plug (2) of the tank (1). Bleed the remaining fuel using the valve (3) then remove the latter. Remove the filter (19) and the fuel gauge (20).

STEP 7

Remove the retaining screw (4) of the access ramp (5) then remove the access ramp (5).

Remove the retaining screw (6) of the access ramp (12) then remove the access ramp (12).

Remove the retaining screw (20) of the access ramp (21) then remove the access ramp (21).

STEP 8

Attach identification tags on the electrical connections of the fuel tank filler pump and disconnect them.

STEP 9

Remove and seal all hoses of the fuel tank filler pump and remove the fuel tank filler pump.

STEP 10

Remove the screws (8) and the protective plate (D) from on top of the fuel tank (1).

Remove the screws (11) and the protective plate (C) from on top of the fuel tank (1).

Remove the screws (10) and the protective plate (B) from on top of the fuel tank (1).

STEP 11

Remove the front storage box (7).

STEP 12

Attach labels on the hoses of the fuel tank and remove them.

STEP 13

Shift the plastic protection (13) from the fuel sensor (14). Remove the retaining screws (15) then the fuel sensor (14) as well as the seal.

STEP 14

Remove the screws (17) from the fuel tank (1), and the spacer (18).

STEP 15

Remove the fuel tank (1) using a hoist. Remove the shims (22).

STEP 16

See the operator's manual for removing the fuel filter.

Installation

NOTE: *The numbers within brackets refer to the figures on pages 5 and 6.*

STEP 1

Using a hoist, position the fuel tank (1) on the machine.

STEP 2

Install the shims (22) as well as the spacer (18) and the screws (17), tighten the screws to the torque specified on the section 1002. Install and tighten the valve (3).

STEP 3

Install a new seal, then the fuel probe (14) using the five screws (15), reposition the plastic protection correctly (13).

STEP 4

Install the hoses by taking help of the labels attached during removal. Tighten using retaining clips.

STEP 5

Install the front storage box.

STEP 6

Install the fuel tank filler pump and connect all hoses.

STEP 7

Install the protective plate (B) on top of the fuel tank (1). Tighten the screws (10).

Install the protective plate (C) on top of the fuel tank (1). Tighten the screws (11).

Install the protective plate (D) on top of the fuel tank (1). Tighten the screws (10).

STEP 8

Install the access ramp (21) using the retaining screws (20).

Install the access ramp (12) using the retaining screws (6).

Install the access ramp (5) using the retaining screws (4).

STEP 9


Fill the fuel tank (see the operator's manual) and make sure that there are no leaks.

STEP 10

Reinstall the protective plate (A) under the fuel tank (1).

Description

Location




- 4 SCREW
- 5 ACCESS RAMP
- 6 SCREW
- 7 BOX
- 8 SCREW

- 10 SCREW
- 11 SCREW
- 12 ACCESS RAMP
- 20 SCREW
- 21 ACCESS RAMP

CRPH06A013G02

Fuel tank



- 1 FUEL TANK
- 2 PLUG
- 3 VALVE
- 13 PLASTIC PROTECTION
- 14 FUEL PROBE

- 15 SCREW
- 17 SCREW
- 18 SPACER
- 19 FILTER
- 22 SHIM


CRPH06F010F

ENGINE CONTROL

Fuel Injection Control (Common rail type)

1. Process to determine quantity of fuel injection

1) System diagram



2) Operation

Engine controller (ECM) gets information (signal from mounted sensors) such as engine speed and engine load.

Based on the information, ECM sends electric signals to supply pump and to injector to make a proper control of fuel injection quantity and injection timing for each cylinder.

1) Injection quantity control

Based mainly on engine speed and load given to actual machine, Injection rate control is carried out for optimum injection by controlling fuel injector.

2) Injection pressure control

Injection pressure is controlled by control of fuel pressure in the common-rail.

The right pressure in the common-rail is calculated by using engine speed and fuel injection quantity.

The supply pump and the pressure control valve are controlled according to the calculated pressure so that it can discharge proper quantity of fuel to pressure-feed into the common-rail for control.

3) Injection timing control


The control substitutes timer function and an appropriate fuel injection timing is calculated by mainly using engine speed and fuel injection quantity to control the injector.

4) Injection rate control

In order to improve fuel consumption in the cylinder, a small amount of fuel is injected (pre injection) for ignition at first, then 2nd time injection (main injection) into the ignited cylinder is carried out.

In this control, the injection quantity control in section 1) and the injection timing control in section 3) are carried out by controlling injector.


2. Mounting position of accessories related to engine



700.1.04.01.23AE2


- | | |
|---|--|
| A2 Engine controller | B50 Camshaft position sensor (or G sensor: cylinder recognition sensor (detects rotation of cam shaft)) |
| B1 Coolant temperature sensor | B51 Boost temperature sensor |
| B3 Fuel temperature sensor | M9 Air conditioner condenser fan motor |
| B6 Air intake temperature sensor | R5 Fuel sensor |
| B47 Boost pressure sensor | S62 Air cleaner sensor |
| B48 Atmospheric pressure sensor | |
| B49 Crankshaft position sensor (or engine speed sensor (flywheel mounted)) | |

B47. Boost pressure sensor



700.1.04.01.23AK


B48. Atmospheric pressure sensor



700.1.04.01.23AJ


- 1 Power, positive (+)
- 2 Power, negative (-)
- 3 Output

B49. Crankshaft position sensor




700.1.04.01.23AL

B50. Camshaft position sensor (or G sensor)




700.1.04.01.23AM

B51. Boost temperature sensor



700.1.04.01.23AH


R5. Fuel level sensor



700.1.04.01.23AO


S62. Vacuum sensor

Operating negative pressure: $6.27 \pm 0.29\text{kPa}$.



700.1.04.01.23AN

GENERAL LOCATION OF THE COMPONENTS (INSIDE THE CAB)



A1 Computer
A2 Engine controller

A4 Wiper controller
B61 Sunload sensor

CS01M598A



Suggest:

If the above button click is invalid.

Please download this document


first, and then click the above link

to download the complete manual.

Thank you so much for reading

- E4 Cab light
- E51 Cigarette lighter
- E52 Air conditioner
- F21 Fuse box
- K2 Relay-glow plug
- K3 Relay-horn
- K5 Relay-rotary light
- K6 Relay-air conditioner condenser fan
- K10 Relay-working light (upperstructure/attachment)
- K11 Relay-working light (cab)
- K32 Relay, hydraulic fan
- K33 Main relay
- M3 Wiper motor
- P1 Instrument panel
- P6 Air conditioner control panel
- R3 Throttle volume
- S1 Key switch
- S13 Overload switch
- S14 Breaker/crusher switch
- S15 Horn switch
- S16 One touch idle
- S17 Boom raising priority switch
- S51 Hydraulic function cancellation lever switch
- S53 Door limit switch
- S54 Front window limit switch
- S64 Cooling hydraulic motor switch
- U1 DC-DC (24 V-12 V) converter
- X8 Radio connector

RELAYS AND MAIN FUSES (BATTERY COMPARTMENT)



- 1 Battery cable
- F22 Fuse 20 A; main fuse for F11 and F12 circuits
- F23 Fuse 65 A; main fuse for F3 to F10 and F13 to F20 circuits
- F24 Fuse 20 A; main fuse for F2 circuit
- F25 Fuse 20 A; main fuse for F1 circuit
- K7 Relay battery

K8 Relay safety

700.1.04.07.20A2

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>