

**210G
Trimmer/Edger,
240G and 260G
Trimmer/
Brush Cutters**
(Serial No. 010001-)

John Deere Horicon Works
OMM95191 Issue J9
(This manual replaces OMM79603 & OMM77677)
LITHO IN U.S.A.
ENGLISH

Introduction

THANK YOU for purchasing a John Deere product.

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.



THIS MACHINE IS OF METRIC design. Measurements in this manual are metric with the customary U.S. measurement following. Use only metric hardware and tools as specified.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

WRITE IDENTIFICATION NUMBERS in the Specifications section. Accurately record all the

numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.



Model 210G Trimmer/Edger

M62794
-UN-10SEP89

Contents

	Page
Safety	1
Operation	6
Fuel and Lubricants	11
Service	13
Troubleshooting	21
Storage	22
Assembly	23
Specifications	27
Index	

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMM95191 J9-19-22DEC89

COPYRIGHT©1989
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



O53,ALERT -19-16JUN87

T81389 -UN-07DEC88

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



O53,SIGNAL -19-07OCT85


TS187 -19-30SEP88

FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.



O53,READ -19-23APR87

TS201 -UN-23AUG88




PROTECT PEOPLE AND PETS

Keep people and pets out of work area.

Do not let anyone operate trimmer without proper instruction. Do not let children operate trimmer.

Do not leave trimmer unattended.

Do not hand trimmer to another person while engine is running.



MX,SABR,A -19-18JUL88

M61442 -UN-01SEP88

PROTECT AGAINST THROWN OBJECTS


Wear eye protection to avoid injury from thrown objects.

Clear work area of objects that may be thrown.

Keep bystanders out of work area.

When using a 210G trim from right to left so trimmer throws particles away from you.

When using a 240G or 260G trim from left to right so trimmer throws particles away from you.



MX,SABR,B -19-01JUL88

M41579 -UN-06SEP88



OPERATE SAFELY

Start trimmer on ground.

Tighten parts on rotating head before you operate trimmer.

Do not use trimmer when you are tired.

Keep hand grips clean and dry.

Hold trimmer firmly with both hands.

Keep solid footing.

Cut at ground level only.

Move trimmer in sweeping motion away from your body.
Do not draw trimmer cutter head toward you.

Do not reach to make a cut.

Do not run engine in an enclosed area.

Stop engine before you remove debris from the cutting head.

Do not operate trimmer without shield.



-UN-01SEP88

M61443

MX,SABR,C -19-18JUL88

HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



-UN-23AUG88

TS202

O53,FIRE1 -19-23APR87




WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



O53,WEAR -19-23APR87


TS206 -UN-23AUG88

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



O53,FIRE2 -19-03MAR88

TS291 -UN-23AUG88


SERVICE TRIMMER SAFELY

Before you service, clean or inspect trimmer:

- Stop engine.
- Let engine cool.

Keep all parts in good condition and fastened in place.

Fix damage immediately. Replace worn or broken parts.




MX,SABR,D -19-18JUL88

M61444 -UN-01SEP88



SAFETY SIGNS



M62783 -19-07SEP89

On Plastic Shield



M62780 -19-07SEP89

On Trimmer Shaft—Model 210G



M62796 -19-07SEP89


On Trimmer Shaft—Models 240G and 260G

MX,SABR,E -19-05AUG88

Operation

LEARNING CONTROLS

- A—Engine Switch
- B—Throttle Trigger
- C—Recoil Starter Handle
- D—Choke Button
- E—Choke Lever



Model 210G



Model 240G

MX,OPBR,A -19-01JUL88

ADJUSTING LINE LENGTH



Model 210G

M41629 -UN-06SEP88



Models 240G and 260G

TY13986 -UN-23AUG88

If line is 50 mm (2 in.) or less you must lengthen it manually:

- Push and hold button (A).
- Pull line(s) to desired length.

To adjust line(s) during operation:

- Run engine at full throttle.
- Firmly tap button (A) on hard surface, not on lawn. Line extends 25 mm (1 in.) with each tap.


MX,OPBR,B -19-01JUL88

ADJUSTING HANDLE—MODEL 210G



CAUTION: Do not put handle over caution decal.

1. Loosen wing nut (A).
2. Put handle in desired position.
3. Tighten wing nut.




MX,OPBR,C -19-18JUL88

M62785 -UN-10SEP89

ADJUSTING HANDLE—MODELS 240G AND 260G

CAUTION: Do not put handle over caution decal.

1. Loosen nuts (A).
2. Put handle in desired position.
3. Tighten nuts.



Model 240G



Model 260G

MX,OPDR,D -19-19JUN89

STARTING COLD ENGINE

CAUTION: Avoid inhaling exhaust fumes. Do not operate trimmer indoors. Start trimmer on ground.

1. Put trimmer on clear, level ground.
2. Support trimmer with shield and engine.

NOTE: Do not start trimmer in tall grass or brush.

MX,OPBR,E -19-05AUG88



Model 240G




Model 210G and 260G

3. Move choke lever (A) to CLOSE position. (Pull up button for CLOSE position on 210G and 260G.)

MX,OPBR,F -19-01JUL88

4. Push switch (B) forward to ON.
5. Pull up trigger (A) to HALF THROTTLE.
6. Pull starter handle until you hear starting sound.
7. Move choke lever or button to OPEN.
8. Pull starter handle until engine starts.
9. Warm engine a few minutes at HALF THROTTLE before you cut.



M41609 -UN-06SEP88

MX,OPBR,G -19-01JUL88

STARTING WARM ENGINE

⚠ CAUTION: Avoid inhaling exhaust fumes. Do not operate trimmer indoors.


1. Push switch (B) forward to ON position.

NOTE: Do not choke a warm engine.

2. Leave trigger (A) at idle position and choke lever or button in OPEN position.

3. Pull starter handle.

NOTE: If engine does not start, follow STARTING COLD ENGINE procedure.




M41609 -UN-06SEP88

MX,OPBR,H -19-18JUL88

STOPPING ENGINE

1. Release trigger (A).
2. Move switch (B) back to STOP position.



M41609 -UN-06SEP88

MX,OPBR,I -19-01JUL88



Suggest:

If the above button click is invalid.

Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading

OPERATING TIPS

Trimming:

- 210G: trim from right to left.
- 240G and 260G: trim from left to right.
- Tilt cutting head for walks, driveways, and curbs.
- Adjust length of cutting line to 102—127 mm (4—5 in.) when you trim around bushes and trees with delicate bark. Do not cut frayed line: frayed ends protect bark.
- Slow engine speed. Work up to tree or bush easily.

Mowing:

- Keep cutting head parallel to the ground as you pass trimmer over area to cut.
- Fix feet firmly on ground and swivel from your hips for better control.

Scalping:

- Tilt cutting head.
- Scalp around tree to the right side. Force cutting line into the ground.
- After you scalp outside of the circle, scalp the inside working in the opposite direction, flush to the tree.

Edging:

IMPORTANT: Nylon line is only intended to cut grass or weeds. Do not use line to cut a trench along curb or driveway.

- Tilt cutting head to vertical position.
- Use line tip only to remove unwanted grass or weeds.

Sweeping:

- Sweep clippings only from hard surface.
- Tilt cutting head to left slightly, so line tip contacts surface lightly.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>