


Page Title	Page Number
Engine - Cylinder Head	010-0005
Engine - Cylinder Head Cover	010-0010
Engine - Intake Manifold	010-0015
Engine - Exhaust Manifold	010-0020
Engine - Cylinder Block	010-0025
Engine - Connecting Rod Bearings - Optional	010-0030
Engine - Oil Sump	010-0035
Engine - Timing Gear Housing	010-0040
Engine - Hanger	010-0045
Engine - Rocker Arm	010-0050
Engine - Camshaft	010-0055
Engine - Piston	010-0060
Engine - Piston - Optional	010-0065
Engine - Crankshaft	010-0070
Engine - Oil Pump	010-0075
Engine - Water Pump	010-0080
Engine - Fan	010-0085
Engine - Injection System	010-0090
Engine - Injection System	010-0095
Engine - Injection Pump	010-0100
Engine - Injection Pump	010-0105
Engine - Fuel Pipe	010-0110

3-IS01-014-A



Engine - Cylinder Head

Item	Part Number	Qty	Description
1	4265866M94	1	Cylinder Head
2	3710542M1	2	Cup
3	3707877M2	5	Plug
4	3710256M1	6	Oil Seal
5	3711713M1	1	Ball
6	3606115M1	1	Gasket
7	3710536M1	14	Bolt
8	3607420M1	2	Stud

<https://www.ebooklibonline.com>

Hello dear friend!


Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>


I-IS02-004-A



Engine - Cylinder Head Cover


Item	Part Number	Qty	Description
1	3608540M92	1	Valve Cover
2	3710554M1	1	Rubber
3	3710561M1	1	Cover
4	3710529M1	4	Screw
5	3710188M1	1	Plug
6	3710553M1	1	Gasket
7	3710127M2	2	Nut
8	4266260M1	2	Gasket
9	3710539M1	1	Hose

3-IS03-011-A




Item	Part Number	Qty	Description
1	3710647M91	1	Intake Manifold
2	3710649M1	1	Gasket
3	4267568M1	6	Bolt

3-IS04-013-A



Item	Part Number	Qty	Description
1	3710651M1	1	Manifold
2	3710652M1	1	Gasket
3	3702273M1	6	Bolt

3-IS05-024-A




1 — { 2
&
8

Engine - Cylinder Block


Item	Part Number	Qty	Description	Comments
1	4260390M91	1	Cylinder Block	
2	3710537M1	8	Bolt	(1)
3	4265578M1	2	Cup	(1)
4	3710130M2	2	Cup	(1)
5	4265580M1	1	Cup	(1)
6	3710542M1	3	Cup	(1)
7	3704257M1	8	Plug	(1)
8	3711695M3	1	Pin	(1)
9	3710160M1	4	Seal	
10	3710161M1	2	Seal	
11	3710571M91	1	Kit, Bearing	
12	3710572M1	4	Bearing	(11)
13	3710573M1	4	Bearing	(11)
14	3710580M1	2	Bearing Thrust	(11)
15	3710544M2	1	Oil Seal	
16	3710137M2	2	Pin	
17	4266242M1	2	Pin	
18	3757960M1	2	Pin	
19	3706536M1	1	Stud	
20	3704353M1	3	Stud	
21	3754115M1	1	Stud	
22	3758287M1	2	Dowel	
23	3754123M1	1	Pipe,Water	
24	3710284M1	1	Connectors	
25	3710162M2	1	Cover	
26	3710163M1	1	Gasket	
27	4267405M1	4	Bolt	
28	3710411M1	1	Pin	
29	4260452M1	1	Fuel Gauge	
30	4260453M91	1	Guide	
31	3756982M1	1	Cap	
32	3756940M1	1	O Ring	

3-IS06-001-A



Item	Part Number	Qty	Description	Comments
1	3710574M91	1	Kit, Bearing	25
	3710577M91	1	Kit, Bearing	50
2	3710580M1	2	Bearing Thrust	
3	4266964M1	3	Bearing	25
	4266969M1	3	Bearing	50


I-IS07-002-A



Engine - Oil Sump


Item	Part Number	Qty	Description	Comments
1	3756979M1	1	Oil Sump	
2	3607358M2	2	Plug	M14X1.5
3	3707793M1	2	O Ring	
4	3704335M1	18	Bolt	M6X35

I-IS09-003-A




Item	Part Number	Qty	Description	Comments
1	4266009M91	1	Gear Case Assy.	
2	3710541M1	2	Plug	
3	3710543M1	1	Cup	
4	3704353M1	4	Stud	8X22
5	3704354M1	2	Stud	M8X55
6	3710484M1	1	Stud	M8X50
7	3710133M1	1	Oil Seal	
8	4267576M1	1	Bolt	M8X85
9	4267575M1	1	Bolt	M8X75
10	4265990M1	1	Washer	08X16X1.2
11	3606214M1	1	Bolt	M8X75
12	4260467M1	2	Nut	
13	4267566M1	3	Bolt	M8X16
14	4267572M1	3	Bolt	M8X50
15	4267574M1	4	Bolt	M8X60
16	3702604M1	1	Clamp	
17	4267569M1	1	Bolt	
18	3756923M1	1	Washer	08X14X01
19	3606190M1	1	Stop	
20	3606191M1	1	Nut	
21	3606189M2	1	Ring	
22	3606192M2	1	Cap	
23	3758721M1	1	Packing	
24	3704257M1	1	Plug	
25	3710400M1	1	Pin	
26	3754238M1	2	Pin	
27	3710401M2	1	Pin	
28	4266261M1	1	Plug	M8X1.25
29	3756923M1	1	Washer	08X14X01
30	3710135M1	1	Pin	3X40
31	3710565M2	1	Gasket	
32	3605696M92	1	Pressure Valve	
33	3605697M2	1	Piston	
34	3710279M1	1	Spring	
35	3711702M1	1	Snapring	
36	3606188M1	1	Bolt	M6X40
37	3606193M1	1	Nut	
38	3606189M2	1	Ring	
39	4264303M2	1	Cap	
40	3710120M1	1	Bolt	M6
41	3710489M1	1	Nut	M6
42	3606142M92	1	Angle Trans.	
43	3708632M1	1	O Ring	
44	4267406M1	2	Bolt	M6X16
45	3710083M1	1	Blank Cover	
46	3710564M3	1	Plate	FRONT
47	3710566M2	1	Gasket	
48	3710482M1	4	Bolt	M8X16
49	3710169M1	1	Spacer	
50	3708634M1	1	O Ring	
51	3710137M2	2	Pin	
52	3704353M1	1	Stud	M8X22
53	3607143M92	1	Shaft	
54	339064X1	2	Bear. 6005	
55	3704361M1	4	Nut	M8
56	353446X1	4	Lock Washer	M8
57	3704361M1	4	Nut	M8
58	353446X1	4	Lock Washer	M8
59	4266254M91	1	Adapter	260X135
60	3710396M3	1	Arm	

3-IS10-011-A




Item	Part Number	Qty	Description	Comments
1	3710190M3	2	Hanger	
2	3704341M1	1	Bolt	
3	4265918M1	1	Bolt	M10X20

3-IS11-012-A



Item	Part Number	Qty	Description	Comments
1	4266230M2	3	Inlet Valve	
2	3710621M1	3	Exhaust Valve	
3	3710622M1	6	Spring	
4	3710254M1	6	Seat	
5	3710255M1	12	Cotter	
6	3710623M3	6	Tappet	
7	3710624M1	6	Pushrod	
8	3710625M92	1	Rocker Shaft Ass	
9	3710260M1	6	Rockerarm	(8)
10	3710627M92	1	Rocker Shaft Ass	(8)
11	3710264M1	2	Plug	(10)
12	3605679M2	2	Bracket	(8)
13	3605680M2	1	Bracket	(8)
14	3710138M1	2	Spring	(8)
15	3702421M1	2	Snapping	(8)
16	3710261M1	6	Adjusting Screw	(8)
17	3710126M1	6	Nut	(8)
18	3710108M1	1	Bolt	(8)
19	4267573M1	1	Bolt	
20	4260467M1	2	Nut	

3-IS12-011-A



Engine - Camshaft

Item	Part Number	Qty	Description
1	3710615M1	1	Camshaft
2	3710616M2	1	Gear
3	4266227M1	1	Key
4	3710619M1	1	Thrust Plate
5	3710478M1	2	Bolt
6	3710618M95	1	Gear



Suggest:

If the above button click is invalid.


Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading

I-IS13-003-A



<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>