

TT00101

KEY	PART NO.	PART NAME	QTY	REMARKS
1	LG224545	SHIELD	1	HEAT
2	LG391086S	SEAL	1	UPPER CRANK (SUB FOR LG391086)
3	LG690222	FLYWHEEL	1	(SUB FOR LG492326)
4	LG222561	OIL CUP	1	
5	LG225136	WASHER	1	(SUB FOR LG224061)
6	LG691323	SPACER	1	(SUB FOR LG280848)
7	LG691058	BOLT	2	(SUB FOR LG94627)
8	LG691927	FAN	1	(SUB FOR LG281355 OR LG281400)
9	LG224413	RETAINER	1	
10	LG690492	SCREEN	1	(SUB FOR LG224948)
11	LG94626	SCREW	3	
12	LG691802	VALVE SEAT	1	NLA; INTAKE (SUB FOR LG261463)
13	LG691844	VALVE SEAT	1	NLA; SUB FOR LG262924; Exhaust
14	LG271866S	GASKET	1	(SUB FOR LG271866)
15	LG494240	CYLINDER HEAD	1	(NLA)
16	LG690904	CAP SCREW	9	NLA; SUB FOR LG94622
17	LG494238	RESERVOIR	1	
18	LG692226	GASKET	1	0.38MM (.015"), (SUB FOR LG271916)
18	LG692406	GASKET	1	0.13MM (.015"), (SUB FOR LG271997)
18	LG692405	GASKET	1	0.23MM (.009"), (SUB FOR LG271996)
19	LG27803S	GASKET	1	(SUB FOR LG27803)
20	LG495735	BREATHER	1	
21	LG691328	TUBE	1	(SUB FOR LG281246)
22	LG691666	CAP SCREW	2	(SUB FOR LG94621)
23	LG692125	CAP SCREW	9	(SUB FOR LG94624)
24	15H623	PIPE PLUG	1	3/8", (SUB FOR LG94239 OR LG690946)
25	LG291675S	SEAL	1	LOWER CRANK (SUB FOR LG291675)
26	LG496413	CRANKCASE	1	NLA, (INCLUDES PARTS MARKED (A))
27	LG491986	BUSHING KIT	1	NLA; (A) Governor Shaft Bushing
28	LG399676	RING GEAR	1	(SUB FOR LG392134)
29	LG399265	BEARING	1	NLA; ORDER MIA11778; (A)
29	MIA11778	SEAL KIT	1	
30	LG691003	CAP SCREW	1	(A) (SUB FOR LG94623 OR LG94386)
31	AM119686	DRAIN VALVE	1	

<https://www.ebooklibonline.com>

Hello dear friend!



Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>


KEY	PART NO.	PART NAME	QTY	REMARKS	
32	M120777	CAP	1		
33	HOSE	1	(MAKE FROM TY22327)	
..	LG499362	LABEL KIT	1	ENGINE (SUB FOR LG491252)	
..	28M7071162	GASOLINE ENGINE	1	(13 HP), (SUB FOR 28M7070526A1 OR 2847071036E1)	



MP18608

KEY	PART NO.	PART NAME	QTY	REMARKS
1	LG222698S	SHAFT KEY	1	(SUB FOR LG222698)
2	LG262932	GEAR	1	
3	LG261961	GUIDE	1	NLA; Exhaust
4	LG231218	GUIDE	1	NLA; Intake
5	LG299691	PISTON PIN	1	(STD)
5	LG391286	PISTON PIN	1	.13 MM (.005") OS
6	LG394661	PISTON	1	(STD) (INCLUDES LG260924)
6	LG394663	PISTON	1	.50 MM (.020") OS
7	LG391780	PISTON RING KIT	1	(STD)
7	LG392331	PISTON RING KIT	1	NLA; STD (CHROME)
7	LG391782	PISTON RING KIT	1	.50 MM (.020") OS
8	LG691792	CLIP	2	(SUB FOR LG260924)
9	LG490348	CONNECTING ROD	1	.020" US, NLA, (STD)
9	LG490469	CONNECTING ROD	1	.50 MM (.020") US, NLA
10	LG281370S	SEAL	1	(SUB FOR LG68838 OR LG281370)
11	LG496113	TUBE	1	
12	LG270920	SEAL	1	
13	LG495230	FILLER CAP	1	
14	LG496415	TUBE	1	NLA
15	LG691968	GEAR	1	(SUB FOR LG490815)
16	M150337	GEAR	1	NLA; CAM (SUB FOR LG212897 OR LG692123)
17	LG691096	CAP SCREW	1	(SUB FOR LG94593)
18	LG298909	PIN	1	
19	LG399891	COUNTERWEIGHT	1	
20	LG691714	LINK	1	(SUB FOR LG213998)
21	LG498971	CRANKSHAFT	1	(SUB FOR LG495162)
22	M153303	SCREW	1	(SUB FOR LG94673 OR LG691658)
23	LG691779	EXTENSION	1	(SUB FOR LG231828)
24	LG691639	KEY	1	(SUB FOR LG94196)
25	LG691811	TAPPET	2	(SUB FOR LG262248)
25	LG691811	TAPPET	1	NLA; ORDERM123333
26	LG690656	RETAINER	1	NLA; SUB FOR LG221596
27	LG494553	RETAINER	1	NLA
28	LG691605	SPRING	1	NLA, (SUB FOR LG65906)

KEY	PART NO.	PART NAME	QTY	REMARKS	
29	LG691939	RETAINER	1	NLA; SUB FOR LG292260	
30	LG262247S	INTAKE VALVE	1	(SUB FOR LG262247)	
31	LG262246S	EXHAUST VALVE	1	SUB FOR LG262246; NLA	
32	LG691597	SPRING	1	NLA; SUB FOR LG26828	
33	37H73	SCREW	2		
34	LG691133	BOLT	2	NLA; (SUB FOR LG94671 OR LG95017)	
35	LG691588	LOCK	1	(PKG OF 2), (SUB FOR LG26026)	



TT00046



Suggest:

For more complete manuals. Please go to the home page.


<https://www.ebooklibonline.com>

If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading

John Deere > Turf And Utility >TRACTOR, LAWN AND GARDEN >SABRE - TRACTOR, LAWN AND GARDEN >SABRE 1338G, 1538H, 1546G, 1638HS, 1646H and EUROPRO 1338GS, 1538HX, 1546GS, 1646HS, Lawn Tractors >20 ENGINE 28M7071162, 28Q7770536E1, 28N7071135 >ST570458 - ENGINE GASKETS (13 HP)

KEY	PART NO.	PART NAME	QTY	REMARKS
1	LG494241	GASKET KIT	1	
2	LG391086S	SEAL	1	UPPER CRANKSHAFT (SUB FOR LG391086)
3	LG291675S	SEAL	1	LOWER CRANKSHAFT (SUB FOR LG291675)
4	LG691870	SEAL	1	DIPSTICK (SUB FOR LG270920)
5	LG281370S	SEAL	1	DIPSTICK TUBE (SUB FOR LG281370)
6	LG691917	GASKET	1	AIR CLEANER (SUB FOR LG281106)
7	LG692407	SEAL	1	CRANKCASE BREATHER TUBE (SUB FOR LG491323)
8	LG692226	GASKET	1	.38 MM (.015"), (SUB FOR LG271916)
8	LG692406	GASKET	1	.13 MM (.005"), (SUB FOR LG271997)
8	LG692405	GASKET	1	.23 MM (.009"), (SUB FOR LG271996)
9	LG271866S	GASKET	1	CYLINDER HEAD (SUB FOR LG271866)
10	LG27803S	GASKET	1	BREATHER (SUB FOR LG27803)
11	LG272554S	GASKET	1	INTAKE MANIFOLD (SUB FOR LG272554)



TT00123

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>