

MP19363

KEY	PART NO.	PART NAME	QTY	Serial No.	REMARKS
1	M150932	SHIELD	1		NLA, HEAT, (SUB FOR LG224545 AND LG690459)
2	LG391086S	SEAL	1		(A), UPPER CRANK, (SUB FOR LG391086)
3	LG693557	FLYWHEEL	1		(SUB FOR LG492326 AND LG690222)
4	LG222561	OIL CUP	1		
5	LG225136	WASHER	1		(SUB FOR LG224061)
6	LG691323	SPACER	1		(SUB FOR LG280848)
7	LG691058	BOLT	2		(SUB FOR LG94627)
8	M145401	FAN	1		NLA; SUB FOR LG281355, LG281400 AND LG691927
9	LG690452	RETAINER	1		(SUB FOR LG224413)
10	LG690492	HOUSING	1		(SUB FOR LG224948)
11	LG691655	CAP SCREW	3		NLA; SUB FOR LG94626
12	LG691802	VALVE SEAT INSERT	1		(A), INTAKE, (SUB FOR LG261463)
13	LG691844	VALVE SEAT INSERT	1		NLA; (A); SUB FOR LG262924; Exhaust
14	LG271866S	GASKET	1		(SUB FOR LG271866)
15	LG494240	CYLINDER HEAD	1		(NLA)
16	LG690904	CAP SCREW	9		NLA; SUB FOR LG94622
17	LG494238	RESERVOIR	1		ENGINE SUMP
18	LG692226	GASKET	1		.015" (0.381 MM), (SUB FOR LG271916)
18	LG692406	GASKET	1		.005" (0.127 MM), (SUB FOR LG271997)
18	LG692405	GASKET	1		.009" (0.229 MM), (SUB FOR LG271996)
19	LG27803S	GASKET	1		(SUB FOR LG27803)
20	LG495734	BREATHER	1		NLA
21	LG692253	STRUCTURAL TUBE	1		(SUB FOR LG280100)
22	LG691666	CAP SCREW	1		(SUB FOR LG94621)
23	LG692125	CAP SCREW	1		(SUB FOR LG94624)
24	15H623	DRAIN PLUG	1		
25	LG291675S	SEAL	1		LOWER CRANK, (SUB FOR LG291675)
26	LG496413	CRANKCASE	1		(INCLUDES PARTS MARKED (A))
27	LG491986	BUSHING KIT	1		NLA; (A); Governor Shaft Bushing
28	LG399676	RING GEAR	1		KIT (INCLUDES STARTING MOTOR PINION), (SUB FOR LG392134)
29	LG399265	BEARING	1		NLA; ORDER MIA11778; (A)
29	MIA11778	SEAL KIT	1		
30	LG94386	SCREW	1	____-095000	(SUB LG691003)

**<https://www.ebooklibonline.com>**

Hello dear friend!


Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

KEY	PART NO.	PART NAME	QTY	Serial No.	REMARKS
30	LG691003	CAP SCREW	1	095001-_____	(A), (SUB FOR LG94930)
31	AM123896	DRAIN VALVE	1		NLA
32	.....	HOSE	1		(CUT FROM PMK010-0812) (SUB FOR M96335)
33	19M7798	SCREW	1		M8 X 40, RH, FRONT
33	19M7897	SCREW	3		M8 X 35
34	14M7298	FLANGE NUT	4		M8
35	LG692407	SEAL	1		GOVERNOR SHAFT (INCLUDES M147497 BUSHING), (SUB FOR LG491323)
36	LG67218	FITTING	1		
37	M153303	SCREW	1		(SUB FOR LG94673 OR LG691658)
..	AM125646	GASOLINE ENGINE	1		(EPA/CARB CERTIFIED) (ENGINE MARKED 28M707- 1147-E1), (SUB FOR AM123891) (SUB AM126483 ) (ALSO ORDER AM126528)
..	LG499362	LABEL KIT	1		NLA (SUB FOR LG491252)



MP30334



**Suggest:**


**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

KEY	PART NO.	PART NAME	QTY	Serial No.	REMARKS
1	LG691639	KEY	1		(SUB FOR LG94196)
2	LG691284	GEAR	1		TIMING, (SUB FOR LG262932)
3	LG261961	GUIDE	1		NLA; Exhaust Valve
4	LG231218	GUIDE	1		NLA; Intake Valve
5	LG498319	PISTON PIN	1		STD, (SUB FOR LG299691)
5	LG391286	PISTON PIN	1		0.127 MM (.005") OS
6	LG499284	PISTON REPLACEMENT KIT	1		STD, (SUB FOR LG394661 OR LG499282)
6	LG499292	PISTON REPLACEMENT KIT	1		0.50 MM (.020") OS, NLA; (SUB FOR LG499290 OR LG394663)
7	LG499996	PISTON RING KIT	1		STD, (SUB FOR LG391780)
7	LG392331	PISTON RING KIT	1		NLA; STD, (CHROME)
7	LG499998	PISTON RING KIT	1		0.50 MM (.020") OS, NLA, (SUB FOR LG391782)
8	LG691792	LOCK	2	____-095000	(SUB FOR LG260924)
8	LG691299	LOCK	2	095001-____	(SUB FOR LG263129)
9	LG490348	CONNECTING ROD	1		NLA, STD
9	LG490469	ROD	1		0.50 MM (.020") OS, NLA
10	LG691597	SPRING	1		NLA; SUB FOR LG26828
11	LG262246S	EXHAUST VALVE	1		SUB FOR LG262246; NLA
12	LG262247S	INTAKE VALVE	1		NLA (SUB FOR LG262247)
13	LG691939	RETAINER	1		NLA; SUB FOR LG292260
14	LG691133	BOLT	2		(SUB FOR LG94671 OR LG95017)
15	LG691968	GEAR	1		GOVERNOR, (SUB FOR LG490815)
16	M150337	GEAR	1		NLA; CAM, (SUB FOR LG212897 OR LG692123)
17	LG691096	CAP SCREW	1		(SUB FOR LG94593)
18	LG298909	PIN	1	____-095000	
18	LG691239	PIN FASTENER	1	095001-____	NLA; (SUB FOR LG230787)
19	LG692423	COUNTERWEIGHT	1		(SUB FOR LG399891, LG691973 OR LG499994)
20	LG691714	LINK	1		(SUB FOR LG213998)
21	AM129705	CRANKSHAFT	1		(INCLUDES LG692423) (SUB FOR LG498971)
22	LG494553	RETAINER	1		NLA
23	LG65906	SPRING	1		
24	LG222698S	SHAFT KEY	1		(SUB FOR LG222698)
25	LG691811	TAPPET	2		NLA; (SUB FOR LG262248)
26	LG690656	RETAINER	1		NLA; SUB FOR LG221596)



TT00103

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**