

# **300 Auger Platform Grass Seed Special**

(Serial No. 915001- )

**John Deere Ottumwa Works  
OME81748 Issue H1**

LITHO IN U.S.A.  
ENGLISH

# Introduction

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction the implement will travel when going forward.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Specification section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers

when you order parts. File the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty applicable to your machine may not apply outside the U.S.



*300 Auger Platform Grass Seed Special*

EX,300GS,IFCOM -19-03JUL91

# Checklists

## DEALER'S RECORD

Owner's Name \_\_\_\_\_ Date Sold \_\_\_\_\_  
Address \_\_\_\_\_ Model Number \_\_\_\_\_  
City \_\_\_\_\_ Serial Number \_\_\_\_\_  
State \_\_\_\_\_ Zip \_\_\_\_\_

EX,300GSU,A -19-03JUN91

## PREDELIVERY

After auger platform has been assembled, be sure it is in good running order before delivering to the customer. The following checklist is a reminder of points to inspect. Check off each item after it is found satisfactory or after the proper adjustment is made.

- All grease fittings have been lubricated and gear case filled. (See Lubrication and Maintenance section in operator's manual.)
- Remove shipping plugs from both knife drive cases and install breather plugs. Check knife drive case mounting bolts and knife drive arm nut torque.
- All moving parts are working freely.

- Check auger and reel speed and position.
- Check all chains for proper installation and adjustment.
- Check tension of both knife drive belts and adjust if necessary.
- Platform has been run and bearings are not heating.
- Slip the auger clutch. (See Slipping Auger Clutch in Service section of operator's manual.)
- Check reel drive clutch. (See Adjusting Reel Clutch in Service section of operator's manual.)

\_\_\_\_\_  
(Date set up)

\_\_\_\_\_  
(Signature)

EX,300GSU,B -19-03JUN91

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

Checklists

**DELIVERY**

The following checklist is a reminder of very important information which should be conveyed directly to the customer at the time the auger platform is delivered. Check off each item as it is fully explained.

- Advise customer that life expectancy of the auger platform, like any other machine, is dependent upon regular lubrication as described in the operator's manual.
- Advise customer of optional attachments that are available for special crop and operating adjustments.

- Give operator's manual to the customer and explain all operating adjustments fully.
- Advise customer of safety precautions that must be exercised while using the auger platform. (See Safety section.)
- When auger platform is transported on a road or highway at night or during the the day, accessory lights and devices should be used for adequate warning to operators of other vehicles. In this regard, tell customers to check local governmental regulations.

\_\_\_\_\_  
(Date Delivered)

\_\_\_\_\_  
(Signature)

EX,300GSU,C -19-04JUN91

Checklists

**AFTER SALE**

It is suggested the following items be checked sometime during the first season's operation.

- Go over entire machine for loose or missing hardware.
- Check for broken or damaged parts.
- Check operating adjustments.
- All chains and belts are properly tensioned.

- Make sure all safety shields are in place.
- If possible, run the platform to see if it is functioning properly.
- Review the entire operator's manual with the customer and stress the importance of proper and regular lubrication and safety precautions.

\_\_\_\_\_  
(Date Checked)

\_\_\_\_\_  
(Signature)

EX\_300GSU,D -19-04JUN91



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

*Checklists*

# Contents

	Page		Page
<b>Safety</b> .....	05-1	Adjusting Auger to Stripper Clearance .....	35-7
<b>Transporting</b> .....	10-1	Adjusting Auger Slip Clutch .....	35-7
<b>Operating the Auger Platform</b>		Slipping Auger Slip Clutch .....	35-8
Before Operating Checks .....	15-1	Adjusting Reel Clutch .....	35-9
Breaking In the Auger Platform .....	15-1	Adjusting Reel Vertically .....	35-10
Determining Starting and Ground Speed .....	15-2	Adjusting Reel Front-To-Rear .....	35-10
Knife Overlap .....	15-2	Adjusting Cam .....	35-11
Producing Uniform Windrows .....	15-3	Adjusting Cam Followers .....	35-12
Cutterbar .....	15-3	Replacing Reel Teeth in Right-Hand and Center Section .....	35-13
Knife Hold-Downs .....	15-4	Replacing Reel Teeth in Left-Hand Section .....	35-14
Platform Guard Angle and Gauge Shoes .....	15-4	Adjusting Knife Drive Belt (Both Sides) .....	35-16
Reel .....	15-5	Removing Knives .....	35-16
Auger .....	15-6	Installing Non-Clog Guards .....	35-17
Platform Float .....	15-6	Installing Center Knife Sections on L.H. and R.H. Cutterbars .....	35-19
Ground Speed .....	15-7	Adjusting Cutterbar .....	35-19
Cutting Grass .....	15-8	Adjust Non-Clog Knife Hold-Downs .....	35-20
Adjusting Platform Float .....	15-9	Cutterbar Knife Sections .....	35-21
Adjusting Platform Guard Angles .....	15-9	Sharpening Knife Sections .....	35-21
<b>Attachments</b>		Installing Knives .....	35-22
Cutterbar Knife Sections .....	20-1	Adjusting Gauge Shoes .....	35-22
Deck Sheets .....	20-1	Replacing Auger Drive Chain .....	35-22
<b>Lubrication and Maintenance</b> .....	25-1	<b>Storage</b> .....	40-1
<b>Troubleshooting</b> .....	30-1	<b>Crime Prevention Tips</b> .....	45-1
<b>Service</b>		<b>Assembly</b> .....	50-1
Practice Safe Service Procedures .....	35-1	<b>Specifications</b> .....	55-1
Tightening Bearing Locking Collars .....	35-1	<b>Index</b>	
Installing O-ring Connector Link .....	35-1		
Care of Chains .....	35-2		
Care of V-Belts .....	35-3		
Auger and Reel Speeds .....	35-4		
Changing Auger Speed .....	35-4		
Adjusting Auger Drive Chain Tension .....	35-5		
Changing Reel Speed .....	35-5		
Adjusting Reel Drive Chain Tension .....	35-6		
Adjusting Auger to Deck Clearance .....	35-6		

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

OME81748 H1-19-03JUL91

COPYRIGHT© 1991  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION™ Manual

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**