


# **710 and 720 Mower-Conditioners**

(Serial No. 101121- )

**John Deere Ottumwa Works  
OME88512 Issue K5  
(Mark old manual OME85380 C5 for  
machines up to Serial No. 101120)**

LITHO IN U.S.A.  
ENGLISH



*John Deere 720 Mower-Conditioner*

-UN-15MAR95  
E38232

**READ THIS MANUAL** carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

**THIS MANUAL SHOULD BE CONSIDERED** a permanent part of your machine and should remain with the machine when you sell it.

**MEASUREMENTS** in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

**RIGHT-HAND AND LEFT-HAND** sides are determined by facing in the direction the implement will travel when going forward.

**WRITE PRODUCT IDENTIFICATION NUMBERS** (P.I.N.) in the Specification section. Accurately record all the numbers to help in tracing the machine should

it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

**WARRANTY** is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

**THE TIRE MANUFACTURER'S** warranty applicable to your machine may not apply outside the U.S.

# Contents

	Page		Page
<b>Safety</b> .....	1	Operating Tips for Making 180 Degree Turn .....	33
<b>Safety Signs</b> .....	9	Producing Uniform Windrows	
<b>Preparing the Tractor</b>		Cutterbar .....	35
Checking Ballast .....	11	Knife Hold-Downs .....	35
Selecting Tractor PTO Speed .....	11	Platform Guard Angle .....	36
Using Drawbar Shield .....	11	Gauge Shoes .....	36
<b>Preparing the Mower-Conditioner</b>		Reel .....	36
Checking Tire Inflation .....	12	Conditioner .....	36
Checking Wheel Bolt Torque .....	12	Platform Float .....	37
Cutterbar Knife Storage .....	12	Ground Speed .....	37
Installing Hydraulic Cylinder .....	13	Cutting	
Routing Hydraulic Hose .....	14	Alfalfa .....	38
<b>Attaching and Detaching</b>		Grass .....	39
Adjusting the Drawbar .....	16	Tall Crop .....	40
Adjusting Mower-Conditioner Hitch Clevis .....	17	Dirt and Mud Buildup .....	40
Determining Need For Turn Limiters .....	19	Adjusting Windrow Width .....	40
Installing Narrow Turn Limiters .....	20	Adjusting Gauge Shoes .....	41
Installing Wide Turn Limiters .....	21	Adjusting Cut Height .....	42
Attaching to Tractor Drawbar .....	22	Adjusting Cutterbar Angle .....	43
Attaching PTO Driveline .....	22	Adjusting Platform Float .....	45
Installing Safety Chain .....	23	Adjusting Reel Speed .....	46
Attaching to Tractor Hydraulic System .....	23	Adjusting Reel Cam .....	48
Storing Jackstand .....	23	Adjusting Conditioner Roll Pressure .....	49
Attaching Tongue Positioner Rope .....	24	Adjusting Roll Spacing .....	50
Detaching Mower-Conditioner from Tractor .....	24	<b>Attachments</b> .....	52
<b>Transporting</b> .....	25	<b>Lubrication and Maintenance</b> .....	56
<b>Operating the Mower-Conditioner</b>		<b>Troubleshooting</b> .....	63
Prestarting Checks .....	28	<b>Service</b>	
Breaking in the Mower-Conditioner .....	29	Practice Safe Service Procedures .....	67
Starting and Driving .....	29	Unplugging Machine .....	67
Positioning Tongue for Field Operation .....	30	Adjusting Wheel Bearing .....	68
Operating Tips for Making Right-Hand Turn .....	31	Care of Chains .....	68
		Adjusting Reel Drive Chain .....	68
		Installing Reel Speed-Up Sprocket .....	69
		Adjusting Reel Drive Belt .....	71
		Adjusting Cutterbar Drive Belt .....	72

Continued on next page

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

OME88512 K5-19-09NOV95

COPYRIGHT© 1995  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION™ Manual

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

Contents

	Page	
Replacing Reel Drive Belt . . . . .	73	
Replacing Cutterbar Drive Belt . . . . .	73	
Adjusting Cam Followers . . . . .	77	
Adjusting or Replacing Wear Pad for Float Spring Bolt . . . . .	77	
Adjusting Slip Clutch . . . . .	78	
Replacing Slip Clutch Lining . . . . .	78	
Slipping the Clutch . . . . .	82	
Replacing Reel Teeth . . . . .	83	
Removing Knives . . . . .	86	
Installing Knives . . . . .	86	
Replacing Bolt-On Knife Sections . . . . .	86	
Installing Regular Cutterbar Parts . . . . .	87	
Installing Non-Clog Cutterbar Parts . . . . .	90	
Adjusting Regular Knife Hold-Downs . . . . .	91	
Adjusting Non-Clog Knife Hold-Downs . . . . .	92	
Changing Tire . . . . .	93	
 <b>Storage</b>		
Storing Mower-Conditioner . . . . .	94	
Removing Mower-Conditioner From Storage . . . . .	95	
 <b>Specifications</b>		
Inch Bolt and Cap Screw Torque Values . . . . .	96	
Metric Bolt and Cap Screw Torque Values . . . . .	97	
Specifications . . . . .	98	
Record Serial Numbers . . . . .	99	
 <b>Crime Prevention Tips</b> . . . . .		100
 <b>Index</b>		

# Safety

## RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-03MAR93

T81389 -UN-07DEC68

## UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93

TS187 -19-30SEP88

## FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-03MAR93


TS201 -UN-23AUG88



## KEEP RIDERS OFF MACHINE

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.



DX,RIDER -19-03MAR93


TS290 -UN-23AUG88

## PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

TS291 -UN-23AUG88


## WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



DX,WEAR -19-10SEP90

TS206 -UN-23AUG88




## HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



DX,MSDS,NA -19-03MAR93

TS1132 -UN-26NOV90

## STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



DX,PTO -19-12SEP95


TS1644 -UN-22AUG95



## USE SAFETY LIGHTS AND DEVICES

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use hand signals or turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible and in good working order. Replace or repair lighting and marking that has been damaged or lost. An implement safety lighting kit is available from your John Deere dealer.



DX,FLASH -19-12SEP95


TSS951 -UN-12APR90

## USE A SAFETY CHAIN

A safety chain will help control drawn equipment should it accidentally separate from the drawbar.

Using the appropriate adapter parts, attach the chain to the tractor drawbar support or other specified anchor location. Provide only enough slack in the chain to permit turning.

See your John Deere dealer for a chain with a strength rating equal to or greater than the gross weight of the towed machine. Do not use safety chain for towing.



DX,CHAIN -19-03MAR93

TSS217 -UN-23AUG88




## TOW LOADS SAFELY

Stopping distance increases with speed and weight of towed loads, and on slopes. Towed loads with or without brakes that are too heavy for the tractor or are towed too fast can cause loss of control. Consider the total weight of the equipment and its load.

Observe these recommended maximum road speeds, or local speed limits which may be lower:

- If towed equipment does not have brakes, do not travel more than 32 km/h (20 mph) and do not tow loads more than 1.5 times the tractor weight.
- If towed equipment has brakes, do not travel more than 40 km/h (25 mph) and do not tow loads more than 4.5 times the tractor weight.

Ensure the load does not exceed the recommended weight ratio. Add ballast to recommended maximum for tractor, lighten the load, or get a heavier towing unit. The tractor must be heavy and powerful enough with adequate braking power for the towed load. Use additional caution when towing loads under adverse surface conditions, when turning, and on inclines.



TS216 -UN-23AUG68

DX,TOW

-19-02OCT95



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**



## PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



DX,SERV -19-03MAR93

TS218 -UN-23AUG88

## REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

TS220 -UN-23AUG88



## AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



DX,TORCH -19-03MAR93

TS953 -UN-15MAY90


## AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID -19-03MAR93

X9811 -UN-23AUG88

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**