

**OPERATOR'S MANUAL**

# **MANURE SPREADER**

**MS2320**

**MS2326**



**HSMFG1212**

**5HPMSSD2026**



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

# **CONTENTS**

Table of Contents .....	1
Warranty & Notes .....	2
Dealer Pre-Delivery Checklist .....	3
Dealer Delivery Checklist .....	5
Specifications .....	7-8
Be Alert Symbol .....	9
Explanation of Safety Signs .....	10
Danger - Warning Signs .....	11-12
Warning - Owner Must Read and Understand .....	13
Bolt Torque Chart .....	14
Set-Up & Assembly .....	15
Transporting .....	16
Storage .....	17
Preparing for Operation .....	17-19
Operation .....	20-25
Adjustments .....	26-27
Service .....	28-29
Optional Features & Accessories .....	30
Lubrication Guide .....	31-34
Troubleshooting Guide .....	35
Decal Location & Identification .....	36-38
Instructions for Ordering Parts - About Improvements .....	39
Parts .....	40-79
Service and Parts Notes .....	80

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**