




PARTS CATALOGUE


580SR



0.040(01) CYLINDER BLOCK

Ref	Part Number	Qty	Description
1	2830082	1	CYLINDER BLOCK, , Includes 2 To 7
2	4899026	10	DOWEL,
3	4895039	3	PLUG,
4	4895038	4	PLUG,
5	4895228	2	PLUG,
6	4891353	10	SCREW, 12X120
7	4895040	1	BUSHING,

0.040(02) CYLINDER BLOCK



<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.





<https://www.ebooklibonline.com>

580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.040(02) CYLINDER BLOCK

Ref	Part Number	Qty	Description
1	4894218	4	SCREW,
2	4895605	1	PLUG, 14x1.5 , Includes 3
3	4899115	1	O-RING,
4	4899009	1	PLUG, 10x1.5 , Includes 5
5	4899072	1	O-RING,
6	4895392	2	PLUG, 18x1.5, Includes 7
7	4895393	1	O-RING,
8	4895049	2	DOWEL,
9	4895180	8	TAPPET,
10	504047260	4	NOZZLE, LUB. OIL JET,

0.042(01) OIL PUMP, PAN




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.042(01) OIL PUMP, PAN

Ref	Part Number	Qty	Description
1	4899020	2	SCREW, 8x20
2	4899091	22	SCREW,
2	4895489	2	SCREW,
3	4898301	1	GASKET,
4	504043550	1	PAN, ENGINE OIL,
5	4895584	1	GASKET,
6	4894139	1	PLUG, 22x1.5
7	504069777	1	GASKET,
8	504062812	1	SPACER,
9	504051893	1	STRAINER ASSY.,
10	4895538	1	SCREW,


0.043(01) CYLINDER BLOCK - COVERS



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.043(01) CYLINDER BLOCK - COVERS

Ref	Part Number	Qty	Description
1	4899026	2	DOWEL,
2	4899091	4	SCREW,
3	4899093	5	SCREW,
4	4899073	2	SCREW,
5	504050848	1	COVER,
6	504074001	1	COVER,
7	17278780	1	O-RING,
8	4895355	2	SCREW, 5x17




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.043(02) CYLINDER BLOCK - COVERS

Ref	Part Number	Qty	Description
1	4897024	1	COVER,
2	4899078	5	SCREW,
3	4899063	8	SCREW, M8x30
4	4890832	1	GASKET,
5	4891209	2	DOWEL,


0.043(03) CYLINDER BLOCK - COVERS



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.043(03) CYLINDER BLOCK - COVERS


Ref	Part Number	Qty	Description
1	4899026	2	DOWEL,
2	4899109	3	SCREW, M10x1.5x80
3	4899075	8	SCREW, M10x1.5x40
4	4895378	2	PLUG,
5	4895379	2	O-RING,
6	4899076	5	SCREW, M12x80
7	4899074	2	SCREW,
8	4890833	1	GASKET,
9	4899103	2	SCREW,
10	504069775	1	COVER,
11	4895358	1	COVER,
12	504030423	1	COVER,
13	4899020	1	SCREW, M8x20
13	504062964	2	SCREW,
14	4895079	1	PLUG,



0.045(01) BREATHER - ENGINE

Ref	Part Number	Qty	Description
1	504069558	1	BREATHER,
2	500315795	1	GASKET,
3	4899110	3	SCREW,

0.060(01) CYLINDER HEAD




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.060(01) CYLINDER HEAD

Ref	Part Number	Qty	Description
1	4892861	4	SCREW,
2	4892859	10	SCREW,
3	4895790	1	CYLINDER HEAD, , Includes 12, 13, 14
4	4895183	16	COTTER, ROCKER ARM,
5	4895188	4	VALVE, ENG EXHAUST, STD,
6	4895187	4	VALVE, ENGINE, INLET, STD,
7	4895347	8	CUP,
8	4895215	8	SPRING,
9	4895184	8	CUP,
10	4899009	1	PLUG, 10X1.5, Includes 11
11	4899072	1	O-RING,
12	4895179	3	PLUG,
13	4897178	4	VALVE SEAT,
14	4897179	4	VALVE SEAT,
15	2830919	1	GASKET, CYLINDER HEAD, SP= 1.25
16	4895078	5	PLUG,


0.063(01) CYLINDER HEAD - COVERS



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.063(01) CYLINDER HEAD - COVERS

Ref	Part Number	Qty	Description
1	4895360	4	BUSHING,
2	16784504	4	SCREW,
3	4895214	4	SCREW,
4	504065040	2	COVER,
5	2830775	1	BAFFLE ASSY.,
6	504053522	4	GASKET,
7	2830784	1	COVER, , Includes 2, 5




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.066(01) CYLINDER HEAD - VALVE MECHANISM

Ref	Part Number	Qty	Description
1	4895195	4	ROCKER ARM, , Includes 5, 6, 7, 11, 12
2	4895361	8	ROD, PUSH,
3	4895193	4	SCREW,
4	4892860	4	SCREW,
5	4895363	2	RING,
6	4895364	2	WASHER,
7	4895196	1	ROCKER ARM, , Includes 8, 9, 10
8	4895365	2	SPACER,
9	4895198	2	NUT,
10	4895199	2	SCREW,
11	4895200	1	ROCKER ARM, , Includes 8, 9, 10
12	4895204	1	SUPPORT,


0.071(01) MANIFOLD - INTAKE



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.071(01) MANIFOLD - INTAKE


Ref	Part Number	Qty	Description
1	504064865	1	COVER,
2	4899039	6	SCREW, 8x1.25x25
3	504063980	2	SLEEVE,
4	4895648	1	SPACER,
5	4899921	2	GASKET,
6	504052006	1	HOSE ASSY.,
7	4895294	4	SCREW, 8x140
8	4899629	2	COLLAR, RETAINER,



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.077(01) MANIFOLD - EXHAUST

Ref	Part Number	Qty	Description
1	4895273	1	
2	2830445	4	GASKET,
3	4895174	8	SCREW,
4	4895336	8	SPACER,
5	4899119	4	STUD,




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.080(01) CRANKSHAFT

Ref	Part Number	Qty	Description
1	504048350	1	CRANKSHAFT, , Includes 2
2	4893386	1	GEAR,
4	2992147	4	SET, CONN ROD BRGS (STD), (- 0.000) (- 0.000)
4	2992148	4	SET OF MAIN BRGS -0.254, (- 0.254) (- 0.250)
4	2992149	4	SET, CONN ROD BRGS (STD), (- 0.508) (- 0.500)
3	2992153	1	SET, CONN ROD BRGS (STD), (+ 0.000) (+ 0.000)
3	2992154	1	SET, CONN ROD BRGS (STD), (+ 0.254) (+ 0.250)
3	2992155	1	BEARING, THRUST, (+ 0.508) (+ 0.500)

0.081(01) PISTONS - CONNECTING ROD




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.081(01) PISTONS - CONNECTING ROD

Ref	Part Number	Qty	Description
1	4895748	4	ROD, CONNECTING, , Includes 2, 3
2	4892708	1	BUSHING,
3	4892707	2	SCREW,
4	8093882	4	SET, CONN ROD BRGS (STD),


0.082(01) PISTONS - CONNECTING ROD



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.082(01) PISTONS - CONNECTING ROD

Ref	Part Number	Qty	Description
1	8093880	4	KIT, PISTON & RINGS, , Includes 2, 3, 4
2	4892712	1	PIN, PISTON,
3	4892713	2	RING, LOCKING,
4	8093881	1	KIT, PISTON RINGS,




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.083(01) FLYWHEEL - ENGINE

Ref	Part Number	Qty	Description
1	504057736	1	FLYWHEEL, , Includes 2
2	504062460	1	GEAR, RING,
3	4894641	8	SCREW,


0.084(01) PULLEY - CRANKSHAFT



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.084(01) PULLEY - CRANKSHAFT


Ref	Part Number	Qty	Description
1	504035087	1	PULLEY,
2	4892867	6	SCREW,
3	504061622	1	PULLEY,



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.105(01) DYNAMIC BALANCER, GEARS & SHAFTS

Ref	Part Number	Qty	Description
1	16866473	1	CIRCLIP,
2	4897123	1	PLATE, THRUST,
3	4897071	16	BUSHING,
4	4897048	1	GEAR, DRIVEN,
5	4896947	1	GEAR, DRIVEN,
6	4895586	3	SCREW,
7	2830433	4	SCREW,
8	2831031	1	SHAFT, IDLE,
9	2831023	2	SHAFT,
10	2830952	1	HOUSING, , See Page 0.105
11	4899109	7	SCREW,
11	4897934	1	SCREW,
12	2830953	1	BALANCER, , Includes 1 to 11




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.105(02) DYNAMIC BALANCER, GEARS & SHAFTS (2830952)

Ref	Part Number	Qty	Description
1	4892836	1	DOWEL,
2	4899027	2	DOWEL,
3	2830948	1	SHAFT, IDLE,
4	2830905	1	PLATE, THRUST,
5	2830934	1	HOUSING,
6	2831101	1	HOUSING, , Includes 7
7	4891209	2	DOWEL,
8	2830411	3	SCREW,
8	4895323	9	SCREW,

0.120(01) CAMSHAFT




580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.120(01) CAMSHAFT

Ref	Part Number	Qty	Description
1	4895323	6	SCREW,
2	504062752	1	GEAR,
3	4899068	2	SCREW, 8x17
4	4897457	1	FLANGE,
5	4899610	1	CAMSHAFT, , Includes 6
6	4899080	1	DOWEL,
7	504034954	1	GEAR, DRIVEN,


0.140(01) FUEL INJECTION PUMP



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.140(01) FUEL INJECTION PUMP

Ref	Part Number	Qty	Description
1	504063450	1	PUMP, FUEL, - ASSY
2	504032877	1	SENDER UNIT,
3	504060728	1	CONNECTOR, WIRE,
4	16979231	2	NUT,



580SR CASE SUPER-R BACKHOE LOADER (1/04-)

0.140(02) FUEL INJECTION SYSTEM

Ref	Part Number	Qty	Description
1	500390441	4	INJECTOR, FUEL SYSTEM,
2	4895297	4	GASKET,



Suggest:

If the above button click is invalid.


Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading

0.142(01) FUEL INJECTION SYSTEM



<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>