

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM

RS42\00040824.png

A-05  
01




A0501

Engine assembly

Inglese

1 3694367M91

John deere 4024h 1 Engine



Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041934.png


A-05  
02



A0502

Cylinder head cover



- 1 3695081M1
- 2 3695082M1
- 3 
- 4 
- 5 
- 6 
- 7 3695085M1
- 8 6516758M1
- 9 3695087M1
-  Not serviced, order

Inglese

- 7 Screw
- 7 Ring
- 1 Note plate
- 1 Screw
- 1 Cover
- 1 Gasket
- 2 Screw
- 1 Gasket
- 1 Plug

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM

RS42\00041935.png

A-05  
03




A0503

Pulley

Inglese

- |   |            |   |        |
|---|------------|---|--------|
| 1 | 3695090M1  | 1 | Screw  |
| 2 | 3695094M1  | 1 | Ring   |
| 3 | 3695113M91 | 1 | Kit    |
| 4 | 3695092M1  | 1 | Washer |
| 5 | 3695093M1  | 1 | Pulley |



**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041936.png

A-05  
04



A0504

Injection pump assy



		Inglese
1	➡	2 Screw
2	➡	2 Washer
3		4 Screw
4	➡	1 Cover
5	➡	1 Gasket
6	➡	1 Clamp
7	➡	1 Cable
8	➡	1 Screw
9	➡	1 Stirrup
10		1 Dowel
11	➡	4 Screw
12		4 Washer
13	➡	4 Clamp
14		1 Kit
15		4 Nozzle
16	➡	4 Screw
17	➡	4 Clamp
18		1 Kit
19		4 Pump
20	➡	4 Pipe
➡		Not serviced, order

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041937.png

A-05  
05



A0505

Oil sump



- 1 3695117M1
  - 2 6516764M1
  - 3 
  - 4 3695134M1
  - 5 3695133M1
  - 6 
  - 7 3695135M91
  - 8 3695132M1
  - 9 3695131M1
  - 10 6519990M1 A
-  Not serviced, order  
A For engine oil sump

Inglese

- 2 Ring
  - 1 Pipe
  - 2 Screw
  - 1 Pan
  - 18 Screw
  - 1 Ring
  - 1 Plug
  - 1 Screw
  - 1 Connector
- 999

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM



RS42\00041938.png

A-05  
06



A0506

Water pump and thermostat



Inglese

- |   |            |   |                  |   |             |
|---|------------|---|------------------|---|-------------|
| 1 | 3695136M1  | ● | 3695136M92(1), N | 1 | Valve       |
| 2 | 3695137M91 | ● | 3695136M92(1)    | 1 | Pump        |
| 3 | 3695756M1  |   |                  | 5 | Screw       |
| 4 | 3695118M1  |   |                  | 1 | Thermostat  |
| 5 |            | ! | 4                | 1 | Ring        |
|   |            | ➡ | Ref.n.4          |   |             |
| 6 | 6510083M91 | A |                  |   | 999 Loctite |
- ! This is a component of an assembly  
➡ Not serviced, order  
● Replacement  
A Water pump

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041939.png

A-05  
07



A0507

Fan drive



		Inglese
1	A	1 Throttle
2	A	1 Washer
3	A	1 Nut
4	3695230M1	1 Screw
5	3695229M1 → 006898	1 Screw
5	6516765M1 → 006899	1 Screw
6	3695228M1 → 006898	1 Ring
6	6516766M1 → 006899	1 Washer
7	→ 006898	1 Pinion
	↳ 6516765m1-6516767m1	
7	6516767M1 → 006899	1 Pulley
8	6504381M1	1 Belt
9	6516769M1	1 Pipe
10	3695804M1	1 Ring
11	3695242M1	1 Union
→ From serial or engine number		
→ Up to serial or engine number		
↳ Not serviced, order		
A To be advised		

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM




RS42\00041940.png

A-05  
08




A0508

Exhaust manifold

- 1 
- 2 
- 3 6516768M1
- 4 3695235M1
-  Not serviced, order

Inglese

- 8 Screw
- 8 Spacer
- 1 Manifold
- 4 Gasket



Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041941.png

A-05  
09



A0509

Starter motor



- |   |            |   |               |   |              |
|---|------------|---|---------------|---|--------------|
| 1 | 3692551M91 | ● | 3692551M92(1) | 1 | Startermotor |
| 2 |            | ▣ |               | 2 | Screw        |
| 3 |            | ▣ |               | 1 | Cable        |
| 4 | 3695171M1  |   |               | 1 | Nut          |
| 5 | 3695246M1  |   |               | 1 | Washer       |
| 6 |            | ▣ |               | 1 | Decal        |
- ▣ Not serviced, order  
● Replacement

Inglese

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041942.png

A-05  
10



A0510

Alternator



- 1 3695246M1
- 2 3695171M1
- 3 3695249M1
- 4 3695250M1
- 5 3695251M1
- 6 3695252M1

Inglese

- 1 Washer
- 1 Nut
- 1 Harness
- 1 Harness
- 1 Alternator
- 2 Screw

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM

RS42\00043437.png

A-05  
105




A05105

Support

- 1 A
- 2 6518970M1
- 3 A
- A To be advised

Inglese

- 1 Screw
- 1 Support
- 1 Screw



Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041943.png

A-05  
11



A0511

Fuel filter



		Inglese	
1	6506792M91		1 Filter
2		☛	1 Kit
		! 1	
3	6516770M91	! 1	1 Kit
4	6516831M91	! 1	1 Kit
5		☛	1 Valve
		! 1	
6	4220245M91	! 1	1 Filter
7		☛	1 Filter
8	3695259M1		2 Clamp
9		☛	1 Pipe
10		☛	2 Union
11		☛	2 Union
12	3695802M1		2 Screw
13		☛	1 Stirrup
14		☛	4 Clamp
15		☛	1 Pipe
16		☛	1 Ring
17		☛	1 Union
18		☛	1 Pipe
19		☛	1 Ring
20		☛	1 Pipe
21		☛	2 Screw

! This is a component of an assembly  
☛ Not serviced, order

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM



RS42\00041944.png

A-05  
12




A0512

Fuel pump

- 1 3695132M1
- 2 
- 3 6516832M91
-  Not serviced, order

Inglese

- 2 Screw
- 1 Kit
- 1 Pump



Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00041945.png

A-05  
13




A0513

Oil dipstick

- 1 6515860M91
- 2 6516834M1
- 3  Not serviced, order

Inglese

- 1 Rod
- 1 Extension
- 1 Plug



Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM

RS42\00041946.png

A-05  
14




A0514

Thermostarter

Inglese

- 1 
- 2 3695288M1
- 3 3695290M1
- 4 3695289M1
- 5 3695291M1
-  Not serviced, order

- 1 Cable
- 1 Ring
- 1 Lock
- 1 Connection
- 4 Spark plug



Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00043150.png

**A-05  
15**



A0515

Distribution cover



1	6518284M91		
2	6518285M1	!	13
3		!	1
		➡	Ref.n.1
4		!	1
		➡	Ref.n.1
5	3695744M91	!	13
6	3695741M1	!	13
7	3695747M1	!	13
8	3695750M1	!	13
9	3695752M1	!	13
10	3695753M1	!	13
11	3695754M1	!	13
13	6516835M91	!	1
14		A	
15	3695756M1		

! This is a component of an assembly  
➡ Not serviced, order  
A To be advised

**Inglese**

1	Coperch.
1	Gasket
6	Screw
1	Oil pump
4	Plug
4	Ring
1	Valve seat
1	Valve
1	Spring
1	Plug
1	Ring
1	Coperch.
1	Screw
1	Screw

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM

RS42\00043181.png

A-05  
16




A0516

Cylinder block

1 6518400M91

Inglese

1 Kit



Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00043182.png

**A-05  
17**



A0517

Cylinder block



		Inglese
1		1 Cylinder block
		A-05 16 1
2	!	1 Dowel
		Ref.n.1
3	!	1 Plug
		Ref.n.1.
4		2 Dowel
5	!	24 Plug
		Ref.n.1
6		1 Plug
7		2 Dowel
8		1 Dowel
9		6 Ring
10		8 Screw
11		2 Screw
12		4 Needle
13		4 Bush
14		1 Ring
15		4 Bush
16		2 Screw
17		1 Kit
18		1 Shim
19		1 Bearing
20		1 Gear
21		1 Gear



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00043182.png

A-05  
17



A0517

Cylinder block



- |    |                                    | Inglese  |
|----|------------------------------------|----------|
| 22 | ! 1                                | 4 Screw  |
|    | ▶ Ref.n.1                          |          |
| 23 | 3695158M1                          | 1 Washer |
| 24 | 3695159M1                          | 1 Screw  |
| !  | This is a component of an assembly |          |
| 👁  | See page - reference number        |          |
| 🛑  | Not serviced, order                |          |

Engine

6600 ARM (2011-2013) - RS42 - 6675 ARM


RS42\00043180.png

A-05  
18



A0518

Rocker arm



- 1 3695757M1 ▶
- 2 3695760M1 ◀
- 3 3695761M1
- 4 3695762M1
- 5 3695763M1
- 6 3695764M1
- 7 3695765M1
- 8 3695766M1
- 9 3695767M1
- ◀ Left hand
- ▶ Right hand

Inglese

- 1 Shaft
- 1 Shaft
- 4 Weight
- 8 Screw
- 4 Screw
- 2 Bush
- 2 Gear
- 2 Ring
- 2 Screw

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**