




PARTS MANUAL

GP/GLP/GDP040VX-GP/GLP/GDP070VX (B875)



YP990149

1	GENERAL TRUCK
2	ENGINE ASSEMBLY
3	EXHAUST SYSTEM
4	COOLING SYSTEM
5	FUEL SYSTEM
6	ELECTRICAL SYSTEM
7	TRANSMISSION
8	DRIVE AXLE
9	STEERING SYSTEM
10	BRAKE SYSTEM
11	HYDRAULIC SYSTEM
12	LIFTING MECHANISM
13	ATTACHMENTS AND HEADER HOSE GROUP
14	OPTIONS
15	FIELD CONVERSION KITS
16	NUMERICAL INDEX

**SECTION 1
GENERAL TRUCK**

DESCRIPTION	PAGE
CAB	
ASSEMBLY AND ATTACHING PARTS	1-16
FRAME AND ATTACHING PARTS	1-18
INTERIOR PANELS	1-20
LH DOOR.....	1-22
RH DOOR AND HEATER ASSEMBLY	1-24
WINDOWS AND WINDOW WIPER SYSTEM	1-30
CAB DOORS	
PVC.....	1-28
CONTROL LEVER LABELS.....	1-56
COUNTERWEIGHTS	1-12
COWL MOUNT.....	1-10
ELECTRONIC LEVER LABELS	
AUXILIARY DUAL FUNCTION	1-60
AUXILIARY SINGLE FUNCTION.....	1-58
FENDER EXTENSIONS.....	1-8
FLOORPLATES AND COVERS	1-4
FORKS	1-66
OPTIONAL.....	1-67
FULL SUSPENSION SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS	
D/B 07/2006⇒.....	1-48
S/N B875B1401⇔S/N B875B1501	1-44
S/N B875B1501⇒ D/B 07/2006	1-46
FULL SUSPENSION SWIVEL SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS	
D/B 07/2006⇒.....	1-50
HOOD ASSEMBLY.....	1-2
JOYSTICK LABELS.....	1-62
WITH RETURN TO SET TILT	1-64
LABELS	
EXTERIOR.....	1-52
INTERIOR.....	1-54
LOAD BACKREST EXTENSION.....	1-68
NON-SUSPENSION SEAT	
WITHOUT ELECTRONIC CONTROLS	
S/N B875B1401⇔S/N B875B1501	1-34
S/N B875B1501⇒	1-36
OVERHEAD GUARD.....	1-14
SEMI-SUSPENSION SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS	1-42
S/N B875B1401⇔S/N B875B1501	1-38
S/N B875B1501⇒ D/B 07/2006	1-40
WEATHER PROTECTION.....	1-32

<https://www.ebooklibonline.com>

Hello dear friend!


Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

HOOD ASSEMBLY



BP120148


HOOD ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY
1	a 524256519	Hood Assembly	1
1	524256522	Hood Assembly (Vented)	1
1	b 524256520	Hood Assembly	1
2	a 524256518	Hood (Low Noise)	1
2	b 524256515	Hood	1
2	524236617	Hood (Vented)	1
3	580063960	Reinforcement Assembly	1
4	580030966	Capscrew	8
5	580058383	Bumper (Hood)	2
6	580004592	Nut	4
7	580057608	Hinge Assembly	2
8	580063963	Pin	2
9	580049011	Capscrew	2
10	580070139	Liner	1
11	518793609	Fastener	4
12	580056851	Seal	1
13	580056434	Handle	1
14	580056433	Latch Rotor	1
15	580049840	Capscrew	4
16	580039900	Capscrew	6
17	a 580065322	Liner (Front Panel) (Low Noise)	1
18	a 580065323	Liner (LH Panel) (Low Noise)	1
19	a 580065324	Liner (RH Panel) (Low Noise)	1
20	b 580049915	Ball Stud	4
20	a 580049915	Ball Stud	3
20	a 580064627	Ball Stud	1
21	580066308	Sound Liner	1
22	580004592	Nut	2
23	b 580056664	Gas Spring	2
23	a 580066569	Gas Spring (Left Hand)	1
23	a 580066568	Gas Spring (Right Hand)	1
24	580051832	Grommet	1
25	580049229	Capscrew	2
26	580057238	Striker Bolt	1
27	580027572	Nut	4
28	580044862	Insert	4
29	932202911	Capscrew	4
30	580070017	Bumper Rest	1
31	580056815	Capscrew	2
32	580049758	Fastener	8
33	580044861	Insert	2
	580058137	Plug (Not Illustrated)	1

FOOTNOTES:

- a** With Cab
- b** With Overhead Guard

FLOORPLATES AND COVERS



BP120144

FLOORPLATES AND COVERS

KEY:

A: With Cab


B: With Overhead Guard

ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
1	580052911	Dash Assembly (Manual Valve).....	1	1
1	580052912	Dash Assembly (Electronic Valve).....	1	1
2	580052409	Cup Holder.....	1	1
3	932728908	Capscrew.....	5	5
4	580046139	Clip.....	6	6
5	580068007	Sound Liner.....	1	..
6	580067860	Sound Liner.....	1	..
7	580067861	Sound Liner.....	1	..
8	580067852	Sound Liner.....	1	..
9	580067859	Sound Liner.....	1	..
10	580067858	Sound Liner.....	1	..
11	580037205	Tail Light Base (LH).....	1	1
12	580050625	Cover (Rear).....	..	1
13	580044859	Insert.....	..	8
13	580044859	Insert.....	5	..
14	580037206	Tail Light Base (RH).....	1	1
15	580041711	Capscrew.....	3	3
16	580058212	Capscrew.....	4	4
17	580052735	Floormat.....	1	1
18	580053622	Floor Plate.....	1	1
19	580049836	Plate (RH).....	1	1
20	580061746	Seal (RH).....	1	1
21	524220654	Panel (Step) (RH).....	1	1
22	580049836	Plate (RH).....	1	1
23	524149438	Splash Shield (Gasoline and Diesel).....	1	1
24	580049835	Plate (LH).....	1	1
25	925776402	Cap (LPG).....	1	1
26	524195754	Radiator Cover Assembly.....	..	1
26	580061815	Seal (LH).....	..	1
26	580061814	Seal (RH).....	..	1
27	449021001	Washer.....	..	2
28	507353800	Snap Ring.....	..	2
29	580058734	Screw.....	..	2
30	524177726	Panel (Rear) (RH).....	1	1
31	580050773	Seal.....	2	2
32	580056224	Trim Seal.....	2	2
33	580061747	Damping Sheet (RH Rear Panel).....	1	1
34	580065318	Sound Liner.....	1	..
35	580065320	Sound Liner.....	1	..
36	580065319	Sound Liner.....	1	..
37	580065316	Sound Liner.....	1	..
38	580041704	Insert.....	6	6
39	580026621	Clip Nut (Gasoline and Diesel).....	23	23
39	580026621	Clip Nut (LPG).....	21	21
40	524180729	Screw.....	6	6
41	580049835	Plate (LH).....	1	1

FLOORPLATES AND COVERS

ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
42	524220653	Panel (Step) (LH).....	1	1
43	580061184	Seal (LH) (LH)	1	1
44	524177724	Panel (Rear) (LH, Gasoline and Diesel)	1	1
44	524177725	Panel (Rear) (LH, LPG)	1	1
45	580061749	Damping Sheet (LH Rear Panel).....	1	1
46	524188741	Panel (Front) (LH).....	1	1
47	524224752	Plug	4	4
48	580059333	Bracket (LH) (Fender Cover)	1	1
49	524211381	Cover (LH Fender).....	1	1
50	505970526	Nut (Foldover).....	4	4
51	580042963	Lock Nut (Standard Tread, Wide Tread)	4	4
51	580042963	Lock Nut (Dual Tread).....	6	6
52	580050478	Mud Guard (Standard Tread).....	2	2
53	580051156	Mud Guard (LH, Wide Tread)	1	1
53	580051157	Mud Guard (RH, Wide Tread).....	1	1
53	580051174	Mud Guard (LH, Dual Tread)	1	1
53	580051390	Mud Guard (RH, Dual Tread).....	1	1
54	580056815	Capscrew (Gasoline and Diesel)	23	23
54	580056815	Capscrew (LPG)	21	21
55	580054552	Seal (Wet Brake)	1	1
55	580054667	Seal (Dry Brake).....	1	1
56	580061748	Damping Sheet (LH Front Panel)	1	1
57	580061189	Damping Sheet (RH Front Panel).....	1	1
58	524188746	Panel (RH Front).....	1	1
59	580059332	Bracket (RH) (Fender Cover).....	1	1
60	524211382	Cover (RH Fender)	1	1
61	580038033	Grommet (RH).....	1	1
62	580068694	Seal Plate	1	1
62	580046075	Seal	1	1
63	580050979	Seal	1	..
64	580026351	Seal (Manual Valve)	1	..
64	580046391	Seal (Electronic Valve)	1	..
65	580046350	Seal (Manual Valve)	1	..
65	580046392	Seal (Electronic Valve)	1	..
66	580046349	Seal	1	..
67	580046348	Seal	1	..
68	580053149	Kick Panel (Single Brake Pedal)	1	1
69	580053150	Kick Panel (Dual Brake Pedal).....	1	1
70	580046138	Cover (Steering Column) (Lower).....	1	1
70	580046143	Cover (Steering Column) (Upper).....	1	1
71	909904403	Screw.....	2	2
	524238067	Underbelly Shield (Not Illustrated).....	1	1

FENDER EXTENSIONS




HP120835

FENDER EXTENSIONS

ITEM	PART NO.	DESCRIPTION	QTY
1	524210176	Fender (Wide Tread) (LH).....	1
1	524210178	Fender (Dual Tread) (LH)	1
1	524210177	Fender (Wide Tread) (RH)	1
1	524210179	Fender (Dual Tread) (RH).....	1
2	580058271	Capscrew.....	8
3	932731908	Capscrew.....	2
4	580058192	Nut.....	10


COWL MOUNT



HP120730

ITEM	PART NO.	DESCRIPTION	QTY
1	580056815	Capscrew.....	2
2	524230676	Cowl.....	1
3	580044860	Insert	2
4	580074879	Insert	7
5	580064483	Capscrew.....	7

COUNTERWEIGHTS





COUNTERWEIGHTS

ITEM	PART NO.	DESCRIPTION	QTY
1	524181656	Counterweight (40VX)	1
1	524181657	Counterweight (50VX)	1
1	524181658	Counterweight (60VX)	1
1	524181660	Counterweight (70VX)	1
1	c 524238063	Counterweight (60VX)	1
2	a 449001399	Capscrew (4 in.)	1
2	b 449001295	Capscrew (6 in.)	1
3	580002019	Washer	1
4	955400911	Lockwasher	1
5	580063959	Pin	1
6	449034061	Pin	1
7	580059365	Seal (Counterweight).....	1
8	580059366	Seal (Counterweight) (Top).....	1
9	580059363	Seal (RH).....	1
10	580059364	Seal (LH)	1
11	504240785	Fastener	4
12	925776402	Cap.....	2

FOOTNOTES:

- a** 40VX
- b** 50-70VX
- c** Use with Short Wheel Base.

OVERHEAD GUARD




OVERHEAD GUARD

ITEM	PART NO.	DESCRIPTION	QTY
1	524240423	Overhead Guard (High)	1
1	524240429	Overhead Guard (Low)	1
2	524201323	Grommet.....	2
3	580041704	Insert	2
4	524208883	Grommet.....	1
5	580036667	Grommet.....	1
6	258979300	Plug	4
7	580056667	Capscrew (M12 x 1.75 x 35).....	8
7	580051941	Capscrew (M12 x 1.75 x 40 Optional)	8
8	580056528	Nut.....	2
9	580044861	Insert	4
10	580056526	Handle (Grab).....	1
11	580056815	Capscrew.....	2
12	580051747	Handle Assembly (RH, Rear)	1
13	580050959	Handle.....	1
14	580058447	Switch (Horn)	1
15	580022893	Connector.....	1
16	505968540	Secondary Lock	1
17	505968514	Terminal (Pin).....	2
18	580058212	Capscrew.....	2
	a 524240692	Plug	1
	a 524230460	Label (Veracitor 40VX RH)	1
	a 524230461	Label (Veracitor 50VX RH)	1
	a 524230463	Label (Veracitor 60VX RH)	1
	a 524230464	Label (Veracitor 70VX RH)	1
	a 524230455	Label (40VX LH).....	1
	a 524230456	Label (50VX LH).....	1
	a 524230458	Label (60VX LH).....	1
	a 524230459	Label (70VX LH).....	1

FOOTNOTES:

a Not Illustrated

CAB
(ASSEMBLY AND ATTACHING PARTS)



BP120156

**CAB
(ASSEMBLY AND ATTACHING PARTS)**

KEY:


- A: With Steel Doors**
- B: With PVC Doors**

ITEM	PART NO.	DESCRIPTION	QTY	
			A	B
1	524275519	Cab Assembly (With Steel Doors)	1	..
1	524275698	Cab Assembly (With PVC Doors)	1
2	580059493	Plug	6	8
3	580056815	Capscrew	8	4
4	580056526	Handle (Grab)	1	1
5	580059127	Seal	2	2
6	580056667	Capscrew	8	8
7	580056528	Nut.....	2	2
8	580066768	Seal	1	2
9	580073550	Shim	AR	AR
10	940400907	Lockwasher	6	6
11	580023890	Capscrew	6	6
12	580067787	Seal (LH)	1	1
12	580067788	Seal (RH)	1	1
13	258979300	Plug	4	2
14	524240692	Plug	1	1
15	524208883	Grommet	1	1
16	580051168	Screw	4	..
17	449022019	Lockwasher	4	..
18	580026712	Fan Assembly.....	1	..
18	150024222	Fan	1	..
18	505968533	Connector	1	..
18	505968540	Secondary Lock	1	..
18	505968514	Terminal (Pin).....	2	..
19	449015012	Nut.....	4	..
20	580056815	Capscrew	2	..
21	580044861	Insert	2	..
22	580066767	Bracket	1	..
23	520038820	Connector.....	1	1
	a 580073522	Shim	AR	AR
	a 524201323	Grommet	1	1

FOOTNOTES:

- a** Not Illustrated

CAB
(FRAME AND ATTACHING PARTS)



BP120158



Suggest:

For more complete manuals. Please go to the home page.

<https://www.ebooklibonline.com>

If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading


**CAB
(FRAME AND ATTACHING PARTS)**

ITEM	PART NO.	DESCRIPTION	QTY
	524275519	Cab Assembly (With Steel Doors)	1
	524275698	Cab Assembly (With PVC Doors)	1
1	580054216	Grommet	2
2	580061879	Grommet	3
3	580074206	Cover (Cable)	1
4	504226242	Washer	4
5	449001013	Capscrew	4
6	580032669	Seal	AR
7	580048511	Clip	3
8	449021003	Washer	7
9	580062146	Cover (Rear).....	1
10	580061878	Water Tank	1
11	449015002	Nut.....	2
12	580014773	Clamp.....	3
13	a 580056815	Capscrew	2
14	a	Heater Hose Bulkhead	1
14	a 580075630	Bracket.....	1
14	a 580015055	Seal.....	AR
15	580061877	Connector	2
16	580032669	Seal.....	AR
17	580067789	Seal	1
18	580014810	Nut.....	6
19	Frame	1
20	580062101	Wire Harness	1
21	580022776	Bolt.....	12

FOOTNOTES:

a With PVC Doors

CAB
(INTERIOR PANELS)



HP120860

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>