



**GENERAL MANUAL FOR MODEL  
DP.6 PLUS  
GIS-READY**



**SAFETY GUIDELINES  
INSTALLATION  
OPERATION  
TROUBLESHOOTING  
PARTS LIST**



**This unit may have been built with  
SPECIAL FEATURES. Provide  
SERIAL NUMBER when ordering  
parts.**

**SERIAL NO.** \_\_\_\_\_

**IMPORTANT: READ THE SAFETY GUIDELINES AND ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING**

**HIGHWAY EQUIPMENT COMPANY – NEW LEADER DIVISION  
1330 76TH AVE SW, CEDAR RAPIDS, IOWA 52404-7052  
PH. (319) 363-8281    [www.highwayequipment.com](http://www.highwayequipment.com)    FAX (319) 632-3081**



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

## TABLE OF CONTENTS

Warranty .....	3
Preface .....	4
Safety .....	5
General Description .....	8
Installation Instructions .....	9
General System Layout .....	9
Console and Cabling .....	9
Spinner Sensor .....	10
Radar .....	10
Console Overview .....	11
Keypad and Display .....	11
Main Screen Display .....	13
Cable Connections .....	14
Calibration & Machine Settings .....	15
Configuration Setup .....	15
Machine Settings .....	15
Distance Calibration: Radar .....	21
Console .....	22
Card Setup .....	25
Memory Setup .....	27
Boundary .....	28
Programming a Job .....	32
Job Description .....	32
Creating the First Job .....	32
Changing Jobs .....	40
Activating, Creating New, Editing and Deleting Jobs .....	41
Fields .....	42
Logging As Applied Data to Card .....	45
Operating Procedures .....	47
Prescription Files .....	47
Activating Jobs .....	51
Clearing Total and Area Applied .....	51
Overriding Active Job Rate .....	52
Conveyor Switch .....	53
DGPS-5000 and Lightbar .....	53
Alarms .....	54
Troubleshooting .....	55
GPS Adapter Cable Installation .....	57
Calibrated CFR .....	58
Application Charts .....	61
English/Metric Conversion Chart .....	63
Instructions for Ordering Parts .....	64
Parts List	
Control Box & Cables .....	65
Spinner Sensor .....	66
Radar .....	67
Quick Reference Sheets-Setup .....	68-71



**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**