

OPERATOR'S MANUAL

TEDDER

TD3418



FRONTIERTM

5PQ990130 (10/08/2014)



Suggest:

For more complete manuals. Please go to the home page.

<https://www.ebooklibonline.com>

If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading

TABLE OF CONTENTS

Introduction	2
Intended Use	2
Serial Number	2
Specifications	2
Safety	3
Power Source Safety	3
Safety Decals	5
Hitching	6
Attaching to the Tractor	6
Transporting	7
Field Transport	7
Road Transport	7
Field Set-up	8
Adjustments	8
Tine Height Adjustment	8
Axle Adjustments	8
Tine Pitch Adjustment	9
General Operation	10
Lubrication and Maintenance	12
Gearbox Lubrication	13
General Lubrication	13
Wheel Bearings	14
Grease Fitting Lubrication	14
PTO Lubrication	15
Timing the Rotors	16
Torque Specifications	19
Standard Torque Chart	19
Metric Torque Chart	20
Warranty	21
Illustrated Parts Breakdowns	22
Tongue Assembly	23
Main Assembly.....	24
Rotor and Wing Assembly.....	25
Axle and Wheel.....	26
Input Gearbox Assembly.....	27
Rotor Gearbox Assembly.....	28
PTO Shaft.....	29
Hydraulics	30
Decals	31

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>