

---

# WDX1002S, WDX1202S, WDX1202 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION .....	2
SECTION 10 - ENGINE .....	3
SECTION 25 - FRONT MECHANICAL DRIVE .....	11
SECTION 29 - HYDROSTATIC TRANSMISSION .....	12
SECTION 33 - BRAKES AND CONTROLS .....	16
SECTION 35 - HYDRAULIC SYSTEMS .....	17
SECTION 44 - REAR AXLE .....	22
SECTION 50 - CLIMATE CONTROL .....	24
SECTION 55 - ELECTRICAL SYSTEMS .....	30
SECTION 58 - HEADER ATTACHMENTS .....	51
SECTION 88 - OPTIONAL EQUIPMENT .....	56
SECTION 90 - PLATFORM, CAB AND DECALS .....	60

The following pages are the collation of the contents pages from each section and chapter of the WDX1002S, WDX1202S and WDX1202 Repair manual. Complete Repair part # 87580753.

The sections used through out all Case IH product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the WDX1002S, WDX1202S and WDX1202 Self-Propelled Windrowers.

---

# SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87580754

## Chapter 1 - General Information

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
00 000	Precautionary Statements .....	2
	Safety .....	3
	General Safety Information .....	5
	Protecting the Electronic/Electrical Systems During Charging or Welding .....	7
	Introduction .....	8
	About Improvements .....	8
	Product Identification Numbers (PIN) .....	9
	Engine PIN Number .....	9
	Company Policy .....	10
	Parts and Accessories .....	10
	Lubrication .....	10
	Recommended Lubricants and Coolants .....	11
	Sealants .....	12
	Minimum Hardware Tightening Torques .....	13
	Installation of Adjustable Fittings in Straight Thread O ring Bosses .....	15
	Standard Torque Data for Hydraulic Tubes and Fittings .....	15
	Pipe Thread Fitting Torque .....	16
	Installation of ORFS (O ring Flat Faced) Fittings .....	16
	Specifications .....	17

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 1 - Engine

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Engine Overhaul Introduction .....	5
	Description of Operation .....	6
	Specifications .....	6
	Special Tools .....	14
	Torques .....	16
	Overhaul .....	18
	Engine .....	18
	Removal .....	18
	Turbocharger .....	24
	Removal .....	24
	Fuel System .....	24
	Removal .....	24
	Thermostat .....	29
	Removal .....	29
	Oil Cooler .....	29
	Removal .....	29
	Water Pump .....	30
	Removal .....	30
	Cylinder Head .....	30
	Removal .....	30
	Front Housing .....	31
	Removal .....	31
	Oil Pump .....	32
	Removal .....	32
	Rear Housing .....	33
	Removal .....	33
	Oil Pan .....	34
	Removal .....	34
	Timing Gears .....	34
	Removal .....	34
	Pistons .....	35
	Removal .....	35

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 1 - Engine (Continued)

### CONTENTS

Section	Description	Page
	Main Bearings .....	36
	Removal .....	36
	Crankshaft .....	36
	Removal .....	36
	Oil Nozzles .....	37
	Removal .....	37
	Camshaft .....	37
	Removal .....	37
	Tappets .....	38
	Removal .....	38
	Block .....	38
	Inspection .....	38
	Crankshaft .....	40
	Inspection .....	40
	Oil Pump Gear .....	42
	Inspection, Removal, and Installation .....	42
	Crankshaft .....	42
	Installation for Inspection .....	42
	Camshaft .....	44
	Inspection .....	44
	Camshaft Bushings .....	45
	Inspection and Installation .....	45
	Tappets .....	46
	Inspection .....	46
	Piston .....	46
	Disassembly .....	46
	Inspection .....	47
	Piston .....	47
	Assembly .....	47
	Connecting Rod .....	50
	Inspection .....	50

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 1 - Engine (Continued)

### CONTENTS

Section	Description	Page
	Bushings .....	50
	Inspection .....	50
	Rod Markings .....	51
	Connecting Rods .....	51
	Inspection .....	51
	Piston and Connecting Rod .....	53
	Assembly .....	53
	Piston Rings .....	54
	Installation .....	54
	Piston and Rod Assembly .....	54
	Installation for Clearance .....	54
	Rod Bearing .....	55
	Clearance .....	55
	Piston .....	57
	Height Measurement .....	57
	Cylinder Head .....	57
	Valve .....	57
	Removal .....	57
	Valve Seals .....	58
	Removal .....	58
	Inspection/Installation .....	58
	Cylinder Head .....	58
	Inspection .....	58
	Valves .....	59
	Specifications .....	59
	Inspection .....	60
	Valve Stem Play .....	61
	Valve Guides .....	61
	Inspection .....	61
	Valve Seats .....	61
	Inspection .....	61

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 1 - Engine (Continued)

### CONTENTS

Section	Description	Page
	Valve Springs .....	63
	Inspection of the Intake and Exhaust Valve Springs .....	63
	Cylinder Head .....	63
	Assembly .....	63
	Installation .....	64
	Push Rods .....	64
	Rocker Arm Group .....	65
	Inspection .....	65
	Installation .....	65
	Block Assembly .....	67
	Tappets .....	67
	Installation .....	67
	Camshaft .....	67
	Installation .....	67
	Oil Nozzles .....	68
	Installation .....	68
	Crankshaft .....	69
	Installation .....	69
	Piston and Connecting Rod .....	70
	Installation .....	70
	Timing Gearbox .....	72
	Installation .....	72
	Camshaft .....	73
	Timing .....	73
	Fuel Pump .....	74
	Installation .....	74
	Engine Components .....	76
	Flywheel Housing .....	76
	Installation .....	76
	Oil Pump .....	82
	Installation .....	82

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 1 - Engine (Continued)

### CONTENTS

Section	Description	Page
	Water Pump .....	82
	Installation .....	82
	Front Cover .....	83
	Installation .....	83
	Crankshaft Pulley .....	84
	Installation .....	84
	Oil Pan .....	85
	Installation .....	85
	Oil Cooling System .....	86
	Installation .....	86
	Injector Assembly .....	86
	Installation .....	86
	Valve Covers .....	87
	Installation .....	87
	Exhaust Manifold .....	87
	Installation .....	87
	Turbocharger .....	88
	Installation .....	88
	Engine .....	89
	Installation .....	89
	Troubleshooting .....	96

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 2 - Fuel System

### CONTENTS

<b>Section</b>	<b>Description</b>	<b>Page</b>
	Specifications .....	2
	4-Cyl. Engine Without Charge Air Cooling .....	3
	4-Cyl. Engine Setup For Charge Air Cooling .....	4
	Torques .....	5
	Special Tools .....	6
	Description of Operation .....	7
	Injection System .....	7
	Injection Pump .....	8
	Mechanical Fuel Pump .....	17
	Fuel Filter .....	18
	Injection Pump .....	20
	Removal .....	20
	Installation .....	24
	Calibration .....	29
	Injection Pump .....	29
	Timing .....	29
	Injectors .....	33
	Removal .....	33
	Reinstallation .....	34
	Fuel System .....	36
	Bleeding .....	36
	Fuel Tanks .....	37
	Removal .....	37
	Install .....	42

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 3 - Air Intake

### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Air Intake System .....	2
	Specifications .....	3
	Air Cleaner .....	3
	Turbocharger .....	3
	Sealants .....	3
	General Torques .....	4
	Description of Operation .....	5
	Turbocharger .....	5
	Overhaul .....	6
	Turbocharger .....	6
	Removal .....	6
	Inspection .....	6
	Installation .....	8
	Air Filter .....	9
	Inspection .....	9
	Primary (Outer) Air Filter .....	9
	Removal .....	9
	Cleaning With Air .....	11
	Cleaning By Washing .....	11
	Installation .....	12
	Secondary (Inner) Air Filter .....	13
	Removal .....	13
	Installation .....	13
	Intake Manifold Assembly .....	14
	Installation .....	14
	Troubleshooting .....	15

---

# SECTION 10 - ENGINE

BOOK 1 - 87580754

## Chapter 4 - Cooling System

### CONTENTS

Section	Description	Page
	Specifications .....	2
	Cooling System .....	2
	Overview - Cooling System .....	3
	Description of Operation .....	5
	Overhaul .....	5
	Thermostat .....	5
	Removal .....	5
	Inspection .....	6
	Installation .....	6
	Coolant Temperature Sender .....	6
	Removal .....	6
	Installation .....	7
	Fan Belt .....	7
	Removal .....	7
	Installation .....	7
	Spring-loaded Automatic Fan Belt Tensioner .....	8
	Removal .....	8
	Installation .....	8
	Inspection .....	8
	Coolant Pump .....	9
	Removal .....	10
	Installation .....	10
	Radiator .....	11
	Removal .....	11
	Installation .....	14
	Troubleshooting .....	17

---

## SECTION 10 - ENGINE

BOOK 1 - 87580754

### Chapter 5 - Lubrication System

#### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Lubrication System .....	2
	Oil Cooler .....	3
	Oil Pump .....	4
	Oil Sump .....	5
	Oil Fume Ventilation .....	6
	Specifications .....	7
	Oil Specification .....	7
	Oil Pump .....	7
	Repair .....	7
	Oil Filter Mount and Oil Cooler .....	7
	Removal .....	7
	Installation .....	9
	Oil Pan .....	9
	Removal .....	9
	Installation .....	10

## SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 2 - 87580755

### Chapter 1 - Front Mechanical Drive

#### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Special Tools .....	2
	Overhaul .....	6
	Front Mechanical Drive .....	6
	Removal .....	6
	Installation .....	9
	Planetary Gearbox Drive .....	12
	Disassembly .....	13
	Assembly .....	17
	Labor Guide .....	23

---

# SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87580755

## Chapter 1 - Ground Drive

### CONTENTS

Section	Description	Page
	Specifications .....	5
	Hydrostatic Transmission Identification .....	6
	Torque Specifications .....	7
	Torque Chart .....	7
	Motor Area .....	7
	Description of Operation .....	8
	Pumps .....	9
	High Pressure Relief Valves .....	10
	Check Valves .....	10
	Charge Pump .....	11
	Charge Relief Valve (Pump) .....	11
	Header Lift Pump .....	11
	Motors .....	11
	Fixed Displacement Motor .....	11
	Variable Displacement Motor .....	11
	Reservoir .....	13
	Oil Flow .....	13
	Neutral .....	13
	Forward/Reverse .....	13
	WDX1002S/1202S Hydraulic System Diagram .....	14
	WDX1202 Hydraulic System Diagram .....	16
	Solenoid Valve (2-Speed Drive Motor Only) .....	18
	Low-Range Operation .....	18
	High-Range Operation .....	18
	Cooling Circuit .....	18
	Relief Valve .....	18
	Operation .....	18
	Linkage .....	19
	Operation .....	19
	Sauer-Danfoss Authorized Service Centers – North America .....	20
	Troubleshooting .....	24
	Excessive Noise .....	24

---

# SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87580755

## Chapter 1 - Ground Drive (Continued)

### CONTENTS

Section	Description	Page
	Overheating Transmissions .....	24
	Loss of Propulsion .....	24
	Control Linkage Inspection .....	25
	High-Pressure Relief Valve Check .....	25
	Charge Pump Relief Valve .....	26
	Check Valve .....	26
	Pressure Testing .....	27
	Port Locations .....	29
	Charge Pressure (WDX1002S/1202S) .....	30
	Charge Pressure (WDX1202) .....	30
	Charge Pressure System Test .....	31
	Tandem Pump Charge Pressure Test .....	31
	Complete Charge System Test (WDX1202 Only) .....	33
	High Pressure Relief Valve Test .....	35
	Gage Port and Relief Valve Locations .....	35
	Pressure Port Locations .....	37
	Case Pressure Test (Pump) .....	38
	Case Pressure Test (Motor, WDX1202 only) .....	38
	Suction Test .....	39
	Case Flow Test (WDX1202 Only) .....	39
	Ground Speed Circuit (WDX1002S/1202S) .....	40
	Operation .....	40
	Troubleshooting .....	40
	Ground Speed Display Does Not Function (WDX1002S/1202S) .....	41
	Ground Speed Circuit (WDX1202) .....	42
	Operation .....	42
	Troubleshooting .....	42
	Ground Speed Display Does Not Function (WDX1202) .....	43
	Troubleshooting Charts .....	45
	Windrower Will Not Shift into High Range .....	45
	Windrower Will Not Shift into Low Range .....	46
	Charge Pump .....	47

---

# SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87580755

## Chapter 1 - Ground Drive (Continued)

### CONTENTS

Section	Description	Page
	Hydrostatic System .....	48
	Explanation of Terms Used in Failure Analysis .....	51
	Lack of Lubrication .....	51
	Operating at Excessive Temperature Levels .....	51
	Use of Improper Fluid .....	51
	Cavitation .....	51
	Overspeeding of the Unit .....	51
	Parts Worn or Scored From Contamination .....	51
	Abrasive Contaminants .....	51
	Plates Scored from Water in Oil (Non-Particle Contaminants) .....	51
	Minor Repairs .....	52
	Tandem Pump .....	53
	Port Locations .....	53
	Rear Half Port Breakdown .....	54
	Front Half Port Breakdown .....	56
	Shaft Seal Replacement .....	58
	Charge Pump Removal .....	59
	Charge Pump Inspection .....	60
	Charge Pump Assembly .....	61
	O Ring Seals .....	62
	Trunnion Seal (Control Shaft Side) .....	63
	Trunnion Cover (Plain) .....	65
	Tandem Pump Removal .....	66
	Tandem Pump Installation .....	69
	Ground Drive Motor .....	71
	Removal .....	71
	Inspection/Parts Breakdown .....	72
	Installation .....	76
	Start-Up .....	77
	Maintenance .....	77
	Worm Shaft .....	78
	Removal .....	78
	Installation .....	79

---

# SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87580755

## Chapter 2 - Propulsion System

### CONTENTS

Section	Description	Page
	WDX1002S/1202S .....	2
	Pintle Arm Rotary Potentiometer (R21) .....	2
	Removal .....	2
	Installation .....	2
	Testing .....	3
	Propulsion Rotary Potentiometer (R21) .....	4
	Removal .....	4
	Installation .....	4
	Testing .....	5
	Neutral Adjustment .....	6
	WDX1202 .....	27
	Theory of Operation .....	27
	Pintle Arm Rotary Potentiometer (R21) .....	28
	Removal .....	28
	Installation .....	28
	Testing .....	29
	Propulsion Rotary Position Sensor (R23) .....	30
	Removal .....	30
	Installation .....	30
	Testing .....	31
	MFH Rotary Position Sensor (R18) .....	32
	Removal .....	32
	Installation .....	33
	Testing .....	34
	Neutral Adjustment .....	35

---

## SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87580755

### Chapter 3 - Active Calibrations (WDX1202 only)

#### CONTENTS

Section	Description	Page
	Active Calibrations .....	2

## SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 2 - 87580755

### Chapter 4 - MFH Calibration (WDX1202 Only)

#### CONTENTS

Section	Description	Page
	Dealer Setup Menu Navigation .....	2
	MFH Calibration .....	2

## SECTION 33 - BRAKES AND CONTROLS

BOOK 2 - 87580755

### Chapter 1 - Brakes and Controls

#### CONTENTS

Section	Description	Page
	Description of Operation .....	2
	Special Tools .....	2
	Overhaul .....	2
	Brake Assembly .....	2
	Removal .....	2
	Installation .....	5
	Disassembly .....	6
	Rotating, Stationary, and Primary Disc Assembly .....	12
	Installation .....	12
	Brake Bleeding Procedure .....	16
	Labor Guide .....	18

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87580756

## Chapter 1 - Hydraulic Systems

### CONTENTS

Section	Description	Page
	Introduction .....	5
	System Component Locations .....	6
	Reading Diagram Symbols .....	7
	WDX1002S/1202S Hydraulic System Diagram .....	12
	WDX1202 Hydraulic System Diagram .....	14
	Hydraulic System Operation .....	16
	Ground Drive .....	16
	Circuit Diagrams .....	18
	WDX1002S/1202S .....	18
	WDX1202 .....	18
	Header Drive .....	26
	Circuit Diagrams .....	28
	WDX1002S/1202S .....	28
	WDX1202 .....	28
	Theory of Operation .....	35
	Header Lift .....	35
	Circuit Diagrams .....	38
	WDX1002S/1202S/1202 .....	38
	Theory of Operation .....	43
	Header Tilt .....	43
	Circuit Diagrams .....	44
	WDX1002S/1202S/1202 .....	44
	Auxiliary Engine Mounted Hydraulic Pump (optional) .....	47
	Control Valve Manifold (WDX1002S/1202S/1202) .....	48
	Service Parts .....	48
	Valve Identification Codes .....	49
	WDX1002S/1202S Component Identification and Location .....	50
	Right-hand (RH) View .....	50
	Plan View .....	51
	Front View .....	52
	Rear View .....	53
	Bottom View .....	54
	Left-hand (LH) View (Hidden Against Mounting Plate) .....	55
	WDX1002S/1202S Solenoid Engagement Chart .....	56
	WDX1202 Component Identification and Location .....	57
	Right-hand (RH) View .....	57
	Plan View .....	58
	Front View .....	59

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87580756

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	Rear View .....	60
	Bottom View .....	61
	Left-hand (LH) View (Hidden Against Mounting Plate) .....	62
	WDX1202 Solenoid Engagement Chart .....	63
	Auxiliary Control Valve (Speed Control) Manifold (WDX1002S/1202S/1202) .....	64
	Service Parts .....	64
	Valve Identification Codes .....	65
	Auxiliary Control Valve Manifold .....	66
	Component Identification and Location .....	66
	Right-Hand (RH) View .....	66
	Plan View .....	67
	Bottom View .....	68
	Left-hand (LH) View (Hidden Against Mounting Plate) .....	69
	Header Control Valve Manifold (WDX1002S/1202S/1202) .....	70
	Service Parts .....	70
	Valve Identification Codes .....	71
	Header Control Manifold - WDX1002S/1202S .....	72
	Component Identification and Location .....	72
	Right-hand (RH) View .....	72
	Front View .....	73
	Top View .....	74
	Header Control Manifold - WDX1202 .....	75
	WDX1202 Component Identification and Location .....	75
	Right-hand (RH) View .....	75
	Front View .....	76
	Top View .....	77
	Cartridge Valves (Solenoid-operated) .....	78
	Main Control Manifold Valves .....	79
	Two-way Two-position (Normally Closed) Poppet Valves .....	79
	Three-way Two-position Spool Valve .....	81
	Two-way Two-position (Normally Open) Poppet Valve .....	82
	(Normally Open) Pressure Reducing/Relieving Valves .....	83
	(Normally Open) Solenoid-operated Relief Valves .....	84
	(Normally Closed) Solenoid-operated Proportional Flow Control .....	84
	Replacement .....	85
	WDX1002S/1202S Main Manifold – Cartridge Torque Requirements .....	86
	WDX1202 Main Manifold – Cartridge Torque Requirements .....	87
	Installation .....	88

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87580756

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	Solenoid Coils .....	89
	Removal .....	89
	Installation .....	89
	Cartridge Valves (Non-solenoid-operated) .....	90
	Direct-acting Flow Control Needle Valve .....	90
	Pilot-operated Relief Valve .....	91
	Differential-Pressure-Sensing Valve .....	92
	WDX1002S/1202S Header Control Manifold – Cartridge Torque Requirements ....	93
	WDX1202 Header Control Manifold – Cartridge Torque Requirements .....	94
	Needle Valve (AD) and Piloted Relief Valves .....	95
	Replacement .....	95
	Adjustment .....	95
Minor Repairs .....		96
	Accumulators - Header Lift .....	96
	Removal .....	96
	Inspection .....	97
	Installation .....	97
	Accumulator - Surge Suppression .....	99
	Specifications .....	99
	Hydraulic Accumulator Breakdown .....	100
	Checking Pre-Charge .....	101
	Pre-Charging Procedure .....	102
	Removal .....	103
	Installation .....	103
Major Components .....		104
	Header Drive Pump .....	104
	Removal .....	104
	Inspection .....	105
	Installation .....	105
	Adjustment Instructions .....	106
	Header Drive System Pressure Adjustment (Valve L-30) .....	107
	Pump Flow .....	114
	Header Lift Pump .....	115
	Removal .....	115
	Disassembly .....	115
	Inspection .....	117
	Assembly .....	117
	Installation .....	120

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87580756

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	Adjustment Instructions .....	121
	Header Lift System Pressure Adjustment (Valve L-03) .....	122
	Auxiliary Engine Mounted Hydraulic Pump (optional) .....	128
	Removal .....	128
	Inspection .....	128
	Installation .....	128
	Start-up Procedure .....	129
	Maintenance .....	130
	Cooling Circuit Bypass Pressure .....	131
	Temperatures .....	131
	Troubleshooting .....	132
	General .....	132
	Reduced System Pressure .....	132
	Reduced Hydraulic Flow .....	132
	Excessive Noise .....	132
	Overheating .....	132
	Power Loss .....	132
	Explanation of Terms Used In Failure Analysis .....	133
	Parts Evaluation .....	134
	Discoloration .....	134
	Scratches or Grooves .....	134
	Rework .....	134
	Repeat Failures .....	134
	Troubleshooting .....	135
	Header Drive System .....	135
	Header Drive Pump .....	138
	Header Drive Motor .....	139
	Service Techniques .....	140
	General .....	140
	Oil Level .....	140
	Hoses and Tubes .....	141
	O Ring Flat Face Seal Fittings .....	141
	O Ring Flat Face Seal Fitting Torque Values .....	141
	Adjustments .....	142
	Header Drive Motors .....	142
	Sauer-Danfoss Authorized Service Centers - North America .....	143
	Tilt Cylinder .....	147

---

# SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 87580756

## Chapter 1 - Hydraulic Systems (Continued)

### CONTENTS

Section	Description	Page
	Removal .....	147
	Inspection .....	151
	Assembly .....	151
Lift Cylinders .....		155
	Removal .....	155
	Inspection .....	159
	Assembly .....	159
Zero Leak Plugs .....		163
	Removal .....	163
	Replacement .....	163
Plug Torque Requirements .....		164
Zero-Leak Plug to SAE J514 ORB Plug Cross Reference .....		164
Hydraulic Reservoir Replacement - WDX1002S and WDX1202S .....		165
	Removal .....	165
	Installation .....	166
	Tank Preparation (Plastic Tanks only) .....	167
Hydraulic Reservoir Replacement - WDX1202 .....		169
	Removal .....	169
	Installation .....	170
	Tank Preparation (Plastic Tanks only) .....	171

---

# SECTION 44 - REAR AXLE

BOOK 3 - 87580756

## Chapter 1 - Non-Suspended Rear Axle

### CONTENTS

Section	Description	Page
	Introduction .....	2
	Overview .....	2
	Specifications .....	3
	Special Tools .....	3
	Description of Operation .....	4
	Extensions and Axle Tube .....	4
	Adjustments .....	3
	Wheel Width .....	8
	Channel Widths (Spindle to Spindle) .....	8
	Axle Extension Position .....	8
	Overhaul .....	9
	Wheel, Axle Shaft and Hub .....	9
	Removal .....	9
	Inspection .....	10
	Installation .....	12
	Axle Support Fork .....	15
	Removal .....	15
	Inspection .....	15
	Installation .....	16
	Rear Axle Extension .....	18
	Removal .....	18
	Inspection .....	19
	Installation .....	19
	Axle Tube and Center Pivot Pin .....	20
	Removal .....	20
	Inspection .....	21
	Installation .....	22
	Labor Guide .....	24

---

# SECTION 44 - REAR AXLE

BOOK 3 - 87580756

## Chapter 2 - Suspended Rear Axle

### CONTENTS

Section	Description	Page
	Introduction .....	2
	Overview .....	2
	Special Tools .....	2
	Specifications .....	3
	Description of Operation .....	4
	Extensions and Axle Tubes .....	4
	Adjustments .....	7
	Wheel Width .....	7
	Extension Widths (Spindle to Spindle) .....	7
	Axle Extension Position .....	7
	Overhaul .....	8
	Wheel, Axle Shaft and Hub .....	8
	Removal .....	8
	Inspection .....	10
	Installation .....	11
	Axle Support Fork .....	13
	Removal .....	13
	Inspection .....	13
	Installation .....	14
	Extension .....	15
	Removal .....	15
	Inspection .....	16
	Installation .....	17
	Air Spring .....	18
	Removal .....	18
	Inspection .....	19
	Installation .....	20
	Axle Tubes and Pivot Pins .....	21
	Removal .....	21
	Inspection .....	22
	Installation .....	23
	Labor Guide .....	25

---

# SECTION 50 - CLIMATE CONTROL

BOOK 3 - 87580756

## Chapter 1 - Climate Control - WDX1002S and WDX1202S

### CONTENTS

Section	Description	Page
	Specifications .....	4
	Special Tools .....	4
	Description of Operation .....	5
	The Basics of Refrigeration .....	5
	Air Conditioning Process .....	6
	R134a Refrigerant Information .....	7
	Refrigerant Ingredients .....	7
	Lubricants .....	7
	Refrigerant (R134a) .....	7
	System Components .....	11
	Compressor Pump .....	11
	Compressor Clutch (L-27) .....	11
	Air Conditioning Filter .....	11
	Condenser .....	12
	Receiver/Drier .....	12
	Expansion Valve .....	13
	Description .....	13
	Valve Components .....	13
	Operation .....	14
	Port Identification .....	17
	Evaporator .....	17
	Blower Fan .....	17
	Description of Operation - Climate Controls .....	18
	Switches and Controls .....	18
	Air Conditioner Temperature (Thermostatic) Control Switch .....	18
	Blower Fan Switch .....	18
	Compressor Protection Switches .....	19
	High-pressure Cutout Switch (S-40) .....	19
	Low-pressure Cutout Switch (S-69) .....	19

---

# SECTION 50 - CLIMATE CONTROL

BOOK 3 - 87580756

## Chapter 1 - Climate Control - WDX1002S and WDX1202S (Continued)

### CONTENTS

Section	Description	Page
	Troubleshooting and Servicing Air Conditioning System . . . . .	20
	General Safety and Service Precautions . . . . .	20
	Cleanliness . . . . .	21
	Preliminary Troubleshooting and Testing . . . . .	21
	Operational Checks . . . . .	21
	Diagnosis Charts - Air Conditioning System . . . . .	22
	Test Procedure: Stabilizing the System . . . . .	24
	Test Ports . . . . .	24
	Pressure/Temperature Relationships . . . . .	25
	Leak Testing . . . . .	25
	Refilling . . . . .	25
	Contaminants . . . . .	26
	General . . . . .	26
	Preventing Mixing of Service Equipment . . . . .	26
	Refrigerant Extraction and Recycling Equipment . . . . .	26
	Using Extraction Equipment . . . . .	27
	Using Recycled Equipment . . . . .	27
	Recycling vs. Reclaiming . . . . .	27
	Containment of Air Conditioning Refrigerants . . . . .	27
	Recovery . . . . .	28
	Flushing . . . . .	28
	Recharging/Refilling . . . . .	28
	Using a Manifold Gauge Set . . . . .	29
	Checking Refrigerant for Excess Air . . . . .	29
	Containers for Storing Recycled Refrigerant . . . . .	30
	Disposal of Empty or Near-Empty Disposable Containers . . . . .	30
	Applicable SAE Standards . . . . .	30
	Gauge Reading . . . . .	31
	Manifold Gauge Readings and Interpretations . . . . .	35
	Performance Test Examples . . . . .	35
	Overhaul - Air Conditioning System . . . . .	46
	Condenser . . . . .	46

---

## SECTION 50 - CLIMATE CONTROL

BOOK 3 - 87580756

### Chapter 1 - Climate Control - WDX1002S and WDX1202S (Continued)

#### CONTENTS

Section	Description	Page
	Removal .....	46
	Inspection and Repair .....	46
	Installation .....	46
	Receiver/Drier .....	47
	Removal .....	47
	Installation .....	47
	High (S-40) and Low (S-69) Pressure Switches .....	47
	Removal .....	47
	Installation .....	47
	Blower Motor (M-20) and Fan Assembly .....	48
	Removal .....	48
	Inspection .....	48
	Installation .....	48
	Expansion Valve .....	49
	Removal .....	49
	Installation .....	49
	Evaporator Core .....	49
	Removal .....	49
	Inspection .....	49
	Installation .....	49
	Compressor and Clutch - Special Tools .....	50
	Compressor Clutch Components .....	50
	Removal .....	50
	Installation .....	51
	Overhaul - Compressor .....	51
	Clutch and seal replacement .....	51
	Removal .....	51
	Inspection and Assembly .....	55
	Labor Guide .....	60

---

# SECTION 50 - CLIMATE CONTROL

BOOK 3 - 87580756

## Chapter 2 - Climate Control - WDX1202

### CONTENTS

Section	Description	Page
	Specifications .....	4
	Description of Operation .....	5
	The Basics of Refrigeration .....	5
	Air Conditioning Process .....	6
	R134a Refrigerant Information .....	7
	Refrigerant Ingredients .....	7
	Lubricants .....	7
	Refrigerant (R134a) .....	7
	Cab Air Flow .....	8
	System Components .....	10
	Compressor Pump .....	10
	Compressor Clutch (L-27) .....	10
	Air Conditioning Filters .....	11
	Removal/Replacement .....	11
	Recirculation Filter .....	13
	Removal .....	14
	Cleaning with Air .....	15
	Condenser .....	15
	Receiver/Drier .....	16
	Expansion Valve .....	17
	Valve Components .....	17
	Operation .....	18
	Port Identification .....	21
	Evaporator .....	21
	Blower Fan .....	21
	Description of Operation - Climate Controls .....	22
	Control Panel - Manual Temperature Control - (A-05) .....	22
	Blower Fan Switch .....	22
	Temperature Control Switch .....	22
	Control Panel - (ATC) Automatic Temperature Control (if equipped) .....	23
	Control Operation Specifications .....	23
	Celsius/Fahrenheit Button .....	24
	Compressor Protection Switches .....	25
	High-pressure Cutout Switch (S-40) .....	25
	Low-pressure Cutout Switch (S-69) .....	25

---

# SECTION 50 - CLIMATE CONTROL

BOOK 3 - 87580756

## Chapter 2 - Climate Control - WDX1202 (Continued)

### CONTENTS

Section	Description	Page
	Troubleshooting and Servicing Air Conditioning System . . . . .	26
	General Safety and Service Precautions . . . . .	26
	Cleanliness . . . . .	27
	Preliminary Troubleshooting and Testing . . . . .	27
	Operational Checks . . . . .	27
	ATC Troubleshooting Fault Code Chart . . . . .	28
	Display Fault Codes . . . . .	28
	Advanced Diagnostics . . . . .	31
	Diagnosis Charts – Air Conditioning System . . . . .	35
	Test Procedure: Stabilizing the System . . . . .	39
	Test Ports . . . . .	39
	Pressure/Temperature Relationships . . . . .	40
	Leak Testing . . . . .	40
	Refilling . . . . .	40
	Contaminants . . . . .	41
	General . . . . .	41
	Preventing Mixing of Service Equipment . . . . .	41
	Refrigerant Extraction and Recycling Equipment . . . . .	41
	Using Extraction Equipment . . . . .	42
	Using Recycled Equipment . . . . .	42
	Recycling vs. Reclaiming . . . . .	42
	Containment of Air Conditioning Refrigerants . . . . .	42
	Recovery . . . . .	43
	Flushing . . . . .	43
	Recharging/Refilling . . . . .	43
	Using a Manifold Gauge Set . . . . .	44
	Checking Refrigerant for Excess Air . . . . .	44
	Containers For Storing Recycled Refrigerant . . . . .	45
	Disposal of Empty or Near-Empty Disposable Containers . . . . .	45
	Applicable SAE Standards . . . . .	45
	Gauge Readings . . . . .	46
	Manifold Gauge Readings and Interpretations . . . . .	50
	Performance Test Examples . . . . .	50
	Overhaul . . . . .	61
	Condenser . . . . .	61
	Removal . . . . .	61
	Inspection and Repair . . . . .	61
	Installation . . . . .	61
	Receiver/Drier . . . . .	62
	Removal . . . . .	62
	Installation . . . . .	62

---

# SECTION 50 - CLIMATE CONTROL

BOOK 3 - 87580756

## Chapter 2 - Climate Control - WDX1202 (Continued)

### CONTENTS

Section	Description	Page
	High (S-40) Pressure Switches .....	62
	Removal .....	62
	Installation .....	62
	Low (S-69) Pressure Switches .....	62
	Removal .....	62
	Installation .....	62
	Blower Motor .....	63
	Removal .....	63
	Inspection .....	65
	Assembly .....	66
	Installation .....	67
	Blower Fan Resistor .....	69
	Removal .....	69
	Installation .....	69
	Expansion Valve .....	69
	Removal .....	69
	Installation .....	69
	HVAC Cores .....	70
	Inspection and Cleaning .....	70
	Removal .....	70
	Heater Core and/or Evaporator Core .....	72
	Removal .....	72
	Inspection .....	73
	Installation .....	74
	Compressor and Clutch .....	77
	Compressor Clutch Components .....	77
	Removal .....	77
	Installation .....	78
	Checking Compressor Oil for Contamination .....	79
	Adding Compressor Oil .....	79
	Clutch Procedures .....	80
	Clutch Run-In .....	80
	Clutch Test .....	80
	Clutch Removal .....	80
	Clutch Inspection .....	82
	Clutch Installation .....	83
	Electrical Connection .....	84
	Tightening Torques .....	85
	Labor Guide .....	90

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 1 - General Information

### CONTENTS

Section	Description	Page
	Introduction .....	3
	Troubleshooting .....	3
	Fault Codes and Fault Finding .....	4
	Electrical Terms and Equipment .....	5
	Definition .....	5
	Electrical System Components .....	7
	Electrical Components Chart .....	7
	Rocker Switches .....	13
	Momentary Rocker Switches .....	13
	Circuit Breakers .....	13
	Location of Circuit Breakers - WDX1002S/1202S .....	14
	Location of Circuit Breakers - WDX1202 .....	14
	Fuses .....	16
	Fuse Panel Identification Tables .....	17
	Basic Circuitry/Component Testing .....	19
	Continuity Test for Open Circuits .....	19
	Continuity Test for Short to Ground .....	20
	Resistance Test for Electrical Components .....	21
	Measuring Voltage .....	22
	Diodes .....	23
	Diode Test Procedure .....	23
	Electro-hydraulic Solenoid Valve Coils .....	24
	Test Procedure .....	24
	Operational Check .....	24
	Relays .....	25
	Test Procedure .....	26
	Welding on the Machine .....	26
	Wiring Harnesses and Connectors - All models .....	31
	Connectors .....	31
	Harness Splices .....	31
	Fuses, Relays and Switches .....	31
	Switch and Relay Contacts .....	31

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 1 - General Information (Continued)

### CONTENTS

Section	Description	Page
	Grounds .....	31
	Power Sources .....	31
	Wire Harness Identification .....	31
	Wire Color Codes .....	32
	Primary Harness Connectors .....	32
	Ground Distribution System - WDX1002S/1202S .....	33
	Introduction .....	33
	Ground Distribution System - WDX1202 .....	38
	Introduction .....	38
	Ground Points .....	38
	Function Monitoring, Machine Configuration, and Diagnostics Menus - WDX1002S and WDX1202S Models .....	44
	Selectable Functions Monitoring .....	44
	Operating Mode .....	44
	Configuration Mode .....	44
	Warning Mode .....	45
	Operational Mode .....	45
	Configuration Mode .....	48
	System Monitoring - WDX1002S/1202S Models .....	55
	Electronic Components - WDX1202 Models .....	57
	Function Monitoring, Machine Configuration, and Diagnostics Menus - WDX1202 Models .....	58
	Selectable Functions Monitoring .....	58
	Machine Configuration/User Setup Menu .....	60
	Critical Warning Displays - Automatic Shutdown .....	65
	Critical Warning Displays - No Shutdown .....	67
	Non-Critical Warning Displays .....	68
	Electrical Fault Codes .....	68
	System Monitoring - WDX1202 Models .....	69

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 2 - Power Distribution

### CONTENTS

Section	Description	Page
	Operation and Troubleshooting (WDX1002 and WDX1202S Models) . . . . .	2
	XCM Power . . . . .	2
	Unswitched Power . . . . .	2
	Operation . . . . .	2
	Switched Power . . . . .	3
	Operation . . . . .	3
	Troubleshooting . . . . .	3
	Power Distribution – WDX1002/1202S . . . . .	4
	Introduction . . . . .	4
	Main Distribution Panel – Fuse Block . . . . .	5
	Unswitched Power . . . . .	6
	Switched Power . . . . .	7
	XCM Function and Configure Select Switches . . . . .	17
	Operation . . . . .	17
	Troubleshooting . . . . .	17
	Operation and Troubleshooting (WDX1202 Models) . . . . .	18
	XCM Power . . . . .	18
	Unswitched XCM Power . . . . .	18
	Operation . . . . .	18
	Switched XCM Power . . . . .	19
	Operation . . . . .	19
	Power Distribution – WDX1202 . . . . .	20
	Introduction . . . . .	20
	Main Distribution Panel – Fuse Block . . . . .	21
	Unswitched Power . . . . .	22
	Switched Power . . . . .	23
	Troubleshooting . . . . .	24
	XCM Function and Configure Select Switches (WDX1202 Models) . . . . .	33
	Operation . . . . .	33
	Troubleshooting . . . . .	33

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 3 - Air Conditioning Systems

### CONTENTS

Section	Description	Page
	Fan (Pressurizer) Circuit - WDX1002S and WDX1202S Models . . . . .	3
	Operation . . . . .	3
	Troubleshooting . . . . .	3
	A/C Clutch Circuit - WDX1002S and WDX1202S Models . . . . .	9
	Troubleshooting . . . . .	9
	Air Conditioning Systems . . . . .	12
	Introduction . . . . .	12
	General Principles of Operation (Manual and ATC Systems) . . . . .	12
	Manual HVAC System (Standard) . . . . .	14
	Operation . . . . .	14
	Troubleshooting . . . . .	14
	A/C Clutch Circuit (Manual HVAC) . . . . .	18
	Operation . . . . .	18
	Troubleshooting . . . . .	18
	Automatic (ATC) HVAC System . . . . .	21
	Operation . . . . .	21
	Control Operation Specifications . . . . .	21
	General Operation . . . . .	22
	Heater Operation . . . . .	22
	Heater Operation – Sequence of Events . . . . .	22
	Defrosting/Defogging Operation . . . . .	23
	Air Conditioner (A/C) Operation . . . . .	23
	Ventilation . . . . .	23
	System Component Functions . . . . .	23
	Automatic Fan Speed Control (AUTO) . . . . .	23
	Manual Mode Fan Speed Control (Up/Down) . . . . .	23
	A/C Compressor Clutch Control . . . . .	23
	Heater Water Valve . . . . .	24
	Cab Air Temperature Sensor . . . . .	24
	Evaporator Probe . . . . .	24
	ATC HVAC Component Usage . . . . .	24

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

### Chapter 3 - Air Conditioning Systems (Continued)

#### CONTENTS

Section	Description	Page
	Troubleshooting .....	25
	Fault Codes .....	25
	Advanced Diagnostics Display Mode .....	28
	Revision Level .....	29
	Setting Parameters .....	30
	ATC Troubleshooting Quick-Checks .....	30
	A/C Clutch Circuit (ATC HVAC) .....	36
	Operation .....	36
	Troubleshooting .....	36

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

### Chapter 4 - Lighting Systems

#### CONTENTS

Section	Description	Page
	Introduction – WDX1002S, WDX1202S, and WDX1202 Models .....	3
	Lamp Replacement Chart – WDX1002S and WDX1202S Models .....	3
	Turn Signals and Hazard Lights – WDX1002S and WDX1202S Models .....	3
	Description .....	3
	Operation .....	4
	Troubleshooting .....	4
	Road Lights, Taillights, and Console Light .....	11
	Description .....	11
	Operation .....	11
	Troubleshooting .....	12

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 4 - Lighting Systems (Continued)

### CONTENTS

Section	Description	Page
	Work Lights - WDX1002S and WDX1202S Models . . . . .	20
	Operation . . . . .	20
	Troubleshooting . . . . .	21
	Overhead Console and Dome Lights - WDX1002S and WDX1202S Models . . . . .	28
	Operation . . . . .	28
	Troubleshooting . . . . .	28
	Introduction - WDX1202 Models . . . . .	33
	Lamp Replacement Chart - WDX1202 Models . . . . .	33
	Turn Signals and Hazard Lights - WDX1202 Models . . . . .	33
	Description . . . . .	33
	Operation . . . . .	34
	Troubleshooting . . . . .	34
	Road Lights, Tail Lights and Console Light - WDX1202 Models . . . . .	43
	Operation . . . . .	43
	Troubleshooting . . . . .	43
	Work Lights - WDX1202 Models . . . . .	52
	Operation . . . . .	52
	Exit Lighting (Left Side Stubble Light) . . . . .	52
	Operation . . . . .	52
	Functional Check . . . . .	53
	Procedure . . . . .	53
	Troubleshooting . . . . .	53
	Console and Dome Lights - WDX1202 Models . . . . .	62
	Operation . . . . .	62
	Troubleshooting . . . . .	62

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 5 - Engine Electrical Systems

### CONTENTS

Section	Description	Page
	General Information .....	2
	Introduction .....	2
	Engine Functions for the XCM .....	2
	Starting Circuits .....	2
	Air Filter Restriction Switch Circuit .....	3
	Troubleshooting .....	4
	Fuel Level Sender Circuit .....	7
	Troubleshooting .....	9
	Coolant Temperature Circuit .....	11
	4-Line Display - Engine Coolant Temperature Scale .....	13
	A-Pillar Display - Engine Coolant Temperature Scale .....	13
	Troubleshooting .....	14
	Engine Fuel Solenoid Circuit .....	17
	Troubleshooting .....	17
	Engine Oil Pressure Sensor Circuit .....	21
	Troubleshooting .....	23
	Engine Starting Motor Circuit .....	25
	Cold-Start Injection Advance Circuit (KSB) .....	29
	Fuel Injection Pump Harness Connections .....	30
	Preheat Circuit (If Equipped) .....	31

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 6 - Charging Electrical Systems

### CONTENTS

Section	Description	Page
	Introduction .....	3
	Battery .....	5
	Size and Rating .....	5
	How a Battery Works .....	5
	Battery Troubleshooting .....	5
	Determining the Cause of Failure .....	6
	Application and Installation .....	6
	Service History .....	6
	Visual Inspection .....	6
	Troubleshooting Summary .....	8
	Testing The Battery - General .....	9
	"Key Off" Current Drain .....	10
	Voltage Drop Test .....	11
	Charging the Battery .....	12
	Determining Battery Charge Procedure .....	12
	Slow Charge Procedure: For Batteries with Charges Below 11.0V .....	12
	Selecting Battery Charging Method .....	13
	Slow Charge Procedure .....	14
	Standard Charge Procedure: Preferred Method for Batteries with Voltage of 11 - 12.5 V .....	15
	Fast Charge Procedure: Alternative Method for Batteries with Voltages of 11 - 12.5 V .....	15
	Battery Charging Precautions .....	16
	Battery Specifications .....	16
	Alternator .....	17
	Charging System Excitation Circuit Operation .....	17
	Alternator and Voltage Regulator .....	17
	Maintaining the Alternator .....	18
	Alternator Connections .....	19
	Alternator and Voltage Regulator Precautions .....	19
	Alternator Belt .....	20



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

---

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

### Chapter 6 - Charging Electrical Systems (Continued)

#### CONTENTS

Section	Description	Page
	Belt Removal/Replacement .....	20
	Welding On the Machine .....	22
	Troubleshooting .....	22
	Testing the Alternator .....	22
	Alternator Removal .....	24
	Alternator Installation .....	26

## SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

### Chapter 7 - Electro-Hydraulic Systems

#### CONTENTS

Section	Description	Page
	Hydraulic Oil Level Switch Circuit .....	2
	Troubleshooting .....	3
	Hydraulic Oil Temperature Switch Circuit - WDX1002S/1202S/1202 .....	6
	Troubleshooting .....	7
	Hydraulic Charge Pressure Switch .....	10
	Troubleshooting .....	11
	Seat Occupied Circuit .....	14
	Troubleshooting .....	15
	Header Drive Circuit - WDX1002S/1202S .....	19
	Header Drive Circuit - WDX1202 .....	21
	Header Reverse Circuit - WDX1002S/1202S (if equipped) .....	23
	Header Reverse Circuit - WDX1202 .....	25
	Master Hydraulic Solenoid Circuit .....	27
	Hydrostatic High Speed Circuit - WDX1202 .....	30

---

# SECTION 55 - ELECTRICAL SYSTEMS

BOOK 4 - 87580757

## Chapter 8 - Diagnostic Test Mode

### CONTENTS

Section	Description	Page
	Introduction .....	2
	Accessing Diagnostic Mode (WDX1002S/1202S) .....	2
	Accessing Diagnostic Mode (WDX1202) .....	3
	Inputs .....	4
	Engine Inputs .....	5
	Fuel Inputs .....	6
	Header Inputs .....	6
	Hydraulics Inputs .....	7
	Lights Inputs .....	8
	Preheat Inputs .....	8
	Propulsion Inputs .....	9
	PTO Inputs .....	9
	Reel Inputs .....	10
	Outputs .....	10
	Header Outputs .....	11
	HVAC Outputs .....	12
	Preheat Outputs .....	12
	Inputs and Outputs Component Chart .....	13
	Wiggle Test .....	17
	Display (LCD) Test .....	17
	Fault History Screen .....	18

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**