

# Operator's Manual

---


## *Combine*

*FENDT 8370 P*

*FENDT 8400 P*

*+ Auto Level*

*+ Rotary Separator*



# Contents

<b>1</b>	<b>General Information.....</b>	<b>9</b>
1.1	Appropriate Use.....	11
1.2	Changes and Improvements.....	11
1.3	Directives and Noise.....	11
1.4	Preface.....	12
1.5	Product Identification.....	13
1.6	Sectional Drawing and Parts Identification.....	14
1.7	Disposal.....	16
<b>2</b>	<b>Safety.....</b>	<b>17</b>
2.1	General Safety Precautions.....	18
2.2	Attention - Warning Symbols.....	19
2.3	Safety Precautions.....	20
2.4	Road Transport.....	22
2.5	Warning/Instruction decals.....	23
2.6	CE Marking and Type Plate on the Combine.....	28
2.7	Position of CE Markings and Type Plate.....	39
<b>3</b>	<b>Operation, Controls and Cab.....</b>	<b>43</b>
3.1	Before Start.....	45
3.2	Operator Cab, Arrangement and Controls.....	48
	Optional Extra.....	50
3.3	Safety Precautions - on the Move.....	51
3.4	Starting and Stopping the Engine.....	52
	Starting the engine.....	52
	Stopping the Engine.....	53
3.5	Drive Controls.....	54
	Multifunction lever.....	54
	Adjustable Armrest and Control Panel.....	55
	Gearshift.....	55
	Reduced Engine Revolutions in Road Transport (Speed Matching System).....	56
	Steering column.....	57
	Brakes.....	57
3.6	Seat.....	58
	Adjustment of Operator Seat.....	58
	Adjustment of Air-Suspended Seat.....	58
	EC declaration of conformity for the operator seat.....	59
	Safety Switch in Operator Seat - (Operator Present Switch).....	60
	Instructor seat.....	61
3.7	Mirrors.....	61
	Electrically Adjustable Rearview Mirrors.....	61
3.8	Accessibility.....	62
	Cab Ladder.....	62
	Ladder for Engine Compartment.....	62
	Cleaning the Windscreen.....	63
3.9	Emergency Situations.....	64
	Emergency Exit.....	64
	Fire extinguisher.....	64
3.10	Light and Lamps.....	65
	Lamps.....	65
	Main Light and Work Light.....	65
3.11	Operator Cab, Climate Control.....	66
	Climate control.....	66
	Operation of Climate Control.....	67
3.12	Printer.....	69
	Exchanging Paper and Ribbon in Printer.....	69

# Contents

	Inserting the Paper Roll .....	69
	Fitting the Ribbon .....	69
<b>3.13</b>	<b>Optional extra .....</b>	<b>70</b>
3.13.1	Four-wheel drive .....	70
	Activating Four-Wheel Drive .....	70
	Forward Speed .....	70
	Operating the Four-Wheel Drive .....	71
	Service .....	71
3.13.2	Reversing camera .....	72
3.13.3	Auto-Guide .....	72
<b>4</b>	<b>Operation, FIELDSTAR® .....</b>	<b>73</b>
4.1	Safety Precautions .....	75
4.2	FIELDSTAR® .....	77
	Menu Structure and Operation .....	77
	Operating FIELDSTAR® from the terminal .....	78
	Operating the Terminal by Remote Control in the Multifunction Lever .....	79
	Contrast and Brightness Control .....	80
	Cleaning the Terminal .....	80
	Data card .....	81
	FIELDSTAR® Menu Structure .....	81
4.3	Harvest Menu .....	83
4.4	Main Menu .....	87
4.5	Monitoring .....	89
	Shaft Speeds .....	89
	Engine Monitoring/Alarm .....	89
	Engine safety alarm .....	90
	Information .....	90
	Shaft Speeds .....	91
4.6	Harvesting Data .....	93
	Accumulated Machine Data .....	93
	Trip Data and Field Data .....	93
4.6.1	Data Logging in General .....	94
4.6.2	Using Data Logging .....	96
	Creating a New Field Job .....	96
	Starting a Job .....	98
	Field Map for a Job .....	100
	Data logging messages .....	102
4.6.3	Data Logging Setup .....	104
	Marker Setup .....	105
	Selecting Position Data .....	106
	Setting up the Logging Rate .....	106
4.6.4	Using Markers .....	107
4.7	Operator's Manual .....	109
	Harvest Settings .....	109
	Routine Servicing .....	109
	FIELDSTAR® .....	109
4.8	Diagnostics .....	111
	Electric Diagnostics .....	111
	Yield Meter .....	111
	System Information .....	111
	System Setup .....	111
	Programming the Computer .....	111
	Control .....	111
	GPS Information .....	112
	DGPS Information .....	113
	Programming .....	115
	Diagnosis .....	115
	Screen Calibration (Touch Calibration) .....	115
4.9	Coding .....	117

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**

# Contents

Clock Adjustment	117
Language	117
Area Measuring	118
Table Calibration	119
Returns Volume	119
Grain loss monitor	119
Concave Calibration	120
Constant Flow	120
Wheel Track and Auto Level Combine	120
Coding of Electrical Straw Deflectors	121
Lead Time and Lag Time	122
Calibration of Actuator for Electrical Sieves	123
<b>4.10 Settings</b>	<b>125</b>
Harvest Settings	125
Table Settings	128
Machine Settings	130
<b>4.11 Returns Volume Monitor</b>	<b>132</b>
Coding	132
<b>4.12 Grain Loss Monitoring</b>	<b>133</b>
Sensors	133
Adjustment of Grain Loss Sensors	133
<b>4.13 Shaft Alarm Calibration</b>	<b>134</b>
<b>4.14 Yield Meter</b>	<b>135</b>
4.14.1 Yield meter (Isotopic)	135
Measuring Principle	135
Mass Flow Measuring	135
Yield Meter Status	136
Using the Yield Meter	136
Yield Meter Calibration	136
4.14.2 Micro-Trak Yield Meter	137
Measuring Principle	137
Zero Point for Micro-Trak Yield Meter	137
Calibration of Micro-Trak Yield Meter	138
Slope Compensation for Micro-Trak Yield Meter	138
4.14.3 Yield Meter Calibration	139
<b>4.15 Moisture Meter</b>	<b>141</b>
Continuous Moisture Measuring	141
Measuring Principle	141
Using the Moisture Meter	141
Cleaning the Moisture Meter	142
Calibration of Moisture Meter	143
<b>4.16 Cutting Height Control</b>	<b>145</b>
Cutting Height Control Setting and Operation	145
Coding the Table	146
<b>4.17 Field Pressure Control</b>	<b>147</b>
Field Pressure Control Setting and Operation	147
<b>4.18 Auto Level Table</b>	<b>149</b>
Bleeding	149
Coding the Auto Level Table	150
Calibration of Table Angle	150
<b>4.19 Operation of Auto Level Table</b>	<b>151</b>
Manual Control	151
Levelling at Turns	151
<b>4.20 Interaction Between Table Controls</b>	<b>152</b>
<b>4.21 Checking and Adjusting the Ground Sensors</b>	<b>153</b>
<b>4.22 Constant Flow</b>	<b>154</b>
Start-up and Adjustment of Constant Flow	154
Constant Flow Engagement	156

# Contents

---

<b>5</b>	<b>Operation, Auto Level Combine.....</b>	<b>159</b>
5.1	Safety Precautions.....	161
	Safety System .....	161
5.2	Combinations.....	162
	Selecting Combination .....	162
5.3	Auto Level Combine .....	163
	Manual Control of Auto Level Combine .....	163
5.4	Auto Level Combine/Table .....	164
	Combine .....	164
	Transport, .....	164
	Auto Level Table .....	165
5.5	Calibration of Auto Level Combine .....	166
	Errors during Calibration .....	167
5.6	Coding the Auto Level Table .....	167
	Zero Cutting Height .....	167
5.7	Attachment/Removal of Table .....	168
5.8	Operation of Auto Level Combine/Auto Level Table .....	169
	Combinations .....	169
	Priority of Hydraulic Functions .....	170
5.9	Safety System, Auto Level .....	171
	Automatic Control of the Tilt Sensor Function .....	171
	Safety System .....	171
	Hose Breach Protection for Auto Level Hydraulics .....	172
5.10	Troubleshooting .....	172
	Machine Not Levelling Correctly .....	173
5.11	Servicing and User Tips .....	174
	Retrofit of New FIELDSTAR® Auto Level Job Computer and Sensors .....	174
	Unintentional Use of Manual Keys in Automatic Mode .....	174
	Diagnostics - Auto Level Combine Functions and Sensors .....	174
<b>6</b>	<b>Engine.....</b>	<b>175</b>
6.1	Safety Precautions.....	177
6.2	Engine Types .....	178
6.3	Air-Intake .....	178
	Filter System .....	178
6.4	Cooling System .....	179
	Rotary Screen and Dust Aspirator .....	179
	Coolers .....	179
	Coolant .....	180
	Checking the Fan Belt Tension .....	180
6.5	Fuel System .....	181
	Filter change .....	182
6.6	Engine Oil/Change .....	183
	Oil and Filter Change .....	183
6.7	Cleaning the Engine Compartment .....	183
6.8	Electronic Engine Management .....	184
6.9	Engine Trouble Shooting .....	184
	EEM3 Electronic Engine Management - Failure Codes (Self-Diagnosis) .....	184
<b>7</b>	<b>Cutting Tables .....</b>	<b>191</b>
7.1	Safety Precautions.....	193
7.2	Attachment of Table, Standard and Auto Level .....	194
7.3	Removal of Table.....	196
	Table Trailer .....	196
	Attachment of combine and trailer .....	197
	Table Trailer Brakes .....	197
	Supports .....	197

# Contents

<b>7.4</b>	<b>Reel</b> .....	<b>198</b>
	Reel Adjustment Up/Down, Fore/Aft .....	198
	Bleeding .....	198
	Reel Rotation .....	199
	Reel Tine Bars .....	199
	Adjustment of the Reel in the Table .....	199
<b>7.5</b>	<b>Knife</b> .....	<b>200</b>
	Knife and Knife Drive .....	200
	Knife Adjustment .....	200
<b>7.6</b>	<b>Feeding</b> .....	<b>201</b>
	Table Auger .....	201
	Cut-Off Strip .....	202
	Replacement of Feathering Fingers .....	202
	Auger Flight Extensions, 20-22-25-30' Tables .....	203
	Reversing .....	203
<b>7.7</b>	<b>Transmission</b> .....	<b>204</b>
	PowerFlow Table, Knife Drive and Table Auger .....	204
	Slip Clutch for Table Auger .....	204
<b>7.8</b>	<b>PowerFlow table</b> .....	<b>205</b>
	Inspection and Running-In of PowerFlow Belts .....	205
	Adjustment of Belts .....	205
	Front Scrapers .....	206
	Rear Scrapers and Adjustment of Bearing Housings .....	206
	Table Bottom .....	206
	Cleaning .....	207
<b>7.9</b>	<b>Crop Lifters</b> .....	<b>207</b>
	Using Crop Lifters .....	207
<b>7.10</b>	<b>Vertical Knives, Rape Auger and Straw Dividers</b> .....	<b>208</b>
	Vertical Knife .....	208
	Mounting of Vertical Knife .....	208
	Rape Auger .....	208
	Torpedo Divider and Straw Divider Bow .....	209
	Fitting the Straw Dividers .....	209
	Adjustment of Torpedo Divider .....	209
<b>7.11</b>	<b>Fixed Table Auger Fingers</b> .....	<b>210</b>
	Using Fixed Table Auger Fingers .....	210
<b>7.12</b>	<b>High Table Sides</b> .....	<b>210</b>
<b>7.13</b>	<b>Main crop elevator</b> .....	<b>211</b>
	Crop Elevator Chain .....	211
	Transmission for Table .....	211
	Stone Trap .....	211
	Initial Adjustment of Cutting Height Indication .....	212
<b>8</b>	<b>Operation of Machine and Cutting Table</b> .....	<b>213</b>
<b>8.1</b>	<b>Safety Precautions</b> .....	<b>215</b>
<b>8.2</b>	<b>Operation of Table</b> .....	<b>216</b>
	Table Height and Table Automatic Control .....	216
	Cutting Height Control .....	217
	Field Pressure Control .....	217
	Preset Cutting Height .....	218
	Auto Level Table .....	218
	Table Engagement - Emergency Stop .....	219
	Slip Clutch .....	219
<b>8.3</b>	<b>Threshing Unit Transmission</b> .....	<b>220</b>
	Threshing Unit Engagement .....	220
	Cylinder Variator .....	220
	Turning Tool for Cylinder .....	221
<b>8.4</b>	<b>Concave Setting, Electrically Adjustable</b> .....	<b>222</b>
	Operation of Concave .....	222

# Contents

---

	Concave Setting . . . . .	222
<b>8.5</b>	<b>Threshing . . . . .</b>	<b>224</b>
	Concave Filler Plates . . . . .	224
	Straw Walkers . . . . .	224
	Rear Beater Curtain . . . . .	225
<b>8.6</b>	<b>Straw Chopper and Spreader Hood . . . . .</b>	<b>226</b>
	Straw chopper . . . . .	226
	Adjustment of Spreader Hood . . . . .	227
	Counter Knives and Cross Bar . . . . .	228
	Replacement of Knives . . . . .	229
<b>8.7</b>	<b>Fanning Mill and Sieves . . . . .</b>	<b>230</b>
	Fanning Mill . . . . .	230
	Shaker shoe . . . . .	230
	Shaker Shoe with Electrical Sieves . . . . .	231
	Manual Adjustment of Sieves . . . . .	231
	Cleaning of Sieves and Main Grain Pan . . . . .	232
	Cleaning the Sieves . . . . .	232
	Shaker Shoe Light . . . . .	233
	Special Sieves . . . . .	234
<b>8.8</b>	<b>Internal Grain Transport . . . . .</b>	<b>235</b>
	Auger Housing/Elevators . . . . .	235
	Returns thresher . . . . .	235
	Tank filling auger . . . . .	236
	Grain Tank . . . . .	236
	Unloading Auger . . . . .	238
	Unloading Auger Clutch . . . . .	238
	Unloading Tube . . . . .	239
<b>8.9</b>	<b>Rotary Separator . . . . .</b>	<b>240</b>
	Changing Rotor Revolutions . . . . .	240
	Concave Setting . . . . .	240
<b>8.10</b>	<b>Straw hood . . . . .</b>	<b>241</b>
	Alarm switch for straw hood blocked . . . . .	241
	Blockage in straw hood . . . . .	241
	Light in straw hood . . . . .	241
<b>8.11</b>	<b>Chaff Spreader . . . . .</b>	<b>242</b>
	Setting . . . . .	242
<b>8.12</b>	<b>Maize Threshing . . . . .</b>	<b>243</b>
	Attachment of Maize Header . . . . .	243
	Area Measuring . . . . .	243
	Main crop elevator . . . . .	244
	Concave/Cylinder/Stone Trap . . . . .	244
	Concave/Initial Settings . . . . .	244
	Threshing cylinder . . . . .	244
	Rotary Separator . . . . .	245
	Shaker shoe . . . . .	245
	Machine with Electrical Sieves . . . . .	245
	Straw walkers . . . . .	245
	Bottom Auger Cover Plate . . . . .	246
	Scrapers . . . . .	246
	Rear Beater Curtain . . . . .	246
	Straw chopper . . . . .	246
<b>8.13</b>	<b>Suggested Harvest Settings . . . . .</b>	<b>247</b>
<b>8.14</b>	<b>Threshing . . . . .</b>	<b>248</b>
<b>9</b>	<b>Transmissions . . . . .</b>	<b>249</b>
<b>9.1</b>	<b>Safety Precautions . . . . .</b>	<b>251</b>
<b>9.2</b>	<b>Adjustment of Transmissions . . . . .</b>	<b>252</b>
	General . . . . .	252
	Threshing Unit Clutch . . . . .	252



**Suggest:**

**For more complete manuals. Please go to the home page.**

**<https://www.ebooklibonline.com>**

**If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.**

**Thank you so much for reading**

# Contents

Hydrostatic Transmission	252
<b>9.3 Transmissions</b>	<b>253</b>
Rear beater	253
Main Crop Elevator and Table	253
Straw chopper	253
Threshing cylinder	254
Unloading Auger	254
Shaker Shoe and Chaff Spreader Counter Drive, and Straw Walker Drive	255
Filling and Returns System Countershaft	256
Returns Elevator and Returns Thresher	256
Tank Filling Elevator and Tank Filling Auger	257
Dust aspirator	257
Rotary screen	258
Fanning Mill	259
Rotary Separator	259
Alternator and Fan	259
Climate control	260
<b>9.4 Transmission Diagram, Left-Hand Side</b>	<b>262</b>
<b>9.5 Transmission Diagram, Right-Hand Side</b>	<b>264</b>
<b>10 Hydraulics</b>	<b>267</b>
<b>10.1 Safety Precautions</b>	<b>269</b>
<b>10.2 Hydraulic System, Standard Combine</b>	<b>270</b>
Hydrostatic Transmission	270
<b>10.3 Hydraulic System, Four-Wheel Drive</b>	<b>271</b>
Hydrostatic Transmission	271
<b>10.4 Oil Change</b>	<b>272</b>
Draining Oil	272
Refilling Oil	272
<b>10.5 Filter Change</b>	<b>273</b>
Return Oil Filter	273
Storage of Hydraulic System	273
<b>10.6 Auxiliary Hydraulics</b>	<b>274</b>
Functions and Auxiliary Hydraulics	274
Reel Adjustment Fore/Aft - Up/down	274
<b>10.7 Hydraulics Diagram, Standard Combine</b>	<b>276</b>
<b>10.8 Hydraulics Diagram, Auto Level Combine</b>	<b>278</b>
<b>10.9 Hydraulics Diagram for Chaff Spreader</b>	<b>280</b>
<b>11 Maintenance</b>	<b>281</b>
<b>11.1 Safety Precautions</b>	<b>283</b>
<b>11.2 Undercarriage</b>	<b>285</b>
Wheel nut torques	285
<b>11.3 Tyre Pressure</b>	<b>286</b>
<b>11.4 Lubrication chart</b>	<b>288</b>
Daily/10 Hours (Red)	288
50 hours (blue)	288
100 hours (yellow)	288
200 hours (white)	289
11.4.1 Lubrication chart	290
11.4.2 Lubrication Chart, Auto Level Combine	292
<b>11.5 Lubricants and Operating Fluids</b>	<b>293</b>
<b>11.6 Maintenance Required</b>	<b>294</b>
<b>11.7 Gear Oil Change</b>	<b>296</b>
Gearbox	296
Final drives	296
<b>11.8 Climate control</b>	<b>297</b>

# Contents

---

Diagram for Climate Control System .....	297
Maintenance .....	297
<b>11.9 Cleaning and Off-Season Storage .....</b>	<b>298</b>
Cleaning .....	298
Off-season storage .....	299
Storage of Engine, Fuel System and Hydraulic System .....	300
Periodical Start-Up .....	300
Removal of Main Crop Elevator .....	301
Removal of Elevator Chains .....	301
After Off-Season Storage .....	301
<b>11.10 Adjustment of Brakes .....</b>	<b>302</b>
Adjustment of Foot Brakes, Disc Brakes .....	302
Adjustment of Parking Brake .....	302
<b>11.11 Dealer Servicing Schedule .....</b>	<b>303</b>
<b>12 Electrical system .....</b>	<b>309</b>
<b>12.1 Safety Precautions .....</b>	<b>311</b>
<b>12.2 Electrical System .....</b>	<b>312</b>
Charging System .....	312
Electric Boxes and Main Switch .....	312
<b>12.3 External 12V connectors .....</b>	<b>313</b>
<b>12.4 Electro-Hydraulic System .....</b>	<b>315</b>
Hydraulic safety .....	315
<b>12.5 Key to Signatures for Wiring Harness .....</b>	<b>316</b>
Wire Codes .....	316
Component Codes .....	316
<b>12.6 Position of Connectors in Electric Box .....</b>	<b>317</b>
<b>12.7 Fuses and Relays, Electric Box and Cab .....</b>	<b>318</b>
<b>12.8 Key to symbols .....</b>	<b>320</b>
<b>12.9 Diagrams survey .....</b>	<b>321</b>
<b>12.10 Fuses, Alphabetical .....</b>	<b>322</b>
<b>12.11 Fuse Ratings .....</b>	<b>323</b>
<b>12.12 Components .....</b>	<b>324</b>
<b>12.13 Diagrams .....</b>	<b>330</b>
<b>13 Specifications .....</b>	<b>341</b>
13.1 Dimensions and Specifications .....	341
<b>14 Index .....</b>	<b>347</b>

**<https://www.ebooklibonline.com>**

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

**<https://www.ebooklibonline.com>**